SAMSUNG



DVM CHILLER

Installation manual

FCU Application KIT MIM-FOON

- Thank you for purchasing this Samsung Product.
- Before operating this unit, please read this Installation manual carefully and retain it for future reference.

SAMSUNG

Contents

PREPARATION	3
Safety precautions	3
CHECKING BEFORE THE INSTALLATION	7
Checking before the installation	7
Accessories	7
Net dimension	7
Name of the parts	8
Diagram of DMS 2.5 and DVM CHILLER & FCU	9
Diagram of BMS and DVM CHILLER & FCU	10
INSTALLATION	12
FCU KIT installation	12
FCU KIT installation	12
Wiring work	15
Functions of FCU KIT	19
Diagram of ASS'Y control	21
Installing water temperature sensor	26
SETTING	28
Setting address of FCU KIT and installation option	28
Procedure of option setting	28
Setting an option	29
Setting address (MAIN/RMC) of FCU KIT	34
Setting FCU KIT installation option	35
Changing a particular option	42
OTHERS	43
Troubleshooting	43
Error code	43
Inspection and test operation	44
Checking FCU KIT installation	44
Trial operation	44
Function of wired remote controller	46
Display	46

These safety precautions are for owner's safety and preventions of property damage. Therefore, please read this manual thoroughly before installing or using your product. (Please refer to appropriate installation for any optional product installation.)

Hazards or unsafe practices that may result in severe personal injury or death.

Hazards or unsafe practices that may result in minor personal injury or property damage.

Follow directions.

- 🚫 Do NOT attempt.
- Acke sure the machine is grounded to prevent electric shock.
- B Unplug the power plug from the wall socket.
- 🕥 Do NOT disassemble.

For installation

- The installation of this product must be performed by a qualified technician or service company.
 - Failure to do so may result in electric shock, fire, product malfunction, or injury.

Connect the power with rated voltage when installing.

• Failure to do so may result in electric shock, fire, or product malfunction.

Check if the installation was done correctly according to the installation manual.

• There is risk of electric shock or fire if the product is installed incorrectly.

Make sure that all wiring work is done by qualified person complying regional standards and instructions in this manual.

• If the installation is done by unqualified person, there is risk of product malfunction, electric shock or fire caused by incorrect installation.

Contact the service center when you need to dispose the product.

Safety precautions

- O not install this product near a heater, inflammable material. Do not install this product in a humid, oily or dusty location, in a location exposed to direct sunlight and water (rain drops). Do not install this product in a location where gas may leak.
 - Potential risk of electric shock or fire.

Do not attempt to move or re-install the product that is already installed.

• There is risk of electric shock or fire.

Do not attempt to repair, disassemble, or modify the product yourself.

 There is risk of product damage, electric shock or fire. When repair is needed, consult service center.

For installation

Install the product on a hard and even place that can support its weight.

• If the place cannot support its weight, the product may fall down and it may cause product damage.

Make sure there is no tension to the cable during installation.

• Cable may get cut and cause fire.

Install the product in a place with temperature between 0 $\,\widetilde{}$ 39 °C (32 $\,\widetilde{}$ 102 °F) with no direct sunlight.

• If not, there is risk of fire or product malfunction.

Do not install the product in a place where special spray or acid/alkali solution is used.

If not, there is risk of fire or product malfunction.

Do not connect the power cable to the communication cable terminal.

There is risk of fire.

When installing the product in hospitals or other places, make sure that the product does not interrupt with other products.

• If not, there is risk of product malfunction.

Do not allow water to enter the product.

• If not, there is risk of electric shock or fire.

Do not press the buttons with any sharp objects.

• There is risk of electric shock or damage to the parts.

For power supply

🛞 Do not pull or excessively bend the power cord. Do not twist or tie the power cord. Potential risk of electric shock or fire.

For operation

/ WARNING

- If the product generates a strange noise, a burning smell or smoke, disconnect the power supply immediately and contact a service center.
 - Potential risk of electric shock or fire.

Contact a service center to reinstall the product.

- If not, there is risk of product malfunction, water leakage, electric shock or fire.
- A delivery service for the product is not provided. If you reinstall the product in another location, additional construction costs and installation fee will be charged.

When an error appears or the product malfunctions, stop the operation immediately.

 If the product generates a burning smell or it malfunctions, turn it off and disconnect the power supply immediately, and then contact a service center. If not, there is risk of electric shock, fire, or damage to the product.



Do not attempt to repair, disassemble, or modify the product yourself.

This may result in electric shock, fire, a product malfunction or injury.

For operation

A CAUTION



Do not allow water to enter the product.

There is risk of fire or explosion.

Safety precautions

\bigcirc Do not operate the product with wet hands.

• There is risk of electric shock.

Do not spray volatile material such as insecticide onto the product.

 As well as being harmful to humans, this may also result in electric shock, fire or a product malfunction.

Do not hit or apply excessive force of any kind to the product.

Do not use this product for other purposes.

• This product is designed to be used only for DVM CHILLER.

Do not press the buttons with any sharp objects.

Electric shock or part damage may occur.

For cleaning

O Do not clean the product by spraying water directly onto it. Do not use benzene, thinner, acetone or alcohol to clean the product.


• This may result in discoloration, deformation, damage, electric shock or fire.

Accessories

Name	Pipe temperature sensor [10 m(32.8 ft)]	Aluminum tape	Rubber tape	M4x16 screws
Quantity	2	4	2	4
Image				Annun()

Name	Insulator	Cable tie	Wired Remote Controller (Purchased separately)
Quantity	2	6	1
Image		¢	

Net dimension



[Unit : mm(inch)]

Checking before the installation

Name of the parts





Diagram of DMS 2.5 and DVM CHILLER & FCU




- FCU KIT and FCU interface module is for integrated control of FCU with DVM CHILLER by DMS 2.5.
- Maximum number of FCU interface modules that can be installed to a DMS2.5, and maximum number of FCU KITs that can be installed to a FCU interface module is both 16.
- Maximum number of FCU interface modules that can be installed to a channel of DMS2.5 is 16 (Max. 128 FCU KITs).
- Some functions of wired remote controller may not work. (Refer to page 46.)
- Control logic of DMS2.5 should be set to interlock FCU KIT and DVM CHILLER. Refer to user manual of DMS2.5 for setting control logic.

Checking before the installation

- FCU interface module should be installed inside of FCU KIT.
- DMS2.0 is not supported.
- Cabel Max length
 - DMS -FCU interface module : max 1000 m(3280.8 ft)
 - FCU interface module -FCU KIT :max 1000 m(3280.8 ft)


• Install FCU that has terminal block to fix power cable by screw. Do not connect power cable by cutting.

Diagram of BMS and DVM CHILLER & FCU



- FCU KIT and FCU interface module is for integrated control of FCU with DVM CHILLER by DMS 2.5.
- Maximum number of FCU interface modules that can be installed to a BACnet/LonWorks, and maximum number of FCU KITs that can be installed to a FCU interface module is both 16.
- Maximum number of FCU interface modules that can be installed to a channel of BACnet/ LonWorks is 16.
- Some functions of wired remote controller may not work. (Refer to page 46.)
- FCU interface module should be installed inside of FCU KIT.

• Install FCU that has terminal block to fix power cable by screw. Do not connect power cable by cutting.




FCU KIT installation

- 1 Check the location of FCU KIT installation.
- Select the installation location that FCU can be fixed (such as wall, etc.) according to structure of FCU.
- **2** Select FCU product that has terminal block, and connect power cable of FCU KIT to the terminal block.
- **3** Select the control type (individual control or integrated control) and install FCU KIT and FCU.
- In case of direct power output from FCU KIT to FCU fan motor, select the fan motor which maximum current is not over 1 A (RMS).
- In case of installing multiple FCU to a FCU KIT, install relay for power supply.

Individual control of FCU


- Install FCU and FCU KIT by 1 to 1.
- Maximum number of FCU KITs that can be installed to a FCU interface module is 16.



- Indoor temperature sensor must be installed to control FCU. Use either wired remote controller built-in sensor or external room sensor (MWR-TA).
 - Option setting value should be changed in service setting mode of wired remote controller after installing the remote controller. (Main menu 1, Sub menu 1, SEG 1, value 1)
 - In case of using external temperature sensor (optional), value of SEG24 (FCU KIT external indoor temperature sensor) of 05 series installation option should be set as 1.

- Water sensor should be attached to inlet pipe (1) for 2 pipe system (Water In), and each inlet pipe (2) for 4 pipe system (Cooling pipe In/Heating pipe In).
- Maximum number of FCU KITs that can be installed and controlled simultaneously by a wired remote controller is 16.

Integrated control of FCU




• Install FCUs and FCU KIT by multiple FCUs to 1 FCU KIT.

• National electric appliance safety standard should be applied for relay installation and capacity and power cable connection of FCU terminal block.

FCU KIT installation

FCU KIT installation

Install FCU KIT where the weight load of the product can be supported.




1 Unscrew 2 screws of FCU KIT cover, and separate cover.

2 Fix the FCU KIT on the wall by 4 screws.

- FCU KIT may be installed vertically or horizontally as shown in the figure.
 - When installing horizontally, install FCU KIT at right angles to prevent entering water.

FCU interface module installation

Before installing the FCU interface module, complete connecting DC power and communication of FCU interface module and sensor cables of FCU KIT.



1 Fix the case with one screw.

OPTION FCU KIT_IBIM_06104A-00_EN.indd 15

Wiring work

Connecting a power cable and communication cable


- Make sure to cut-off the power before connecting the power cable.
- The power cable and communication cable of FCU KIT should be within 10% of the maximum allowable length of the cable or voltage drop.
- Install circuit breaker (ELCB) concerning total power consumption of connected FCU KIT.
- Connect F3, F4 of FCU KIT terminal block to communication terminal block (F3, F4) of wired remote controller. (Refer to page 18.)
- Use appropriate tools to connect the cables firmly within rated torque range so that it can withstand external forces, and arrange the cables neatly so that cover or any other parts won't get loose. If the cable is connected loosely, overheat, electric shock or fire may occur.
- Install the power and communication cable in a protection tube to protect them from water or external shock.

Tightening part	Tightening torque		
ngntening part		N∙m	lbf·ft
Interface module, wired remote controller connection	M3	0.5 ~ 0.75	0.37 ~ 0.55
AC FAN, 2/3 WAY VALVE connection	M3.5	0.8 ~ 1.2	0.59 ~ 0.89
2P TERMINAL BLOCK for power supply	M4	1.2 ~ 1.8	0.89 ~ 1.33

• Connect power cable to ELCB.

FCU KIT installation

- The circuit diagram on the cables as shown above represents only outline and it does not describe detailed instruction on the actual installation work.
- The communication cable should not branch due to possible communication error.




- When peeling off outer sheath of the power cable, be careful not to damage the inner sheath of the cable by using a correct tool.
- The unpeeled sheath of the power and communication cable must be inserted more than 20 mm(0.78 inch) to inside of FCU KIT holder.
- The installation of communication cable should be separated from power cable or other communication cables.

Selecting solderless ring terminal

6

- **1** Select the solderless ring terminal depending on the nominal dimension of the power cable.
- 2 Cover and insulate the solderless ring terminal and connection part of the power cable.

Soldering



FCU KIT power cable specification

This specification is when installing a FCU KIT.

Europe

Power supply	Power cable	Ground wire	Communication cable	ELCB
AC 220 - 240 V~ 50 Hz, 1 Ph	Min. 2.5 mm² (0.0039 inch²)	Min. 2.5 mm² (0.0039 inch²)	Min. 0.75 mm² (0.0012 inch²)	15 A

Part	Rated Capacity
Fan (High, Mid, Low)	AC 220 - 240 V~ 50 Hz, 1 Ph, 1 A
Water Valve	AC 220 - 240 V~ 50 Hz, 1 Ph, 0.5 A

USA

Power supply	MCA	МОР
AC 208 - 230 V~ 60 Hz, 1 Ph	2.75	15 A

Part	Rated Capacity
Fan (High, Mid, Low)	AC 208 - 230 V~ 60 Hz, 1 Ph, 1 A
Water Valve	AC 208 - 230 V~ 60 Hz, 1 Ph, 0.5 A


DC Wire

Part	Rated Capacity
Remote controller	DC 12 V
External contact	Zero voltage contact input
Sensor cable	NTC ./10 kΩ 25 °C


INSTALLATION

Functions of FCU KIT

- Fan control (Auto, High, Mid, Low), valve control, setting indoor temperature, sensing inlet water pipe temperature is possible by FCU KIT. (Room temperature sensor must be installed.)
- For direct power supply from FCU KIT, fan motor must work at AC 208 230 V $^{\sim}$ 60 Hz, AC 220 240 V $^{\sim}$ 50 Hz and 1 A or low. Otherwise, install relay for external power suppy to the fan motor.
- 2/3 way solenoid valve is a type that works at AC 208 230 V $^{\sim}$ 60 Hz, AC 220 240 V $^{\sim}$ 50 Hz and supports product with 0.5 A or low.







- Use conduit (1/2") and fitting (1/2") for power cable, and use cable gland (3/4") for DC cables.
- Each parts must be certified by national authority.
 - USA: UL certified products (UL514B), Europe: CE certified products
- Withdraw DC cables by spare holes if the DC cable wire holder is too tight.
- Use double-sheathed cables when using DC spare holes.
- Fix the power and communication cable at internal mount tie by using cable ties.
- Do not unscrew water valve cable wire holder if not used.
- Installation may be more simple by inserting sensor connector before connecting communication cable.

NOTE


20 _

• Arrange communication cables (F1, F2, R1, R2) to the opposite way of power cable.

Diagram of ASS'Y control


1 Water valve contact output status for operation mode.

When using a 2-way valve (normal close type)



Terminals for 2-pipe type Terminals for 4-pipe type

When using a 3-way valve



Terminals for 2-pipe type Terminals for 4-pipe type

When connecting the valve power cable, be sure to connect the wires (N, L) to the correct terminals (N, L).
 Failure to do so may damage the PBA.

Pipe type	Operation power output		AC power output (Max. 0.5 A)	Remarks
2-pipe	Cooling/	Thermo ON	1-2	Normal Close Type
z-hihe	Heating	Thermo OFF	1-3	Normal Open Type
	Cooling	Thermo ON	1-2	Normal Close Type
4 pipo	Cooling	Thermo OFF	1-3	Normal Open Type
4-pipe —	Heating	Thermo ON	4-5	Normal Close Type
	пеациу	Thermo OFF	4-6	Normal Open Type

• Connect 3 Way valve power cable according to value of operation mode power output.

• Select each valve that is below 0.5 A of operation current.


• Installation option setting(05series, SEG14) is required to define 2 pipe or 4 pipe system.


INSTALLATION

FCU KIT installation

2 Sensor connection by FCU type

- Install water pipe sensor at inlet within 1 m from FCU.
- Connect the sensor after checking the installing location. (Refer to page 22 for sensor connection.)






INSTALLATION

Pipe type	Location of PBA sensor	Location of pipe
2-pipe	Water-IN 1	Water inlet pipe
4-pipe	Water-IN 1	Chilled water inlet pipe
4-pipe	Water-IN 2	Heating water inlet pipe

• When using 4-pipe system, set SEG14 of 05 series installation option as 1.

• In case of opposite installation of water pipe 1, 2 sensor in 4 pipe system, error(pipe block) will be occurred in 30minutes of operation(E992 or E993).

3 FCU interface module connection



• Maximum number of FCU interface module and FCU KIT that can be installed to a channel of DMS is 16 and 128.

INSTALLATION


FCU KIT installation

4 External contact connection

• In case of connecting external contact, set SEG14 of installation option according to the table.

		External contact
	A	~ O

Installation	External contact status								
option SEG14	Open	Close							
0	Disuse	Disuse							
1	FCU OFF, remote control possible	ON, remote control possible							
2	FCU OFF, remote control impossible	Remain OFF, remote control possible							
3	FCU OFF, remote control impossible	 Remain operation status of FCU before external contact open Operation ON of FCU before external contact open: FCU ON 							
		Operation OFF of FCU before external contact open: FCU OFF							
		Remote control possible							



5 Option room sensor (Model: MRW-TA)


(05series, SEG24 = 1)

• Use either wired remote controller with built-in room sensor or external room sensor (MWR-TA) must be installed.

• In case of installing room sensor as option, set installation option according to the table.




Installing water temperature sensor



1 Check the sensor and sensor holder.

NOTE


Pipe type	Location of PBA sensor	Classification	Diameter of sensor	Location of pipe
2-pipe	Water-IN 1			Water inlet pipe
4-pipe	Water-IN 1	Pipe temperature	Ø7	Chilled water inlet pipe
	Water-IN 2	sensor (Blue)		Heating water inlet pipe



2 Stick the sensor to the pipe.


Attaching sensor

- Attach the sensor where temperature sensing is performed best.
- Stick the sensor as close as possible to attaching area.
- Do not use sensor holder.




3 After fixing the sensor, stick the sensor to the pipe by using aluminum tape.


INSTALLATION



4 Cover the sensor by rubber tape.



5 Fix the sensor by cable tie.




6 Attach insulator around sensor attached area.

Setting address of FCU KIT and installation option

Procedure of option setting

- Setting address of FCU KIT and installation option is set by remote controller option. It is also possible by wired remote controller and S-NET pro2.
- Remote controller receiver of wireless remote controller is included in FCU KIT PBA.



Step 1. Entering setting mode

- **1** Remove batteries from the remote controller.
- 2 While pressing and holding the [Temp +] and [Temp -] buttons, insert the batteries.
- **3** Check whether you enter the option setting stage



SETTING

Step 2. Procedure of option setting

After entering the option setting stage, select the option as shown below.

- 24 digits are available to be input for the option setting.
- SEG1, SEG7, SEG13, and SEG19 are page display option so they do not need to be set.
- Set the SEG2~SEG6, SEG8~SEG12 in 'ON' status and SEG14~18, SEG20~24 in 'OFF' status.

SEG1	SEG2	SEG3	SEG4	SEG5	SEG6	SEG7	SEG8	SEG9	SEG10	SEG11	SEG12	ON (SEG1 ~ SEG12)	OFF (SEG13 ~ SEG24)
0	Х	Х	Х	Х	Х	1	Х	Х	Х	Х	Х	Auto	Auto
SEG13	SEG14	SEG15	SEG16	SEG17	SEG18	SEG19	SEG20	SEG21	SEG22	SEG23	SEG24		off
2	Х	Х	Х	Х	Х	3	Х	Х	Х	Х	Х		

Setting an option

Status	Setting an option						
Auto and Auto SEG2 SEG3	 1 Setting SEG2, SEG3 option Press [Fan∨] button to enter SEG2 value. Press [Fan ∧] button to enter SEG3 value. Each time you press the button, [SEG image] will be selected in rotation. 						
	2 Setting Cool mode Press [Mode] button to change to Cool mode in the On status.						

Setting address of FCU KIT and installation option

Status	Setting an option
Cool on SEG4 SEG5 Cool on Cool on SEG5	 3 Setting SEG4, SEG5 option Press [Fan∨] button to enter SEG4 value. Press [Fan ∧] button to enter SEG5 value. Each time you press the button, [SEG image] will be selected in rotation.
	4 Setting Dry mode Press [Mode] button to change to Dry mode in the On status.
Dry on Dry SEC6 SEC8	 5 Setting SEG6, SEG8 option Press [Fan∨] button to enter SEG6 value. Press [Fan ∧] button to enter SEG8 value. Each time you press the button, [SEG image] will be selected in rotation.
	6 Setting Fan mode Press [Mode] button to change to Fan mode in the On status.
Fan on SEC9 SEG10	 7 Setting SEG9, SEG10 option Press [Fan∨] button to enter SEG9 value. Press [Fan ∧] button to enter SEG10 value. Each time you press the button, [SEG image] will be selected in rotation.
Heat on The second seco	8 Setting Heat mode Press [Mode] button to change to Heat mode in the On status.


Status	Setting an option					
	9 Setting SEG11, SEG12 option Press [Fan∨] button to enter SEG11 value.					
	Press [Fan ∧] button to enter SEG12 value.					
SEG11 SEG12	Each time you press the button, [SEG image] will be selected in rotation.					
Auto	10 Setting Auto mode					
	Press [Mode] button to change to Auto mode in the Off status.					
Auto I Auto I	11 Setting SEG14, SEG15 option					
	Press [Fan∨] button to enter SEG14 value.					
	Press [Fan ∧] button to enter SEG15 value.					
SEG14 SEG15	Each time you press the button, [SEG image] will be selected in rotation.					
	12 Setting Cool mode					
	Press [Mode] button to change to Cool mode in the Off status.					
	13 Setting SEG16, SEG17 option					
	Press [Fan∨] button to enter SEG16 value.					
	Press [Fan ∧] button to enter SEG17 value.					
SEG16 SEG17	Each time you press the button, [SEG image] will be selected in rotation.					
Orry Orry	14 Setting Dry mode Press [Mode] button to change to Dry mode in the Off status.					

Setting address of FCU KIT and installation option

Status	Setting an option					
OFF OFF OFF OFF OFF OFF	 15 Setting SEG18, SEG20 option Press [Fan∨] button to enter SEG18 value. Press [Fan ∧] button to enter SEG20 value. Each time you press the button, [SEG image] will be selected in rotation. 					
Ean off	16 Setting Fan mode Press [Mode] button to change to Fan mode in the Off status.					
Fan orf SEG21 SEG22	 17 Setting SEG21, SEG22 option Press [Fan∨] button to enter SEG21 value. Press [Fan ∧] button to enter SEG22 value. Each time you press the button, [SEG image] will be selected in rotation. 					
Heat	18 Setting Heat mode Press [Mode] button to change to Heat mode in the Off status.					
Heat off SEG23 SEG24	 19 Setting SEG23, SEG24 option Press [Fan ∨] button to enter SEG23 value. Press [Fan ∧] button to enter SEG24 value. Each time you press the button, [SEG image] will be selected in rotation. 					

Step 3. Procedure of option setting

After option setting is complete, press the [Mode] button to check whether the setting value is correct or not.



Step 4. Inputting an option

Press [Power] button twice consecutively to remote controller receiver to finish the setting. Try more than two times to make sure that option is set.

Step 5. Check for operation

- 1 Check automatic reset when entering FCU KIT option, and check if it operates normally using wired remote controller.
- **2** Reset the power of FCU interface module after setting address. Unplug the V1, V2 connectors connected to FCU interface module and plug them again.

Setting address of FCU KIT and installation option

Setting address (MAIN/RMC) of FCU KIT

- 1 Check if power is supplied to FCU KIT.
- When the power is not supplied to FCU KIT, there should be additional power supply to it.
- 2 Remote controller receiver of wireless remote controller is included in FCU KIT PBA.
- **3** Depending on the installation condition of FCU KIT, address (MAIN/RMC) to each FCU KIT should be set.
- 4 Set the FCU KIT address (MAIN/RMC) by using a remote controller.
- The default setting value of the FCU KIT address (MAIN/RMC) is "OA0000-100000-200000-300000".

Option No. :	OAXX	XX-1)	XXXXX	-2XXX	XX-3X	XXXX						
Option	SEG1		SEG2		SEG3		SEG4		SEG5		SEG6	
Description	Page		Mode		Setting main address		Hundreds digit of address		Tens digit of address		Ones digit of address	
Remote controller display			Auto		Auto						Dry	
	Display	Detail	Display	Detail	Display	Detail	Display	Detail	Display	Detail	Display	Detail
Display/detail	0		A		0	No main address						
Display/actai					1	Address setting mode	0	Hundreds digit	0~9	Tens digit	0~9	Ones digit
Option	SE	G7	SEG8		SEG9		SEG10		SEG11		SEG12	
Description	Pa	ige			Setting RMC address				Group channel(*16)		Group address	
Remote controller display			No function		Fan On Concernent		No function		Heat		Heat On D	
	Display	Detail	INUTU	NOTUREDUT		Detail		JIICTION	Display	Detail	Display	Detail
Display/detail						No main address						
		1			1	Address setting mode			RMC1	0~F	RMC2	0~F

- Main address (SEG5 \sim SEG6) can be set in range of 0 \sim 47.
- When using automatic address setting, FCU interface module automatically assigns FCU KIT address between 00 $^{\sim}$ 15.
- If you set the SEG 3 as 0, the FCU KIT will maintain the existing main address even if you input the option value of SEG5 \sim SEG6.
- If you set the SEG9 as 0, the FCU KIT will maintain existing RMC address even if you input the option value of SEG11 $^{\sim}$ SEG12.

Setting FCU KIT installation option

- 1 Check if power is supplied to FCU KIT.
- When the power is not supplied to FCU KIT, there should be additional power supply to it.
- 2 Remote controller receiver of wireless remote controller is included in FCU KIT PBA.
- **3** Depending on the installation condition of FCU KIT, installation option to each FCU KIT should be set.
- **4** Set the FCU KIT installation option by using a remote controller.
- The default setting value of the FCU KIT installation option is "020000-100000-200000-300000".

SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
0	2	-	Fan control when Thermo Off	Central control	-
SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
1	-	-	-	-	-
SEG13	SEG14	SEG15	SEG16	SEG17	SEG18
2	External control	External control output	-	-	-
SEG19	SEG20	SEG21	SEG22	SEG23	SEG24
3	-	Heating setting compensation	-	-	-

02 series installation option

• SEG5 (Central control) is set as 1 (Use) in default setting. Setting option is not necessary when using central control. Error will not occur even when central control is not connected, and change the value to 0 (Disuse) when excluding indoor unit from central control.

• When setting the option other than above SEG values, the option will be set as "0".

option	NO. : C)2777		^^^-2/		-3XXXX	IN I							
Option	SE	G1	SE	G2	S	EG3			G4(*1)		SEC			G6
Description	Pa	ge	Mo	de		-		Fan control v	vhen Thermo	Off	Use of cent	ral control		-
Remote controller display			Auto			-					Cool			-
	Display	Detail	Display	Detail	Display	Detail	Display	Fan stop when Cool/ Heat Thermo Off	Detail Minimal fan operation when Heat Thermo Off	Minimal fan operation when Cool Thermo Off	Display	Detail	Display	Deta
Display/detail	()		2		-	0 1 2 3 4 5 6	Disuse Enable Disuse Enable Disuse Enable Disuse	Disuse - Enable - Disuse - Enable	Disuse - Disuse - Enable - Enable	0	Disuse Enable	-	-
0.1		~~					7	Enable	-	-				
Option Description	SE	-	SE	68	5	EG9		5	EG10		SEG	11	SEC	512
Remote controller display	Pa	yc				-			-		-			
Display/detail	Display	Detail	Display	Detail	Display	Detail	[Display	. D	etail	Display -	Detail	Display	Deta
Option	SEC		SEC	514	SE	G15		S	EG16		SEG	17	SEC	G18
Description	Pa	ge	Use of exte	rnal control	CO	itput of external ntrol			-		-			
Remote controller display			Auto		Auto				-		-			-
	Display	Detail	Display	Detail	Display	Detail		Display	1	Detail	Display	Detail	Display	Deta
Display/detail	:	2	0 1 2 3	Disuse ON/OFF control OFF control Window ON/ OFF control	0	Thermo ON Operation ON			-		-		-	
Option	SEC	519	SEC	520		G21		S	EG22		SEG	23	SEC	524
Description	Pa	ge				ig compensation ifset			-		-			
Remote controller display					off				-		-			-
Display/detail	Display	Detail	Display	Detail	Display 0 1 2	Detail 0 °C (0 °F) 2 °C (3.6 °F)	Display		Detail		Display .	Detail	Display .	Det

(*1) Minimal fan operation when Thermo Off

- Fan operates for 20 seconds every 5 minutes in Heat mode.
- Fan stops in Cool mode.

SETTING

_ 37

05 series installation option

SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
0	5	Use Auto Change Over for 4-pipe only	(When setting SEG3) Standard heating temp. offset	(When setting SEG3) Standard cooling temp. offset	(When setting SEG3) Standard for mode change Heating → Cooling
SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
1	(When setting SEG3) Standard for mode change Cooling → Heating	(When setting SEG3) Required time for mode change	-	-	-
SEG13	SEG14	SEG15	SEG16	SEG17	SEG18
2	FCU KIT pipe installation structure	-	Valve open control when Thermo Off	-	FCU cool air prevention compensation temperature
SEG19	SEG20	SEG21	SEG22	SEG23	SEG24
3	-	-	-	Setting cool/heat air prevention skip	FCU KIT external room sensor

Option	n No. : ()5XXX)	K-1XXX	(XX-2X)	XXX-	зххххх	(
Option	SE	G1	S	EG2		SEG3	9	SEG4	S	EG5		SEG6
Description	Pa	age	N	lode		hange Over for ipe only		g SEG3) Standard temp. offset		SEG3) Standard emp. offset	for mode ch	g SEG3) Standard hange Heating → ooling
Remote controller display			Auto		Auto				Co			Dry
	Display	Detail	Display	Detail	Display	Detail	Display	Detail	Display	Detail	Display	Detail
					0	Follow product option	0	0 °C (0 °F)	0	0 °C (0 °F)	0	1 °C (1.8 °F)
							1	0.5 °C (0.9 °F)	1	0.5 °C (0.9 °F)	1	1.5 °C (2.7 °F)
Display/							2	1 °C (1.8 °F)	2	1 °C (1.8 °F)	2	2 °C (3.6 °F)
detail		0		5		Use Auto	3	1.5 °C (2.7 °F)	3	1.5 °C (2.7 °F)	3	2.5 °C (4.5 °F)
					1	Change Over	4	2 °C (3.6 °F)	4	2 °C (3.6 °F)	4	3 °C (5.4 °F)
						for 4-pipe only	5	2.5 °C (4.5 °F)	5	2.5 °C (4.5 °F)	5	3.5 °C (6.3 °F)
							6	3 °C (5.4 °F)	6	3 °C (5.4 °F)	6	4 °C (7.2 °F)
							7	3.5 °C (6.3 °F)	7	3.5 °C (6.3 °F)	7	4.5 °C (8.1 °F)
Option	SE	EG7	S	EG8	9	SEG9	S	EG10	SE	G11	9	EG12
Description	Pa	age	for mode ch	I SEG3) Standard ange Cooling → ating		g SEG3) Required mode change		-		-		-
Remote controller display		-	0n		Fan on			-		-		-
	Display	Detail	Display	Detail	Display	Detail	Display	Detail	Display	Detail	Display	Detail
			0	1 °C (1.8 °F)	0	5 min.						
			1	1.5 °C (2.7 °F)	1	7 min.						
Display/			2	2 °C (3.6 °F)	2	9 min.						
detail		1	3	2.5 °C (4.5 °F)	3	11 min.						-
			4	3 °C (5.4 °F)	4	13 min.						
			5	3.5 °C (6.3 °F)	5	15 min.						
			6	4 °C (7.2 °F)	6	20 min.						
			7	4.5 °C (8.1 °F)	7	30 min.						

Renote display Display Detail Display Display Display Display Display Detail Display Deta	Option	SE	G13	SE	G14	S	EG15	SE	EG16	SE	G17	9	EG18
Remote controller display Display Detail Display Display Display Display Display Display Display Detail Display Detail Display Display Detail Display Display Display Display Display Display Display Display Detail Display Detail Display Display Detail	Description	Р	age				-				-		
Display/ detail Z 0 2-pipe 0 Valve close (pormally close bype) 0 0 0 Display/ detail Z 1 4-pipe - 1 Valve close bype) - 1 1 1'C 2 2'C 1 4-pipe - 1 Valve open (normally close bype) - <	controller						-				-	or	Dry
Display/ detail 2 0 2 2 0 0 0 0 0 1		Display	Detail	Display	Detail	Display	Detail	Display		Display	Detail	Display	Detail
Display/ detail 2 1 4-pipe - 1 Valve open (normally close type) - 1 Valve open (normally close type) - <td></td> <td></td> <td></td> <td>0</td> <td>2-pipe</td> <td></td> <td></td> <td>0</td> <td>(normally close</td> <td></td> <td></td> <td>0</td> <td>0 °C (0 °F)</td>				0	2-pipe			0	(normally close			0	0 °C (0 °F)
Description Page FCU KIT external root Remote controller display Image: Controller Display Image: Controot Image: Controller Display			2	1	4-pipe			1	Valve open (normally close			2 3 4 5 6 7 8 9 A 8 0 C D E	$\begin{array}{c} 1\ ^{\circ}\mathbb{C}\ (1,8\ ^{\circ}\mathrm{F})\\ 2\ ^{\circ}\mathbb{C}\ (3,6\ ^{\circ}\mathrm{F})\\ 3\ ^{\circ}\mathbb{C}\ (5,4\ ^{\circ}\mathrm{F})\\ 4\ ^{\circ}\mathbb{C}\ (7,2\ ^{\circ}\mathrm{F})\\ 5\ ^{\circ}\mathbb{C}\ (9,0\ ^{\circ}\mathrm{F})\\ 6\ ^{\circ}\mathbb{C}\ (10,8\ ^{\circ}\mathrm{F})\\ 7\ ^{\circ}\mathbb{C}\ (12,6\ ^{\circ}\mathrm{F})\\ 7\ ^{\circ}\mathbb{C}\ (12,6\ ^{\circ}\mathrm{F})\\ -7\ ^{\circ}\mathbb{C}\ (12,6\ ^{\circ}\mathrm{F})\\ -5\ ^{\circ}\mathbb{C}\ (-10,8\ ^{\circ}\mathrm{F})\\ -5\ ^{\circ}\mathbb{C}\ (-10,8\ ^{\circ}\mathrm{F})\\ -3\ ^{\circ}\mathbb{C}\ (-5,4\ ^{\circ}\mathrm{F})\\ -3\ ^{\circ}\mathbb{C}\ (-5,4\ ^{\circ}\mathrm{F})\\ -2\ ^{\circ}\mathbb{C}\ (-3,6\ ^{\circ}\mathrm{F})\\ -1\ ^{\circ}\mathbb{C}\ (-1,8\ ^{\circ}\mathrm{F})\\ 0\ ^{\circ}\mathbb{C}\ (0\ ^{\circ}\mathrm{F})\\ \end{array}$
Display/ detail Display Detail Display Dis	Option	SE	G19	SE	G20	S	EG21	SE	EG22			9	EG24
Display Detail Display Display<	Description	Р	age		-		-		-			FCU KIT exte	rnal room sensor
Display/ detail 0 Use in cool Use in heat 0 D 0 1 Display/ Use in heat 0 0 D	controller				-		-		-	off		off	
Display/ detail 3 - - - - - 0 U U U U U Display/ detail 3 -		Display	Detail	Display	Detail	Display	Detail	Display	Detail	Display		Display	Detail
Uspipy/ detail 1 Use in heat 2 Use in cool 1 1										0		0	Disuse
			3		-		-				Use in heat		
3 Disuse in cool Disuse in heat											Disuse in heat Disuse in cool	1	Enable


• Valve open control when Thermo Off: Set to open valve when Thermo Off in case of applying Close type water valve (Valve closes normally if it is not set.)

- FCU cool air prevention compensation temperature: Temperature for preventing cool air can be controlled.
 - Default temp. + SEG18 ≥Water-IN temp. (°C): Heating fan On
 - Default temp. + SEG18 < Water-IN temp. (°C): Heating fan Off
- Fan speed can be various according to the water in temperature.

- Room < Water-IN temp. (°C) 1 °C: Fan Off
- Room > Water-IN temp. (°C): Fan On
- In case of using external temperature sensor or minimal fan operation function, external temperature sensor or wired remote controller should be connected. (Internal temperature sensor option of wired remote controller should be set "Use" to use the function. Refer to installation manual of wired remote controller.)

SEG3, 4, 5, 6, 8, 9 additional information

When the SEG3 is set as "1" and follow Auto Change Over for 4-pipe only operation, it will operate as follows.



Cooling/Heating mode can be changed when Thermo Off status is maintained during the time with SEG9.

SETTING

41

Changing a particular option

You can change each digit of set option.

Option	S	EG1		SEG2		SEG3		SEG4		SEG5		SEG6
Description	Р	age		Mode	Option r	node to change	-	of option SEG to change		t of option SEG to change	Value t	be changed
Remote controller display			Auto		Auto		On		On		on	Dry
	Display	Detail	Display	Detail	Display	Detail	Display	Detail	Display	Detail	Display	Detail
Display/ detail		0		D	Option mode	0~F	Tens digit of SEG	0~9	Ones digit of SEG	0~9	Value to be changed	0~9

NOTE

- Set SEG3 as "A" when changing one digit of FCU KIT address setting option.
- Set SEG3 as "2" when changing one digit of FCU KIT installation option.
 - Ex) When setting the 'Central control' into Use status

Option	SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
Description	Page	Mode	Option mode to change	Tens digit of option SEG to change	Ones digit of option SEG to change	Value to be changed
Setting	0	D	2	0	5	1


Troubleshooting

Error code

Operation and error status can be checked by LED of FCU KIT.

Error code	R-LED	Y/G-LED	Error	Solutions
162	ON	OFF	EEPROM error	Change EEPROM
163	OFF	ON	Option input error	Reset option
Communication error	ON	ON	Communication error (between interface modules or wired remote controller)	Check communication status between FCU KIT and interface module or wired remote controller
-	OFF	OFF	Power not supplied	Check power supply
-	Blinking	Blinking	Normal	

Error code	Error description
E121	Indoor temperature sensor error (Open/Short)
E990	Water-IN 1 sensor error (Open/Short)
E991	Water-IN 2 sensor error (Open/Short)
E101	Communication error between indoor and outdoor unit when there is no
LIUI	communication for 2 minutes
	Communication error on interface module detection
E201	 Incomplete interface module tracking in 10 minutes
LZUI	 Mixed installation of FCU KIT and indoor unit
	 Exceeding maximum installation number of FCU KIT (16)
E108	Error on repeated communication address
E109	Uncomplete setting communication address
E992	Sensor detached or water blocked in Cool mode
E993	Sensor detached or water blocked in Heat mode
E198	Thermal fuse open error
E162	EEPROM error
E163	EEPROM option error



OTHERS

Inspection and test operation


Checking FCU KIT installation

- Check if FCU KIT is installed properly.
 - Check if cables of FCU KIT are properly connected.
 - Check if FCU KIT is installed vertically or horizontally.
 - Install FCU KIT avoiding condensation area and water pipe line.
 - Tighten wire holder to fix power and communication cable.
 - Check if the locations of FCU KIT sensor and valve is appropriate.
 - Check if the location of sensor is placed at inlet and the sensor is attached to the pipe.

Trial operation

- **1** Before supplying the power, use DC 500 V insulation resistance tester to measure the insulation resistance of power (L, N) terminal and FCU KIT grounding.
- Measurement should be over 30 M Ω .

- Do not measure the communication terminal as the communication circuit can be damaged.
- Use common circuit tester on communication terminal to check open or short.



- 2 Check the power voltage (L, N) before supplying power and then turn on the switch.
- **3** After completing the installation, check the followings to make sure FCU KIT operates without a problem.
- Heat resistance of water pipe insulator
- Power connection
- Circuit breaker connection, grounding
- Operation of each operation mode for system
- Operation of 2 Way valve according to operation mode

OTHERS

Solution for mixed operation prevention

- This function is to prevent DVM CHILLER and FCU (KIT) from operating in different modes.
 - Ex.) The situation that cool air comes out since DVM CHILLER is operating in Cool mode and FCU is operating in Heat mode in 2-pipe system
 - If Lock function is set on DMS2.5 or Touch centralized controller: Other operation modes cannot be operated by FCU KIT if administrator selected Cool/Heat mode and set Lock function on DMS2.5 or Touch centralized controller
 - If Lock function is not set on DMS2.5 or Touch centralized controller: Refer for maintenance that it detects water outlet temperature and stops fan after 10 minutes if temperature is not appropriate, and error message will occur if the fan is stopped for more than 30 minutes (E992, E993).

Function of wired remote controller

Display

- The following function of FCU KIT can only be used when using wired remote controller.
 - Operation On/Off
 - Auto/Cool/Fan/Heat mode
 - Setting temperature (Temperature range: Cool 18 $^{\sim}$ 30 °C (65 $^{\sim}$ 86 °F), Heat 16 $^{\sim}$ 30 °C (61 $^{\sim}$ 86 °F))
 - Fan speed (Auto, High, Mid, Low)
 - Timer

 $\% \, {\rm Other}$ functions do not work when pressing the button.

• Refer to user manual of wired remote controller for more details on using.



Memo