

Air conditioner

Installation manual

AC***MNADKH / AC***MNTDEH

- Thank you for purchasing this Samsung air conditioner.
- Before operating this unit, please read this Installation manual carefully and retain it for future reference.



SAMSUNG

Contents

Installation	3
Safety Information on Installation	3
Preparation	5
Step 1.1 Choosing the installation location	
Step 1.2 Checking and preparing accessories and tools	
Step 1.3 Drilling a hole through the wall	
Step 1.4 Performing the gas leak test	
Step 1.5 Insulating the refrigerant pipes	
Indoor Unit Installation	8
Step 2.1 Disassembling the cover panel	
Step 2.2 Disassembling the installation plate	
Step 2.3 Connecting the power and communication cables (assembly cable)	
Step 2.4 Optional: Extending the power cable	
Step 2.5 Installing and connecting the drain hose	
Step 2.6 Optional: Extending the drain hose	
Step 2.7 Optional: Changing the direction of the drain hose	
Step 2.8 Installing and connecting the assembly pipes to the refrigerant pipes (assembly pipe)	
Step 2.9 Optional: Installing DPM	
Step 2.10 Shortening or extending the refrigerant pipes (assembly pipe)	
Step 2.11 Fixing the installation plate	
Step 2.12 Fixing the indoor unit to the installation plate	
Step 2.13 Assembling the cover panel	
Setting an indoor unit address and installation option	17
Troubleshooting	25

For information on Samsung's environmental commitments and product specific regulatory obligations e.g. REACH visit: samsung.com/uk/aboutsamsung/samsungelectronics/corporatecitizenship/data_corner.html

Safety Information on Installation

Carefully follow the precautions listed below because they are essential to guarantee the safety of both the air conditioner and the workers.

- Always disconnect the air conditioner from the power supply before servicing it or accessing its internal components.
- Verify that installation and testing operations are performed by qualified personnel.
- Verify that the air conditioner is not installed in an easily accessible area.

General information

- Carefully read the content of this manual before installing the air conditioner and store the manual in a safe place in order to be able to use it as reference after installation.
- For maximum safety, installers should always carefully read the following warnings.
- Store the operation and installation manual in a safe location and remember to hand it over to the new owner if the air conditioner is sold or transferred.
- This manual explains how to install an indoor unit with a split system with two SAMSUNG units. The use of other types of units with different control systems may damage the units and invalidate the warranty. The manufacturer shall not be responsible for damages arising from the use of non compliant units.
- The manufacturer shall not be responsible for damage originating from unauthorised changes or the improper connection of electric and requirements set forth in the "Operating limits" table, included in the manual, shall immediately invalidate the warranty.
- The air conditioner should be used only for the applications for which it has been designed: the indoor unit is not suitable to be installed in areas used for laundry.
- Do not use the units if damaged. If problems occur, switch the unit off and disconnect it from the power supply.
- In order to help prevent electric shocks, fires or injuries, always stop the unit, disable the protection switch and contact SAMSUNG's technical support if the unit produces smoke, if the power cable is hot or damaged or if the unit is very noisy.
- Always remember to inspect the unit, electric connections, refrigerant tubes and protections

regularly. These operations should be performed by qualified personnel only.

- The unit contains moving parts, which should always be kept out of the reach of children.
- Do not attempt to repair, move, alter or reinstall the unit. If performed by unauthorised personnel, these operations may cause electric shocks or fires.
- Do not place containers with liquids or other objects on the unit.
- All the materials used for the manufacture and packaging of the air conditioner are recyclable.
- The packing material and exhaust batteries of the remote control (optional) must be disposed of in accordance with current laws.
- The air conditioner contains a refrigerant that has to be disposed of as special waste. At the end of its life cycle, the air conditioner must be disposed of in authorised centres or returned to the retailer so that it can be disposed of correctly and safely.

Installation of the unit

- **IMPORTANT:** When installing the unit, always remember to connect first the refrigerant tubes, then the electrical lines. Always disassemble the electric lines before the refrigerant tubes.
- Upon receipt, inspect the product to verify that it has not been damaged during transport. If the product appears damaged, **DO NOT INSTALL** it and immediately report the damage to the carrier or retailer (if the installer or the authorised technician has collected the material from the retailer.)
- After completing the installation, always carry out a functional test and provide the instructions on how to operate the air conditioner to the user.
- Do not use the air conditioner in environments with hazardous substances or close to equipment that release free flames to avoid the occurrence of fires, explosions or injuries.
- Our units must be installed in compliance with the spaces indicated in the installation manual to ensure either accessibility from both sides or ability to perform routine maintenance and repairs. The units' components must be accessible and that can be disassembled in conditions of complete safety either for people or things. For this reason, where it is not observed as indicated into the Installation Manual, the cost necessary to reach and repair the unit (in safety, as required by current regulations in force) with slings,

Safety Information on Installation

trucks, scaffolding or any other means of elevation won't be considered in-warranty and will be charged to end user.

Power supply line, fuse, or circuit breaker

- Always make sure that the power supply is compliant with current safety standards. Always install the air conditioner in compliance with current local safety standards.
- Always verify that a suitable grounding connection is available.
- Verify that the voltage and frequency of the power supply comply with the specifications and that the installed power is sufficient to ensure the operation of any other domestic appliance connected to the same electric lines.
- Always verify that the cut-off and protection switches are suitably dimensioned.
- Verify that the air conditioner is connected to the power supply in accordance with the instructions provided in the wiring diagram included in the manual.
- Always verify that electric connections (cable entry, section of leads, protections...) are compliant with the electric specifications and with the instructions provided in the wiring scheme. Always verify that all connections comply with the standards applicable to the installation of air conditioners.
- Devices disconnected from the power supply should be completely disconnected in the condition of overvoltage category.
- Install the indoor unit away from lighting apparatus using the ballast.
 - If you use the wireless remote controller, reception error may occur due to the ballast of the lighting apparatus.
- Do not install the air conditioner in following places.
 - Place where there is mineral oil or arsenic acid. Resin parts flame and the accessories may drop or water may leak. The capacity of the heat exchanger may reduce or the air conditioner may be out of order.
 - The place where corrosive gas such as sulfurous acid gas generates from the vent pipe or air outlet.
- The copper pipe or connection pipe may corrode and refrigerant may leak.
 - The place where there is a machine that generates electromagnetic waves. The air conditioner may not operate normally due to control system.
 - The place where there is a danger of existing combustible gas, carbon fiber or flammable dust.
- The place where thinner or gasoline is handled. Gas may leak and it may cause fire.
- Be sure not to perform power cable modification, extension wiring, and multiple wire connection.
 - It may cause electric shock or fire due to poor connection, poor insulation, or current limit override.
 - When extension wiring is required due to power line damage, refer to "Step 2.4 Optional:Extending the power cable" in the installation manual.



CAUTION

- Make sure that you earth the cables.
 - Do not connect the earth wire to the gas pipe, water pipe, lighting rod or telephone wire. If earthing is not complete, electric shock or fire may occur.
- Install the circuit breaker.
 - If the circuit breaker is not installed, electric shock or fire may occur.
- Make sure that the condensed water dripping from the drain hose runs out properly and safely.
- Install the power cable and communication cable of the indoor and outdoor unit at least 1m away from the electric appliance.

Preparation

Step 1.1 Choosing the installation location

Overview of installation location requirements

(Unit : m)

Model	Pipe length		Pipe height
	Minimum	Maximum	Maximum
AC026/035MNADKH	3	20	15
AC052MNADKH	3	30	20
AC071MNADKH	3	50	30
AC100MNTDEH			

Outdoor Unit

Outer wall

Indoor Unit

Cut insulation to have rainwater drained

CAUTION

Make a U-trap (A) on the pipe (which is connected to the indoor unit) at outer wall and cut the bottom part of the insulation (about 10 mm) to prevent rainwater from getting inside through the insulation.

Step 1.2 Checking and preparing accessories and tools

Accessories








Accessories in the indoor unit package

AC***MNADKH

Installation plate (1) **026/035** (01 frame)	Installation plate (1) **052** (04 frame)
Installation plate (1) **071** (05 frame)	Remote control (1)
Remote control battery (2)	User Manual (1)
Installation Manual (1)	Cap screw (3)
Remote Control Holder (1)	M4 x 16 Tapped Screws (2)
Guide Left(1)	Guide Right(1)

Preparation

AC***MNTDEH

Installation plate (1) **100**	Remote control (1)
	
Remote control battery (2)	User Manual (1)
	
Installation Manual (1)	Remote Control Holder (1)
	
M4 x 16 Tapped Screws (2)	
	

Tools

General tools

- Vacuum pump (Backward flowing prevention)
- Manifold gauge
- Stud finder
- Torque wrench
- Pipe cutter
- Reamer
- Pipe bender
- Spirit level
- Screwdriver
- Spanner
- Drill
- L-wrench
- Measuring tape


Tools for test operation

- Thermometer
- Resistance meter
- Electroscopes

Step 1.3 Drilling a hole through the wall


Before fixing the installation plate to a wall and then fixing the indoor unit to the installation plate, a window frame, or a gypsum board, you must determine the position of a hole (with 65 mm inner diameter) through which the pipe bundle (consisting of power and communication cables, refrigerant pipes, and drain hose) will pass and then drill that hole.

- 1 Determine the position of a 65 mm hole in consideration of the possible directions of the pipe bundle and the minimum distances between the hole and the installation plate.



CAUTION

- If changing the pipe direction from left to right, do not drastically bent it but slowly turn it in the opposite direction as shown. Otherwise, the pipe may be damaged in the process.




<Minimum distances between the hole and the installation plate>

(Unit : mm)

Model	A	B	C	D
AC026MNADKH AC035MNADKH	36	60	65	36
AC052MNADKH	36	190	81	36
AC071MNADKH	33	110	110	33

Pipe bundle hole: Ø 65 mm



<Minimum distances between the hole and the installation plate>

(Unit : mm)

Model	A	B	C	D	E	F
AC100MNTDEH	156	67	364	34.5	64.5	19.5


Pipe bundle hole: Ø 65 mm

2 Drill the hole.



CAUTION

- Be sure to drill only one hole.
- Make sure that the hole slants downwards so that the drain hose slants downwards to drain water well.



<The hole slants downwards>

Step 1.4 Performing leak test


Leak test

LEAK TEST WITH NITROGEN (before opening valves)

In order to detect basic refrigerant leaks, before recreating the vacuum and recirculating the R410A, it's responsible of installer to pressurize the whole system with nitrogen (using a pressure regulator) at a pressure above 4.1MPa (gauge).

LEAK TEST WITH R410A (after opening valves)

Before opening valves, discharge all the nitrogen into the system and create vacuum. After opening valves check leaks using a leak detector for refrigerant R410A.



Test parts for the indoor unit




CAUTION

- Discharge all the nitrogen to create a vacuum and charge the system.

Step 1.5 Wrapping the pipes with the insulation

After checking for gas leaks in the system, insulate the pipe, hose and cables. Then place the indoor unit on the installation plate.

- 1 To avoid condensation problems, place heat-resistant poly-ethylene foam separately around each refrigerant pipe in the lower part of the indoor unit.




- 2 Wrap the refrigerant pipe and the drain hose in the rear of the indoor unit with the absorbent pad.



NOTE

- Wind the pipe and hose three times to the end of the indoor unit with the absorbent pad. (20mm interval)
- 3 Wind the pipe, assembly cable and drain hose with insulation tape.
 - 4 Place the bundle (the pipe, assembly cable and drain hose) in the lower part of the indoor unit carefully so it doesn't project from the rear of the indoor unit.



- 5 Hook the indoor unit to the installation plate and move the unit to the right and left until it is securely in place.
- 6 Wrap the rest of the pipe with vinyl tape.
- 7 Attach the pipe to the wall using clamps (optional).



Indoor Unit Installation



Please scan this QR code for detail video of indoor unit installation.
(This QR code only for AC***MNADKH)



Step 2.1 Disassembling the cover panel (Only for AC***MNADKH)

- 1 Remove the cap screws, then the screws.




Step 2.2 Disassembling the installation plate

- 2 Unlock the side hooks (1, 2), then centre hooks (3). Then unlock the bottom hooks (4) to pull out the cover panel.




Step 2.3 Connecting the power and communication cables (assembly cable)



Before connecting				
	Correct	Upside down	Damaged	Non-circular
After connecting				
	Correct (Front view)	Correct (Side view)	Upside down	Non-fitted

<Circular terminal>



Fasten the screws for the wire holders.

Model	AC026MNADKH AC035MNADKH AC052MNADKH AC071MNADKH AC100MNTDEH
Power cable (Outdoor unit)	3G X 1.5 mm ² , H07RN-F
Outdoor-to-indoor power cable	3G X 1.0 mm ² , H07RN-F
Communication cable	2 X 0.75 mm ² , H05RN-F
Type GL	16A

- When performing electrical and earthing works, be sure to comply with the 'technical standards of electrical installations' and the 'wiring regulations' in the local regulations.
- Tighten the terminal block screw to 1.2-1.8 N•m (12-18 kgf•cm).

NOTE

- Each wire is labelled with the corresponding terminal number.
- Use shield cable (Category 5; less than 50pF/m) for noisy environmental site.
- Power supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord. (Code designation IEC: 60245 IEC 66/ CENELEC: H07RN-F, IEC: 60245 IEC 57/CENELEC: H05RN-F)
- Power & Communication cable shall not exceed 30m.

CAUTION

- For the terminal block wiring, use a wire with a ring terminal socket only. Regular wires without a ring terminal socket may become a hazard due to overheating of the electrical contact during installation.
- If you need to extend the pipe, be sure to extend the cable too. The maximum length of each of the cable and pipe used should not exceed 15 metres.
- Do not connect two or more different cables to extend the length. This connection may cause fire.
- Each circular terminal must match the size of its corresponding screw in the terminal block.
- After connecting the cables, make sure that terminal numbers on the indoor and outdoor units match.
- Ensure that power and communication cables are separated, they must not be in the same cable.





WARNING

- Connect the wires firmly so that wires cannot be pulled out easily. (If they are loose, it could cause burn-out of the wires.)

Indoor Unit Installation

Step 2.4 Optional: Extending the power cable

1 Prepare the following tools.


Tools	Spec	Shape
Crimping pliers	MH-14	
Connection sleeve (mm)	20xØ7.0 (HxOD)	
Insulation tape	Width 18 mm	
Contraction tube (mm)	50xØ8.0 (LxOD)	

2 As shown in the figure, peel off the shields from the rubber and wire of the power cable.

- Peel off 20 mm of cable shields from the pre-installed tube.


CAUTION

- For information about the power cable specifications for indoor and outdoor units, refer to the installation manual.
- After peeling off cable wires from the pre-installed tube, insert a contraction tube.




3 Insert both sides of core wire of the power cable into the connection sleeve.

- **Method 1:** Push the core wire into the sleeve from both sides.
- **Method 2:** Twist the wire cores together and push it into the sleeve.




4 Using a crimping tool, compress the two points and flip it over and compress another two points in the same location.

- The compression dimension should be 8.0.




- After compressing it, pull both sides of the wire to make sure it is firmly pressed.




5 Wrap it with the insulation tape twice or more and position your contraction tube in the middle of the insulation tape.


Three or more layers of insulation are required.



6 Apply heat to the contraction tube to contract it.



7 After tube contraction work is completed, wrap it with the insulation tape to finish.




CAUTION

- Make sure that the connection parts are not exposed to outside.
- Be sure to use insulation tape and a contraction tube made of approved reinforced insulating materials that

have the same level of withstand voltage with the power cable. (Comply with the local regulations on extensions.)



⚠ WARNING

- In case of extending the electric wire, please DO NOT use a round-shaped pressing socket.
 - Incomplete wire connections can cause electric shock or a fire.




Step 2.5 Installing and connecting the drain hose

- 1 Install the drain hose.




- 2 Pour water into the drain pan. Check whether the hose is well drained.



⚠ CAUTION

- Make sure that the indoor unit is in upright position when you pour water to check for leakage. Make sure that the water does not overflow onto the electrical part.
- If the diameter of the connection hose is smaller than the product's drain hose, water leakage may occur.
- Inadequate installation may cause water leakage.
- If the drain hose is routed inside the room, insulate the hose so that dripping condensation does not damage the furniture or floors.
- Do not box in or cover the drain hose connection. Drain hose connection must be easily accessible and serviceable.


Step 2.6 Optional: Extending the drain hose




Indoor Unit Installation

Step 2.7 Optional: Changing the direction of the drain hose


AC***MNADKH



- 3 Insert the drain hose by fixing it into the groove of the drain hose and the outlet of the drain pan.




- 4 Attach the rubber cap with a screwdriver by turning it to the right until it fixes to the end of the groove.
- 5 Check for leakage on both side of the drain outlet.




AC***MNTDEH

Change the direction only when it is necessary.

- 1 Detach the rubber cap with the flyer.



- 2 Detach the drain hose by pulling it and turning to the left.



⚠ CAUTION

- Make sure that the indoor unit is in upright position when you pour water to check for leakage. Make sure that the water does not overflow onto the electrical part.


Step 2.8 Installing and connecting the assembly pipes to the refrigerant pipes (assembly pipe)

Connect indoor and outdoor units with field-supplied copper pipes by means of flare connections. Use insulated seamless refrigeration grade pipe only, (Cu DHP type according to ISO1337), degreased and deoxidized, suitable for operating pressures of at least 4200 kPa and for burst pressure of at least 20700 kPa. Under no circumstances must sanitary type copper pipe be used.

There are 2 refrigerant pipes of different diameters:

- The smaller one is for the liquid refrigerant
- The larger one is for the gas refrigerant

A short liquid refrigerant pipe and a short gas refrigerant pipe are already fitted to the air conditioner. The connection procedure for the refrigerant pipes varies according to the exit position of each pipe when facing the wall:



- 1 Cut out the appropriate knock-out piece (A, B, C) on the rear of the indoor unit unless you connect the pipe directly from the rear.
- 2 Smooth the cut edges.
- 3 Remove the protection caps of the pipes and connect the assembly pipe to each pipe. Tighten the nuts first with your hands, and then with a torque wrench, applying the following torque:

Outer diameter (mm)	Torque (N·m)	Torque (kgf·cm)
ø 6.35	14 to 18	140 to 180
ø 9.52	34 to 42	350 to 430
ø 12.70	49 to 61	500 to 620
ø 15.88	68 to 82	690 to 830

NOTE

- If you want to shorten or extend the pipes, see **Step 2.9 Shortening or extending the refrigerant pipes (assembly pipe)** on page 14.
- 4 Cut off the remaining foam insulation.
 - 5 If necessary, bend the pipe to fit along the bottom of the indoor unit. Then pull it out through the appropriate hole.
 - The pipe should not project from the rear of the indoor unit.
 - The bending radius should be 100 mm or more.
 - 6 Pass the pipe through the hole in the wall.
 - 7 Fix the indoor unit on the wall. Pass the cables, pipes and hose through the knock-out hole which would be connected to the outdoor unit.
 - 8 Use 2 screws to fix the indoor unit as shown in the picture 2.
 - 9 Assemble the Guide into the position of A or B as shown in the picture 3.

NOTE

- The pipe will be insulated and fixed permanently into position after finishing the installation and the gas leak test.


CAUTION

- Tighten the flare nut with a torque wrench according to specified method. If the flare nut is over-tightened, the flare may break and cause refrigerant gas leakage.
- Do not box in or cover the pipe connection. All refrigerant pipe connection must be easily accessible and serviceable.



Indoor Unit Installation

Step 2.9 Optional: Installing DPM

- When installing DPM, you should set "DPM setting" to the outdoor unit.
- If DPM model is not set, communication error may occur.
- While the outdoor unit is tracking the indoor unit for one minute after the power supply is turned on, the operation may stop if the remote control reception signal of the installed indoor unit is different.
- When DPM is installed, Automatic Air-Volume function cannot be performed simultaneously for all indoor units. Automatic Air-Volume function must be performed for each indoor unit with the wired remote control attached.




Step 2.10 Shortening or extending the refrigerant pipes (assembly pipe)



CAUTION

- If you need a pipe longer than specified in piping codes and standards, you must add refrigerant to the pipe. Otherwise, the indoor unit may freeze.
- While removing burrs, put the pipe face down to make sure that the burrs do not get in to the pipe.



NOTE

- Excessive torque may cause gas leakage. When extending the pipe with welding or brazing, ensure that nitrogen is used during the welding or brazing process. The joint must be accessible and serviceable.

CAUTION

- Tighten the flare nut at the specified torque. If the flare nut is over-tightened, it may break to cause leakage of refrigerant gas.

Step 2.11 Fixing the installation plate


You can install the indoor unit on a wall, window frame, or gypsum board.

WARNING

- Make sure that the wall, window frame, or gypsum board can withstand the weight of the indoor unit. If you install the indoor unit in a place where it is not strong enough to withstand the unit's weight, the unit could fall and cause injury.

When fixing the indoor unit on a wall


Fix the installation plate to the wall giving attention to the weight of the indoor unit.



(Unit : mm)

Model	A	B	C	D
AC026MNADKH	36	60	65	36
AC035MNADKH	36	60	65	36
AC052MNADKH	36	190	81	36
AC071MNADKH	33	110	110	33

Pipe bundle hole: Ø 65 mm



(Unit : mm)

Model	A	B	C	D	E	F
AC100MNTDEH	156	67	364	34.5	64.5	19.5

Pipe bundle hole: Ø 65 mm

NOTE

- If you mount the plate to a concrete wall using plastic anchors, make sure that gaps between the wall and the plate, created by projected anchor, is less than 20 mm.

When fixing the indoor unit on a window frame

- Determine the positions of the wooden uprights to be attached to the window frame.
- Attach the wooden uprights to the window frame giving attention to the weight of the indoor unit.
- Attach the installation plate to the wooden upright using tapping screws.

When fixing the indoor unit on a gypsum board


- Use stud finder to find out locations of the studs.
- Fix the plate hanger on two studs.

CAUTION

- If you fix the indoor unit on a gypsum board, use only specified anchor bolts on reference positions. Otherwise, the gypsum surrounding the joints may crumble over time and cause the screws to be loosened and stripped. This may lead to physical injury or equipment damage.
- Search for other spots if there are less than two studs, or the distance between the studs are different from the plate hanger.
- Fix the installation plate without inclining to one side.

Indoor Unit Installation

Step 2.12 Fixing the indoor unit to the installation plate




⚠ CAUTION

- Make sure that the pipe bundle does not move when you install the indoor unit onto the installation plate.

Step 2.13 Assembling the cover panel (Only for AC***MNADKH)


- 1 Lock the side hooks (D), then centre hooks (B). Then lock the bottom hooks (C) to engage the cover panel in place.
- 2 Fasten the screw (A-①), then assemble the cap screws (A-②).



Setting an indoor unit address and installation option

- Set the indoor unit address and installation option with remote controller option. Set the each option separately since you cannot set the ADDRESS setting and indoor unit installation setting option at the same time. You need to set twice when setting indoor unit address and installation option.
- Please use the proper wireless remote controller which can set 24 digit option code.
- Please refer to the wired remote controller installation manual for setting with the wired remote controller.


Common steps for setting the addresses and options



NOTE

- The remote control display and buttons may vary depending on the model.

- 1 Enter the mode for setting the options:
 - a Remove the batteries from the remote control, and then insert them again.
 - b While holding down the (High Temp) and (Low Temp) buttons simultaneously, insert the batteries into the remote control.
 - c Make sure that you are entered to the mode for setting the options:



- 2 Set the option values.

CAUTION

























- The total number of available options are 24: SEG1 to SEG24.
- Because SEG1, SEG7, SEG13, and SEG19 are the page options used by the previous remote control models, the modes to set values for these options are skipped automatically.
- Set a 2-digit value for each option pair in the following order: SEG2 and SEG3 → SEG4 and SEG5 → SEG6 and SEG8 → SEG9 and SEG10 → SEG11 and SEG12 → SEG14 and SEG15 → SEG16 and SEG17 → SEG18 and SEG20 → SEG21 and SEG22 → SEG23 and SEG24

























SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
0	X	X	X	X	X
SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
1	X	X	X	X	X
SEG13	SEG14	SEG15	SEG16	SEG17	SEG18
2	X	X	X	X	X
SEG19	SEG20	SEG21	SEG22	SEG23	SEG24
3	X	X	X	X	X

On (SEG1 to SEG12)	Off (SEG13 to SEG24)











Setting an indoor unit address and installation option

Take the steps presented in the following table:


Option setting	Status
1 Setting SEG2, SEG3 option Press Low Fan button  to enter SEG2 value. Press High Fan button  to enter SEG3 value. Each time you press the button, 0 → 1 → ... → E → F will be selected in rotation.	<div>   </div> <div> SEG2 SEG3 </div>
2 Setting Cool mode  Press Mode button to be changed to Cool mode in the ON status.	
3 Setting SEG4, SEG5 option Press Low Fan button  to enter SEG4 value. Press High Fan button  to enter SEG5 value. Each time you press the button, 0 → 1 → ... → E → F will be selected in rotation.	<div>   </div> <div> SEG4 SEG5 </div>
4 Setting Dry mode  Press Mode button to be changed to DRY mode in the ON status.	
5 Setting SEG6, SEG8 option Press Low Fan button  to enter SEG6 value. Press High Fan button  to enter SEG8 value. Each time you press the button, 0 → 1 → ... → E → F will be selected in rotation.	<div>   </div> <div> SEG6 SEG8 </div>
6 Setting Fan mode  Press Mode button to be changed to FAN mode in the ON status.	
7 Setting SEG9, SEG10 option Press Low Fan button  to enter SEG9 value. Press High Fan button  to enter SEG10 value. Each time you press the button, 0 → 1 → ... → E → F will be selected in rotation.	<div>   </div> <div> SEG9 SEG10 </div>
8 Setting Heat mode  Press Mode button to be changed to HEAT mode in the ON status.	



Option setting	Status
9 Setting SEG11, SEG12 option Press Low Fan button  to enter SEG11 value. Press High Fan button  to enter SEG12 value. Each time you press the button, 0 • 1 • ... • E • F will be selected in rotation.	<div data-bbox="695 300 837 408">  </div> <div data-bbox="866 300 1009 408">  </div> <div data-bbox="740 437 785 453">SEG11</div> <div data-bbox="913 437 958 453">SEG12</div>
10 Setting Auto mode  Press Mode button to be changed to AUTO mode in the OFF status.	<div data-bbox="781 472 924 568">  </div>
11 Setting SEG14, SEG15 option Press Low Fan button  to enter SEG14 value. Press High Fan button  to enter SEG15 value. Each time you press the button, 0 • 1 • ... • E • F will be selected in rotation.	<div data-bbox="695 584 837 679">  </div> <div data-bbox="866 584 1009 679">  </div> <div data-bbox="740 699 785 715">SEG14</div> <div data-bbox="913 699 958 715">SEG15</div>
12 Setting Cool mode  Press Mode button to be changed to Cool mode in the OFF status.	<div data-bbox="781 735 924 831">  </div>
13 Setting SEG16, SEG17 option Press Low Fan button  to enter SEG16 value. Press High Fan button  to enter SEG17 value. Each time you press the button, 0 • 1 • ... • E • F will be selected in rotation.	<div data-bbox="695 847 837 943">  </div> <div data-bbox="866 847 1009 943">  </div> <div data-bbox="740 959 785 975">SEG16</div> <div data-bbox="913 959 958 975">SEG17</div>
14 Setting Dry mode  Press Mode button to be changed to Dry mode in the OFF status.	<div data-bbox="781 995 924 1091">  </div>
15 Setting SEG18, SEG20 option Press Low Fan button  to enter SEG18 value. Press High Fan button  to enter SEG20 value. Each time you press the button, 0 • 1 • ... • E • F will be selected in rotation.	<div data-bbox="695 1102 837 1198">  </div> <div data-bbox="866 1102 1009 1198">  </div> <div data-bbox="740 1217 785 1233">SEG18</div> <div data-bbox="913 1217 958 1233">SEG20</div>
16 Setting Fan mode  Press Mode button to be changed to Fan mode in the OFF status.	<div data-bbox="781 1254 924 1350">  </div>

Setting an indoor unit address and installation option

Option setting	Status
17 Setting SEG21, SEG22 option Press Low Fan button  to enter SEG21 value. Press High Fan button  to enter SEG22 value. Each time you press the button, 0 → 1 → ... → E → F will be selected in rotation.	<div>  SEG21 </div> <div>  SEG22 </div>
18 Setting Heat mode  Press Mode button to be changed to HEAT mode in the OFF status.	 Heat
19 Setting SEG23, SEG24 option Press Low Fan button  to enter SEG23 value. Press High Fan button  to enter SEG24 value. Each time you press the button, 0 → 1 → ... → E → F will be selected in rotation.	<div>  SEG23 </div> <div>  SEG24 </div>

- 3 Check whether the option values that you have set are correct by pressing the  button repeatedly.



- 4 Save the option values into the indoor unit:
 Press the  button with the direction of remote control for set. For correcting option values, input the option values twice.
- 5 Check whether the air conditioner operates in accordance with the option values you have set:
- Reset the indoor unit by pressing the Reset button on the indoor or outdoor unit.
 - Remove the batteries from the remote control, insert them again, and then press the  button on the remote control.

Setting the indoor unit addresses

- 1 Make sure that the power is supplied to the indoor unit. If the indoor unit is not plugged in, it must include a power supply.
- 2 The panel(display) should be connected to an indoor unit to receive option.
- 3 Before installing the indoor unit, assign an address to the indoor unit according to the air conditioning system plan.
- 4 Assign an indoor unit address by wireless remote controller.
 - The initial indoor unit ADDRESS is set as "MAIN : 0, RMC : 0".
 - Set Main and RMC Address only the setting is required.
 - There is no need to assign the indoor unit Main Address if the outdoor unit is addressing automatically. The indoor unit Main address will follow the outdoor unit's automatically.
 - Assign 12 digit when setting the indoor unit address.
 - No need to assign SEG4, 5, 8, 10 which are non applicable. Even though those segments are set, they will be ignored.
 - If you set the applicable segments with numbers other than the indicated, the initial setting will be maintained.

Option No. : 0AXXXX-1XXXXX-2XXXXX-3XXXXX

Option	SEG1		SEG2		SEG3		SEG4	SEG5	SEG6		
Explanation	PAGE		MODE		Setting Main address		RESERVED	RESERVED	The unit digit of an indoor unit		
Indication and Details	Indication	Details	Indication	Details	Indication	Details			Indication	Details	
	0		A		0	No Main address			0~3(ACN*)	Details	
					1	Main address setting mode			0~4 (AJN*)	A single digit	
Option	SEG7		SEG8		SEG9		SEG10	SEG11	SEG12		
Explanation	PAGE		RESERVED		Setting RMC address		RESERVED	Group channel(*16)		Group address	
Indication and Details	Indication	Details			Indication	Details		Indication	Details	Indication	Details
	1				0	No RMC address		RMC1	0~2	RMC2	0~F
					1	RMC address setting mode					

*SEG6: AJN** models should check maximum installation indoor unit number of outdoor unit.
(Indoor1: 0, Indoor2: 1, ~)



CAUTION


- When "A"~"F" is entered to SEG5~6, the indoor unit MAIN ADDRESS is not changed.
- If you set the SEG 3 as 0, the indoor unit will maintain the previous MAIN ADDRESS even if you input the option value of SEG6.
- If you set the SEG 9 as 0, the indoor unit will maintain previous RMC ADDRESS even if you input the option value of SEG11~12.

Example) If you want to set as "MAIN: 3, CHANNEL: 1, RMC: B",

Setting an indoor unit address and installation option

SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
0	A	1	-	-	3
SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
1	-	1	-	1	B

assign option codes except SEG 1, 7 which are page options.



Setting the installation options in a batch

- 1 Make sure that the power is supplied to the indoor unit. If the indoor unit is not plugged in, it must include a power supply.
- 2 The panel(display) should be connected to an indoor unit to receive option.
- 3 Set the installation option according to the installation condition of an air conditioner.
 - The default setting of an indoor unit installation option is "02000-100000-200000-300000".
 - Individual control of a remote controller(SEG20) is the function that controls an indoor unit individually when there is more than one indoor unit.
 - No need to assign SEG3, 6, 9, 10, 11, 16, 21, 22, 23, 24 which are non applicable. Even though those segments are set, they will be ignored.
 - If you set the applicable segments with numbers other than the indicated, the initial setting will be maintained.
- 4 Set the indoor unit option by wireless remote controller.

Option No. : 02XXXX-1XXXXX-2XXXXX-3XXXXX

Option	SEG1		SEG2		SEG3	SEG4		SEG5		SEG6
Explanation	PAGE		MODE		RESERVED	Use of external temperature sensor		Use of central control		RESERVED
Indication and details	Indication	Details	Indication	Details		Indication	Details	Indication	Details	
	0		2			0	Disuse	0	Disuse	
						1	Use	1	Use	
Option	SEG7		SEG8		SEG9	SEG10		SEG11		SEG12
Explanation	PAGE		Use of drain pump		RESERVED	RESERVED	RESERVED	Group address		
Indication and details	Indication	Details	Indication	Details				Indication	Details	
	1		0	Disuse				0	slave	
			1	Use				1	master	
			2	Use + 3minute delay						

Option	SEG13		SEG14		SEG15		SEG16		SEG17		SEG18
Explanation	PAGE		Use of external control		Setting the output of external control		S-Plasma ion		Buzzer control		RESERVED
Indication and details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	
	2		0	Disuse	0	Thermo on	0	Disuse	0	Use	
			1	On/Off control							
			2	Off control	1	Operation on	1	Use	1	Disuse	
			3	Window on/off control							
Option	SEG19		SEG20		SEG21		SEG22		SEG23		SEG24
Explanation	PAGE		Individual control of a remote controller		Heating setting compensation		RESERVED		RESERVED		RESERVED
Indication and details	Indication	Details	Indication	Details	Indication	Details					
	3		0 or 1	Indoor 1	0	Disuse					
			2	Indoor 2							
			3	Indoor 3	1	2°C					
			4	Indoor 4							

If you input a number other than 0~4 on the individual control of the indoor unit(SEG 20), the indoor is set as "Indoor 1".

Example) If you want to set as "Exterior temperature sensor : USE, External control : USE

SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
0	2	-	1	0	-
SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
1	0	-	-	-	0
SEG13	SEG14	SEG15	SEG16	SEG17	SEG18
2	1	0	-	0	0
SEG19	SEG20	SEG21	SEG22	SEG23	SEG24
3	0	-	-	-	-

assign option codes except SEG 1, 7, 13, 19 which are page options.

- * Level control : The centralized controller can limit the functions and inputs of connected products with this function enabled.
 [Example: Operation mode limit (Cooling only/Heating only/No limitation), Heating temperature upper limit, Cooling temperature lower limit]
 To enable 'Level control' when applying the DPM with the centralized controller, appoint the master (Set 'Use of external control [SEG14] option to 4 or higher).

Setting an indoor unit address and installation option

Example : When installing DPM (1 Outdoor unit with 4 indoor units)

Condition		SEG 14 Setting				Result
External control	Level control	Indoor 1	Indoor 2	Indoor 3	Indoor 4	
Default		Not set (0)				Slave (All)
Disuse	Use	4	Not set (0)	Not set (0)	Not set (0)	Master (Indoor 1), Slave (Indoor 2,3,4)
Use (Indoor 3)	Disuse	Not set (0)	Not set (0)	1~3	Not set (0)	Slave (All)
Use (Indoor 4)	Use	Not set (0)	Not set (0)	Not set (0)	5~7	Master (Indoor 4), Slave (Indoor 1,2,3)

Changing the addresses and options individually

You can change each digit of set option.

Option	SEG1		SEG2		SEG3		SEG4		SEG5		SEG6	
Explanation	PAGE		MODE		The option mode you want to change		The tens' digit of an option SEG you will change		The unit digit of an option SEG you will change		The changed value	
Indication and Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details
	0		D		Option mode	0~F	Tens' digit of SEG	0~9	Unit digit of SEG	0~9	The changed value	0~F

NOTE

- When changing a digit of an indoor unit address setting option, set the SEG3 as 'A'.
 - When changing a digit of indoor unit installation option, set the SEG3 as '2'.
- Example) When setting the 'buzzer control' into disuse status.

Option	SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
Explanation	PAGE	MODE	The option mode you want to change	The tens' digit of an option SEG you will change	The unit digit of an option SEG you will change	The changed value
Indication	0	D	2	1	7	1

Troubleshooting

Detection of errors




- ◆ If an error occurs during the operation, an LED flickers and the operation is stopped except the LED.
- ◆ If you re-operate the air conditioner, it operates normally at first, then detect an error again.

LED Display on the receiver & display unit

LED Display

- ◆ If you turn off the air conditioner when the LED is flickering, the LED is also turned off.
- ◆ If you re-operate the air conditioner, it operates normally at first, then detect an error again.
- ◆ When E108 error occurs, change the address and reset the system.Ex.) When address of the indoor unit #1 and #2 are set as 5, address of the indoor unit #1 will become 5 and indoor unit #2 will display E108, A002.

● On ○ Flickering ✕ Off

<u>Abnormal condition</u>	<u>Error code</u>	<u>LED Display</u>		
				
Error on indoor temperature sensor (Short or Open)	E121	✕	○	✕
1. Error on Eva-in sensor (Short or Open) 2. Error on Eva-out sensor (Short or Open) 3. Discharge sensor error (Short or Open)	E122 E123 E126	○	○	✕
Indoor fan error	E154	✕	✕	○
1. Error on outdoor temperature sensor (Short or Open) 2. Error on cond sensor 3. Error on discharge sensor Other outdoor unit sensor error that is not on the above list	E221 E237 E251	○	✕	○
1. When there is no communication between the indoor•outdoor units for 2 minutes 2. Communication error received from the outdoor unit 3. 3 minute tracking error on outdoor unit 4. Communication error after tracking due to unmatching number of installed units 5. Error due to repeated communication address 6. Communication address not confirmed Other outdoor unit communication error that is not on the above list	E101 E102 E202 E201 E108 E109	✕	○	○
Self diagnosis error display 1. Error due to opened EEV (2nd detection) 2. Error due to closed EEV (2nd detection) 3. Eva in sensor is detached 4. Eva out sensor is detached 5. Thermal fuse error (Open)	E151 E152 E128 E129 E198	●	○	○

SAMSUNG

