# Contents

| Safety precautions3  |
|--|
| Preparations for Installation         6           • Outdoor unit classification         6           • Accessories         6           • Optional accessories         7 |
| Selecting installation location7   |
| · Space requirements 10  |
| · Moving the outdoor unit14  |
| Basic construction and installation of the outdoor unit  |
| · Installation of outdoor unit   |
| Installation of Air-conditioner 18   |
| · Refrigerant pipe work 18   |
| · Selecting refrigerant pipe 19  |
| · Keeping refrigerant pipe24   |
| $\cdot$ Temper grade and minimum thickness of the  |
| refrigerant pipe25   |
| · Refrigerant pipe brazing and safety  |
| information25  |
| · Cutting or flaring the pipes 26  |
| · Connecting the flared pipes 27   |
| · Pipe installation for an outdoor unit 28   |
| · Connecting the drain hose to the outdoor unit  |
| 29   |
| Examples of refrigerant pipe installation 30   |
| · Allowable length of the refrigerant pipe and   |
| the installation examples31  |
| Installation of refrigerant Y-joint  |
| · Installation of the distribution header 37   |
| Wiring work  |
| · Specification of the circuit breaker and power   |
| cable38  |
| Power wiring Diagram40   |

| Selecting solderless ring terminal  |
|---|
| Air tightness test and vacuum drying  |
| Charging refrigerant  |
| Pipe insulation   |
| Basic segment display54   |
| Setting outdoor unit option switch and key function   |
| Things to check after completing the installation 79 $$   |
| Inspection & trial operation81 • Checklist before auto trial operation81 • Auto trial operation82 |
| Automatic refrigerant amount detection function   |
| 84  |

For information on Samsung's environmental commitments and product regulatory obligations, e.g. REACH, visit our sustainability page available via www.samsung.com

# Safety precautions

Please follow the following safety information for safety of the installer and the user.

- ★ DVM S ECO air conditioner uses R-410A refrigerant.
  - When using R-410A, moisture or foreign substances may affect the performance and reliability of the product.
     Safety precautions must be obeyed when installing the refrigerant pipe.
  - The designed maximum pressure of the system is 4.1MPa and therefore select appropriate material and thickness according to the regulations.
  - R-410A is a quasi-azeotrope of two refrigerants and it has to be charged in liquid phase when filling the refrigerant. (If you charge vapor refrigerant, it may change the blend of the refrigerant and cause product malfunction.)
- \* You must connect the indoor units for R-410A refrigerant. Refer to product catalog to find out the models names for connectable indoor units. (If you connect the indoor units that are not designed for R-410A, it cannot operated normally.)
- \* After completing the installation and trial operation, explain to the user how to use and maintain the product. Also, hand over this installation manual so that it can be stored by the user.
- \* Manufacturer is not responsible for the incidents occurred by improper installation. Installer is responsible for any installation related claims from the user occurred by neglecting warnings and cautions stated in this manual. (Installer will be responsible for any service charges that may occur)
- \* Generally, system air conditioners should not be relocated after installation. But when it has to be relocated for inevitable reasons, please contact Samsung's qualified dealers for system air conditioners.

| <b>WARNING</b>  | Hazards or unsafe practices that may result in severe personal injury or death.                              |
|-----------------|--|
| <u></u> CAUTION | Hazards or unsafe practices that may result in minor personal injury (to installer/user) or property damage. |

#### SEVERE WARNING SIGNS

Consult qualified installer or dealer for installation.

- When installation is done by unqualified person, problems such as water leakage, electric shock or fire may occur. Installation work must be done properly according to this installation manual.
- ▶ When installation is not done properly, it may cause water leakage, electric shock or fire.

When installing the unit in a small room, take measure to keep the refrigerant concentration from exceeding allowable safety limits in case of refrigerant leakage. Consult the dealer for precautionary measure before the installation.

When refrigerant leaks and exceed dangerous concentration level, it may cause suffocation accidents.

If any gas or impurities, except R-410A refrigerant, come into the refrigerant pipe, serious problem may occur and it may cause injury.

Use the supplied accessories, specified components and tools for the installation.

- ▶ Do not use the pipe and the installation product used for the R-22 refrigerant.
- Failure to use the specified components can cause product fall down, water leakage, electrical shock, and fire. (The pipe and flare components used for R-22 refrigerant must not be used)

Install the outdoor unit on a hard and even place that can support its weight.

▶ If the place cannot support its weight, the outdoor unit may fall down and it may cause injury.

# Safety precautions

Check the following before installation and service work.

- ▶ Before welding, remove dangerous and inflammable things that may cause an explosion and fire around the work.
- ▶ Before welding, remove the refrigerant from inside the pipe or the product.
  - If you perform welding while refrigerant is in the pipe, it may increase the pressure of the refrigerant and cause the pipe to burst. If the pipe bursts or explodes, it may cause severe injury to the installer.
- ▶ When welding, use the nitrogen gas to eliminate oxidation inside the pipe.

Do not modify the product on your own.

Potential risk of electric shock, fire, product failure or injury.

Fix the outdoor unit securely on foundation to resist strong wind or earthquake.

If the outdoor unit is not properly fixed, it turns over and accidents may occur.

Electric work must be done by qualified persons, complying the national wiring regulations and installed according to the instruction stated in the installation manual with leased circuit.

► Capacity shortage on the leased circuit and improper installation may cause electric shock or fire.

Make sure to perform grounding work.

Do not connect the ground wire to a gas pipe, water pipe, lightning rod or telephone grounding. Improper grounding could cause electric shock.

Wiring must be connected with the designated wires and it must be fixed securely so that it does not apply any external force to the connection part of the terminals.

If connection for fixation is not properly done, it may cause heat generation or fire.

Neatly arrange the wires in the electrical parts to make sure that electrical cover is closed securely without any gaps.

If the cover is not properly closed, heat may generate on the electrical terminal and cause electric shock or fire.

Exclusive circuit breaker (MCCB, ELB) must be installed to the power supply.

- When overcurrent or current leakage occurs with no circuit breaker installed, power will not be cut-off and it may cause electric shock or fire.
- Do not use damaged parts. It may cause fire or electric shock.

You must cut-off the power before you work on, or adjust any power supply part for product installation, maintenance, repair or any other services.

- ► There is risk of electric shock.
- ► Even when the power is off, it is dangerous when you come in contact with inverter PCB, fan PCB since high pressure DC voltage is charged to those parts.
- ▶ When replacing/repairing the PCB, cut-off the power and wait until the DC voltage is discharged before replacing/repairing them. (Wait for more than 15 minutes to allow it to discharge naturally.)

If the refrigerant gas leaks during the installation, you should ventilate the room.

▶ When the refrigerant gas gets in contact with flammable substance, it may generate toxic gas.

Gas leakage must be checked after installation is completed.

When the refrigerant gas gets in contact with flammable substance, it may generate toxic gas.

You can get a frostbite if you get in contact with the leaked refrigerant gas.

Supply power to the product during winter time since the product will operate in protection mode itself when the temperature decrease below  $0^{\circ}$ C.

- ▶ If you cut-off the power, compressor protection mode cannot be operated and may cause damage to the product.
- ▶ The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety: Young children should be supervised to ensure that they do not play with the appliance.
- ▶ For use in Europe: This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

## **CAUTION SIGNS**

Do not install the drain pipe directly to the bottom part of the outdoor unit and built a proper drainage so that water drains out smoothly. If not, pipe may freeze or bursts during winter time and cause damage to the product or water leakage.


▶ When the draining work is not done properly, water leak may occur and cause property damage.

Install the power cable and communication cable of the indoor and outdoor unit at least 1.5m away from the electric appliances and install it at least 2m away from the lightning conductor.

Noise may be generated from the electronic devices, depending on the status of the electric wave.

Install the outdoor unit within the angle stated in the table, according to the height of the building.

- Do not leave the refrigerant container under the hot sunlight. (There is risk of explosion.)
- ▶ You must use the appropriate pipes according to the standard since the pressure of the refrigerant is very high.
- Make sure that the pipes does not get any weaker by welding it too much.
- ► Make sure to install the product away from children's' reach. (Sharp parts of the heat exchanger is may cause personal injury and when parts of the product gets damage, it may decrease product's performance.)



| Height of the building | Protection control |
|------------------------|--------------------|
| 20m or less            | 55°                |
| 40m or less            | 35°                |
| 60m or less            | 25°                |

Install the indoor unit away from lighting apparatus that uses ballast stabilizer.

- If you use the wireless remote control, it may not operate normally due to ballast stabilizer.
- Do not install the product in following places.

Building

- Place where outdoor unit's noise and warm air may disturb neighbors. (It may cause property loss.)
- Do not leave any obstacles around the inlet and outlet of the product. (It may cause damage or accidents.)
- ► The place where there is mineral oil or arsenic acid.
  - Those parts may get damaged due to burned resin and cause water leakage or product may fall.
  - The efficiency of the heat exchanger may reduce or product may break.
- The place where corrosive gas such as sulfurous acid gas generates from the vent pipe or air outlet.
  - The copper pipe or connection pipe may corrode and refrigerant may leak.
- The place where there is a machine that generates electromagnetic waves.
  - The air conditioner may not operate normally due to problems in control system.
- ▶ The place where there is a danger of combustible gas leakage or place where thinner or gasoline is handled.
  - (There is risk of fire or explosion.)
- ▶ The place with carbon fiber or flammable dust.
- ▶ The place near seashore or hot spring where there is risk of outdoor unit corrosion.

Wear protective equipment (such as safety gloves, goggles, and headgear) during installation and maintenance works. Installation/repair technicians may be injured if protective equipment is not properly equipped.


# Safety precautions

Changes in DVM S ECO (inverter) compare to conventional models that has to noted when installing

- For optimal distribution of the refrigerant, you must use Y-joint as branch joint for connecting outdoor units. (Not to use T-joint)
- ▶ You cannot operate normally if you do not complete the trial operation through outdoor unit key mode. You must use KEY MODE to run trial operation.
- ▶ DVM S ECO air conditioner uses R-410A refrigerant.
- ▶ Check the compatibility of other products such as indoor unit, EEV kits etc. which will be connected to DVM S ECO.

# Preparations for Installation

# Outdoor unit classification





## Packaging material disposition

- Safely store or dispose the packaging materials.
  - Sharp metals such as nails or wooden material packaging that may break into pieces become a cause for personal injury.
  - Make sure to store or dispose the vinyl type packaging material to keep it out of reach of children. Children may put them over their face, which is very dangerous since it may lead them to suffocation.

## Accessories

- \* You must keep following accessories until the installation is finished.
- \* Hand over the installation manual to the customer after finishing the installation.

|  | Installation Manual | Cap Drain | Drain Plug | Rubber Leg | Tube Joint |
|--|---------------------|-----------|------------|------------|------------|
|  |                     |           |            |            | 0          |
| AM100KXMDG*<br>AM100BXMWGH*                          | 1                   | 5         | 1          | 4          | -          |
| AM120/140KXMDG*<br>AM120BXMWGH*                      | 1                   | 5         | 1          | 4          | 1          |
| AM030RXMDEH*<br>AM040/050KXMDEH*<br>AM040/050BXMDEH* |                     | 5         | 2          | 4          | -          |

# **Preparations for Installation**

## Optional accessories

\* The following accessories are needed when connecting the outdoor and indoor unit.


| Model               | Model       | Total capacity                   |
|---------------------|-------------|----------------------------------|
| Y-joint             | MXJ-YA1509M | 15.0 kW and below                |
|                     | MXJ-YA2512M | Over 15.0 kW ~ 40.0 kW and below |
| Distribution header | MXJ-HA2512M | 45.0 kW and Below (for 4 rooms)  |
|                     | MXJ-HA3115M | 70.3 kW and below (for 8 rooms)  |

<sup>\*</sup> Refrigerant distributor component has to be installed when connecting indoor unit with no built-in EEV (electronic expansion valve)

# Selecting installation location

Decide the installation location, with the consideration of the following conditions, under user's approval.

- Place where hot discharge air or noise from the outdoor unit may not disturb the neighbor (Especially in residential areas, keep the operation hours in mind.)
- ▶ Place where structure can bear the weight and vibration of the outdoor unit.
- ▶ Place with flat surface where rainwater does not settle or leak.
- Place where it is not exposed to strong wind.
- Well ventilated place with sufficient service place for repairs and maintenance. (Discharge duct can be purchased separately)
- ▶ Place where you can connect the refrigerant pipes between indoor and outdoor units within allowable distance.
- Place where it allows easy waterproofing and draining work for the condensation water generated from the outdoor unit during heating operation.
- ▶ Place where there is no risk of inflammable gas leakage.
- ▶ Place where there is no direct influence of snow or rain.
- ▶ Do not install the product in a place where it will be directly exposed to sea breeze.
  - Consult an installation expert (or company) since you will need to take extra anti-corrosion measures if you need to
    install the product in a place where it can be exposed to direct sea breeze. (You have to remove dusts and salinity on
    the heat exchanger and apply designated rust inhibitor more than once a year.)
- ▶ If the outdoor unit is installed in the location where it can be attacked by high wind, please pay attention to these issues:
  - Caution when outdoor unit air outlet side was blow by high wind that speed over 5m/s, Because the outlet air was suctioned in once again, reduce the airflow of machine, and may cause these appearance:
  - Lower capacity; -severe frost in heating mode; machine break down for high pressure .
- If the air outlet side of the outdoor unit encountered a large continuous strong wind blowing, the fan will run reversely with high speed, and may be damaged by it. so please refer to the installation instruction.




## Selecting installation location

## Installation Guide at the seashore

Make sure to follow below guides when installing at the seashore.

- ▶ Do not install the product in a place where it is directly exposed to sea water and sea breeze.
  - Make sure to install the product behind a structure (such as building) that can block see breeze.
  - Even when it is inevitable to install the product in seashore, make sure that product is not directly exposed to sea breeze by installing a protection wall.
- ▶ Consider that the salinity particles clinging to the external panels should be sufficiently washed out.
- ▶ Because the residual water at the bottom of the outdoor unit significantly promotes corrosion, make sure that the slope does not disturb drainage.
  - Keep the floor level so that rain does not accumulate.
  - Be careful not to block the drain hole due to foreign substance.
- ▶ When product is installed in seashore, periodically clean it with water to remove attached salinity.
- Make sure to install the product in a place that provides smooth water drainage. Especially, ensure that the base part has good drainage.
- ▶ If the product is damaged during the installation or maintenance, make sure to repair it.
- ► Check the condition of the product periodically.
  - Check the installation site every 3 months and perform anti-corrosion treatment such as R-Pro supplied by SAMSUNG (Code: MOK-220SA) or commercial water repellent grease and wax, etc., based on the product condition.
  - When the product is to be shut down for a long period of time, such as off-peak hours, take appropriate measures like covering the product.
- ▶ If the product installed within 500m of seashore, special anti-corrosion treatment is required.
- \* Please contact your local SAMSUNG representative for further details.




Protection wall should be constructed with a solid material that can block the sea breeze and the height and width of the wall should be 1.5 times larger than the size of the outdoor unit. (You must secure more than 700 mm of space between the protection wall and the outdoor unit for air circulation.)

- \* Choose a place free of direct sunlight.
- \* Choose a place free of exposure to the rain and snow.
- \* Choose a place free of leakage of inflammable gases.
- \* Choose a place that the pipelines are accessible to the indoor and outdoor unit.



- System air conditioner may cause static noise when listening to AM stations. Therefore, select an installation location for indoor unit where electrical wiring can be done while keeping certain distance from a radio, computer and stereo equipment.
- ▶ Especially, keep the unit at least 3m away from the electrical equipment in an area with weak electromagnetic waves and put the main power cable and communication cables in a separately installed protection tube.
- Make sure that there is no equipment that generates electromagnetic waves. If not electromagnetic waves may cause problem to the control systems which may lead to air conditioner malfunction. (Example: Remote control sensor of the indoor unit may not receive the signal very well, due to ballast stabilizer of the lighting equipment.)
- ▶ In regions with heavy snowfall, make sure to install the outdoor unit where there is no concerns of direct snowfall on the outdoor unit. Also, build higher base support so that accumulated snow does not block the air inlet or the heat exchanger.
- R-410A refrigerant is a safe, nontoxic and nonflammable refrigerant. However, if the place holds any concerns for exceeding dangerous level of refrigerant concentration in case of refrigerant leakage, extra ventilation system is required.
- When you install the outdoor unit in a high places such as roof, install fence or guardrail around it. When there is no fence or guardrail, service person could fall.
- Do not install the product in places where corrosive gases such as sulfur oxides, ammonia, and sulfurous gas are produced. (e.g. Toilet outlet, ventilation opening, sewage works, dyeing complex, cattle shed, sulfuric hot spring, nuclear power plant, ship etc.) When installing the product in those places, contact an installation specialty store as the copper pipe and brazing part will need additional corrosion proof or anti-rust additive to prevent corrosion.
- Make sure to keep any inflammable materials (such as wooden materials, oil etc.) around the outdoor unit. When there's fire, those inflammable material will easily catch the fire and may pass it on to the product.
- ▶ Depending on the condition of power supply, unstable power or voltage any cause malfunction of the parts or control system. (At the ship or places using power supply from electric generator...etc)
- ▶ When the outdoor unit is installed near seashore or in a place where sulfuric acid gas may leak, corrosion may occur in outdoor unit and cause product malfunction.


# Selecting installation location



- ▶ Make sure that the water dripping from the drain hose runs away correctly and safety.
- ▶ You should repaint or protect the damaged part so that the paint of the cabinet does not peel off and become rusty during installation. When the cabinet becomes rusty, the life of an outdoor will be reduced.

# Space requirements

- ▶ Make a space for ventilation and service as seen in the picture.
- When multiple outdoor units are combined for installation, allow enough space for ventilation against a wall. If the ventilation space is not allowed, product malfunction may occur.
- ▶ The side with logo is the front side of the outdoor unit.
- \* Figure description



• Direction of airflow


## Installation location

<Instructions for parallel installation>


Unit: mm

## (A) When the air inlet is blocked


- \* The upper part of the outdoor unit is not blocked
- 1 When installing 1 outdoor unit
  - -. Only the air inlet is blocked




-. Air inlet and 2 sides of the outdoor unit are blocked




- 2) When parallel installing more than 2 outdoor units(\*1)
  - -. Air inlet and 2 sides of the outdoor unit are blocked




- 来 The upper part of the outdoor unit is blocked
- ①When installing 1 outdoor unit
  - -. When the air inlet is blocked




-. Air inlet and 2 sides of the outdoor unit are blocked



- ②When parallel installing more than 2 outdoor units(\*1)
  - -. Air inlet and 2 sides of the outdoor unit are blocked





# Selecting installation location


## (B) When the air outlet is blocked


米 The upper part of the outdoor unit is not blocked

Unit: mm


1 When installing 1 outdoor unit


②When parallel installing more than 2 outdoor units(\*1)







- 米 The upper part of the outdoor unit is blocked
- 1 When installing 1 outdoor unit





②When parallel installing more than 2 outdoor units(\*1)






## (C) When air inlet and air outlet of the outdoor unit are blocked


Unit: mm

Case 1: Obstacle on exhausting side is higher than the unit.(regardless of the height of obstacle on suction side)

- ※ The upper part of the outdoor unit is not blocked.
- 1) When installing 1 outdoor unit

②When parallel installing more than 2 outdoor units(\*1)






▲ The backside block can not be higher than the outdoor unit. If the backside block is higher than the outdoor unit, arrange the outdoor unit higher than the backside block.

Case 2: Obstacle on exhausting side is lower than the unit.(regardless of the height of obstacle on suction side)

- \* The upper part of the outdoor unit is not blocked
- ①When installing 1 outdoor unit


②When parallel installing more than 2 outdoor units(\*1)





- ▲ The frontside block can not be higher than the outdoor unit. If the frontside block is higher than the outdoor unit, arrange the outdoor unit higher than the frontside block.
- (\*1) When installing outdoor units paralleled, more than 600mm gap shall be left.

When front and rear side of the outdoor unit is toward the wall



## Selecting installation location

## Moving the outdoor unit


- Select the moving path in advance.
- ▶ Be sure that moving path can support weight of the outdoor unit.
- ▶ Do not slant the product more than 30° when carrying it. (Do not lay the product down in sideways.)
- ▶ Surface of the heat exchanger is sharp. Be careful not to get injured while moving the product.



· You must use certain part of the product when moving the product.

#### 1)When moving with a crane

- Fasten the wire rope as shown in the figure.
- To protect damage or scratches, insert a piece of cloth between the outdoor unit and the wire rope.
- 2) When moving with a forklift
- Carefully insert the forklift forks into the forklift holes at the bottom of the outdoor unit.
- ▶ Be careful with the forklift from damaging the product.
- When moving the product without wooden pallet and the crane is not available for use
- ► Connect a wire rope to the outdoor unit as you would move it with a
- ▶ Hang the wire rope to the forklift fork to move the outdoor unit.
- 4) When the equipment is moved by the installers
- \* When the equipment is moved to a location that is so near that can be handled by the installers.
- Two workers are required to move the product by the handles.
- ► Take care not to damage the heat exchanger.
- ▶ Take care not to be cut by the sharp edges of the heat exchanger.



## Basic construction and installation of the outdoor unit


## Installation of outdoor unit



Make sure to remove the wooden pallet before installing the outdoor unit. If you do not remove the wooden pallet, there is risk of fire during welding the pipes. If the outdoor unit is installed with wooden pallet on, and it was used for long period time, wooden palette may break and cause electrical hazard or high pressure may damage the pipes.


- Install the outdoor unit 150mm higher than the base ground and install the drain hole to connect the pipe to the drainage.
- 2. When the front fan of an outdoor unit is installed in a place where the average snowfall is more than 150mm, the discharge duct should be attached to the outdoor unit.
- 3. The concrete foundation should be 1.5 times larger than bottom of the outdoor unit.
- 4. It is necessary to install wire mesh or steel bar when outdoor units are installed on a soft foundation.
- 5. When installing multiple outdoor units at the same place, install the H beam on the base ground. (When installing a number of outdoor units, you can install it on the base ground.)
- 6. Install the H beam(150mm x 150mm x t10: basic specification) or vibration absorption frame to jut out from the base ground.
- 7. After installing the H beam, apply corrosion protection.
- 8. Install a square pad(t=20mm or more) to prevent vibration from the outdoor unit onto the base ground. Place the outdoor unit on the H beam and fix it with the bolt, nut and washer. (Fix with M10 basic anchor bolt, nut and washer.)


Unit: mm



## Basic construction and installation of the outdoor unit

## Base ground contruction







► The outdoor unit should be supported within the range of measurement below for base ground work.

Unit: mm


## **♦** AM100/120/140KXMDGH\*, AM100/120BXMWGH\*



## ♦ AM030RXMDEH\* AM040/050KXMDEH\*, AM040/050BXMDEH\*



- ▶ When the outdoor unit needs to be supported, fix it with wire as shown in the picture.
  - Slightly unwind the four screws on the cover top of the outdoor unit.
  - Wind wires round the four screws and fasten the screws again.
  - Fix the wires to the ground.





- If the outdoor unit is not fixed securely, product may fall and it might cause loss of life or property damage.
- · Do not install the outdoor unit on the wooden pallet.
- Fix the outdoor unit securely to the base ground with anchor bolts.
- The manufacturer is not responsible for the damage occurred by not adhering to the standard of the installation.
- To protect the outdoor unit from external condition such as rain, install it on the base ground and connect the drain pipe to the drainage.



- Please firstly ensure the strength and levelness of the platform, ground and the support so as to lower the noise and vibration for fear of human injuries.
- The hanging mount on the wall is prohibited due to the heavy machine. The improper installation shall lead to the fall of the machine as well as human injuries.



<The machine shall be installed on the ground or on the high platform>


- As shown in Figure 1, to ensure the shadow part is on the bearing surface without suspension.
- As shown in Figure 1, the four installation footings shall be firmly fastened on the base platform by the bolts (preparing four sets of M10 bolts with fitful nuts and washer which are used on site)
- ▶ In order to reduce the vibration of the noisemeter, the vibration absorber (offer on site) shall be used between the contact of machine and base platform.
- lt is optimal that anchor bolt is 20mm above the surface. (See Figure 2)

#### The base of the outdoor unit and the position of foundation bolts

Unit: mm

# Position of the foundation bolts (Ø12.0 Hole 4Points) Bearing surface Position of the foundation bolts (Ø12.0 Hole 4Points) Bearing surface (Ø12.0 Hole 4Points) Figure 1 Figure 2 Figure 2 Figure 2 Figure 2 Figure 3 Figure 4 Figure 4 Figure 5 Figure 5 Figure 6 Figure 6 Figure 7 Figure 9 Figure 9

- ▶ Please ensure the shadow part in Figure 1 is really installed on the bearing surface without any suspension.
- ▶ The ground base that is larger than the standing leg of the air-conditioner (90mm in width and 520mm in length) shall be used to support the air-conditioner (See Figure 1), and the rubber mat shall be fully placed on the whole bearing surface.
- ▶ The base platform shall be at least 150mm above the ground.





- When the grounding pipe comes out from the below, please reserve the place for the connection pipe.
- The installation mode mentioned above shall ensure that the shadow part in Figure 1 is really on the installation surface.



When installing, make sure there is no leakage. When collecting the refrigerant, stop the compressor first
before removing the connection pipe. If the refrigerant pipe is not properly connected and the compressor
works with the service valve open, the pipe inhales the air and it makes the pressure inside of the
refrigerant cycle abnormally high which may lead to explosion and injury.


## Refrigerant pipe work

- ► The length of refrigerant pipe should be as short as possible and the height difference between an indoor and outdoor unit should be minimized.
- ▶ Piping work must be done within allowable piping length, height difference, and the allowable length after branching.
- ▶ The pressure of the R-410A is high. Use only certified refrigerant pipe and follow the installation method.
- After installing the pipes, calculate the total length of the pipe to check if additional refrigerant is needed. When you need to charge the additional refrigerant, make sure to use R-410A refrigerant.
- ▶ Use clean refrigerant pipe and there shouldn't be any harmful ion, oxide, dust, iron content or moisture inside pipe.
- Use tools and accessories that fit on R-410A only.

| Tools                                    | Installation process/purpose    | Compatibility with conventional tool  |   |  |
|--|---------------------------------|---|---|--|
| Pipe cutter                              |                                 | Pipe cutting  | Compatible  |  |
| Flaring tool                             |                                 | Pipe flaring  | Compatible  |  |
| Refrigerant<br>machine oil               | Refrigerant pipe installation   | Apply refrigerant oil on flared part  | Exclusive ether oil, ester oil, alkali<br>benzene oil or synthetic oil  |  |
| Torque wrench                            |                                 | Connect flare nut with pipe   |   |  |
| Pipe bender                              |                                 | Pipe bending  | Compatible  |  |
| Nitrogen gas                             | Air tightness test              | Prevent oxidation within the pipe   |   |  |
| Welder                                   | 3                               | Pipe welding  |   |  |
| Manifold gage                            | Air tightness test ∼ additional | filling as well as inspecting operation   | Need exclusive one to prevent mixture<br>of R-22 refrigerant oil use and also the<br>measurement is not available due to<br>high pressure |  |
| Refrigerant charging hose                | refrigerant charging            |   | Need exclusive one since there is risk of refrigerant leakage or inflow of impurities   |  |
| Vacuum pump                              | Pipe drying                     | Compatible (Use products which contain the check valve to prever<br>the oil from flowing backward into the outdoor unit.) Use the one<br>that can be vacuumed up to -100.7kpa(5Torr). |   |  |
| Electronic scale for refrigerant filling |                                 |   | Compatible  |  |
| Air leak tester                          |                                 | Gas leak test   | Need exclusive one<br>(Ones used for R-134a is compatible)  |  |
| Pipeline joint                           |                                 | Must use the flare nut equipped with the product. Refrigerant leakage may occur when the conventional flare nut for R-22 is used.   |   |  |

# Selecting refrigerant pipe

- Install the refrigerant pipe according to main pipe size of each outdoor unit capacity.
- When the pipe length (including elbow) between an outdoor unit and the farthest indoor unit exceeds 90m, you must increase the size of the gas pipe (main pipe) by one grade which connects between the outdoor unit to the first branch joint. (The liquid pipe size will be maintained.)
- ▶ If the capacity of the outdoor unit can decline due to the pipe length, upgrade the pipe size one step (gas pipe).



## Size of the pipe between the outdoor unit and the first branch joint

| Outdoor unit capacity [HP] | Liquid pipe [mm] | Gas pipe [mm] | Increased gas pipe [mm] |
|----------------------------|------------------|---------------|-------------------------|
| 10                         | Ø9.52            | Ø22.22        | Ø25.40                  |
| 12                         | Ø12.70           | Ø28.58        | Ø28.58                  |
| 14                         | Ø12.70           | Ø28.58        | Ø28.58                  |
| 3/4/5                      | Ø9.52            | Ø15.88        | Ø19.05                  |

## Selection of branch joint

| Selection of the other branch joint according to the sum of indoor unit capacity which will be connected after the branch |                                  |             |
|---|----------------------------------|-------------|
| Classification  | Indoor unit capacity<br>[kW]     | Model name  |
| Visint  | 15.0 kW and below                | MXJ-YA1509M |
| Y-joint   | Over 15.0 kW ~ 40.0 kW and below | MXJ-YA2512M |
| Distribution  | 45.0 kW and Below (for 4 rooms)  | MXJ-HA2512M |
| Header  | 70.3 kW and below (for 8 rooms)  | MXJ-HA3115M |

## Size of the pipe between branch joints

Selecte the pipe size according to the sum of indoor unit capacity which will be connected after the branch.

| Inddor unit capacity             | Liquid pipe | Gas pipe |
|----------------------------------|-------------|----------|
| [kW]                             | [mm]        | [mm]     |
| 15.0 kW and below                |             | Ø15.88   |
| Over 15.0 kW ~ 22.4 kW and below | Ø9.52       | Ø19.05   |
| Over 22.4 kW                     |             | Ø22.22   |

## Selecting additional refrigerant charging

## ▶ Basic refrigerant

The basic amount of refrigerant charged at a factory

| Outdoor unit (Series) | Factory charge (kg) | Connect maximum number of indoor (unit) |
|-----------------------|---------------------|---|
| AM100KXMDGH∗          | 3.7                 | 18                                      |
| AM120KXMDGH∗          | 4.3                 | 21                                      |
| AM140KXMDGH∗          | 4.8                 | 26                                      |
| AM040KXMDEH∗          | 2.0                 | 7                                       |
| AM050KXMDEH∗          | 2.5                 | 9                                       |
| AM030RXMDEH∗          | 2.0                 | 5                                       |
| AM040BXMDEH∗          | 2.0                 | 7                                       |
| AM050BXMDEH∗          | 2.5                 | 9                                       |
| AM100BXMWGH∗          | 4.3                 | 18                                      |
| AM120BXMWGH∗          | 4.8                 | 21                                      |

## ► Charging additional refrigerant

The amount of additional refrigerant charging = The amount of refrigerant charging for pipe +
the amount of refrigerant correction charging for an indoor unit

-. Amount of additional refrigerant has to be calculated based on the sum of all liquid pipe length.

| Size of liquid pipe      | Ø6.35 | Ø9.52 | Ø12.70 | Ø15.88 | Ø19.05 | Ø22.22 | Ø25.40 | Ø28.58 |
|--------------------------|-------|-------|--------|--------|--------|--------|--------|--------|
| Additional amount (kg/m) | 0.02  | 0.06  | 0.125  | 0.18   | 0.27   | 0.35   | 0.53   | 0.65   |

Additional refrigerant charging calculation = The sum of total length of  $\emptyset$ 9.52 liquid pipe(m) x 60g + the sum of total length of  $\emptyset$ 6.35 liquid pipe(m) x 20g

Ex)  $a(\emptyset 9.52)=40m,b+c+d(\emptyset 9.52)=15m,e+f+q(\emptyset 6.35)=15m$ 

The amount of additional refrigerant =  $55m \times 60g + 15m \times 20g = 3600g$ 

2) In case of using EEV kit, amount of additional refrigerant of liquid pipe between EEV kit and indoor unts is 0.01kg per meter.

<sup>1)</sup> The amount of additional refrigerant depending on the pipe size.

# Amount of additional refrigerant for each indoor unit


Unit: kg

| 1000<br>CMH   |  |   |   |                                     |                                     |                                  |                              |                              |   |   |                              |                              |   |   |                              |  |
|---------------|--|---|---|-------------------------------------|-------------------------------------|----------------------------------|------------------------------|------------------------------|---|---|------------------------------|------------------------------|---|---|------------------------------|--|
| 500<br>CMH    |  |   |   |                                     |                                     |                                  |                              |                              |   |   |                              |                              |   |   |                              |  |
| 50.0          |  |   |   |                                     |                                     |                                  |                              |                              |   |   |                              |                              |   |   |                              |  |
| 32.0          |  |   |   |                                     |                                     |                                  |                              |                              |   |   |                              |                              |   |   |                              |  |
| 28.0          |  |   |   |                                     |                                     |                                  |                              |                              |   |   |                              |                              |   |   | 1.18                         |  |
| 22.4          |  |   |   |                                     |                                     |                                  |                              |                              |   |   |                              |                              |   |   |                              | 1.15   |
| 22.0          |  |   |   |                                     |                                     |                                  |                              |                              |   |   |                              |                              |   |   | 1.18                         |  |
| 18.0          |  |   |   |                                     |                                     |                                  |                              |                              |   |   |                              |                              |   |   |                              | 1.15   |
| 16.0          |  |   |   |                                     |                                     |                                  |                              |                              |   |   |                              |                              |   |   |                              |  |
| 14.0          |  |   |   | 0.69                                | 0.88                                | 69'0                             | 0.62                         | 0.62                         | 0.62  | 0.62  |                              | 0.38                         |   | 0.84  | 0.68                         | 0.38   |
| 12.8          |  |   |   | 69.0                                | 0.88                                | 69.0                             | 0.62                         | 0.62                         | 0.62  | 0.62  |                              | 0.38                         |   | 0.84  | 0.68                         | 0.38   |
| 11.2          |  |   |   | 0.57                                | 0.73                                | 0.69                             | 0.42                         | 0.42                         | 0.42  | 0.42  | 0.54                         | 0.38                         | 0.54  | 0.84  | 0.68                         | 0.38   |
| 9.3           |  |   |   |                                     |                                     |                                  |                              |                              |   |   |                              |                              |   |   |                              |  |
| 9.0           |  |   |   | 0.45                                | 0.73                                | 0.45                             | 0.42                         | 0.42                         | 0.42  | 0.42  | 0.32                         | 0.31                         | 0.32  | 0.80  |                              |  |
| 8.2           |  |   |   |                                     |                                     |                                  |                              |                              |   |   |                              |                              |   |   |                              |  |
| 7.1           |  | 0.32                                    |   | 0.45                                | 09:0                                | 0.45                             | 0.31                         | 0.45                         | 0.45  | 0.31  | 0.28                         | 0.22                         | 0.28  | 0.45  |                              |  |
| 0.9           |  |   | 0.37  |                                     |                                     |                                  |                              |                              |   |   |                              |                              |   |   |                              |  |
| 5.6           |  | 0.32                                    | 0.37  | 0.45                                | 09:0                                | 0.45                             | 0.24                         | 0.35                         | 0.35  | 0.24  | 0.28                         | 0.22                         | 0.28  | 0.45  |                              |  |
| 4.5           |  |   | 0.37  | 0.45                                | 0.45                                | 0.45                             | 0.24                         | 0.35                         | 0.35  | 0.24  | 0.28                         | 0.22                         | 0.28  | 0.45  |                              |  |
| 4.0           |  |   |   |                                     |                                     |                                  |                              |                              |   |   |                              |                              |   |   |                              |  |
| 3.6           |  | 0.25                                    | 0.29  |                                     | 0.45                                |                                  | 0.17                         | 0.26                         | 0.17  |   | 0.24                         | 0.22                         | 0.24  | 0.45  |                              |  |
| 2.8           |  | 0.25                                    | 0.29  |                                     | 0.45                                |                                  | 0.13                         | 0.17                         | 0.13  |   | 0.24                         |                              | 0.24  | 0.45  |                              |  |
| 2.2           | 0.15                                       | 0.25                                    | 0.29  |                                     |                                     |                                  | 0.13                         | 0.17                         | 0.13  |   | 0.24                         |                              | 0.24  | 0.45  |                              |  |
| 1.7           | 0.15                                       |   |   |                                     |                                     |                                  | 0.13                         | 0.17                         | 0.13  |   |                              |                              |   |   |                              |  |
| 1.5           |  |   | 0.29  |                                     |                                     |                                  |                              |                              |   |   |                              |                              |   |   |                              |  |
| Capacity (KW) | Interior 1way cassette<br>(AM***NN1PEH/**) | "Slim 1way cassette<br>(AM***NN1D*H/**) | 4way cassette S (600x600)<br>(AM***NNNDEH/**) | 4way cassette S<br>(AM***NN4DEH/**) | 4way cassette S<br>(AM***AN4PKH/**) | 360 cassette<br>(AM***KN4DEH/**) | LSP duct<br>(AM***ANLDKH/**) | LSP duct<br>(AM***FNLDEH/**) | LSP duct (with drain pump) (AM***KNLDEH/**) | LSP duct (with drain pump) (AM***MNLD*H/**) | MSP duct<br>(AM***FNMDEH/**) | MSP duct<br>(AM***HNMPKH/**) | MSP duct (with drain pump) (AM***KNMDEH/**) | MSP duct (with drain pump) (AM***ANMPKH/**) | HSP duct<br>(AM***FNHDEH/**) | HSP duct<br>(AM***HNHPKH/**)<br>(AM***JNHFKH/**) |

| 1000<br>CMH   |   |                             |  |                             |                             |                               |                                  |  |   | 0.36                                    |                                   |                                  |                                 |
|---------------|---|-----------------------------|--|-----------------------------|-----------------------------|-------------------------------|----------------------------------|--|---|---|-----------------------------------|----------------------------------|---------------------------------|
| 500<br>CMH    |   |                             |  |                             |                             |                               |                                  |  |   | 0.11                                    |                                   |                                  |                                 |
| 50.0          |   |                             |  |                             |                             |                               |                                  |  |   |   | 1.20                              |                                  |                                 |
| 32.0          |   |                             |  |                             |                             |                               |                                  |  |   |   | 0.70                              |                                  |                                 |
| 28.0          |   | 1.18                        | 1.85   |                             |                             |                               |                                  |  |   |   |                                   |                                  |                                 |
| 22.4          |   |                             |  |                             |                             |                               |                                  |  |   |   |                                   |                                  |                                 |
| 22.0          |   | 1.18                        |  |                             |                             |                               |                                  |  |   |   |                                   |                                  |                                 |
| 18.0          |   |                             |  |                             |                             |                               |                                  |  |   |   |                                   |                                  |                                 |
| 16.0          |   |                             |  |                             |                             |                               |                                  |  |   |   | 09:0                              |                                  |                                 |
| 14.0          | 0.84  | 0.68                        | 69:0   |                             | 0.95                        |                               |                                  |  |   |   |                                   |                                  |                                 |
| 12.8          | 0.84  |                             |  |                             |                             |                               |                                  |  |   |   |                                   |                                  |                                 |
| 11.2          | 0.84  |                             |  |                             | 0.56                        |                               |                                  |  |   |   |                                   | ote1)                            | .0                              |
| 9.3           |   |                             |  |                             |                             |                               |                                  |  | 89'0  |   |                                   | 0.60 Note1)                      | 0.50                            |
| 9.0           | 0.80  |                             |  |                             |                             |                               |                                  |  |   |   |                                   |                                  |                                 |
| 8.2           |   |                             |  |                             |                             | 0.64                          |                                  | 0.64                                     |   |   |                                   |                                  |                                 |
| 7.1           | 0.80  |                             | 0.32   |                             | 0.39                        | 0.48                          | 0.49                             | 0.48                                     | 0.49  |   |                                   |                                  |                                 |
| 0:9           |   |                             |  |                             |                             |                               |                                  |  |   |   |                                   |                                  |                                 |
| 5.6           | 0.80  |                             | 0.32   | 0.27                        | 0.39                        | 0.48                          | 0.49                             | 0.48                                     | 0.49  |   |                                   |                                  |                                 |
| 4.5           |   |                             |  | 0.27                        |                             | 0.48                          | 0.49                             | 0.48                                     | 0.49  |   |                                   |                                  |                                 |
| 4.0           |   |                             |  |                             |                             |                               |                                  |  |   |   |                                   |                                  |                                 |
| 3.6           |   |                             | 0.22   | 7 0.27                      |                             | 2 0.32                        | 2 0.32                           | 2 0.32                                   | 2 0.32  |   |                                   |                                  |                                 |
| 2.8           |   |                             |  | 0.16 0.27                   |                             | 0.23 0.32                     | 0.24 0.32                        | 0.23 0.32                                | 0.24 0.32   |   |                                   |                                  |                                 |
| 22            |   |                             |  | 0.16                        |                             | 0.23                          | 0.2                              | 0.23                                     | 0.2   |   |                                   |                                  |                                 |
| 1.7           |   |                             |  |                             |                             |                               |                                  |  |   |   |                                   |                                  |                                 |
| 15            |   |                             |  |                             |                             | 0.23                          | 0.24                             | 0.23                                     | 0.24  |   |                                   |                                  |                                 |
| Capacity (KW) | HSP duct (with drain pump) (AM***ANHPKH/**) | OAP duct<br>(AM***NEPEH/**) | Floor Standing<br>(AM****NFDEH/**)<br>(AM****NPDKH/**) | Console<br>(AM****NJDEH/**) | Ceiling<br>(AM****NCD*H/**) | Wall mounted (AM***TNADKH/**) | Wall mounted<br>(AM***KNTDEH/**) | Wall mounted (with EEV) (AM***TNVDKH/**) | Wall mounted (with EEV) (AM***KNQDEH/**) (AM***MNQDEH/**) | Ventilation (ERV plus) (AM****NKDEH/**) | Hydro Unit HE<br>(AM****NBDEH/**) | Hydro Unit HT<br>(AM***NBF*B/**) | MCU/HR Changer<br>(MCU-**NE**N) |

Note1) In case the capacity conjunction of the Hydro Unit HT exceeds 50% among the total indoor unit, please don't put the additional refrigerant.

# Method to calculate total amount of additional refrigerant



► Total amount of additional refrigerant

Total amount of additional refrigerant = Amount of additional refrigerant depending on the pipe length + Amount of additional refrigerant for each indoor unit

\* Amout of additional refrigerant depending on the pipe length

| Size of Liquid pipe<br>(mm) | Length(m) | Unit amount of refrigerant (kg/m) | Amount of additional refrigerant (kg) | Total amount<br>of additional<br>refrigerant (kg) |
|-----------------------------|-----------|-----------------------------------|---------------------------------------|---|
| Ø6.35                       | 20        | 0.02                              | 0.4                                   |   |
| Ø9.52                       | 20        | 0.06                              | 1.2                                   | 1.75  |
| EEV kit ~ indoor unit       | 15        | 0.01                              | 0.15                                  |   |

\* Amount of additional refrigerant charging for each indoor unit

| Model name of Indoor unit | Number of units (EA) | Unit amount of refrigerant<br>(kg/m) | Amount of additional refrigerant (kg) | Total amount<br>of additional<br>refrigerant (kg) |
|---------------------------|----------------------|--------------------------------------|---------------------------------------|---|
| AM045NN4DEH*              | 1                    | 0.45                                 | 0.45                                  |   |
| AM071NN4DEH*              | 1                    | 0.45                                 | 0.45                                  | 1.86  |
| AM036KNTDEH*              | 3                    | 0.32                                 | 0.96                                  |   |

Total amount of additional refrigerant = 1.75 + 1.86 = 3.61 (kg)



When charging additional refrigerant while outdoor unit operating, you should follow below guides:

#### Caution

- Cooling mode: charge on the low pressure service valve.
- Heating mode: charge on the charging port. (Refer to the picture on the right.)
- Do not use the high pressure service valve as a refrigerant charge while outdoor unit operating except on vacuumizing. (High pressure refrigerant can lead to human injuries.)



# Keeping refrigerant pipe

To prevent foreign materials or water from entering the pipe, storing method and sealing method (especially during installation) is very important. Apply correct sealing method depending on the environment.

| Exposure place | Exposure time          | Sealing type |
|----------------|------------------------|--------------|
|                | Longer than one month  |              |
| Outdoor        | Shorter than one month | Taping       |
| Indoor         | -                      | Taping       |

# Temper grade and minimum thickness of the refrigerant pipe

| Outer diameter (mm) | Minimum thickness (mm) | Material |
|---------------------|------------------------|----------|
| Ø6.35               | 0.7                    |          |
| Ø9.52               | 0.7                    | Annealed |
| Ø12.70              | 0.8                    | Annealed |
| Ø15.88              | 1.0                    |          |
| Ø19.05              | 0.9                    | Drawn    |
| Ø22.22              | 0.9                    | Diawii   |

Caution

 For pipes larger than Ø 19.05, drawn type (C1220T-1/2H or C1220T-H) copper pipe must be used. If a annealed type (C1220T-O) copper pipe is used, pipe may break due to its low pressure resistance and cause personal injury.

## Refrigerant pipe brazing and safety information




Important information for refrigerant pipe work

- Make sure there is no moisture inside the pipe.
- Make sure there are no foreign substances and impurities in the pipe.
- · Make sure there is no leakage.
- Make sure to follow the instruction when welding or storing the pipe.

## Nitrogen flushing brazing

- ▶ Use Nitrogen gas when brazing the pipes as shown in the picture.
- ▶ If you do not perform nitrogen flushing when brazing the pipes, oxide may form inside the pipe. It can cause the damage of the important parts such as compressor and valves etc.
- ▶ Adjust the flow rate of the Nitrogen flushing with a pressure regulator to maintain 0.05m³/h or less.



## Direction of the pipe when brazing

- ▶ Brazing the pipe shold be done with the pipe headed downward or horizontally.
- Avoid brazing with the pipe headed upward.

Caution

• The test liquid used to detect leakage after pipe brazing should be the designated one. The use of the test liquid containing sulfur element may cause pipe corrosion.

# Cutting or flaring the pipes

- 1. Make sure that you prepared the required tools.
- Pipe cutter, Deburring tool, flaring tool and pipe holder, etc.
- 2. If you want to shorten the pipe, cut it with a pipe cutter ensuring that the cut edge remains at 90° with the side of the pipe.
- Refer to below illustrations for correct and incorrect examples of cut edges.











- 3. To prevent a gas leak, remove all burrs at the cut edge of the pipe using a Deburring tool.
- Carry out flaring work using flaring tool as shown below.

## [Flaring tools]











Yoke Flaring bar Pipe

| A        |
|----------|
| <b> </b> |
|          |
| l        |

| D: I:                     | Depth of flaring part [A (mm)] |                                 |               |  |  |
|---------------------------|--------------------------------|---------------------------------|---------------|--|--|
| Pipe diameter<br>[D (mm)] | Using flaring tool for         | Using conventional flaring tool |               |  |  |
| [[] ([[]])]               | R-410A                         | Clutch type                     | Wing nut type |  |  |
| Ø 6.35                    | 0~0.5                          | 1.0~1.5                         | 1.5~2.0       |  |  |
| Ø 9.52                    | 0~0.5                          | 1.0~1.5                         | 1.5~2.0       |  |  |
| Ø 12.70                   | 0~0.5                          | 1.0~1.5                         | 1.5~2.0       |  |  |
| Ø 15.88                   | 0~0.5                          | 1.0~1.5                         | 1.5~2.0       |  |  |

- 5. Check that you flared the pipe correctly.
- Refer to below illustrations for correct and incorrect examples of flared pipe.












Uneven Thickness


- Caution
- · If foreign matters or burrs are not removed after cutting pipe, refrigerant gas may leak.
- If foreign matters enter inside the pipe, important interior parts of the unit may get damaged or product efficiency will be reduced. So, the direction of pipe should be downward during pipe cutting or flaring.

# Connecting the flared pipes

- ▶ Check if the flaring is properly done according to the standard size.
- Align the center of the piping and tighten the flare nut with your hands. Then, tighten the flare nut with torque wrench in a direction of the arrow indicated in below illustration.
- Make sure to use ester oil to coat the flare connection section.



| Outer<br>diameter<br>(D,mm) | Connection<br>torque<br>(N·m) | Flare dimension<br>(L,mm) | Flare shape (mm)                       |
|-----------------------------|-------------------------------|---------------------------|--|
| Ø6.35                       | 14~18                         | 8.7~9.1                   |  |
| Ø9.52                       | 34~42                         | 12.8~13.2                 | R 0.4~0.8                              |
| Ø12.70                      | 49~61                         | 16.2~16.6                 | 00 00 00 00 00 00 00 00 00 00 00 00 00 |
| Ø15.88                      | 68~82                         | 19.3~19.7                 | 9 1 2 1                                |
| Ø19.05                      | 100~120                       | 23.6~24.0                 | ,                                      |



| Outer            | Tightening torque |                            |  |  |  |
|------------------|-------------------|----------------------------|--|--|--|
| Diameter<br>(mm) | Body cap<br>(N·m) | Charging port cap<br>(N·m) |  |  |  |
| Ø6.35            | 20~25             |                            |  |  |  |
| Ø9.52            | 20~25             |                            |  |  |  |
| Ø12.70           | 25~30             | 10~12                      |  |  |  |
| Ø15.88           | 30~35             |                            |  |  |  |
| Ø19.05           | 35~40             |                            |  |  |  |

 $(1 \text{ N} \cdot \text{m} = 10 \text{ kgf} \cdot \text{cm})$ 



- Blowing Nitrogen gas should be done when welding the pipe.
- Make sure to use the provided flare nut.
- Make sure that there are no cracks or twisted part when you need to bend the pipe.
- Do not fasten the flare nut with excessive strength.
- R-410A is a high pressure refrigerant and there is a risk of refrigerant leakage if the flare connection is not coated with ester oil. Therefore, apply ester oil to coat the flare connection area.

## Pipe installation for an outdoor unit


### 1. Pipe direction

The refrigerant pipe can be pulled out from front, flank, rear, and bottom side, so install it depending on the installation site condition.

# Caution

#### Caution for using knock-out hole

- Cut the pipe outlet to the exact pipe size. In addition, remove foreign substances and burrs around the outlet.
- Perform cutting with only a cutter (ex. nipper) and never tap with a hammer near the pipe outlet. Otherwise, it may cause product damage such as warping of the cabinet.
- · Make sure not to damage the exterior of the outdoor unit.
- · Remove all burrs at the edge of the knock-out hole and apply the paints it to prevent rust.
- Use a cable tube and bushing to prevent a cable from being damaged when passing through a knock-out hole.
- After installing pipes, block the unused knock hole to prevent small animal from entering.
   However, the radiant heat hole (A) should be able to intake air.




Pipe outlet



## Caution for welding the pipe to an outdoor unit:

- When welding the pipe, the unit may get damaged by the heat and flame from welding. Specifically outdoor's pipe near by EEV,the fire would damage the EEV.Use a flame proofing cloth to protect the unit from a welding fire or flame.
- The O-ring and Teflon packing inside service valve may get damaged by the heat from welding. Wrap the bottom side of the service valve with a wet cloth and weld it as shown in the illustration. Also, water dripping from the wet cloth may interrupt the welding. Make sure the water does not drip from the wet cloth.
- Make sure that connected pipes does not interrupt each other or make contact with the product. (Vibration may cause damage to the pipes.)
- To prevent welding flame from burning the felt during welding, it is necessary to place a baffle before the felt.



High pressure Low pressure (Liquid side) (Gas side)


## 2. Outdoor unit refrigerant pipe connection


| Classification     | Front, flank, rear side of pipe connection   | Bottom side of pipe connection   |
|--------------------|--|--|
| Working<br>process | <ul> <li>First, remove the pipe cover from the unit.</li> <li>Separate the knock-out hole to use. If the hole is open, small animals such as squirrels and rats may get into the unit through the hole and the unit may be damaged.</li> </ul> | Separate the knock-out hole at the bottom side of the unit and install the pipe. After installing and insulating the pipe, close up the remaining gap. If the gap remains open, small animals such as rats and squirrels may get inside the unit and cause damage to the unit. |

# Connecting the drain hose to the outdoor unit


When using the air conditioner in the heating mode, ice may accumulate. During de-icing (defrost operation), the condensed water must be drained off safely. Consequently, you must install a drain hose on the outdoor unit, following the instructions below.

- ► Leave space of more than 50mm between the bottom of the outdoor unit and the ground for installation of the drain hose, as shown in figure.
- ▶ Insert the drain plug into the hole on the underside of the outdoor unit.
- ► Connect the drain hose to the drain plug.
- ▶ Ensure that the drained water runs off safely and correctly.






▶ Be sure to plug the rest of drain holes not connected with drain plugs using drain caps.



AM100/120/140KXMDGH\* AM100/120BXMWGH\*




AM030RXMDEH\* AM040/050KXMDEH\* AM040/050BXMDEH\*


# Examples of refrigerant pipe installation

## ₩ Using Y-joint







※ Using Y-joint / EEV kit



\* Using distribution header



★ Using distribution header / Y-joint




# Allowable length of the refrigerant pipe and the installation examples

## AM100/120/140KXMDGH\*, AM100/120BXMWGH\*


## ★ Connection by Y-joint

## Outdoor unit



\* Connection by Y-joint / EEV kit

## Outdoor unit



| Classification                         |                          |                   | Y joint connection   | Y-joint / EEV kit connection   |  |
|--|--------------------------|-------------------|--|--|--|
|  |                          |                   | The distance between the outdoor unit and the farthest indoor unit ≤ 160m  |  |  |
| Maximum                                |                          | Actual length     | Ex) 8 indoor units   | Ex) 6 indoor units   |  |
| allowable                              | Outdoor unit             |                   | a+b+c+d+e+f+g+p ≤ 160m   | a+b+c+d+j ≤ 160m   |  |
| length of                              | ~ Indoor unit            | Equivalent length | The distance between an outdoor unit and the farthest indoor unit $\leq$ 185m  |  |  |
| pipe                                   |                          | Main pipe length  | The main pipe(a) from the the outdoor unit to the first Y joint < 120m   |  |  |
| Total length:                          |                          | Total length:     | The sum of the total length of the pipes < 300m  |  |  |
| Maximum                                | imum Outdoor unit Height |                   | H1: The difference of height between an outdoor unit and indoor unit < 50/40m Note 1)                                      |  |  |
| allowable                              | ~ Indoor unit            | Height            | H2: The difference of height between indoor units ≤50m   |  |  |
| height ~ indoor unit                   |                          | neight            | But, when AM****NQDEH* is installed, H2 is 15 m or less.   |  |  |
| Maximum allowable length after Y joint |                          | Actual length     | The distance between the first Y-joint and the farthest indoor unit $\leq$ 40m Ex) 8 indoor units b+c+d+e+f+q+p $\leq$ 40m | Allowable length between EEV kit and an indoor unit $\leq$ 20m Ex): h, i, j $\leq$ 20m |  |


<sup>\*</sup> When the equivalent length between an outdoor unit and the farthest indoor unit exceeds 90m,upgrade the low pressure pipe of the main pipe one step.

<sup>\*</sup> Note 1) When indoor unit is located at higher level than outdoor unit, allowable height difference is 40m, but when the indoor unit is located at lower level than outdoor unit, allowable height difference is 50m.


|                       | EEV kit            |              | Model name   |          | Remarks   |
|-----------------------|--------------------|--------------|--------------|----------|---|
|                       | Actual pipe length | 2 m          | MEV-E24SA    | 1 indoor | Apply to products without EEV<br>(Wall mount & ceiling) |
|                       |                    |              | MEV-E32SA    |          |   |
|                       |                    | 20 m or less | MXD-E24K132A | 2 indoor |   |
|                       |                    |              | MXD-E24K200A |          |   |
| EEV kit ~ Indoor unit |                    |              | MXD-E32K200A |          |   |
|                       |                    |              | MXD-E24K232A |          |   |
|                       |                    |              | MXD-E24K300A |          |   |
|                       |                    |              | MXD-E32K224A |          |   |
|                       |                    |              | MXD-E32K300A |          |   |

<sup>※</sup> Please refer to the EEV Kit manual.

\* Connection by distribution header



\* Connection by Y-joint/distribution header



| Classification                            |                                   |                   | Distribution connection  | Y-joint / distribution connection   |  |
|---|-----------------------------------|-------------------|--|---|--|
| Maximum                                   |                                   |                   | The distance between the outdoor unit and the farthest indoor unit ≤ 160m                            |   |  |
|   |                                   | Actual length     | Ex) 8 indoor units   | Ex) 8 indoor units  |  |
| allowable                                 | Outdoor unit                      |                   | a+g ≤ 160m   | a+b+c ≤ 160m  |  |
| length of                                 | ~ Indoor unit                     | Equivalent length | The distance between outdoor unit and the farthest indoor unit $\leq$ 185m                           |   |  |
| pipe                                      |                                   | Main pipe length  | The main pipe(a) from the the outdoor unit to the first Y joint < 120m                               |   |  |
|   |                                   | Total length:     | The sum of the total length of the pipes < 300m  |   |  |
| Maximum                                   | Outdoor unit                      | Height            | H1: The height difference between an outdoor unit and the indoor unit $< 50/40 m^{Note}$             |   |  |
| allowable                                 | allowable<br>height ~ Indoor unit |                   |  | H2: The height difference between the indoor units ≤50m   |  |
| height                                    |                                   | rieigrit          | But, when AM****NQDEH* is installed, H2 is 15 m or less.   |   |  |
| Maximum allowable<br>length after Y joint |                                   | Actual length     | The distance between the header joint and the indoor unit $\leq$ 40m Ex) b, c $\sim$ f, g $\leq$ 40m | The distance between the first Y joint and the farthest indoor unit $\leq$ 40m Ex) 5 indoor units b+c, d+g $\leq$ 40m |  |


<sup>\*</sup> When the equivalent length between an outdoor unit and the farthest indoor unit exceeds 90m,upgrade the low pressure pipe of the main pipe one step.

<sup>\*\*</sup> Note 1) When indoor unit is located at higher level than outdoor unit, allowable height difference is 40m, but when the indoor unit is located at lower level than outdoor unit, allowable height difference is 50m.

## AM030RXMDEH\*, AM040/050KXMDEH\*, AM040/050BXMDEH\*


★ Connection by Y-joint

## Outdoor unit



★ Connection by Y-joint / EEV kit

## Outdoor unit




| Classification                            |               |   | Y joint connection  | Y-joint / EEV kit connection   |  |
|---|---------------|---|---|--|--|
|   |               |   | The distance between the outdoor unit and the farthest indoor unit ≤ 50m  |  |  |
| Maximum                                   |               | Actual length                           | Ex) 8 indoor units  | Ex) 6 indoor units   |  |
| allowable                                 | Outdoor unit  |   | a+b+c+d+e+f+g+p ≤ 50m   | $a+b+c+d+j \le 50m$  |  |
| length of                                 | ~ Indoor unit | Equivalent length                       | The distance between an outdoor unit and the farthest indoor unit ≤ 65m   |  |  |
| pipe                                      |               | Main pipe length                        | The main pipe(a) from the the outdoor unit to the first Y joint < 40m   |  |  |
| Total length: The sum of the              |               | The sum of the total length of the pipe | e sum of the total length of the pipes < 150m   |  |  |
| allowable allowable                       |               | Height                                  | H1: Height difference between outdoor unit and indoor unit: not more than 30m when the outdoor unit is higher, or not more than 25m when the outdoor unit is lower. |  |  |
| height                                    |               | Height                                  | H2: Height difference between indoor unit is not more than 15m.   |  |  |
| Maximum allowable<br>length after Y joint |               | Actual length                           | The distance between the first Y-joint and the farthest indoor unit $\leq$ 40m Ex) 8 indoor units b+c+d+e+f+g+p $\leq$ 40m  | Allowable length between EEV kit and an indoor unit $\leq$ 20m Ex): h, i, j $\leq$ 20m |  |

<sup>\*</sup> When the equivalent length between an outdoor unit and the farthest indoor unit exceeds 90m,upgrade the low pressure pipe of the main pipe one step.

|                       | EEV kit            |              | Model name   |                      | Remarks   |
|-----------------------|--------------------|--------------|--------------|----------------------|---|
|                       | Actual pipe length | 2 m          | MEV-E24SA    | 1 indoor             | Apply to products without EEV<br>(Wall mount & ceiling) |
|                       |                    |              | MEV-E32SA    |                      |   |
|                       |                    | 20 m or less | MXD-E24K132A | 2 indoor<br>3 indoor |   |
| EEV kit ~ Indoor unit |                    |              | MXD-E24K200A |                      |   |
|                       |                    |              | MXD-E32K200A |                      |   |
|                       |                    |              | MXD-E24K232A |                      |   |
|                       |                    |              | MXD-E24K300A |                      |   |
|                       |                    |              | MXD-E32K224A |                      |   |
|                       |                    |              | MXD-E32K300A |                      |   |

<sup>\*</sup> Please refer to the EEV Kit manual.



| Classification                            |                            |                   | Distribution connection   | Y-joint / distribution connection   |
|---|----------------------------|-------------------|---|---|
|   | Outdoor unit ~ Indoor unit |                   | The distance between the outdoor unit and the farthest indoor unit ≤ 50m  |   |
| Maximum<br>allowable                      |                            | Actual length     | Ex) 8 indoor units $a+g \le 50m$  | Ex) 8 indoor units<br>a+b+c ≤ 50m   |
| length of                                 |                            | Equivalent length | The distance between outdoor unit and the farthest indoor unit ≤ 65m  |   |
| pipe                                      |                            | Main pipe length  | The main pipe(a) from the the outdoor unit to the first Y joint < 40m   |   |
|   |                            | Total length:     | The sum of the total length of the pipes < 150m   |   |
| Maximum<br>allowable                      | Outdoor unit               | Height            | H1: Height difference between outdoor unit and indoor unit: not more than 30m when the outdoor unit is higher, or not more than 25m when the outdoor unit is lower. |   |
| height                                    |                            | Height            | H2: Height difference between indoor unit is not more than 15m.   |   |
| Maximum allowable<br>length after Y joint |                            | Actual length     | The distance between the header joint and the indoor unit $\leq$ 40m Ex) b, c $\sim$ f, g $\leq$ 40m  | The distance between the first Y joint and the farthest indoor unit $\leq$ 40m Ex) 5 indoor units b+c, d+g $\leq$ 40m |

<sup>\*\*</sup> When the equivalent length between an outdoor unit and the farthest indoor unit exceeds 90m,upgrade the low pressure pipe of the main pipe one step.

# Installation of refrigerant Y-joint

Install the Y-joint horizontally or vertically.

\* Install horizontally








\* Install vertically






- ▶ When using A-J type of Y-joint, connect the Y-joint to the pipe with the provided reducer.
- When using K-Z type of Y-joint,connect the Y-joint to the pipe by cutting the inlet of the Y-joint or provided reducer properly.





- Install the Y-joint within  $\pm 15^{\circ}$  on the horizontal or on the vertical.
- Make sure that the pipe does not break at Y-joint adn pipe connection.
- Caution Keep a minimum straight line distance of 500mm or more before connecting Y-joint.




|                                      | Correct use<br>(The insertion depth of the connecting pipe) | Incorrect use<br>(The insertion depth of the connecting pipe) |
|--------------------------------------|---|---|
| Basic<br>specification               | Connecting pipe   | Connecting pipe   |
| Position<br>of cutting<br>connection | Connecting pipe   | Connecting pipe   |


• When inserting connecting pipe into Y-joint, please comply with the installation regulation.

### Installation the distribution header

1) Select the reducer fitted on the diameter of the pipe.



2) If the number of connected indoor units is fewer than ports on the distribution header, block the unused ports with caps




- For A~J type distribution header: Connect the distribution header to the connection pipe with the provided reducer.
- ► For K-Z type distribution header: Cut the provided socket, according to the diameter of the connection pipe, before connecting it.



Caution

- · Connect the indoor units in order, while respecting the direction of the arrow shown in the illustration.
- When indoor units are connected to same distribution head, indoor unit must be connected in order of their capacity, from largest to smallest.
- 3) Install the distribution header horizontally.
- Install the distribution header horizontally so that its ports does not face down.



<Liquid side>

37

<Gas side>

# Wiring work

## Specification of the circuit breaker and power cable

### **DVM S ECO Series**

| Capacity (HP) | Model        | MCA (A) | MFA (A) |
|---------------|--------------|---------|---------|
| 10            | AM100KXMDGH∗ | 21.5    | 30.0    |
| 12            | AM120KXMDGH* | 23.5    | 30.0    |
| 14            | AM140KXMDGH* | 32.0    | 40.0    |
| 4             | AM040KXMDEH* | 24.0    | 32.0    |
| 5             | AM050KXMDEH* | 27.0    | 40.0    |
| 3             | AM030RXMDEH* | 16.5    | 25.0    |
| 4             | AM040BXMDEH* | 24.0    | 32.0    |
| 5             | AM050BXMDEH* | 27.0    | 40.0    |
| 10            | AM100BXMWGH* | 21.5    | 30.0    |
| 12            | AM120BXMWGH* | 23.5    | 30.0    |

- ※ MCA: Minimum Circuit Ampere;
- \* MFA: Maximum Fuse Ampere
- \* Please refer to the MCA specification to selecte the line parameter.
- \* Please refer to the MFA specification to selecte the MCCB and ELB specification.
- \* Power Supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord. (Code designation IEC:60245 IEC 66 / CENELEC: H07RN-F)
- This device is intended for the connection to a power supply system with a maximum permissible system impedance shown in the table (on the left page) at the interface point (power service box) of the user's supply.
- The user must ensure that this device is connected only to a power supply system which fulfills the requirement above. If necessary, the user can ask the public power supply company for the system impedance at the interface point.
- This equipment complies with IEC 61000-3-12 provided that the short-circuit power Ssc is greater than or equal to Ssc(\*2) at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power Ssc greater than or equal to Ssc(\*2).
- [Ssc (\*2)]

| Capacity (HP) | Model        | Ssc [MVA]                              |
|---------------|--------------|--|
| 10            | AM100KXMDGH* | 4.6                                    |
| 12            | AM120KXMDGH∗ | 5.1                                    |
| 14            | AM140KXMDGH* | 5.9                                    |
| 4             | AM040KXMDEH* | 3.3                                    |
| 5             | AM050KXMDEH* | 3.6                                    |
| 3             | AM030RXMDEH* | 3.3                                    |
| 4             | AM040BXMDEH* | Equipment complying with IEC61000-3-12 |
| 5             | AM050BXMDEH* | Equipment complying with IEC61000-3-12 |
| 10            | AM100BXMWGH* | 4.6                                    |
| 12            | AM120BXMWGH* | 5.1                                    |

Sheath

(Outer

cover)

(Example of exposed core)

# Caution

Caution for electrical work

You must install ELCB or MCCB + ELB

- ELCB: Earth leakage breaker
- MCCB: Molded case circuit breaker
- ELB: Earth leakage breaker
- · Do not operate the outdoor unit before completing the
- · refrigerant pipe work.
- Do not disconnect or change the cable inside the product. It may cause damage to the product.
- Specification of the power cable is selected based on following installation condition; culvert installation/ ambient temperature 30 °C/ single multi conductor cables. If the condition is different from the ones stated, please consult an electrical installation expert and re-select the power cable.

Exposed core

- If the length of power cable exceed 50m, re-select the power cable considering the voltage drop.
- Use a power cable made out of incombustible material for the insulator (inner cover) and the sheath (outer cover).
- Do not use the power cable with the core wire exposed due to insulator damage occurred during removal of the sheath. When the core wire is exposed, it may cause fire.
- When you install the power and communication cables, be careful not to touch on the refrigerant pipes. It can damage on the cables because of the high temperature of the non-insulated refrigerant pipes.

## Specification of the protection tube

| Name                                      | Temper grade                                    | Applicable conditions  |
|---|---|--|
| Flexible PVC conduit                      | PVC   | When the protection tube is installed indoor and not exposed to outside, because it is embedded in concrete structure                                  |
| Class 1 flexible conduit                  | Galvanized steel sheet                          | When the protection tube is installed indoor but exposed to outside so there are risk of damage to the protection tube                                 |
| Class 1 PVC<br>coated flexible<br>conduit | Galvanized steel sheet<br>and Soft PVC compound | When the protection tube is installed outdoor and exposed to outside so there are risk of damage to the protection tube and extra waterproof is needed |



Caution for perforating the knock-out hole

Caution

- · Perforate a knock-out hole by punching it with a hammer.
- After perforating the knock-out hole, apply rust resisting paint around the hole.
- When you need to pass the cables through the knock-out hole, remove burrs on the hole and protection the cable with a protection tape or bushing etc.

Caution for installing communication cable


• When you connect the cable, it may sag and pressed by other parts. Therefore cables should be fixed to a clamp highlighted with a box on the illustration.


# Wiring work

## Power wiring Diagram

#### AM100/120/140KXMDGH\*, AM100/120BXMWGH\*

Supplying 3phase 4wire(380-415V~)






- ► Connect a power cable of the outdoor unit after checking that R-S-T-N (3 phase 4 wire) is properly connected. (If the 380-415 V power is supplied to the N phase, PCB and other electrical part will be damaged.)
- ► Communication cable between indoor and outdoor units and communication cable between outdoor units has no polarity.
- Arrange the cables with a cable tie.
- \* ELCB and ELB must be installed since there is risk of electric shock or fire when they are not installed.

#### AM030RXMDEH\*, AM040/050KXMDEH\*, AM040/050BXMDEH\*

### Supplying 1phase 2wire(220V~)




- ▶ Connect a power cable of the outdoor unit after checking that L-N (1 phase 2 wire) is properly connected.
- ► Communication cable between indoor and outdoor units and communication cable between outdoor units has no polarity.
- Arrange the cables with a cable tie.
- \* ELCB and ELB must be installed since there is risk of electric shock or fire when they are not installed.

# Wiring work

# Selecting solderless ring terminal

- ▶ Select a solderless ring terminal for a power cable according to the nominal dimensions for cable.
- ▶ Apply insulation coating to the connection part of the solderless ring terminal and the power cable.
- ▶ The exposed part of ring terminal must be insulated with insulation bushing or tape in order to ensure that the crimping terminal is not loose after installation and that the clearance between exposed parts of neighboring terminals is at least more than 4mm.



| Nominal                         | Nominal |                       | 3         | [                     | )            | d                     | 1         | Е    | F    | L    | d                     | 2         | t    |
|---------------------------------|---------|-----------------------|-----------|-----------------------|--------------|-----------------------|-----------|------|------|------|-----------------------|-----------|------|
| for cable<br>(mm <sup>2</sup> ) | sl .    | Standard<br>dimension | Allowance | Standard<br>dimension | Allowance    | Standard<br>dimension | Allowance | Min. | Min. | Max. | Standard<br>dimension | Allowance | Min. |
| 1.5                             | M4      | 6.6                   | 100       | 2.4                   | +0.3         |                       |           | 4.1  |      | 1.5  | 4.2                   | +0.2      | 0.7  |
| 1.5                             | M4      | 8                     | ±0.2      | 3.4                   | - 0.2        | 1.7                   | ±0.2      | 4.1  | 6    | 16   | 4.3                   | 0         | 0.7  |
|                                 | M4      | 6.6                   |           |                       | +0.3         |                       |           |      |      |      |                       | +0.2      |      |
| 2.5                             | M4      | 8.5                   | ±0.2      | 4.2                   | - 0.2        | 2.3                   | ±0.2      | 6.0  | 6    | 17.5 | 4.3                   | 0         | 0.8  |
| 6                               | M5      | 9.5                   | ±0.2      | 5.6                   | +0.3<br>-0.2 | 3.4                   | ±0.2      | 6.0  |      | 20   | 5.3                   | ± 0.4     | 0.9  |

### Connecting the power terminal


- ▶ Connect the cables to the terminal board with solderless ring terminals.
- Properly connect the cables by using certified and rated cables and make sure to fix them properly so that external force is not applied to the terminal.
- ▶ Use a driver and wrench that can apply the rated torque when tightening the screws on the terminal board.
- ► Tighten the terminal screws by complying rated torque value. If the terminal is loose, fire can occur due to arc heat generation and if the terminal is too tight, terminal board could get damaged.

|      | Tightening torque for terminal |  |  |  |  |  |  |
|------|--------------------------------|--|--|--|--|--|--|
| M5   | 2.39~2.92 (N·m)                | 3 phase(380V-415V~) / (220V-240V) power line |  |  |  |  |  |
| IVID | 24.4~29.8(kgf·cm)              | L/N 220-240V Power line                      |  |  |  |  |  |
| M4   | 1.18~1.47 (N·m)                | F1/F2 communication line, L/N 220-240V Power |  |  |  |  |  |
| IVI4 | 12.0~15.0(kgf·cm)              | line   |  |  |  |  |  |



- When removing the outer sheath of the power supply cable, be careful not to scratch the inner sheath of the
- Make sure that more than 20mm of the outer sheath of the indoor unit power and communication cable are inside the electrical component box.
- Install the communication cable separately from power cable and other communication cables.

### Examples of how to use the cable striper



- Adjust the blade position by coin. (Controller is at the bottom side of the tool.) Fix the blade
  position according to the outer sheath thickness of the power cable.
- 2. Fix the power cable and tool by using the hook at the top side of the tool.
- Cut out the outer sheath of the power cable by revolving the tool in the direction of the arrow, two or three times.
- At this situation, cut out the outer sheath of the power cable by moving the tool toward the direction of the arrow.
- 5. Slightly bend the wire and pull out the cut part of the outer sheath.














# Wiring work

### Fixing the power cable






- Do not let the power cable come into contact with the pipes inside the outdoor unit. If the power supply
  cable touches the pipes, the vibration of the compressor is transferred to the pipes and can damage the
  power supply cables or pipes, creating the danger of fire or explosion.
- Make sure that the place where the sheath of power supply cable is removed is inside the power supply box. If it is impossible, you should connect the protection tube for power cable to the power supply box.
- After arranging the power cable into the power supply box, tighten the cover.

### Connect the ring terminal of 3 phase cable

- Cut the power cable to an appropriate length and connect it with the solderless terminal.
- After connecting the power cable to the terminal as seen in the illustration, fix it with cable tie.
- 3. Fix the housing, which has an insulator to the terminal board.



# Installing grounding wire

- ▶ Grounding must be done by a qualified installer for you safety.
- ▶ Use the grouding wire by referring to the specification of the electric cable of the outdoor unit.

#### 1) Grounding the power cable

- ▶ The standard of grounding may vary according to the rated voltage and installation place of the air conditioner.
- ► Ground the power cable according to the following.

| Power condition<br>Installation place | Voltage to ground is lower than 150V   | Voltage to ground is over 150V                                  |  |
|---------------------------------------|--|---|--|
| High humidity                         | Must perform the grounding work 3. Note 1) (Including the case where earth leakage breaker is installed) |   |  |
| Average humidity                      | Perform grounding work 3. Note 1)  | Must perform the grounding work 3. Note 1)                      |  |
| Low humidity                          | Perform grounding work 3, if possible, for your safety. Note 2)  | (Including the case where earth leakage breake<br>is installed) |  |

#### Note 1) Grounding Work 3


- Grounding work must be done by an expert (with qualification).
- Check if the grounding resistance is lower than  $100\Omega$ . When installing a earth leakage breaker (that can cut the electric circuit within 0.5 second in case of a short circuit), allowable grounding resistance should be  $30{\sim}500\Omega$ .

#### Note 2) Perform ground work in a dry place

• The grounding resistance should be lower than  $100\Omega$ . Even in worst case, grounding resistance should be lower than  $250\Omega$ .

#### 2) Performing the grounding work

▶ Use a rated grounding cable by referring to the specification of the electric cable for the outdoor unit.




# Wiring work

If the power distribution circuit does not have a grounding or the grounding does not comply with specifications, a ground rod must be installed.

The corresponding accessories are not supplied with the air conditioner.

1) Select a grounding rod that complies with the specifications given in the illustration.



- PVC-insulated green / yellow wire
- 2) Select a proper place for the grounding rod installation.priate installing position for ground rod.
  - In damp hard soil rather than loose sandy or gravel soil that has a higher grounding resistance.
  - Away from underground structures or facilities, such as gas pipes, water pipes, telephone lines and underground cables.
  - At least two meters away from lightening(as in a strom) conductor.





· The grounding wire for the telephone line cannot be used to ground the air conditioner.

- 3) Install a green / yellow grounding wire:
  - Please refer to the "Wiring work" for the specification of grounding wire.
  - When the grounding wire is too short, extend the grounding wire but bind the connection part with insulation tepe.
     Extend the ground lead if too short and use the heat-insulated tape to secure the connection part.
     (Do not bury the connection)
  - Secure the grounding wire in position with staples.



• When the grounding rod is installed in a place where many people pass by, you must fix it firmly.

- 4) Carefully check the installation, by measuring the grounding resistance with a ground resistance tester.
  - If the resistance is above required level, drive the grounding rod deeper into the ground or increase the number of grounding rods.
- 5) Connect the grounding wire to the electrical component box inside of the outdoor unit.

# Air tightness test and Vacuum drying

### Air Tightness

- ▶ Use tools for R-410A to prevent the inflow of foreign substances and resist against the internal pressure.
- Do not remove the core of filling port.
- Use Nitrogen gas for air tightness test as shown in the illustration.

Apply pressure to the liquid side pipe and gas side pipe (when installing outdoor units in module) with Nitrogen gas at 4.1MPa.

If you apply pressure at more than 4.1MPa, pipes may get damaged. Apply pressure with pressure regulator and pay attention to the pressure of the nitrogen.

Keep it for minimum 24 hours to check if pressure drops.


After applying Nitrogen gas, check there's any change of pressure, using a pressure regulator.

If the pressure drops, check for gas leakage.

If the pressure is changed, apply soap water to check for leakage and check the pressure of the nitrogen gas again.

Maintain 1.0MPa of the pressure before performing vacuum drying and check for further gas leakage.

After checking the first gas leakage, maintain 1.0MPa to check for further gas leakage.




- · Perform a Nitrogen gas leak test with the service valve of the outdoor unit closed.
- When charging the nitrogen gas, charge it from the both (high-low pressure) sides.

Caution • If the pipe is filled in a short time with a highly excessive pressure of Nitrogen gas, the pipes may get damaged. Make sure to use a regulator to prevent the high pressure Nitrogen gas, over 4.1MPa, from entering into the pipe.

# Air tightness test and Vacuum drying

### Vacuum drying pipes and indoor unts

- ▶ Use tools for R-410A to prevent the inflow of foreign substances and resist against the internal pressure.
- Use vacuum pump that allows vacuuming under -100.7kPa (5 Torr).
- Use the vacuum pump with the check valve to prevent pump oil from flowing backward while the vacuum pump is stopped.
- ► Completely close the liquid-gas side service valve of the outdoor unit.



- \* If the pressure rises in an hour, either water is remaining inside the pipe or there is a leakage.
- # When the ambient temperature of vacuuming pipe is low (less than 0 °C), moisture might remain within the pipe. Therefore, pay special attention to the pipe sealing in the winter.

# Charging refrigerant

## Important information regulation regarding the refrigerant used


This product contains fluorinated greenhouse gases. Do not vent gases into the atmosphere.

Caution

Inform user if the system contains 5 tCO2e or more of fluorinated greenhouse gases. In this case, it must be
checked for leakage at least once every 12 months, according to regulation No. 517/2014. This activity must be
covered by qualified personnel only. In the case of the situation above, the installer (or authorized person with
responsibility for final check) must provide a maintenance book, with all the information recorded, according
to REGULATION (EU) No. 517/2014 OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 16 April 2014 on
fluorinated greenhouse gases.

Please fill in the following with indelible ink on the refrigerant charge label supplied with this product and on this manual.

- 1 the factory refrigerant charge of the product.
- 2 the additional refrigerant amount charged in the field.
- ▶ (1)+(2) the total refrigerant charge.
- \* The refrigerant charge label supplied with the product.



| Unit   | Kg | tCO₂e |
|--------|----|-------|
| ①, a   |    |       |
| ②, b   |    |       |
| ①+②, c |    |       |
|        |    |       |

**GWP** value

2088

- R-410A
   GWP=Global Warming Potential
- Calculating tCO₂e: kg x GWP / 1000

Refrigerant type

- a Factory refrigerant charge of the product: see unit name plate.
- b Additional refrigerant amount charged in the field. (Refer to the above information for the quantity of refrigerant replenishment.)
- c Total refrigerant charge.
- d Refrigerant cylinder and manifold for charging.




• The filled-out label must be adhered in the proximity of the product charging port.

(ex. onto the inside of the stop valve cover.)

# Charging refrigerant

### Charging refrigerant

- ▶ The R410A refrigerant is blended refrigerant. Add only liquid refrigerant.
- ▶ Measure the quantity of the refrigerant according to the method to calculate total amout of additional refrigerant.
- ► Add quantity of the refrigerant using a scale.
- Open the manifold gauge valve connected to the liquid side service valve and add the liquid refrigerant.
- ▶ If you cannot add the whole quantity of the refrigerant while the outdoor unit is stopped, open the gas side and liquid side service valve.
- ▶ Then, add remaining refrigerant by pressing the refrigerant charging button of the outdoor PCB.
- ▶ When using the function of the refrigerant charging in cooling mode, please use the gas side manifold gauge.
- ▶ When using the function of the refrigerant charging in heating mode, please connect manifold gauge to the charging port for heating and use it.



• Open the gas side and liquid side service valve completely after charging the refrigerant. (If you operate the air conditioner with the service valve closed, the important parts may be damaged.)

Caution. Put on safety equipment when charging refrigerant.

- Do not charge the refrigerant when you adjust or control other product such as indoor units or EEV kits.
- When the ambient temperature is low in winter time, do not heat the refrigerant container to speed up the charqing process. There is risk of explosion.
- Beware for possibility of refrigerant leakage when you connect the manifold gauge to the charging port for heating.
- Close the valve of the refrigerant container immediately after charging the refrigerant. If not, there might be a change in entire amount of refrigerant.

# Pipe insulation

### Insulating the refrigerant pipes and branch joints

- Check for gas leakage before completing (the hose and pipe insulation) and if there is no sign of leakage, make sure to insulate the pipes and hoses.
- Use EPDM material insulator that meets the following conditions.

| Test item                       | Unit         | Standard             |  |  |
|---------------------------------|--------------|----------------------|--|--|
| Density                         | g/cm³        | 0.048~0.096          |  |  |
| Dimensional change rate by heat | %            | Below -5             |  |  |
| Absorption rate                 | g/cm³        | Below 0.005          |  |  |
| Thermal conduction rate         | W/m-K        | Below 0.037          |  |  |
| Moisture transpiration factor   | ng/(m²·s·Pa) | Below 15             |  |  |
| Moisture transpiration grade    | g/(m²·24h)   | Below 15             |  |  |
| Formaldehyde dispersion         | mg/L         | There should be none |  |  |
| Oxygen rate                     | %            | Over 25              |  |  |

## Selecting the refrigerant pipe insulator

- ▶ Insulate the gas pipe and liquid pipe by referring to the thickness of insulator for each pipe size.
- ▶ The standard condition is: temperature at 30°C, humidity less than 85%. If case if the humidity is higher, you must increase the size by one grade as stated in below table.

|             |                         | Insulator (          |                  |                                    |
|-------------|-------------------------|----------------------|------------------|------------------------------------|
| Pipe        | Diameter of refrigerant | General [30°C,85%]   | High humidity    | Remarks                            |
| Tipe        | pipe (mm)               | General [50 C,05 /0] | [30°C, over 85%] |                                    |
|             |                         | E                    |                  |                                    |
| Liquid pipe | Ø6.35~Ø9.52             | 9 mm                 | ←                |                                    |
| Liquiu pipe | Ø12.7~Ø50.80            | 13 mm                | ←                |                                    |
|             | Ø6.35                   | 13 mm                | 19 mm            | Heating resisting temperature over |
| Caspina     | Ø9.52~ Ø25.40           | 19 mm                | 25 mm            | 120°C                              |
| Gas pipe    | Ø28.58~ Ø44.45          | 1911111              | 32 mm            |                                    |
|             | Ø50.80                  | 25 mm                | 38 mm            |                                    |


<sup>\*</sup> When installing insulation in places and conditions below, use the same insulation that is used for high humidity conditions.


- <Geological condition>
- High humidity places such as shoreline, hot spring, near lake or river, and ridge (when the part of the building is covered by earth and sand.)
- <Operation purpose condition>
- Restaurant ceiling, sauna, swimming pool etc.
- <Building construction condition>
- The ceiling frequently exposed to moisture and cooling is not covered. (e.g. The pipe installed at a corridor of a dormitory and studio or near an exit that opens and closes frequently.")
- The place where the pipe is installed is highly humid due to the lack of ventilation system.

## Pipe insulation

## Insulate the refrigerant pipe


- ▶ Make sure to insulate the refrigerant pipe, branch joint, distribution header, and the connection part of the pipes.
- ▶ If you insulate the pipes, condensed water will not fall from the pipes.
- Check if there are any cracks on the insulation at the bent part of the pipe.






#### Insulating pipes

- The insulation of the gas and liquid pipes can be in contact with each other but they should not press excessively against each other.
- When the gas side and liquid side pipes are contacting each other, increase the thickness of the insulation by one grade.




#### Insulating pipes connected behind the EEV kit

- When installing the gas side and liquid side pipes, leave at least 10mm of space.
- When the gas side and liquid side pipes are contacting each other, increase the thickness of the insulation by one grade.




<u>^</u>


- Install the insulation without any gaps or cracks and use adhesive on the connection part of it to prevent moisture from entering.
- Bind the refrigerant pipe with insulation tape if it is exposed to outside sunlight. (When binding the pipe with finishing tape, be careful not to reduce the thickness of the insulation.)
  - Install the refrigerant pipe respecting that the insulation does not get thinner on the bent part or hanger of pipe.
  - When the thickness of insulation is reduced, reinforce the reduced thickness with additional insulation.




#### Insulate the distribution header

- Fix the distribution header with a cable tie and cover the connected part.
- Insulate the distribution header and the welded part and wrap the connected part with an adhesive insulation tape to prevent dew formation.






Fix the distribution header with a hanger after insulating it.




## Insulating the branchjoint

- ► Tightly attach the insulator, provided with the branch joint, to the separately purchased insulator. Wrap the connected part with an insulator (separately purchased item) that has thickness of at least 10mm.
- ▶ Use an insulator that resist heat up to 120°C. Wrap the branch joint with an insulation that has thickness of at least 10mm.



Insulation tape (Separately purchased item)




Pipe insulator (Separately purchased item)

\* Attach the adhesive insulation tape to the pipe, as shown in the picture, after insulating the pipe.

# Pipe insulation

## Insulating the pipe located inside of the outdoor unit

- ▶ With a pipe insulator, insulate the pipe up to whole service valve located inside of the outdoor unit.
- ▶ Seal the gap between the outdoor unit pipe and the insulator. Rainwater and dewdrops may soak through the gap between the pipe and the insulation of the outdoor unit installed on the outside.
- Separate the cover of the pipe and close it after insulation work. Only remove a knock-out hole cover where the pipe will be installed. If the knock-out hole is open unnecessarily, it must be closed. If not, small animals such as squirrels and rats may get into the unit through the hole and the unit may be damaged.




# Basic segment display

| Step   | Display content                  | Display  |                       |            |   |  |
|--|----------------------------------|----------|-----------------------|------------|---|--|
| At initial manner in much  | Charling agains and display      | SEG 1    | SEG 2                 | SEG 3      | SEG 4   |  |
| At initial power input   | Checking segment display         | "8"      | "8"                   | "8"        | "8"   |  |
| While setting communication<br>between indoor and outdoor<br>unit (Addressing) |                                  | SEG 1    | SEG 1 SEG 2 SEG 3 SEG |            |   |  |
|  | Number of connected indoor units | "A"      | "d"                   | * Refer to | mmunicated units "View Mode" for nication address |  |
| After communication setting (usual occasion)                                   |                                  | SEG 1    | SEG 2                 | SEG 3      | SEG 4   |  |
|  | Transmit/Reception address       | I/U: "A" | I/U: "0"              |            | ion address<br>mal number)                        |  |


<sup>※</sup> I/U: Indoor unit

### AM100/120/140KXMDGH\*, AM100/120BXMWGH\*

## Setting outdoor unit key function



| Switch | Set | ting  | Function   | Remarks  |  |  |
|--------|-----|-------|--|--|--|--|
|        | K5  |       | _  | Not applicable   |  |  |
|        | KO  | Off   | _  | ног аррисавіе  |  |  |
|        | On  |       | Enable maximum capacity restriction for cooling operation  | Restrict excessive capacity increase when operating indoor units with small capacity |  |  |
| SW53   | K6  | Off   | Disable maximum capacity restriction for cooling operation | _  |  |  |
|        | 1/7 | On    | _  | N.A. analkashi.  |  |  |
|        | K7  | Off — |  | Not applicable   |  |  |
|        | K8  | On    | _  | Matanaliaskia  |  |  |
|        | Nδ  | Off   | _  | Not applicable   |  |  |



#### Setting total number of installed indoor units using K1~K4

1. In the initial, display will show the following.



2. Press and hold simultaneously K1, K2 to enter the setting mode.

If you enter the setting mode, display will show the following.




3. If you want to set manually, press K2 or K4 shortly.

- K2: 10 digit / K4: 1 digit

Example) total number of installed indoor unit: 24

press K2 2 times, press K4 4 times.

then, display will show



4. If you want to set automatically, press and hold K4 for 2 seconds.


Display will show total number of installed indoor units.

But you have to be careful, it is displayed only for the indoor unit in which a communication and power lines are connected normally.

5. If you want to finish setting mode, press and hold K2.

And then Main PCB will be reset after display blinking in 3 seconds.

₩ In case of inputting in the wrong way while you inputting, press "K3" (Main PCB reset) and progress again from the first step.



#### Installing and setting the option with tact switch and explanation of the functions

#### ■ Setting the option

- (1) Press and hold K2 to enter the option setting. (Only available when the operation is stopped)
  - If you enter the option setting, display will show the following.



- Seg 1 and Seg 2 will display the number for selected option.
- Seg 3 and Seg 4 will display the number for set value of the selected option.
- (2) If you have entered option setting, you can shortly press the K1 switch to adjust the value of the Seg 1, Seg 2 and select the desired option. (Refer to pages 58~60 for the Seg number of the function for each option)



(3) If you have selected desired option, you can shortly press the K2 switch to adjust the value of the Seg 3, Seg 4 and change the function for the selected option. (Refer to pages 58~60 for the Seg number of the function for each option)



(4) After selecting the function for options, press and hold the K2 switch for 2 seconds. Edited value of the option will be saved when entire segments blinks and tracking mode begins.




- $\bullet \ \, \text{Edited option will not be saved if you do not end the option setting as explained in above instruction.}$
- \* While you are setting the option, you may press and hold the K1 button to reset the value to previous setting.
- \* If you want to restore the setting to factory default, press and hold the K4 button while you are in the option setting mode.
  - If you press and hold the K4 button, setting will be restored to factory default but it doesn't mean that restored setting is saved. Press and hold the K2 button. When the segments shows that tracking mode is in progress, setting will be saved.

| Optional item    | Input unit       | SEG1 | SEG2 | SEG3 | SEG4 | Function of the option     | Remarks   |   |                        |  |
|------------------|------------------|------|------|------|------|----------------------------|---|---|------------------------|--|
| Emergency        |                  |      |      | 0    | 0    | Disabled (Factory Default) |   |   |                        |  |
| operation for    | eration for Main |      | 0    | 0    | 1    | Not applicable             |   |   |                        |  |
| malfunction      |                  |      |      | 0    | 2    | Not applicable             |   |   |                        |  |
|                  |                  |      |      | 0    | 0    | 7-9 (Factory default)      |   |   |                        |  |
|                  |                  |      |      | 0    | 1    | 5-7                        | Targeted evaporation                                |   |                        |  |
| Cooling          |                  |      |      | 0    | 2    | 9-11                       | temperature [°C].                                   |   |                        |  |
| capacity         | Main             | 0    | 1    | 0    | 3    | 10-12                      | (When low temperature value is set, discharged air  |   |                        |  |
| correction       |                  |      |      | 0    | 4    | 11-13                      | temperature of the indoor                           |   |                        |  |
|                  |                  |      |      | 0    | 5    | 12-14                      | unit will decrease)                                 |   |                        |  |
|                  |                  |      |      | 0    | 6    | 13-15                      |   |   |                        |  |
|                  |                  |      |      | 0    | 0    | 3.0 (Factory default)      |   |   |                        |  |
|                  |                  |      |      | 0    | 1    | 2.5                        |   |   |                        |  |
|                  | Main             |      |      | 0    | 2    | 2.6                        | Targeted high pressure [MPa].                       |   |                        |  |
| Capacity         |                  | 0    | 2    | 0    | 3    | 2.7                        | (When low pressure value is set, discharged air     |   |                        |  |
| correction for   |                  |      |      | 0    | 4    | 2.8                        | temperature of the indoor                           |   |                        |  |
| heating          |                  |      |      | 0    | 5    | 2.9                        | unit will decrease)                                 |   |                        |  |
|                  |                  |      |      | 0    | 6    | 3.1                        | ★ Unused by the cooling only models                 |   |                        |  |
|                  |                  |      |      | 0    | 7    | 3.2                        |   |   |                        |  |
|                  |                  |      |      | 0    | 8    | 3.3                        |   |   |                        |  |
|                  |                  |      |      |      |      |                            | 0   | 0 | 100% (Factory default) |  |
|                  |                  |      |      | 0    | 1    | 95 %                       |   |   |                        |  |
|                  |                  |      |      | 0    | 2    | 90 %                       |   |   |                        |  |
|                  |                  |      |      | 0    | 3    | 85 %                       |   |   |                        |  |
|                  |                  |      |      | 0    | 4    | 80 %                       |   |   |                        |  |
| Current          | Main             | 0    | 3    | 0    | 5    | 75 %                       | When restriction option is set, cooling and heating |   |                        |  |
| restriction rate | IVIdIII          |      | 3    | 0    | 6    | 70 %                       | performance may decrease.                           |   |                        |  |
|                  |                  |      |      | 0    | 7    | 65 %                       |   |   |                        |  |
|                  |                  |      |      |      |      |                            | 0   | 8 | 60 %                   |  |
|                  |                  |      |      | 0    | 9    | 55 %                       |   |   |                        |  |
|                  |                  |      |      | 1    | 0    | 50 %                       |   |   |                        |  |
|                  |                  |      |      | 1    | 1    | No restriction             |   |   |                        |  |

| Optional item   | Input unit | SEG1 | SEG2                                 | SEG3                         | SEG4 | Function of the option   | Remarks   |  |
|---|------------|------|--------------------------------------|------------------------------|------|--|---|--|
| Oil collection  | Main       | 0    | 4                                    | 0                            | 0    | Factory default  |   |  |
| interval  | Main       | 0    | 4                                    | 0                            | 1    | Shorten the interval by 1/2  |   |  |
|   |            |      |                                      | 0                            | 0    | Factory default  |   |  |
| Temperature to trigger defrost operation                        | Main       | 0    | 5                                    | 0                            | 1    | Apply setting when the product is being installed in humid area such as near river or lake | The defrost option shortens<br>the starting time of the<br>defrost operation<br>张 Unused by the cooling only<br>models          |  |
| Fan speed   |            |      |                                      | 0                            | 0    | Disabled (Factory default)   |   |  |
| correction for outdoor unit                                     | Main       | 0    | 6                                    | 0                            | 1    | Increase fan speed   | Increase the outdoor unit's fan speed to maximum value  |  |
|   |            |      |                                      | 0                            | 0    | Basic (Factory default)  |   |  |
| Silent mode for   |            |      |                                      | 0                            | 1    | LEVEL 1 / Auto   | Enables the silent mode for   |  |
| night-time  | Main       | 0    | 7                                    | 0                            | 2    | LEVEL 2 / Auto   | night-time in cooling mode. (It operates automatically  |  |
|   |            |      |                                      | 0                            | 3    | LEVEL 3 / Auto   | depending on the temperature.)  |  |
|   |            |      |                                      | 0                            | 0    | Disabled (Factory default)   |   |  |
| High-head   | Main       |      |                                      | 0                            | 1    | Level 1 of height difference<br>type 1 (indoor unit is lower than<br>outdoor unit)         | When outdoor unit is located 40~80m above the indoor unit   |  |
| condition setting   |            | 0    | 8                                    | 0                            | 2    | Not applicable   |   |  |
|   |            |      |                                      | 0                            | 3    | Height difference type 2<br>(outdoor unit is lower than<br>indoor unit)                    | When indoor unit is over 30m above the outdoor unit   |  |
| Long-pipng  |            |      |                                      | 0                            | 0    | Disabled (Factory Default)   |   |  |
| condition setting<br>(Setting is<br>unnecessary<br>if high-head | Main       | 0    | 9                                    | 0                            | 1    | LEVEL 1  | When equivalent length of farthest indoor unit from the outdoor unit is over 100m   |  |
| condition is set)   |            |      |                                      | 0                            | 2    | Not applicable   |   |  |
|   |            |      |                                      | 0                            | 0    | Disabled (Factory default)   |   |  |
| Energy saving setting   | Main       | 1    | 0                                    | 0                            | 1    | Energy saving mode   | Energy saving mode triggers when the room temperature reaches desired temperature while operating in heating mode.              |  |
| Unused option   | Main       | 1    | 1~2                                  | 0                            | 0    | Unused option  | Unused option by this model   |  |
| Channel address   | Main       | 1    | 2                                    | Α                            | U    | Automatic setting (factory default)  | Address for classifying the product from upper level  |  |
| Charmer address   |            |      | Manual setting for channel<br>0 – 15 | controller(DMS,S-NET 3,etc.) |      |  |   |  |
| Snow  |            |      |                                      | 0                            | 0    | Enabled  | During snow accumulation,   |  |
| accumulation<br>prevention<br>control                           | Main       | 1    | 4                                    | 0                            | 1    | Disabled (Factory default)   | the fan may spin even when<br>the unit is not in operation  |  |
|   |            |      |                                      | 0                            | 0    | Basic (Factory default)  |   |  |
|   |            |      |                                      | 0                            | 1    | LEVEL 1 / External contact   | If the external contact   |  |
| Silent mode for   | Main       | 1    | 5                                    | 0                            | 2    | LEVEL 2 / External contact   | interface module(MIM-B14)   |  |
| external contact  |            | '    |                                      | 0                            | 3    | LEVEL 3 / External contact   | <ul> <li>is used, entering the silent<br/>mode is available with<br/>contact signal in cooling and<br/>heating mode.</li> </ul> |  |

| Optional item                             | Input unit | SEG1 | SEG2 | SEG3 | SEG4 | Function of the option  | Remarks   |
|---|------------|------|------|------|------|---|---|
| Unused option                             | Main       | 1    | 6~9  | 0    | 0    | Unused option   | Unused option by this model   |
| Unused option                             | Main       | 2    | 0~1  | 0    | 0    | Unused option   | Unused option by this model   |
|   |            |      |      | 0    | 0    | Disabled (Factory default)                                      |   |
| Emergency<br>operation for<br>indoor unit | Main       | 2    | 2    | 0    | 1    | Indoor high humidity condition<br>(operating for up to 12hours) | When set, emergency operation is possible even if an indoor communication |
| communication<br>error                    |            |      |      | 0    | 2    | Indoor low humidity condition (operating for up to 24hours)     | error occurs.   |
| Unused option                             | Main       | 2    | 3~4  | 0    | 0    | Unused option   | Unused option by this model   |
|   | Main       |      |      | 0    | 0    | Not applied (Factory default)                                   |   |
| Aux Heater's                              |            |      | 5    | 0    | 1    | Switching delay to heating (30 mins.)                           | When using the Aux Heater,  |
| interworking<br>control for cycle         |            | 2    |      | 0    | 2    | Switching delay to heating (15 mins.)                           | set the delay time for switching from cooling to                          |
| heating<br>(cooling priority<br>control)  |            | 2    |      | 0    | 3    | Switching delay to heating (10 mins.)                           | heating.  ** Unused by the cooling  |
| Control)                                  |            |      |      | 0    | 4    | Switching delay to heating<br>(5 mins.)                         | only models   |
|   |            |      |      | 0    | 5    | No switching delay  |   |
| Auto Change                               | Main       | 2    | 6    | 0    | 0    | Not applied (Factory default)                                   | With Thermo off for all running indoor units, change the operation mode.  |
| Over                                      |            |      |      | 0    | 1    | Applied   | ★ Unused by the cooling only models                                       |

Display on segment



K1 Control

| Press and hold 1 time | Auto trial operation  | "K" "K" "BLANK" "BLANK"  |  |
|-----------------------|---|--|--|
| K1(Number of press)   | KEY operation   | Display on segment   |  |
| 1 time                | Refrigerant charging in Heating mode (Note 1)                             | ""K" "1" "BLANK" "BLANK"   |  |
| 2 times               | Trial operation in Heating mode (Note 1)                                  | "K" "2" "BLANK" "BLANK"  |  |
| 3 times               | Pump out in Heating mode (Note 1)   | "K" "3" "BLANK" "1"  |  |
| 4 times               | Vacuumig  | "K" "4" "BLANK" "1"  |  |
| 5 times               | End Key operation   | _  |  |
| K2(Number of press)   | KEY operation   | Display on segment   |  |
| 1 time                | Refrigerant charging in Cooling mode                                      | "K" "5" "BLANK" "BLANK"  |  |
| 2 times               | Trial operation in Cooling mode   | "K" "6" "BLANK" "BLANK"  |  |
| 3 times               | Pump down in Cooling mode   | "K" "7" "BLANK" "BLANK"  |  |
| 4 times               | Automatic setting of operation mode (Cooling/Heating) for trial operation | "K" "8" "BLANK" "BLANK"  |  |
| 5 times               | Checking the amount of refrigerant  | "K" "9" "X" "X"  (Display of last two digits may differ depending on the progress) |  |
| 6 times               | Discharge mode of DC link voltage   | "K" "A" "BLANK" "BLANK"  |  |
| 7 times               | Forced defrost operation (Note 1)   | "K" "B" "BLANK" "BLANK"  |  |
| 8 times               | Forced oil collection   | "K" "C" "BLANK" "BLANK"  |  |
| 9 times               | Inverter compressor check   | "K" "D" "BLANK" "BLANK"  |  |
| 10 times              | Fan 1 check   | "K" "E" "BLANK" "BLANK"  |  |
| 11 times              | Fan 2 check   | "K" "F" "BLANK" "BLANK"  |  |
| 12 times              | End Key operation   | -  |  |

(Note 1) Not available on AM\*\*\*FXM\*\*C Series

- \* Even when the outdoor unit power is off, it is dangerous when you come in contact with inverter PCB since it is charged with high DC voltage.
- \* When replacing/repairing the PCB, cut-off the power and wait until the DC voltage is discharged before replacing/repairing them. (Wait for more than 15 minutes to allow it to discharge naturally.)
- \* When there were errors, 'Dicharge mode of DC link voltage' may not have been effective. Especialy if error E464 has been occured, power element might be damaged by fire and therefore, do not use the 'Discharge mode of DC link voltage'.
- \* During "Discharge mode of DC link voltage", voltage of INV will be displayed.


| K3(Number of press) | KEY operation             | Display on segment    |  |  |
|---------------------|---------------------------|-----------------------|--|--|
| 1 time              | Intialize (Reset) setting | Same as initial state |  |  |

| K4 (Press and hold for   |                               | Display on segment |                        |                  |  |  |  |
|--|-------------------------------|--------------------|------------------------|------------------|--|--|--|
| 2 seconds to enter the<br>setting) → K4 press<br>(Number of press) | Displayed content             | Page 1             | Page 2                 |                  |  |  |  |
| 1 time   | Main version                  | MAIN               | Ver. (ex) 1412)        |                  |  |  |  |
| 2 times  | Inverter version              | INV1               | Ver. (ex) 1412)        |                  |  |  |  |
| 3 times  | Fan 1 version                 | FAN 1              | Ver. (ex) 1412)        |                  |  |  |  |
| 4 times  | Fan 2 version                 | FAN 2              | Ver. (ex) 1412)        |                  |  |  |  |
| 5 times  | EEP version                   | EEP                | Ver. (ex) 1412)        |                  |  |  |  |
| 6 times  | Assigned address of the units | AUTO               | SEG 1,2                | SEG 3,4          |  |  |  |
| o times  | Assigned address of the units | AUTO               | Indoor unit: "A", "0"  | Address (ex) 07) |  |  |  |
| 7 times  | Manually assigned address of  | MANU               | SEG 1,2                | SEG 3,4          |  |  |  |
| 7 times  | the units                     | IVIAINO            | Indoor unit: "A" , "0" | Address (ex) 15) |  |  |  |

| K4(Number | VEV  | Display on segment |  |  |  |  |
|-----------|--|--------------------|--|--|--|--|
| of press) | KEY operation  | SEG 1              | SEG2, 3, 4   |  |  |  |
| 1 time    | Outdoor unit capacity (HP)   | 1                  | 10 HP → 0, 1, 0  |  |  |  |
| 2 times   | Order frequency of compressor  | 2                  | 120 Hz → 1, 2, 0   |  |  |  |
| 3 times   | High pressure  | 3                  | 1.52 MPa → 1, 5, 2   |  |  |  |
| 4 times   | Low pressure   | 4                  | 0.43 MPa → 0, 4, 3   |  |  |  |
| 5 times   | Discharge temperature of compressor  | 5                  | 87 °C → 0, 8, 7  |  |  |  |
| 6 times   | IPM temperature of compressor  | 6                  | 87 °C → 0, 8, 7  |  |  |  |
| 7 times   | CT sensor value of compressor  | 7                  | 2 A → 0, 2, 0  |  |  |  |
| 8 times   | Suction temperature  | 8                  | -42 °C → -, 4, 2   |  |  |  |
| 9 times   | COND OUT temperature   | 9                  | -42 °C → -, 4, 2   |  |  |  |
| 10 times  | Liquid pipe temperature  | А                  | 87 °C → 0, 8, 7  |  |  |  |
| 11 times  | TOP temperature of compressor  | В                  | 87 °C → 0, 8, 7  |  |  |  |
| 12 times  | Outdoor temperature  | С                  | -42 °C → -, 4, 2   |  |  |  |
| 13 times  | EVI inlet temperature  | D                  | -42 °C → -, 4, 2   |  |  |  |
| 14 times  | EVI outlet temperature   | Е                  | -42 °C → -, 4, 2   |  |  |  |
| 15 times  | Main EEV step  | F                  | 2000 steps → 2, 0, 0   |  |  |  |
| 16 times  | EVI EEV step   | G                  | 300 steps → 3, 0, 0  |  |  |  |
| 17 times  | Fan step   | Н                  | 13 steps → 0, 1, 3   |  |  |  |
| 18 times  | Current frequency of compressor  | I                  | 120 Hz → 1, 2, 0   |  |  |  |
| 19 times  | Master indoor unit address<br>(Master indoor unit can be selected by<br>wired remote-controller) | J                  | Master indoor unit not seleted $\rightarrow$ BLANK , N , D If indoor unit No.1 is seleted as the master unit $\rightarrow$ 0 , 0 , 1 |  |  |  |
| 20 times  | End Key operation  |                    | -  |  |  |  |

#### AM040/050KXMDEH\*, AM030RXMDEH\*

#### Setting outdoor unit key function



#### ► Setting outdoor install option

| Step  | Button   | Display | Description        |     | Note        |  |  |  |  |  |
|-------|--|---------|--------------------|-----|-------------|--|--|--|--|--|
|       | Quantity of indoor units   |         |                    |     |             |  |  |  |  |  |
|       | 58 Setting required  |         |                    |     |             |  |  |  |  |  |
| Step1 | Press (K1+K2)<br>for 2 seconds   | 68 88   | Ready to set       |     | -           |  |  |  |  |  |
|       | K2 x n times   | 88 x 8  | Tens digit (0 ~ 1) | Ex) | 03:3 units  |  |  |  |  |  |
| Step2 | K4 x n times   | 888X    | 58                 |     | 10:10 units |  |  |  |  |  |
|       | * K4 : Press for 2 seconds - automatic detection of indoor units' quantity |         |                    |     |             |  |  |  |  |  |
| Step3 | Press K2 button for 2 seconds to save & exit.<br>(system will be reset)    |         |                    |     |             |  |  |  |  |  |

#### Installing and setting the option with tact switch and explanation of the functions

#### Setting the option

- 1. Press and hold K2 to enter the option setting. (Only available when the operation is stopped)
  - If you enter the option setting, display will show the following. (If you have set the 'Emergency operation for compressor malfunction', 1 or 2 will be displayed on Seq 4.)





- Seg 1 and Seg 2 will display the number for selected option.
- Seg 3 and Seg 4 will display the number for set value of the selected option.
- 2. If you have entered option setting, you can shortly press the K1 switch to adjust the value of the Seg 1, Seg 2 and select the desired option.

#### Example)









3. If you have selected desired option, you can shortly press the K2 switch to adjust the value of the Seg 3, Seg 4 and change the function for the selected option.










4. After selecting the function for options, press and hold the K2 switch for 2 seconds. Edited value of the option will be saved when entire segments blinks and tracking mode begins.





- \* While you are setting the option, you may press and hold the K1 button to reset the value to previous setting.
- \* If you want to restore the setting to factory default, press and hold the K4 button while you are in the option setting mode.
  - If you press and hold the K4 button, setting will be restored to factory default but it doesn't mean that restored setting is saved. Press and hold the K2 button. When the segments shows that tracking mode is in progress, setting will be saved.

| Optional item  | Input<br>unit | SEG1   | SEG2 | SEG3  | SEG4 | Function of the option   | Remarks   |  |
|--|---------------|--------|------|-------|------|--|---|--|
|  |               |        |      | A U A |      | Automatic setting (factory default)                                  | Address for classifying the produ   |  |
| Channel address  | Main          | 0      | 0    | 00    | ~ 15 | Manual setting for channel<br>0 – 15                                 | from upper level controller (DMS,S-<br>NET 3,etc.)  |  |
|  |               |        |      | 0     | 0    | Disabled (Factory default)   |   |  |
| emergency<br>operation for<br>indoor unit<br>communication | Main          | 0      | 1    | 0     | 1    | Indoor high humidity condi-<br>tion (operating for up to<br>12hours) | When set, emergency op-<br>eration is possible even if an<br>indoor communication error   |  |
| error  |               |        |      | 0     | 2    | Indoor low humidity condition (operating for up to 24hours)          | occurs.   |  |
|  |               |        |      | 0     | 0    | Disabled (Factory default)   |   |  |
| Aux Heater's   |               |        |      | 0     | 1    | Switching delay to heating (30 mins.)                                | M/L and the state of the state |  |
| interworking control for                                   | N 4 - 1       |        | _    | 0     | 2    | Switching delay to heating (15 mins.)                                | When using the Aux Heater, set the delay time for switching from cooling to heating.  |  |
| cycle heating (cooling prior-                              | Main          | ain 0  | 2    | 0     | 3    | Switching delay to heating (10 mins.)                                | <ul> <li>Unused by the cooling only models</li> </ul>   |  |
| ity control)   |               |        |      | 0     | 4    | Switching delay to heating (5 mins.)                                 | models  |  |
|  |               |        |      | 0     | 5    | No switching delay   |   |  |
|  |               |        |      | 0     | 0    | Disabled (Factory default)   | With Thermo off for all running indoor units, change the opera-   |  |
| Auto Change<br>Over  | Main          | 0      | 3    | 0     | 1    | Applied  | tion mode.  * Unused by the cooling only models   |  |
| View mode  |               |        |      | 0     | 0    | °C & MPa (Factory default)   | Converts the temperature, pres-   |  |
| Unit Option  | Main          | 0      | 4    | 0     | 1    | °F & psi   | sure units in the view mode (K4 switch)   |  |
| Silent mode  |               |        |      | 0     | 0    | Automatic Silent mode opera-<br>tion (Factory default)               | Automatic silent mode is available in the cooling model only. (It operates automatically depending on the temperature.)   |  |
| operation<br>control                                       | Main          | Main 0 |      | 0     | 1    | Manual Silent mode operation   | When the manual silent mode is set and the external contact interface module(MIM-B14) is used, silent mode is available with contact signal in cooling and heating mode.  |  |

| Optional item                | Input<br>unit | SEG1 | SEG2 | SEG3 | SEG4 | Function of the option     | Remarks   |
|------------------------------|---------------|------|------|------|------|----------------------------|---|
| Snow ac-<br>cumulation       |               |      |      | 0    | 0    | Disabled (Factory default) | During snow accumulation,                                   |
| prevention control           | Main          | 0    | 6    | 0    | 1    | Enabled                    | the fan may spin even when the unit is not in operation     |
|                              |               |      |      | 0    | 0    | 7-9                        | Targeted evaporation tem-                                   |
| Capacity                     |               |      |      | 0    | 1    | 5-7 (Factory default)      | perature [°C].  |
| correction for               | Main          | 0    | 7    | 0    | 2    | 9-11                       | (When low temperature value is set, discharged air tempera- |
| cooling                      |               |      |      | 0    | 3    | 10-12                      | ture of the indoor unit will<br>decrease)                   |
|                              |               |      |      | 0    | 0    | Disabled (Factory default) |   |
| Silent mode                  |               |      |      | 0    | 1    | LEVEL 1                    | When the silent mode is set,                                |
| for night-time               | Main          | 0    | 8    | 0    | 2    | LEVEL 2                    | cooling and heating perfor-                                 |
|                              |               |      |      | 0    | 3    | LEVEL 3                    | mance may decrease instead of reducing noise.               |
|                              | Main          |      |      | 0    | 0    | Basic (Factory default)    | Targeted high pressure [MPa].                               |
|                              |               | 0    |      | 0    | 1    | Basic - 0.2MPa             | When the lower target pressure is set, energy efficiency    |
| Capacity correction for      |               |      | 9    | 0    | 2    | Basic - 0.1MPa             | increases, but the dischare air temperature from the indoor |
| heating                      |               |      |      | 0    | 3    | Basic + 0.1MPa             | unit decreases.  * Unused by the cooling only models        |
|                              |               |      |      | 0    | 0    | Basic (Factory default)    |   |
| Current                      | Main          | 1    | 0    | 0    | 1    | I_DOWN_OP1                 | When restriction option is set,                             |
| restriction                  | Mairi         |      | 0    | 0    | 2    | I_DOWN_OP2                 | cooling and heating perfor-                                 |
|                              |               |      |      | 0    | 3    | I_DOWN_OP3                 | mance may decrease.   |
| Temperature                  |               |      |      | 0    | 0    | MID (Factory default)      | When the LOW is set, entering temperature of defrost opera- |
| to trigger<br>defrost opera- | Main          | 1    | 1    | 0    | 1    | LOW1                       | tion decreases.   |
| tion                         |               |      |      | 0    | 2    | LOW2                       | * Unused by the cooling only models                         |

<sup>\*</sup> Defrost mode will start when the temperature difference between outdoor and outdoor heat exchanger has become more than certain standard.

<sup>\*</sup> Factory default status is MID. When the function changes to LOW with option control, defrost entering temperature decreases. When defrost entering temperature decreases, the operation hour will be long but this means that the operation hour with the reduced heating capacity increases. This option is used at places where humidity is high and the defrost mode enters too frequently.

<sup>\*</sup> Maintaining factory default status is recommended.

#### ► Changing current restriction option table

| C                    | Function       |                |                |  |  |  |  |  |  |
|----------------------|----------------|----------------|----------------|--|--|--|--|--|--|
| Current limit option | 4 HP           | 5 HP           | 6 HP           |  |  |  |  |  |  |
| DFFAULT              | Default        | Default        | Default        |  |  |  |  |  |  |
| I_DOWN_OP1           | Default - 4(A) | Default - 2(A) | Default - 2(A) |  |  |  |  |  |  |
| I_DOWN_OP2           | Default - 6(A) | Default - 4(A) | Default - 4(A) |  |  |  |  |  |  |
| I_DOWN_OP3           | Default - 8(A) | Default - 6(A) | Default - 6(A) |  |  |  |  |  |  |

| Cla | ssification | Model        | Default |
|-----|-------------|--------------|---------|
|     | 3HP         | AM030RXMDEH* | 16.50 A |
| ø1  | 4HP         | AM040KXMDEH* | 24A     |
|     | 5HP         | AM050KXMDEH* | 27A     |

#### Setting key operation and checking the view mode with tact switch

| TACT switch | Number of presses     | Content                            | SEG1 | SEG2 | SEG3 | SEG4 | Remark                            |
|-------------|-----------------------|------------------------------------|------|------|------|------|-----------------------------------|
|             | Press and hold 1 time | Check operation                    | E    | E    |      |      |                                   |
|             | 1                     | Heating refrigerant charging       |      |      |      |      |                                   |
| K1          | 2                     | Heating trial operation            |      |      |      |      | Unused by the cooling only models |
|             | 3                     | Heating pump out                   |      |      |      |      | Offig frioders                    |
|             | 4                     | Vacuum                             |      |      |      |      |                                   |
|             | 5                     | Completion                         |      |      |      |      |                                   |
|             | 1                     | Cooling refrigerant charging       | E    |      |      |      |                                   |
|             | 2                     | Cooling trial operation            | E    |      |      |      |                                   |
| 1/2         | 3                     | Cooling pump down                  |      | ij   |      |      |                                   |
| K2          | 4                     | Checking the amount of refrigerant | E    | Ü    |      |      |                                   |
|             | 5                     | Inverter check                     | E    |      |      |      |                                   |
|             | 6                     | Completion                         |      |      |      |      |                                   |
| К3          |                       | Reset                              |      |      |      |      |                                   |

<sup>\*</sup> If you perform Cooling refrigerant charging or Cooling pump down in high temperature environment, E407 (High pressure protection control) error or high pressure protection switch may operate.

<sup>\*</sup> Even when the outdoor unit power is off, it is dangerous when you come in contact with inverter PCB since it is charged with high DC voltage.

<sup>\*</sup> When replacing/repairing the PCB, cut-off the power and wait until the DC voltage is discharged before replacing/repairing them. (Wait for more than 15 minutes to allow it to discharge naturally.


#### ► K4 input display order

| K4 (Number of press) | KEY operation  | Display on segment |   |  |
|----------------------|--|--------------------|---|--|
|                      |  | SEG1               | SEG2, 3, 4  |  |
| 1 time               | Current frequency of compressor  | 1                  | 120 Hz → 1, 2, 0  |  |
| 2 times              | Low pressure   | 2                  | 0.43 MPa → 0, 4, 3 / 62 psi → 0, 6, 2   |  |
| 3 times              | Outdoor temperature  | 3                  | -42 °C → -, 4, 2 / -44 °F → -, 4, 4   |  |
| 4 times              | Discharge temperature of compressor  | 4                  | 87 °C → 0, 8, 7 / 189 °F → 1, 8, 9  |  |
| 5 times              | OLP temperature of compressor  | 5                  | 87 °C → 0, 8, 7 / 189 °F → 1, 8, 9  |  |
| 6 times              | COND temperature   | 6                  | -42 °C → -, 4, 2 / -44 °F → -, 4, 4   |  |
| 7 times              | Liquid pipe temperature  | 7                  | 87 °C → 0, 8, 7 / 189 °F → 1, 8, 9  |  |
| 8 times              | High pressure  | 8                  | 1.52 MPa → 1, 5, 2 / 220 psi → 2, 2, 0  |  |
| 9 times              | Fan RPM  | 9                  | 700 RPM → 7, 0, 0   |  |
| 10 times             | ESC(EVI) EEV step  | Α                  | 300 steps → 3, 0, 0   |  |
| 11 times             | Main EEV step  | В                  | 2000 steps → 2, 0, 0  |  |
| 12 times             | CT sensor value of compressor  | C                  | 2 A → 0, 2, 0   |  |
| 13 times             | Number of connected indoor units   | D                  | 7 EA → 0, 0, 7  |  |
| 14 times             | Number of operating indoor units   | Е                  | 4 EA → 0, 0, 4  |  |
| 15 times             | Sum of indoor unit capacity  | F                  | 14.5 kcal/h → 1, 4, 5   |  |
| 16 times             | Main indoor unit address<br>(Main indoor unit can be select-<br>ed by wired remote-controller) | G                  | Main indoor unit not selected  → BLANK, N, D  If indoor unit No.1 is selected as the main unit  → 0, 0, 1 |  |
| 17 times             | End Key operation  |                    | -   |  |

| K4 (Press and hold for 2                                   | Displayed content                      | Display on segment |                                 |                  |
|--|--|--------------------|---------------------------------|------------------|
| seconds to enter the setting) → K4 press (Number of press) |  | Page 1             | Page 2                          |                  |
| 1 time   | Main version                           | MAIN               | Ver. (ex) 1412)                 |                  |
| 2 times  | Inverter version                       | INV1               | Ver. (ex) 1412)                 |                  |
| 3 times  | EEP version                            | EEP                | Ver. (ex) 1412)                 |                  |
|  | Assigned address of the units          | AUTO               | SEG 1,2                         | SEG 3,4          |
| 4 times  |  |                    | Indoor unit: "A", "0"           |                  |
|  |  |                    | HR Changer/MCU Unit<br>:"C","1" | Address (ex) 07) |
| Edinor   | Manually assigned address of the units | MANU               | SEG 1,2                         | SEG 3,4          |
| 5 times  |  |                    | Indoor unit: "A", "0"           | Address (ex) 15) |
| Press and hold (for 2sec.)                                 | End Key operation                      |                    | -                               |                  |


#### AM040/050BXMDEH\*

### Setting outdoor unit key function




#### Setting total number of installed indoor units using K1~K4

1. In the initial, display will show the following.



2. Press and hold simultaneously K1, K2 to enter the setting mode.

If you enter the setting mode, display will show the following.




3. If you want to set manually, press K2 or K4 shortly.

- K2: 10 digit / K4: 1 digit

 $Example)\ total\ number\ of\ installed\ indoor\ unit: 24$ 

press K2 2 times, press K4 4 times.

then, display will show



4. If you want to set automatically, press and hold K4 for 2 seconds.


Display will show total number of installed indoor units.

But you have to be careful, it is displayed only for the indoor unit in which a communication and power lines are connected normally.

5. If you want to finish setting mode, press and hold K2.

And then Main PCB will be reset after display blinking in 3 seconds.

\* In case of inputting in the wrong way while you inputting, press "K3" (Main reset) and progress again from the first step.



#### Installing and setting the option with tact switch and explanation of the functions

#### ■ Setting the option

- (1) Press and hold K2 to enter the option setting. (Only available when the operation is stopped)
  - If you enter the option setting, display will show the following.



- Seg 1 and Seg 2 will display the number for selected option.
- Seg 3 and Seg 4 will display the number for set value of the selected option.
- (2) If you have entered option setting, you can shortly press the K1 switch to adjust the value of the Seg 1, Seg 2 and select the desired option. (Refer to pages 72~74 for the Seg number of the function for each option)



(3) If you have selected desired option, you can shortly press the K2 switch to adjust the value of the Seg 3, Seg 4 and change the function for the selected option. (Refer to pages 72~74 for the Seg number of the function for each option)



(4) After selecting the function for options, press and hold the K2 switch for 2 seconds. Edited value of the option will be saved when entire segments blinks and tracking mode begins.



- $\bullet \ \, \text{Edited option will not be saved if you do not end the option setting as explained in above instruction.}$
- \* While you are setting the option, you may press and hold the K1 button to reset the value to previous setting.
- \* If you want to restore the setting to factory default, press and hold the K4 button while you are in the option setting mode.
  - If you press and hold the K4 button, setting will be restored to factory default but it doesn't mean that restored setting is saved. Press and hold the K2 button. When the segments shows that tracking mode is in progress, setting will be saved.

| Optional item               | Input unit | SEG1 | SEG2 | SEG3 | SEG4 | Function of the option | Remarks   |                        |  |
|-----------------------------|------------|------|------|------|------|------------------------|---|------------------------|--|
| Unused option               | Main       | 0    | 0    | 0    | 0    | Unused option          | Unused option by this model                         |                        |  |
|                             |            |      |      | 0    | 0    | 7-9                    |   |                        |  |
|                             |            |      |      | 0    | 1    | 5-7(Factory default)   | Targeted evaporation                                |                        |  |
|                             |            |      |      | 0    | 2    | 9-11                   | temperature [°F (°C)].                              |                        |  |
| Cooling capacity correction | Main       | 0    | 1    | 0    | 3    | 10-12                  | (When low temperature  value is set, discharged air |                        |  |
| correction                  |            |      |      | 0    | 4    | 11-13                  | temperature of the indoor                           |                        |  |
|                             |            |      |      | 0    | 5    | 12-14                  | unit will decrease)                                 |                        |  |
|                             |            |      |      | 0    | 6    | 13-15                  |   |                        |  |
|                             |            |      |      | 0    | 0    | 3.0 (Factory default)  |   |                        |  |
|                             |            |      |      | 0    | 1    | 2.5                    |   |                        |  |
|                             |            |      |      | 0    | 2    | 2.6                    | Targeted high pressure [MPa].                       |                        |  |
| Capacity                    |            |      |      | 0    | 3    | 2.7                    | (When low pressure value is set, discharged air     |                        |  |
| correction for              | Main       | 0    | 2    | 0    | 4    | 2.8                    | temperature of the indoor                           |                        |  |
| heating                     |            |      |      | 0    | 5    | 2.9                    | unit will decrease)                                 |                        |  |
|                             |            |      |      | 0    | 6    | 3.1                    |   |                        |  |
|                             |            |      |      | 0    | 7    | 3.2                    |   |                        |  |
|                             |            |      |      | 0    | 8    | 3.3                    |   |                        |  |
|                             |            |      |      |      |      | 0                      | 0   | 100% (Factory default) |  |
|                             |            |      |      | 0    | 1    | 95 %                   |   |                        |  |
|                             |            |      |      | 0    | 2    | 90 %                   |   |                        |  |
|                             |            |      |      | 0    | 3    | 85 %                   |   |                        |  |
|                             |            |      |      | 0    | 4    | 80 %                   |   |                        |  |
| Current                     |            |      |      | 0    | 5    | 75 %                   | When restriction option is                          |                        |  |
| restriction rate            | Main       | 0    | 3    | 0    | 6    | 70 %                   | set, cooling and heating performance may decrease.  |                        |  |
|                             |            |      |      | 0    | 7    | 65 %                   | ]   |                        |  |
|                             |            |      |      | 0    | 8    | 60 %                   | 7   |                        |  |
|                             |            |      |      | 0    | 9    | 55 %                   | 7   |                        |  |
|                             |            |      |      | 1    | 0    | 50 %                   | 7   |                        |  |
|                             |            |      |      | 1    | 1    | No restriction         |   |                        |  |


# Setting outdoor unit option switch and key function

| Optional item  | Input unit | SEG1 | SEG2 | SEG3 | SEG4 | Function of the option  | Remarks  |  |
|--|------------|------|------|------|------|---|--|--|
| Oil collection   | Main       | 0    | 4    | 0    | 0    | Factory default   |  |  |
| interval   | iviain     | U    | 4    | 0    | 1    | Shorten the interval by 1/2   |  |  |
|  |            |      |      | 0    | 0    | Factory default   |  |  |
| Temperature to trigger defrost operation                           | Main       | 0    | 5    | 0    | 1    | Apply setting when the<br>product is being installed<br>in humid area such as near<br>river or lake | The defrost option shortens<br>the starting time of the defrost<br>operation<br>张 Unused by the cooling only<br>models |  |
| Fan speed  |            |      |      | 0    | 0    | Disabled (Factory default)  |  |  |
| correction for<br>outdoor unit                                     | Main       | 0    | 6    | 0    | 1    | Increase fan speed  | Increase the outdoor unit's fan speed to maximum value   |  |
|  |            |      |      | 0    | 0    | Basic (Factory default)   |  |  |
|  |            |      |      | 0    | 1    | LEVEL 1 / Auto  | Enables the silent mode for  |  |
|  |            |      |      | 0    | 2    | LEVEL 2 / Auto  | night-time in cooling mode. (It operates automatically   |  |
| Silent mode for  |            |      | _    | 0    | 3    | LEVEL 3 / Auto  | depending on the   |  |
| night-time   | Main       | 0    | 7    | 0    | 4    | LEVEL 1 / External contact  | temperature.)  |  |
|  |            |      |      | 0    | 5    | LEVEL 2 / External contact  | However, if the external contact interface module(MIM-B14) is  |  |
|  |            |      |      | 0    | 6    | LEVEL 3 / External contact  | used, entering the silent mode<br>is available with contact signal<br>in cooling and heating mode.                     |  |
|  |            |      |      | 0    | 0    | Disabled (Factory default)  |  |  |
| High-head<br>condition   | Main       | 0    |      | 0    | 1    | Level 1 of height difference<br>type 1 (indoor unit is lower<br>than outdoor unit)                  | When outdoor unit is located 131~262ft (40~80m) above the indoor unit  |  |
| setting  | IVIAIII    | 0    | 8    | 0    | 2    | Not applicable  |  |  |
| J  |            |      |      | 0    | 3    | Height difference type 2<br>(outdoor unit is lower than<br>indoor unit)                             | When indoor unit is over 98ft (30m) above the outdoor unit   |  |
| Long-piping  |            |      |      | 0    | 0    | Disabled (Factory Default)  |  |  |
| condition<br>setting<br>(Setting is<br>unnecessary<br>if high-head | Main       | 0    | 9    | 0    | 1    | LEVEL 1   | When equivalent length of<br>farthest indoor unit from the<br>outdoor unit is over 328ft<br>(100m)                     |  |
| condition is set)  |            |      |      | 0    | 2    | Not applicable  |  |  |
|  |            |      |      | 0    | 0    | Disabled (Factory default)  |  |  |
| Energy saving setting  | Main       | 1    | 0    | 0    | 1    | Energy saving mode  | Energy saving mode triggers when the room temperature reaches desired temperature while operating in heating mode.     |  |
|  |            |      |      | 0    | 2    | Rapid cooling   | This function increases cooling speed.   |  |
| Unused option  | Main       | 1    | 1~2  | 0    | 0    | Unused option   | Unused option by this model  |  |
| Channel address  | Main       | 1    | 3    | Α    | U    | Automatic setting (factory default)   | Address for classifying the  |  |
| Chairner address   | ividili    | '    |      | 00 - | ~ 15 | Manual setting for channel<br>0 – 15  | product from upper level<br>controller(DMS,S-NET 3,etc.)   |  |
| Snow   |            |      |      | 0    | 0    | Enabled   | During snow accmulation , the  |  |
| accumulation<br>prevention<br>control                              | Main       | 1    | 4    | 0    | 1    | Disabled (Factory default)  | fan may spin even when the<br>unit is not in operation   |  |

| Optional item                  | Input unit | SEG1 | SEG2 | SEG3 | SEG4 | Function of the option   | Remarks   |
|--------------------------------|------------|------|------|------|------|--|---|
| Unused option                  | Main       | 1    | 5~7  | 0    | 0    | Unused option  | Unused option by this model   |
|                                |            |      |      | 0    | 0    | Enabled (Factory default)  | Restrict excessive capacity   |
| Max. capacity restriction      | Main       | 1    | 8    | 0    | 1    | Disabled   | increase when operating indoor units with small capacity                                      |
| Gas leak                       |            |      |      | 0    | 0    | Disabled (Factory default)                                       | If the gas leak occurred it   |
| pump down                      | Main       | 1    | 9    | 0    | 1    | Enabled  | should be entered in the pump down operation.   |
| Unused option                  | Main       | 2    | 0~1  | 0    | 0    | Unused option  | Unused option by this model   |
| Emergency                      |            |      |      | 0    | 0    | Disabled (Factory default)                                       |   |
| operation for                  |            |      |      | 0    | 1    | Indoor high humidity condition                                   | When set, emergency   |
| indoor unit                    | Main       | 2    | 2    |      | ·    | (operating for up to 12hours)                                    | operation is possible even if an indoor communication   |
| communication<br>error         |            |      |      | 0    | 2    | Indoor low humidity condition (operating for up to 24hours)      | error occurs.   |
|                                |            |      |      | 0    | 0    | Disabled (Factory default)                                       |   |
| Base Heater                    | Main       | 2    | 3    | 0    | 1    | Enabled  | Set when Base Heater is installed.  |
| Unused option                  | Main       | 2    | 4    | 0    | 0    | Unused option  | Unused option by this model   |
|                                |            |      |      | 0    | 0    | Not applied (Factory default)                                    |   |
| Aux Heater's                   |            |      |      | 0    | 1    | Switching delay to heating (30 mins.) When using the Aux Heater, |   |
| interworking control for cycle | Main       | 2    | 5    | 0    | 2    | Switching delay to heating (15 mins.)                            | set the delay time for switching from cooling to  |
| heating<br>(cooling priority   | Iviain     | 2    | 5    | 0    | 3    | Switching delay to heating (10 mins.)                            | heating.  ** Unused by the cooling  |
| control)                       |            |      |      | 0    | 4    | Switching delay to heating (5 mins.)                             | only models   |
|                                |            |      |      | 0    | 5    | No switching delay   |   |
|                                |            |      |      | 0    | 0    | Not applied (Factory default)                                    | With Thermo off for all   |
| Auto Change<br>Over            | Main       | 2    | 6    | 0    | 1    | Applied  | running indoor units, change<br>the operation mode.<br>※ Unused by the cooling<br>only models |
| Unused option                  | Main       | 2    | 7~8  | 0    | 0    | Unused option  | Unused option by this model   |
| View mode Unit                 |            |      |      | 0    | 0    | °C & MPa (Factory default)                                       | Converts the temperature,   |
| Option                         | Main       | 2    | 9    | 0    | 1    | °F & psi   | pressure units in the view mode (K4 switch)   |

## Setting outdoor unit option switch and key function

#### Setting key operation and checking the view mode with tact switch



| K1 Control            | KEY operation        | Display on segment      |
|-----------------------|----------------------|-------------------------|
| Press and hold 1 time | Auto trial operation | "K" "K" "BLANK" "BLANK" |

| K1(Number of press) | KEY operation                                 | Display on segment       |  |
|---------------------|---|--------------------------|--|
| 1 time              | Refrigerant charging in Heating mode (Note 1) | ""K" "1" "BLANK" "BLANK" |  |
| 2 times             | Trial operation in Heating mode (Note 1)      | "K" "2" "BLANK" "BLANK"  |  |
| 3 times             | Pump out in Heating mode (Note 1)             | "K" "3" "BLANK" "1"      |  |
| 4 times Vacuumig    |   | "K" "4" "BLANK" "1"      |  |
| 5 times             | End Key operation                             | _                        |  |

| K2(Number of press) | KEY operation   | Display on segment  |  |
|---------------------|---|---|--|
| 1 time              | Refrigerant charging in Cooling mode                                      | "K" "5" "BLANK" "BLANK"   |  |
| 2 times             | Trial operation in Cooling mode   | "K" "6" "BLANK" "BLANK"   |  |
| 3 times             | Pump down in Cooling mode   | "K" "7" "BLANK" "BLANK"   |  |
| 4 times             | Automatic setting of operation mode (Cooling/Heating) for trial operation | "K" "8" "BLANK" "BLANK"   |  |
| 5 times             | Checking the amount of refrigerant  | "K" "9" "X" "X"<br>(Display of last two digits may differ<br>depending on the progress) |  |
| 6 times             | Discharge mode of DC link voltage   | "K" "A" "BLANK" "BLANK"   |  |
| 7 times             | Forced defrost operation (Note 1)   | "K" "B" "BLANK" "BLANK"   |  |
| 8 times             | Forced oil collection   | "K" "C" "BLANK" "BLANK"   |  |
| 9 times             | Inverter compressor check   | "K" "D" "BLANK" "BLANK"   |  |
| 10 times            | Not applicable  | "K" "H" "BLANK" "BLANK"   |  |
| 11 times            | End Key operation   | -   |  |

(Note 1) Not available on AM\*\*\*TXMD\*C Series

- \* Even when the outdoor unit power is off, it is dangerous when you come in contact with inverter PCB since it is charged with high DC voltage.
- \* When replacing/repairing the PCB, cut-off the power and wait until the DC voltage is discharged before replacing/repairing them. (Wait for more than 15 minutes to allow it to discharge naturally.)
- \* When there were error, 'Dicharge mode of DC link voltage' may not have been effective. Especialy if error E464 has been occured, power element might be damaged by fire and therefore, do not use the 'Discharge mode of DC link voltage'.
- \* During "Discharge mode of DC link voltage", voltage of INV will be displayed.

| K3(Number of press)  | KEY operation                 |        | Display on segment                                 |                  |  |  |
|--|-------------------------------|--------|--|------------------|--|--|
| 1 time   | Intialize (Reset) settin      | g      | Same as initial state                              |                  |  |  |
| K4 (Press and hold for   |                               |        | Display on segment                                 |                  |  |  |
| 2 seconds to enter the<br>setting) → K4 press<br>(Number of press) | Displayed content             | Page 1 | Page 2   |                  |  |  |
| 1 time   | Main version MAIN             |        | Ver. (ex) 1412)                                    |                  |  |  |
| 2 times  | Inverter version              | INV1   | Ver. (ex) 1412)                                    |                  |  |  |
| 3 times  | EEP version                   | EEP    | Ver. (ex) 1412)                                    |                  |  |  |
|  |                               |        | SEG 1,2  | SEG 3,4          |  |  |
| 4 times  | Assigned address of the units | AUTO   | Indoor unit: "A" , "0"<br>HR Changer/MCU:"C" , "1" | Address (ex) 07) |  |  |
| 5 times  | Manually assigned address of  |        | SEG 1,2  | SEG 3,4          |  |  |
| o umes   | the units                     | MANU   | Indoor unit: "A", "0"                              | Address (ex) 15) |  |  |

# Setting outdoor unit option switch and key function


| K4(Number | VEV  |       | Display on segment   |
|-----------|--|-------|--|
| of press) | KEY operation  | SEG 1 | SEG2, 3, 4   |
| 1 time    | Outdoor unit capacity (HP)   | 1     | 5 HP → 0, 0, 5   |
| 2 times   | Order frequency of compressor  | 2     | 120 Hz → 1, 2, 0   |
| 3 times   | High pressure  | 3     | 1.52 MPa → 1, 5, 2 / 220 psi → 2, 2, 0   |
| 4 times   | Low pressure   | 4     | 0.43 MPa → 0, 4, 3 / 62 psi → 0, 6, 2  |
| 5 times   | Discharge temperature of compressor  | 5     | 87 °C →0, 8, 7 / 189 °F → 1, 8, 9  |
| 6 times   | IPM temperature of compressor  | 6     | 87 °C →0, 8, 7 / 189 °F → 1, 8, 9  |
| 7 times   | CT sensor value of compressor  | 7     | 2 A → 0, 2, 0  |
| 8 times   | Suction temperature  | 8     | -42 °C → -, 4, 2 / -44 °F → -, 4, 4  |
| 9 times   | COND OUT temperature   | 9     | -42 °C → -, 4, 2 / -44 °F → -, 4, 4  |
| 10 times  | Liquid pipe temperature  | А     | 87 °C →0, 8, 7 / 189 °F → 1, 8, 9  |
| 11 times  | TOP temperature of compressor  | В     | 87 °C →0, 8, 7 / 189 °F → 1, 8, 9  |
| 12 times  | Outdoor temperature  | С     | -42 °C → -, 4, 2 / -44 °F → -, 4, 4  |
| 13 times  | EVI inlet temperature  | D     | -42 °C → -, 4, 2 / -44 °F → -, 4, 4  |
| 14 times  | EVI outlet temperature   | E     | -42 °C → -, 4, 2 / -44 °F → -, 4, 4  |
| 15 times  | Main EEV step  | F     | 2000 steps → 2, 0, 0   |
| 16 times  | EVI EEV step   | G     | 300 steps → 3, 0, 0  |
| 17 times  | Fan step   | Н     | 13 steps → 0, 1, 3   |
| 18 times  | Current frequency of compressor  | I     | 120 Hz → 1, 2, 0   |
| 19 times  | Master indoor unit address<br>(Master indoor unit can be selected by<br>wired remote-controller) | J     | Master indoor unit not seleted $\rightarrow$ BLANK , N , D If indoor unit No.1 is seleted as the master unit $\rightarrow$ 0 , 0 , 1 |
| 20 times  | MCU's side EEV open degree   | К     | 300 steps → 3, 0, 0  |
| 21 times  | End Key operation  |       | -  |

### Things to check after completing the installation

- 1. Before supplying the power, use DC 500 V insulation resistance tester to measure the power (3 phase: R, S, T/1 phase: L, N) terminal and the outdoor unit grounding.
  - Measurement should be over  $30M\Omega$ .
- 2. Before supplying the power, use a voltmeter and phase tester to check the voltage and the phase.
  - R, S, T, N terminal: check if the voltage is within 380-415 V between wires (R-S, S-T, T-R) and 200-240 V between phases (R-N, S-N, T-N) before turning on the switch.
  - L, N terminal: Voltage 220-240V



- · Never measure the communication terminal since communication circuit may get damaged.
- Check for short-circuit of the communication terminal with a general circuit tester.



- 3. Check if the R-410A indoor units are connected.
- 4. When N phase is not correctly connected to R, S and T phase, over-voltage protection control will be in effect and it will cut-off the power of the PCB. Check the power cable connection of the N phase if the PCB is not turned on.
- 5. Check the following after the installation is completed.

# Things to check after completing the installation

| Installation<br>work   | Outdoor<br>unit<br>Indoor<br>unit | <ul> <li>Have you checked the external surface and the inside of the outdoor unit?</li> <li>Is there any possibility of short-circuit caused by the heat of an outdoor unit?</li> <li>Is the place well-ventilated and ensures space for service?</li> <li>Is the outdoor unit fixed securely to withstand any external force?</li> <li>Have you checked the external surface and the inside of the indoor unit?</li> <li>Is there enough space for service?</li> <li>Have you checked if the center of the indoor unit is ensured and it is installed horizontally?</li> </ul>  |  |  |  |  |
|------------------------|-----------------------------------|--|--|--|--|--|
| Refrigerant (          | pipe work                         | <ul> <li>Have you selected correct pipes?</li> <li>Are the liquid and gas valve open?</li> <li>Is the total number of connected indoor units within the allowable range?</li> <li>Are the length and the height difference between the refrigerant pipes within the allowable range?</li> <li>Are the branch joints properly installed?</li> <li>Did you check the connection of liquid and gas pipes?</li> <li>Have you selected correct insulator for pipes and insulated them correctly?</li> <li>Dld you insulate the pipes and connection part correctly?</li> <li>Is the quantity of the additional refrigerant correctly weighed in? (You must record the amount of additional refrigerant on the service record paper placed inside of the outdoor unit.)</li> </ul> |  |  |  |  |
| Drain pipe work        |                                   | <ul> <li>Have you checked if the drain pipes of the indoor and outdoor unit are connected together?</li> <li>Have you completed the drain test?</li> <li>Is the drain pipe properly insulated?</li> </ul>  |  |  |  |  |
| Electrical wiring work |                                   | <ul> <li>Are the power cable and communication cable tightened firmly on the terminal board within the range of rated tightening torque?</li> <li>Have you checked for cross-connection of the power and communication cables?</li> <li>Have you performed the earthing work 3 to the outdoor unit?</li> <li>Did you make sure to use 2-core cable (not multi-core cable) for the communication cable?</li> <li>Is the length of the wire within allowed range?</li> <li>Is the wiring route correct?</li> </ul>   |  |  |  |  |
| Setting address        |                                   | <ul> <li>Did you set the address of the indoor and outdoor units properly?</li> <li>Did you set the address of the indoor and outdoor units properly? (When using multiple remote controllers)</li> </ul>  |  |  |  |  |
| Option                 |                                   | If there is a possibility of the outdoor unit from vibrating, check whether the anti-vibration frame is correctly installed.   |  |  |  |  |

### Inspection & trial operation



#### Precautions before test operation

- When the outdoor temperature is low, turn on the main power 6 hours before beginning the operation.
  - If you start the operation immediately after turning on the main power, it may cause serious damage to the part within the product.
- Do not touch the refrigerant pipe during or right after the operation.
  - Refrigerant pipe may be hot or cold during or right after the operation depending on the status of the
    refrigerant which flows through the refrigerant pipe, compressor and other parts of the refrigerant cycle.
- Do not operate the product with its panel or protection nets off.
  - There is risk of personal injury from the parts that rotates, heated or with the high voltage.
- Do not turn off the main power immediately after stopping the operation.
  - Wait for at least 5 minutes before turning off the main power. If not, water leakage or other problems may occur.

#### Checklist before auto trial operation


- 1. Check the power cable and communication cable of the indoor and outdoor unit.
- Supply power to the outdoor unit 6 hours (AM100/120/140KXMDGH\*, AM100/120BXMWGH\*)/3 hours (AM040/050KXMDEH\*, AM040/050BXMDEH\*) before trial operation to pre-heat the crank case heater.
- 3. Before supplying the power, use a voltmeter and phase tester to check the voltage and the phase.
  - R, S, T, N terminal: check if the voltage is within 380 -415 V between wires (R-S, S-T, T-R) and 200-240 V between phases (R-N, S-N, T-N).
  - L,N terminal: 220-240V between power lines
- 4. When the power is supplied, outdoor unit will execute tracking to check the indoor unit connection and other optional functions.
- 5. Write down the installation report on the service history report paper attached on the front part of the control box.



• Supply power to the outdoor unit 6 hours (AM100/120/140KXMDGH\*, AM100/120BXMWGH\*) / 3 hours (AM040/050KXMDEH\*, AM040/050BXMDEH\*) before auto trial operation to pre-heat the crank case heater.

6. Guaranteed range of auto trial operation

For precise judgment, you must perform auto trial operation in below indoor/outdoor temperature condition.



- In Auto trial operation, product will automatically select either cooling or heating mode and operate in selected mode.
- AM\*\*\*FXM\*\*C (Cooling Only) models operate only cooling mode in Auto trial operation.
   (Cooling only models don't operate Auto trial operation in case of outdoor temperature below -5°C or indoor temperature below 5°C)
- In the temperature range marked with slashed pattern, system protection control may trigger during operation.(If the system protection control is enabled, it can be hard to get the precise judgment after the auto trial operation.)
- When the temperature is outside of guaranteed range, accuracy of judgment on auto trial operation may decrease near boarder line area.

### Inspection & trial operation


## Auto trial operation

- 1. If the Auto Trial Operation is not completed, normal operation will be prohibited.
  - When the auto trial operation is not completed, UP (UnPrepared) will appear on the segment after the communication check and restrict compressor from operating. (UP Mode will be cleared automatically when auto trial mode is completed.)
  - Auto trial operation may take 20 minutes to maximum 2 hours depending on the operation status.
  - During auto trial operation, noise can be generated due to vavle inspection. (Check the product if abnormal noise occurs continously)
- 2. When error occurs during auto trial operation, check the error code and take appropriate measures.
  - Refer to next page when E503 error occurs.
  - Refer to service manual if you need inspection or when other errors occur.
- 3. When auto trial operation ends, use S-NET pro 2 or S-CHECKER to issue a result report.
  - Refer to service manual for further actions if you have any items with "inspection required" sign on the result report.
  - After taking appropriate measure for the items with "inpection required" sign, run the auto trial operation again.
- 4. Check the following items by running trial operation (cooling/heating).
  - Check if cooling/heating operation performs normally.
  - Individual indoor unit control: Check for air flow direction and fan speed.
  - Check for abnormal operation noise from the indoor and outdoor unit.
  - Check for proper draining from the indoor unit during cooling operation.
  - Use S-NET pro 2 to check the detail operation status.
- 5. Explain to the user how to use the air conditioner according to the user's manual.
- 6. Hand over the installation manual to the customer so they can keep it with them.



 Make sure to close the outdoor unit cabinet during operation. If you operate the unit with the front cabinet open, it may cause damage to the product.

#### Measure to take when E503 error occurs




- \* Symptoms for abnormal operation of the 4way valve
  - Refrigerant noise is increased while compressor operatres and suction temperature remains over 20°C compared to low pressure's saturation temperature.
  - Temperature of Eva. in/out remains below 0 °C during heating operation.
- \* Symptoms for abnormal operation of the Main EEV
  - Error on controlling degree of superheat of compressor inlet during heating operation.
    - : If there's operation error while the EEV is fully opened, suction superheat cannot be secured (below 0  $^{\circ}$ C) and discharge temperature of the compressor will be low. (DSH is below 10 $^{\circ}$ C)
    - : If there's operation error while the EEV is fully closed, low pressure will decrease and suction superheat will increase excessively.



- If the service valve need to be detected, auto detection mode will end. Check both gas pipe and liquid pipe service valves when detecting service valve.
- When 4way valve, Main EEV detection is needed, run heating trial operation for more than 1 hour and analyze the data to check for a problem.
- If there's frost formed in outdoor unit or the outdoor unit is operating in deforst operation, it may be hard to detect problem normally. In this case, run heating trial operation for more than 1 hour.
- · If the opreation range is not within guaranteed range, error may occur even though the product is normal.

## Automatic refrigerant amount detection function

This function checks amount of refrigerant in the system through refrigerant amount detection operation.





- If the temperature is out of the guaranteed range below, exact result will not be obtained.
  - Indoor: 20~32 °C
  - Outdoor: 5~43 °C
- If the operation cycle is not stable, the operation of refrigerant amount check may be forcibly finished.
- Accuracy of the result may decrease if the product has not been operated for a long period of time or heat
  mode has been operated before running the function of refrigerant amount check. Therefore, use the
  function of refrigerant amount check after operating the product in cool mode for at least 30 minutes.
- Product may trigger system protection operation depending on the installation environment. In this case, the result of refrigerant amount check may not be accurate.

#### Actions to take for the check result

- · Excessive amount of refrigerant
  - Discharge 10% of total amount of refrigerant and restart the refrigerant amount check.
- · Insufficient amount of refrigerant
  - Add 10% of the total amount of refrigerant and restart the refrigerant amount check.
- · Judgment not available
- Check if the function of refrigerant amount check is executed within the guaranteed temperature range. Run trial operation to check if there are other problems on the system.

### Model specification (Dimension and weight)

| Dimension and weight |                 |                  |      |  |  |  |  |
|----------------------|-----------------|------------------|------|--|--|--|--|
| Туре                 | Net weight (kg) |                  |      |  |  |  |  |
|                      | AM100KXMDGH/EU  | 940 x 460 x 1630 | 145  |  |  |  |  |
|                      | AM120KXMDGH/EU  | 940 x 460 x 1630 | 155  |  |  |  |  |
|                      | AM140KXMDGH/EU  | 940 x 460 x 1630 | 162  |  |  |  |  |
|                      | AM040KXMDEH/EU  | 940 x 330 x 998  | 79   |  |  |  |  |
| Outdoor unit         | AM050KXMDEH/EU  | 940 x 330 x 998  | 83.5 |  |  |  |  |
| Outdoor unit         | AM030RXMDEH/EU  | 940 x 330 x 998  | 79   |  |  |  |  |
|                      | AM040BXMDEH/EU  | 940 x 330 x 998  | 79   |  |  |  |  |
|                      | AM050BXMDEH/EU  | 940 x 330 x 998  | 83.5 |  |  |  |  |
|                      | AM100BXMWGH/EU  | 940 x 460 x 1630 | 155  |  |  |  |  |
|                      | AM120BXMWGH/EU  | 940 x 460 x 1630 | 162  |  |  |  |  |

## **SAMSUNG**

Samsung, PO Box 12987, Blackrock, Co. Dublin. IE or Euro QA Lab. Saxony Way, Yateley, Hampshire GU46 6GG, UK







## Installation manual

AM\*\*\*\*XMDG / AM\*\*\*\*XMDE / AM\*\*\*XMWG Series

- Thank you for purchasing this Samsung air conditioner.
- Before operating this unit, please read this manual carefully and retain it for future reference.

SAMSUNG