
Order No: PAPAMY1711007CE

# Service Manual Air-to-Water Heatpump

Mono Bloc Unit WH-MDC12H6E5 WH-MDC16H6E5

> Destination Europe Turkey



## 

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the products dealt with in this service information by anyone else could result in serious injury or death.

### A PRECAUTION OF LOW TEMPERATURE

In order to avoid frostbite, be assured of no refrigerant leakage during the installation or repairing of refrigerant circuit.



© Panasonic Corporation 2017.

## TABLE OF CONTENTS

#### PAGE

| 1.     | Safety Precautions  |          |
|--------|---|----------|
| 2.     | Specifications  | .6       |
| _      | 2.1 WH-MDC12H6E5<br>2.2 WH-MDC16H6E5  |          |
| 3.     | Features  | 12       |
| 4.     | Location of Controls and Components   | 13       |
| 4      | 1 Indoor Unit   | 13       |
| 5.     | Dimensions  | 37       |
| 5      | 5.1 Mono Bloc Unit  | 37       |
| 6.     | Refrigeration and Water Cycle Diagram   | 88       |
| -      | <ul> <li>Standard System</li> <li>(Optional PCB not connected)</li> <li>Advance System</li> </ul> |          |
| _      | (Optional PCB connected)  |          |
| 7.     | Block Diagram   | 10       |
| 8.     | Wiring Connection Diagram   |          |
| -      | 3.1       Water System  | 11<br>12 |
| 9.     | Electronic Circuit Diagram  | 13       |
| -      | 0.1 Water System  |          |
| 10.    | Printed Circuit Board   | 15       |
|        | 0.1 Water System       4         0.2 Refrigerant System       4                                   |          |
| 11.    | Installation Instruction  | 19       |
| 1<br>1 | 1.1       Mono Bloc Unit  | 60<br>67 |
| 12.    | Operation and Control   | 31       |
| 1      | 2.1 Basic Function  | 31       |
| 1      | 2.2 Water Pump  | 91       |
| 1      | <ul><li>2.3 Indoor Unit Safety</li></ul>  | 94       |
|        | 2.5 Indication Panel  |          |
|        | 2.6 Indoor Back-Up Heater Control   |          |
| -      | 2.7 Tank Heater Control   |          |
|        | <ul><li>2.8 Base Pan Heater Control (Optional)</li></ul>  | 98       |
|        | 2.10 Powerful Operation   |          |
| 1      | 2.11 Quiet Operation10  | )0       |
|        | 2.12 Sterilization Mode   |          |
|        | 2.13 Outdoor Ambient Thermo OFF Control10<br>2.14 Alternative Outdoor Ambient Sensor<br>Control   |          |
| 1      | 2.15 Force DHW mode   |          |
| 1      | 2.16 Anti Freeze Control10  | )3       |
|        | 2.17 Solar Operation (Optional)10<br>2.18 Boiler Bivalent Control                                 |          |

| 12.20<br>12.22<br>12.23<br>12.24<br>12.24<br>12.25<br>12.26<br>12.25<br>12.25 | External Room Thermostat Control<br>(Optional)107Three Ways Valve Control108Two Ways Valve Control108External OFF/ON Control109External Compressor Switch<br>(Optional PCB)110Heat/Cool Switch (Optional PCB)110SG Ready Control (Optional PCB)111Demand Control (Optional PCB)112Holiday Mode113Dry Concrete113Flow Sensor113 |
|---|--|
|   | otection Control 114   |
|   | Protection Control for All Operations 114<br>Protection Control for Heating  |
| 13.3  | Operation  |
| 14. Sei   | vicing Mode  |
| 14.1  |  |
| 14.2<br>14.3<br>14.4<br>14.5<br>14.6  | Checking119Maintenance119Pump Down Procedures120How To Adjust Pump Speed121How To Adjust Pump Speed122How To Unlock Cool Mode123   |
| 14.7  | EEPROM Factory Default Data Setup<br>Procedure   |
| 14.8  | Dry Concrete Setup 125 intenance Guide 127   |
|   |  |
|   | Maintenance Menu   |
|   | bubleshooting Guide 130  |
| 16.2<br>16.3<br>16.4  | Refrigeration Cycle System130Relationship between the Condition of theAir-to-Water Heatpump Indoor andOutdoor Units and Pressure and ElectricCurrent131Breakdown Self Diagnosis Function132Error Codes Table134Self-diagnosis Method136  |
| 17. Dis   | assembly and Assembly Instructions 188   |
| 17.1  | To Remove The Cabinet Front Plate 188  |
| 17.2  | To Remove The Cabinet Top Plate  |
|   | To Remove The Cabinet Rear Plate 189<br>To Remove Pressure Gauge   |
|   | To Remove Water System Electronic<br>Controller Board  |
| 17.6  | To Remove Air Purge Valve  |
| 17.7<br>17.9  | To Remove Flow Sensor  |
|   | To Remove Heater 193   |

PAGE

| 18. Teo                                 | chnical Data  | 195 |  |  |  |
|---|---|-----|--|--|--|
|   | Operation Characteristics<br>Heating Capacity Table |     |  |  |  |
|   | Cooling Capacity Table                              |     |  |  |  |
| 19. Exploded View and Replacement Parts |   |     |  |  |  |
|   | •   |     |  |  |  |
|   | bloded View and Replacement Parts                   | 200 |  |  |  |

## 1. Safety Precautions

- Read the following "SAFETY PRECAUTIONS" carefully before installation of (Mono bloc) Air-to-Water Heatpump system (hereafter referred to as "Mono bloc unit").
- Electrical works and water installation works must be done by licensed electrician and licensed water system installer respectively. Be sure to use the correct rating and main circuit for the model to be installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below.

Incorrect installation due to ignorance or negligence of the instructions will cause harm or damage, and the seriousness is classified by the following indications.

| MARNING         This indication shows the possibility of causing death or serious injury. |   |
|---|---|
|   | This indication shows the possibility of causing injury or damage to properties only. |

The items to be followed are classified by the symbols:

| $\bigcirc$ | Symbol with white background denotes item that is PROHIBITED from doing. |
|------------|--|
| 00         | Symbol with dark background denotes item that must be carried out.       |

- Carry out test run to confirm that no abnormality occurs after the installation. Then, explain to user the operation, care and
  maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.
- If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.

| 1.  | Do not install Mono bloc unit near handrail of veranda. When installing Mono bloc unit at veranda of high rise building, child may climb up to Mono bloc unit and cross over the handrail and causing accident.   | $\bigcirc$ |
|-----|---|------------|
| 2.  | Do not use unspecified cord, modified cord, join cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire.  | $\bigcirc$ |
| 3.  | Do not tie up the power supply cord into a bundle by band. Abnormal temperature rise on power supply cord may happen.   | $\bigcirc$ |
| 4.  | Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury.  | $\bigcirc$ |
| 5.  | Do not sit or step on the unit, you may fall down accidentally.   | $\bigcirc$ |
| 6.  | Keep plastic bag (packaging material) away from small children, it may cause suffocation.   | $\bigcirc$ |
| 7.  | Do not use pipe wrench to install refrigerant pipe. It might deform the piping and cause the unit to malfunction.   | $\bigcirc$ |
| 8.  | Do not purchase unauthorized electrical parts for installation, service, maintenance and etc They might cause electrical shock or fire.   | $\bigcirc$ |
| 9.  | This unit is a multi supply appliances. All circuits must be disconnected before accessing to the unit terminals.   | $\bigcirc$ |
| 10. | Do not modify the wiring of Mono bloc unit for installation of other components (i.e. heater, etc). Overloaded wiring or wire connection points may cause electrical shock or fire.   | $\bigcirc$ |
| 11. | Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury etc.   | $\bigcirc$ |
| 12. | For electrical work, follow the local national wiring standard, regulation and this installation instruction. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in electrical work, it will cause electrical shock or fire. | 0          |
| 13. | For water circuit installation work, follow to relevant European and national regulations (including EN61770) and local plumbing and building regulation codes.   | 0          |
| 14. | Must engage an authorized dealer or specialist for installation. If installation is defective, it will cause water leakage, electrical shock or fire.   | 0          |
| 15. | Install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electrical shock or fire.  | 0          |
| 16. | Only use the supplied or specified installation parts. Else, it may causes Mono bloc unit vibrate, fall, water leakage, electrical shock or fire.   | 0          |
| 17. | Install at a flat, strong and firm location which is able to withstand the Mono bloc unit's weight. If the location is slanting, or strength is not enough the set will fall and cause injury.  | 0          |
| 18. | This equipment is strongly recommended to be installed with Residual Current Device (RCD) on-site according to the respective national wiring rules or country-specific safety measures in terms of residual current.   | 0          |
| 19. | The unit is only for use in a closed water system. Utilization in an open water system may lead to excessive corrosion of the water piping and risk of incubating bacteria colonies, particularly Legionella, in water.   | 0          |
| 20. | If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.   | 0          |
| 21. | Select a location where in case of water leakage, the leakage will not cause damage to other properties.  | 0          |

| 22. | When installing electrical equipment at wooden building of metal lath or wire lath, in accordance with electrical facility standard, no electrical contact between equipment and building is allowed. Insulator must be installed in between.  | 0          |
|-----|--|------------|
| 23. | This installation may be subjected to building regulation approval applicable to respective country that may require to notify the local authority before installation.  | 0          |
| 24. | Any work carried out on the Mono bloc unit after removing the front panel which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor.   | 0          |
| 25. | This unit must be properly earthed, the electrical earth must not be connected to a gas pipe, water pipe, the earth of a lightning rod or a telephone. Otherwise there is a danger of electrical shock in the event of an insulation breakdown or electrical earth fault in the Mono bloc unit.  | 0          |
|     |  |            |
|     |  |            |
| 1.  | Do not install the Mono bloc unit in areas where there is a risk of flammable gas leakage. There is a risk of fire if flammable gas accumulates near or around the Mono bloc unit.   | $\bigcirc$ |
| 2.  | Do not release refrigerant during piping work for installation, re-installation and during repairing a refrigeration parts. Take care of the liquid refrigerant, it may cause frostbite.   | $\bigcirc$ |
| 3.  | Make sure the power supply cord does not contact with hot part (i.e. water piping). High temperature may cause insulator of power supply cord damage hence electrical shock or fire.   | $\bigcirc$ |
| 4.  | Do not touch the sharp aluminium fin, sharp parts may cause injury. 🚳  | $\bigcirc$ |
| 5.  | Do not apply excessive force to water pipes that may damage the pipes. If water leakage occurs, it will cause flooding and damage to other properties.   | $\bigcirc$ |
| 6.  | Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water leakage may happen and may cause damage to properties of the user.  | 0          |
| 7.  | The piping installation work must be flushed before the Mono bloc unit is connected to remove contaminants. Contaminants may damage the Mono bloc unit components.   | 0          |
| 8.  | Select an installation location where it is accessible for maintenance.  |            |
| 9.  | <ul> <li>Power supply connection to Mono bloc unit.</li> <li>Power supply point should be in easily accessible place for power disconnection in case of emergency.</li> <li>Must follow local national wiring standard, regulation and this installation instruction.</li> <li>Strongly recommended to make permanent connection to a circuit breaker. It must be a double pole switch with a minimum 3.0 mm gap.</li> <li>Power supply 1: Use approved 30A circuit breaker</li> <li>Power supply 2: Use approved 30A circuit breaker</li> </ul> | 0          |
| 10. | Ensure the correct polarity is maintained throughout all wiring. Otherwise, it will cause electrical shock or fire.  | 0          |
| 11. | After installation, the installer is obliged to verify correct operation of the Mono bloc unit. Check the connection point for water leakage during test run. If leakage occurs, it will cause damage to other properties.   | 0          |
| 12. | Installation work.<br>Four or more people are required to carry out the installation work. The weight of Mono bloc unit might cause injury if carried by less<br>than four people.   | 0          |

## 2. Specifications

## 2.1 WH-MDC12H6E5

|                            | Item                   | Unit                                       |  | Refrigerant System |            |
|----------------------------|------------------------|--|--|--------------------|------------|
| Performance Test Condition |                        |  | EN 14511   |                    |            |
|                            |                        | Condition<br>(Ambient/Water)               |  | A35W7              |            |
| Cooling Capacity           |                        | kW   |  | 10.00              |            |
|                            |                        | BTU/h                                      | 34100  |                    |            |
|                            |                        | kcal/h                                     | 8600   |                    |            |
|                            |                        | W/W  | 2.81   |                    |            |
| Cooling EER                |                        | kcal/hW                                    |  | 2.42               |            |
|                            |                        | Condition<br>(Ambient/Water)               | A7W35  |                    | A2W35      |
| Heating Capacity           |                        | kW   | 12.00  |                    | 4.80       |
| ricating Capacity          |                        | BTU/h                                      | 41000  |                    | 38900      |
|                            |                        | kcal/h                                     | 10320  |                    | 9800       |
|                            |                        | W/W  | 4.74   |                    | 3.44       |
| Heating COP                |                        | kcal/hW                                    | 4.08   |                    | 2.96       |
|                            | Low Temperature Appl   | ication (W35)                              |  |                    | 0.11       |
|                            | Application            | Climate                                    | Warmer   | Average            | Colder     |
| 1                          | Pdesign                | kW   | 11.0   | 10.0               | 11.0       |
|                            | Tbivalent / TOL        | °C   | 2/2  | -10 / -10          | -15 / -22  |
|                            | SCOP / ns              | (W/W) / %                                  | 6.21 / 245   | 4.82 / 190         | 4.29 / 168 |
|                            | Annual Consumption     | kWh  | 2368   | 4286               | 6327       |
|                            | Class                  |  | A++  | A++                | A++        |
| Heating ErP                | Medium Temperature Ap  | plication (W55)                            |  |                    |            |
|                            | Application            | Climate                                    | Warmer   | Average            | Colder     |
|                            | Pdesign                | kW   | 9.0  | 8.0                | 9.0        |
|                            | Tbivalent / TOL        | °C   | 2/2  | -10 / -10          | -15 / -22  |
|                            | SCOP / ns              | (W/W) / %                                  | 4.05 / 159   | 3.42 / 134         | 3.10 / 121 |
|                            | Annual Consumption     | kWh  | 2970   | 4840               | 7147       |
|                            | Class                  |  | A++  | A++                | A+         |
|                            |                        | Condition<br>(Ambient/Water)               | A35W7  | A7W35              | A2W35      |
| Noise Level                |                        | dB (A)                                     | Cooling: 50  | Heating: 52        | -          |
|                            |                        | Power Level dB                             | Cooling: 68  | Heating: 69        | -          |
| Air Flow                   |                        | m <sup>3</sup> /min (ft <sup>3</sup> /min) | Cooling: 93.3 (3290)<br>Heating: 80.0 (2830)                         |                    |            |
| Refrigeration Cont         | rol Device             |  |  | Expansion Valve    |            |
| Refrigeration Oil          |                        | cm <sup>3</sup>                            |  | FV50S (1200)       |            |
| Refrigerant (R410/         | A)                     | kg (oz)                                    |  | 2.1 (74.1)         |            |
| F-GAS                      | GWP                    |  | 2088   |                    |            |
| 1 0/10                     | CO2eq (ton) (Precharge | ed / Maximum)                              |  | 4.385 / -          |            |
|                            | Туре                   |  | Hermetic Motor   |                    |            |
| Compressor                 | Motor Type             |  | Brushless (4-poles)  |                    |            |
|                            | Rated Output           | kW   | 3.00   |                    |            |
|                            | Туре                   |  |  | Propeller Fan      |            |
|                            | Material               |  | PP   |                    |            |
| <b>F</b> an                | Motor Type             |  |  | DC (8-poles)       |            |
| Fan                        | Input Power            | W  |  | -                  |            |
|                            | Output Power           | W  | 60   |                    |            |
|                            | Fan Speed              | rpm  | Cooling: 600 (Top), 640 (Bottom)<br>Cooling: 520 (Top), 640 (Bottom) |                    |            |

|   | ltem                                  | Unit            | Refrigerant System |                       |               |  |  |
|---|---------------------------------------|-----------------|--------------------|-----------------------|---------------|--|--|
|   | Fin material                          |                 |                    | Aluminium (Pre Coat)  |               |  |  |
| Liest Eveloperat  | Fin Type                              |                 | Corrugated Fin     |                       |               |  |  |
| Heat Exchanger  | Row × Stage × FPI                     |                 |                    | 2 × 51 × 18           |               |  |  |
|   | Size (W × H × L)                      | mm              |                    | 903.7 × 1295.4 × 38.1 |               |  |  |
|   | Power Source (Phase, Voltage, Cycle)  |                 |                    | Single                |               |  |  |
| Power Source (Pha                                       |                                       |                 | 230                |                       |               |  |  |
|   |                                       | Hz              | 50                 |                       |               |  |  |
| Input Power   | Input Power                           |                 | A35W7              | A7W35                 | A2W35         |  |  |
|   |                                       | kW              | Cooling: 3.56      | Heating: 2.53         | Heating: 3.31 |  |  |
| Maximum Input Po  | wer For Heatpump System               | kW              | 5.30               |                       |               |  |  |
| Power Supply 1 : Phase (Ø) / Max. Current (A) / Max. Ir |                                       | Input Power (W) | 1Ø / 24.0 / 5.30k  |                       |               |  |  |
| Power Supply 2 : Phase (Ø) / Max. Current (A) / Max. Ir |                                       | Input Power (W) | 1Ø / 26.0 / 6.00k  |                       |               |  |  |
| Power Supply 3 : F                                      | Phase (Ø) / Max. Current (A) / Max. I | Input Power (W) | -/-/-              |                       |               |  |  |

|   | Item                   | Unit                         | Mono Bloc Unit     |               |               |  |
|---|------------------------|------------------------------|--------------------|---------------|---------------|--|
| Starting Current  |                        | А                            | 16.2               |               |               |  |
| Running Current   |                        | Condition<br>(Ambient/Water) | A35W7              | A7W35         | A2W35         |  |
| 5   |                        | А                            | Cooling: 16.2      | Heating: 11.7 | Heating: 15.0 |  |
| Maximum Curre   | nt For Heatpump System | А                            | 24.0               |               |               |  |
| Power Factor<br>Power factor means total figure of compressor and<br>outdoor fan motor. |                        | %                            | Cooling: 96        | Heating: 94   | Heating: 96   |  |
|   | Height                 | mm (inch)                    | 1410 (55-1/2)      |               |               |  |
| Dimension   | Width                  | mm (inch)                    | 1283 (50-1/2)      |               |               |  |
|   | Depth                  | mm (inch)                    | 320 (12-19/32)     |               |               |  |
| Net Weight  | L                      | kg (lbs)                     | 140 (309)          |               |               |  |
|   | Number of core         |                              | -                  |               |               |  |
| Power Cord  | Length                 | m (ft)                       | -                  |               |               |  |
| Thermostat  |                        |                              | Electronic Control |               |               |  |
| Protection Device   |                        |                              | Electronic Control |               |               |  |

| Item                        |                  | Unit                      | Water System                               |
|-----------------------------|------------------|---------------------------|--|
| Performance Test Conc       | dition           |                           | EN 14511                                   |
| Operation Range             | Outdoor Ambient  | °C                        | Cooling: 16 ~ 43<br>Heating: -20 ~ 35      |
| Operation Range             | Water Outlet     | °C                        | Cooling: 5 ~ 20<br>Heating: 20 ~ 55        |
| Internal Pressure Different | ential           | kPa                       | Cooling: 36.0<br>Heating: 51.0             |
| Water Pipe Connector (      | (in.)            |                           | (1-1/4)                                    |
| Water Drain Hose Inner      | Diameter         | mm (inch)                 | 15.0 (19/32)                               |
| Dum                         | Motor Type       |                           | DC Motor                                   |
| Pump                        | Input Power      | W                         | 80   |
|                             | Туре             |                           | Brazed Plate                               |
|                             | No. of Plates    |                           | 36   |
| Hot Water Coil              | Size (W × H × L) | mm                        | 65 × 120 × 376                             |
|                             | Water Flow Rate  | l/min (m <sup>3</sup> /h) | Cooling: 28.7 (1.7)<br>Heating: 34.4 (2.1) |
| Pressure Relief Valve V     | Vater Circuit    | kPa                       | Open: 300, Close: 266 and below            |
| Flow Switch                 |                  |                           | Electronic Sensor                          |
| Protection Device           |                  | A                         | Residual Current Circuit Breaker (40)      |
|                             | Volume           | I                         | 10   |
| Expansion Vessel            | MWP              | bar                       | 3  |
| Capacity of Integrated E    | Electric Heater  | kW                        | 6.00                                       |

#### Note:

 Cooling capacities are based on outdoor air temperature of 35°C Dry Bulb with controlled indoor water inlet temperature of 12°C and water outlet temperature of 7°C.

Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled indoor water inlet temperature of 30°C and water outlet temperature of 35°C.

• Specification are subjected to change without prior notice for further improvement.

 Flow rate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and =5°C

## 2.2 WH-MDC16H6E5

|                            | ltem                  | Unit                                       |  | Refrigerant System                           |            |
|----------------------------|-----------------------|--|--|--|------------|
| Performance Test Condition |                       |  | EN 14511   |  |            |
|                            |                       | Condition<br>(Ambient/Water)               | A35W7  |  |            |
| Cooling Capacity           |                       | kW   |  | 12.20  |            |
|                            |                       | BTU/h                                      | 41600  |  |            |
|                            |                       | kcal/h                                     | 10490  |  |            |
|                            |                       | W/W  |  | 2.56   |            |
| Cooling EER                |                       | kcal/hW                                    | 2.30   |  |            |
|                            |                       | Condition                                  | A7W35  |  | A2W35      |
|                            |                       | (Ambient/Water)<br>kW                      | 16.00  |  | 13.00      |
| Heating Capacity           | ,                     | BTU/h                                      | 54600  |  | 44300      |
|                            |                       | kcal/h                                     | 13760  |  | 11180      |
|                            |                       | W/W  | 4.28   |  | 3.28       |
| Heating COP                |                       | kcal/hW                                    | 3.68   |  | 2.82       |
|                            | Low Temperature App   |  | 3.08   | <u> </u>                                     | 2.02       |
|                            | Application           | Climate                                    | Warmer   | Average                                      | Colder     |
|                            | Pdesign               | kW   | 13.0   | 12.0   | 12.0       |
|                            | Tbivalent / TOL       | °C   | 2/2  | -10 / -10                                    | -15 / -22  |
|                            | SCOP / ns             | (W/W) / %                                  | 6.20 / 245   | 4.82 / 190                                   | 4.28 / 168 |
|                            | Annual Consumption    | kWh  | 2801   | 5146   | 6911       |
|                            | Class                 |  | A++  | A++  | A++        |
| Heating ErP                | Medium Temperature A  | onlication (W55)                           | 7.1.1  |  |            |
|                            | Application           | Climate                                    | Warmer   | Average                                      | Colder     |
|                            | Pdesign               | kW   | 10.0   | 13.0   | 10.0       |
|                            | Tbivalent / TOL       | °C   | 2/2  | -3 / -10                                     | -15 / -22  |
|                            | SCOP / ns             | (W/W) / %                                  | 4.30 / 169   | 3.33 / 130                                   | 3.10 / 121 |
|                            | Annual Consumption    | kWh  | 3104   | 8076   | 7955       |
|                            | Class                 |  | A++  | A++  | A+         |
|                            |                       | Condition                                  | A35W7  | A7W35  | A2W35      |
| Noise Level                |                       | (Ambient/Water)<br>dB (A)                  | Cooling: 54  | Heating: 55                                  |            |
|                            |                       | Power Level dB                             | Cooling: 72  | Heating: 72                                  | _          |
| Air Flow                   |                       | m <sup>3</sup> /min (ft <sup>3</sup> /min) | 550mig. 72   | Cooling: 97.8 (3450)<br>Heating: 90.0 (3180) |            |
| Refrigeration Cor          | ntrol Device          |  |  | Expansion Valve                              |            |
| Refrigeration Oil          |                       | cm <sup>3</sup>                            |  | FV50S (1200)                                 |            |
| Refrigerant (R41)          | 0A)                   | kg (oz)                                    |  | 2.1 (74.1)                                   |            |
| E 040                      | GWP                   |  | 2088   |  |            |
| F-GAS                      | CO2eq (ton) (Precharg | ed / Maximum)                              | 4.385 / -  |  |            |
|                            | Туре                  |  | Hermetic Motor   |  |            |
| Compressor                 | Motor Type            |  | Brushless (4-poles)  |  |            |
|                            | Rated Output          | kW   | 3.00   |  |            |
|                            | Туре                  |  | Propeller Fan  |  |            |
|                            | Material              |  | PP   |  |            |
| <b>F</b>                   | Motor Type            |  | DC (8-poles)   |  |            |
| Fan                        | Input Power           | W  |  | -  |            |
|                            | Output Power          | W  | 60   |  |            |
|                            | Fan Speed             | rpm  | Cooling: 630 (Top), 670 (Bottom)<br>Heating: 580 (Top), 620 (Bottom) |  |            |

|  | Item                                  |                              |                       | Refrigerant System |               |
|--|---------------------------------------|------------------------------|-----------------------|--------------------|---------------|
|  | Fin material                          |                              | Aluminium (Pre Coat)  |                    |               |
| Liest Eveloperat   | Fin Type                              |                              |                       | Corrugated Fin     |               |
| Heat Exchanger   | Row × Stage × FPI                     |                              |                       | 2 × 51 × 18        |               |
|  | Size (W × H × L)                      | mm                           | 903.7 × 1295.4 × 38.1 |                    |               |
| Power Source (Phase, Voltage, Cycle)                                 |                                       | Ø                            | Single                |                    |               |
|  |                                       | V                            | 230                   |                    |               |
|  |                                       | Hz                           | 50                    |                    |               |
| Input Power  |                                       | Condition<br>(Ambient/Water) | A35W7                 | A7W35              | A2W35         |
| patt ener  |                                       | kW                           | Cooling: 4.76         | Heating: 3.74      | Heating: 3.96 |
| Maximum Input Power For Heatpump System k                            |                                       | kW                           | 5.74                  |                    |               |
| Power Supply 1 : Phase (Ø) / Max. Current (A) / Max. Input Power (W) |                                       | 1Ø / 26.0 / 5.74k            |                       |                    |               |
| Power Supply 2 : Phase (Ø) / Max. Current (A) / Max. Input Power (W) |                                       | 1Ø / 26.0 / 6.00k            |                       |                    |               |
| Power Supply 3 : F   | Phase (Ø) / Max. Current (A) / Max. I | nput Power (W)               | -/-/-                 |                    |               |

|   | Item           | Unit                         | Mono Bloc Unit     |                    |               |
|---|----------------|------------------------------|--------------------|--------------------|---------------|
| Starting Current  |                | A                            | 21.5               |                    |               |
| Running Current   |                | Condition<br>(Ambient/Water) | A35W7              | A7W35              | A2W35         |
|   |                | А                            | Cooling: 21.5      | Heating: 16.9      | Heating: 17.9 |
| Maximum Current For Heatpump System   |                | A                            | 26.0               |                    |               |
| Power Factor<br>Power factor means total figure of compressor and<br>outdoor fan motor. |                | %                            | Cooling: 96        | Heating: 96        | Heating: 96   |
| Height  |                | mm (inch)                    | 1410 (55-1/2)      |                    |               |
| Dimension   | Width          | mm (inch)                    | 1283 (50-1/2)      |                    |               |
|   | Depth          | mm (inch)                    | 320 (12-19/32)     |                    |               |
| Net Weight  |                | kg (lbs)                     | 140 (309)          |                    |               |
| David Oard  | Number of core |                              |                    | -                  |               |
| Power Cord  | Length         | m (ft)                       | -                  |                    |               |
| Thermostat  |                |                              | Electronic Control |                    |               |
| Protection Devic  | ce             |                              |                    | Electronic Control |               |

|                                 | Item             | Unit                      | Water System                               |
|---------------------------------|------------------|---------------------------|--|
| Performance Test Condi          | tion             | ·                         | EN 14511                                   |
| Operation Range                 | Outdoor Ambient  | °C                        | Cooling: 16 ~ 43<br>Heating: -20 ~ 35      |
|                                 | Water Outlet     | °C                        | Cooling: 5 ~ 20<br>Heating: 20 ~ 55        |
| Internal Pressure Differential  |                  | kPa                       | Cooling: 52.0<br>Heating: 88.0             |
| Water Pipe Connector (in.)      |                  |                           | (1-1/4)                                    |
| Water Drain Hose Inner Diameter |                  | mm (inch)                 | 15.0 (19/32)                               |
| Dump                            | Motor Type       |                           | DC Motor                                   |
| Pump                            | Input Power      | W                         | 148  |
|                                 | Туре             |                           | Brazed Plate                               |
|                                 | No. of Plates    |                           | 36   |
| Hot Water Coil                  | Size (W × H × L) | mm                        | 65 × 120 × 376                             |
|                                 | Water Flow Rate  | l/min (m <sup>3</sup> /h) | Cooling: 35.0 (2.1)<br>Heating: 45.9 (2.8) |
| Pressure Relief Valve W         | ater Circuit     | kPa                       | Open: 300, Close: 266 and below            |
| Flow Switch                     |                  |                           | Electronic Sensor                          |
| Protection Device               |                  | A                         | Residual Current Circuit Breaker (40)      |
|                                 | Volume           | I                         | 10   |
| Expansion Vessel                | MWP              | bar                       | 3  |
| Capacity of Integrated E        | lectric Heater   | kW                        | 3.00                                       |

#### Note:

 Cooling capacities are based on outdoor air temperature of 35°C Dry Bulb with controlled indoor water inlet temperature of 12°C and water outlet temperature of 7°C.

 Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled indoor water inlet temperature of 30°C and water outlet temperature of 35°C.

• Specification are subjected to change without prior notice for further improvement.

 Flow rate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and =5°C

## 3. Features

- **Inverter Technology** - Energy saving
- **High Efficiency** •
- **Compact Design** .
- **Environment Protection** . - Non-ozone depletion substances refrigerant (R410A)
- Easy to use control panel •
- Weekly Timer setting

#### **Quality Improvement**

- Random auto restart after power failure for safety restart operation
- Gas leakage protection
- Prevent compressor reverse cycle
- Inner protector to protect compressor

#### •

- Serviceability Improvement Breakdown Self Diagnosis function
  - System Status Check Buttons for servicing purpose
  - System Pumpdown Button for servicing purpose Front maintenance design for outdoor unit

#### **Operation Condition**


|         |         | Indoor                        | Outdoor                  |
|---------|---------|-------------------------------|--------------------------|
|         |         | Water outlet temperature (°C) | Ambient temperature (°C) |
| COOLING | Maximum | 20                            | 43                       |
| COOLING | Minimum | 5                             | 16                       |
| HEATING | Maximum | 55                            | 35                       |
| HEATING | Minimum | 20                            | -20                      |

NOTICE : When the outdoor temperature is out of the above temperature range, the heating capacity will drop significantly and outdoor unit might stop for protection control.

## 4. Location of Controls and Components

## 4.1 Indoor Unit

#### 4.1.1 Location of Control



|               | 2 3 4  |
|---------------|--|
|               | ⊮⊌ <u>⊐</u> ⊆ℝ҈≣฿ฅ <b>‴⊡</b> 10:34am, Mon  |
|               | $1  2  2  4  5  40^{\circ} \text{c}  5  18^{\circ} \text{c}  5  5  18^{\circ} \text{c}  5  5  18^{\circ} \text{c}  5  5  5  5  5  5  5  5  5  $  |
|               | splay  |
| (1)           | Mode selection   |
|               | AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO<br>AUTO   |
|               | AUTO<br>+ TANK<br>+ TA |
|               | HEAT<br>+ The panel/floor HEAT operation is<br>either turned ON or OFF.<br>• The outdoor unit provides heat to<br>the system.<br>• The outdoor unit provides heat to<br>• T   |
|               | <ul> <li><b>HEAT</b></li> <li><b>The outdoor unit provides heat to the water tank and the system.</b></li> <li><b>This mode can be selected only when the water tank is installed.</b></li> <li><b>This mode can be selected only when the water tank is installed.</b></li> <li><b>This mode can be selected only when the water tank is installed.</b></li> <li><b>Room operation / Tank operation.</b></li> <li><b>Deice operation.</b></li> </ul>  |
| 2             | Operation icons<br>The status of operation is displayed.<br>Icon will not display (under operation OFF screen) whenever operation is OFF except weekly timer.  |
|               | Holiday operation status (1) Weekly Timer operation status (1) Quiet operation status  |
|               | Zone:Room Thermostat<br>→Internal sensor status<br>→Internal sensor status<br>→<br>→<br>→<br>→<br>→<br>→<br>→<br>→<br>→  |
|               | Room Heater status Solar status  |
|               | Bivalent status<br>(Boiler)  |
|               | ne system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.<br>Ily displayed when COOL mode is unlocked (This means when COOL mode is available).   |
| 3             | Temperature of each zone   |
| 4             | Time and day   |
| 5             | Water Tank temperature   |
| $\frac{6}{7}$ | Outdoor temperature Sensor type/Set temperature type icons   |
| ·/·           | Water Temperature<br>$\rightarrow$ Compensation curve<br>Room Thermostat<br>$\rightarrow$ ExternalWater Temperature<br>$\rightarrow$ Direct<br>Room Thermostat<br>$\rightarrow$ InternalPool only  |
|               |  |

#### 4.1.2 Initialization

Before starting to install the various menu settings, please initiate the Remote Controller by selecting the language of operation and installing the date and time correctly.

It is recommended that the installer conducts the following initialization of the Remote Controller.

#### Selecting the language

Press \_\_\_\_\_ and wait while the display is initializing.

- (1) Scroll with  $\nabla$  and  $\blacktriangle$  to select the language.

#### Initialization 12:00am, Mon LCD blinking Initializing ... 12:00am, Mor Language ENGLISH FRANÇAIS DEUTSCH ITALIANO [+-]Confirm -Select Clock format 12:00sm, Mor 24h am/pm \*Select [⊷]Contirm Date & Tima 12:00sm, Mon Year/Month/Day Haur : Min / 01 / 07 2D15 10:00 am C) Select [⊷]Contirm


10:00am, Wad

#### Setting the clock

- Select with ▼ or ▲ how to display the time, either 24h or am/pm format (for example, 15:00 or 3 pm).
- ③ Use ▼ and ▲ to select year, month, day, hour and minutes. (Press → to confirm the selection each time.)
- Once the time is set, time and day will appear on the display even if the Remote Controller is turned OFF.

Powerful

Force Defrost



[Ċ]Start

#### 4.1.3 Quick Menu

Force DHW

Timer

After the initial settings have been completed, you can select a quick menu from the following options and edit the setting.

(3) Press 🚽 to turn on/off the select menu.

1 Press to display the quick menu.

After the initial settings have been completed, you can select a quick menu from the following options and edit the setting.


| Panasonic         Image: Constraint of the second | <ul> <li>Panasonic</li> <li>Panasonic</li> <li>Select</li> <li< th=""></li<></ul> |
|--|---|
| Quick Menu   | I <sup>I</sup> Quiet<br>Force<br>Heater   |
| Weekly<br>Timer  | • Fror Reset R/C Lock   |
| → Select         [←]ON/OFF   | Select each setting and confirm the setting<br>according to the instructions displayed at the<br>bottom of the screen. (The icons refer to each<br>selection key.)  |

To return to the Main Screen,

Press 🖽 or ⊃ .

Note:

• If the system is not connected to the tank (Tank Connection is OFF), the Quick Menu screen will be displayed as right. Make sure the Tank Connection is ON.




#### Notes on operation icon



Operation icon indicate with "....." = OFF

Operation icon indicate with "------" = ON



**Force DHW** 

## Select this icon to turn the Tank DHW on or off. Press I to confirm your selection. • Force DHW is turned off. • Force DHW is turned on.

Note:

- Force DHW is disabled when Force Heater is turned on.
- When Force DHW is turned off, operation & mode should change back to the previous memorized status.



Powerful

Select this icon to operate the heating/cooling system powerfully.

#### Press 🚽 to confirm your selection.

 $\checkmark$ 

 $\rightarrow$ 

 $\blacksquare$ 

(The powerful operation starts approximately 1 minute after  $\checkmark$  is pressed.)

Powerful mode is set off.


• The Powerful mode operates for 30 minutes.

• The Powerful mode operates for 60 minutes.

• The Powerful mode operates for 90 minutes.

#### Note:

• Powerful is disabled when operation is turned OFF.






#### Select this icon to operate quietly.

Press  $\prec$  to confirm your selection.

#### (The quiet operation starts approximately 1 minute after $\downarrow$ is pressed.) ᠋᠋᠊ᡰᠶ • Quiet mode is set off. $\rightarrow$ • The Quiet mode operates at level 1. $\rightarrow$ • The Quiet mode operates at level 2. $\mathbf{I}$ • The Quiet mode operates at level 3. Level 3 is the most quiet mode. $\blacksquare$ নু শ • Select this to set a timer for the Quiet mode operation. After 1 sec delay. Do you want to edit Select "Yes". Quiet timer pattern? Select "Yes" using buttons. Yes No Pattern Time Leve 1 630D Select pattern "1" ~ "6". 9:00 D. 10/00 ᡟ EF il Select "Edit". Delete • If you select "Delete", the timer setting of the selected pattern will be deleted. 6 : 00 am Set the hour and minutes. W) Select the level of Quiet. Note: • If the time overlaps with another pattern, Set time is overlapped! "Set time is overlapped!" will appear on the screen. [\_]Close



Force Heater

#### Select to force the Heater on.

#### Press 🚽 to confirm your selection.

(The Force Heater mode starts approximately 1 minute after  $\checkmark$  is pressed.)



Force Heater is turned off.


• Force Heater is turned on.

Note:

• Force Heater is disabled whenever operation is already on and 'Disabled due to Operation ON!' will be displayed.


Disabled due to Operation ONI

[⊐] Close



#### Note:

- Timer is disabled when Force Heater is turned on or Heat-Cool SW is enabled.
- If you have preset the Weekly Timer on 2 zones, you must repeat the same procedure with Zone 2.



Select menus and determine settings according to the system available in the household. All initial settings must be done by an authorised dealer or a specialist. It is recommended that all alterations of the initial settings are also done by an authorised dealer or a specialist.


- After initial installation, you may manually adjust the settings.
- The initial setting remains active until the user changes it.
- The Remote Controller can be used for multiple installations.
- Ensure the operation indicator is OFF before setting.
- The system may not work properly if set wrongly. Please consult an authorised dealer.

To display <Main Menu>: ⋮≡

To select menu: 🔺 🔻

Menu

To confirm the selected content:



#### Default Setting Setting Options / Display

| 1 > Weekly timer   |  |  |
|--|--|--|
| Once the weekly timer is set up,<br>User can edit from Quick Menu.<br>To set up to 6 patterns of<br>operation on a weekly basis. | Timer setup<br>Select day of the week and<br>set the patterns needed<br>(Time / Operation ON/OFF / Mode) | Weekly timer     10:34am, Mor       Sun     Mon       Tue     Wed       Tue     Wed       Thu     Fri       San     Mon       Tue     Wed       Wed     Wed       We |
| <ul> <li>Disabled if Heat-Cool SW is<br/>pressed or if Force Heater<br/>is on.</li> </ul>  | Timer copy<br>Select day of the week   | <ul> <li>2. 12:00pm ON</li></ul>   |

| Jiday timer<br>ve energy, a holiday period<br>e set to either turn OFF the<br>n or lower the temperature<br>the period.<br>kly timer setting may be tem<br>be restored once the Holida<br>viet timer<br>erate quietly during the<br>period.<br>erns may be set.<br>0 means the mode is off.<br>the room heater<br>the room heater ON or<br>nk heater<br>the tank heater ON or<br>able only if connected to the | Date<br>OFF or lowe<br>porarily disabled during<br>ay timer is completed.<br>Time to<br>Date<br>Level of  | start and end.<br>and time<br>red temperature<br>Holiday timer setting but<br>start Quiet :<br>and time<br>f quietness:<br>) ~ 3   | Cri<br>Cri<br>Cri<br>Holiday: Fnd<br>Year/Month/Day<br>2015 / D1 / D7<br>2015 / D1 / D1 / D7<br>2015 / D1 / D1 / D7<br>2015 / D1 / D1 / D1 / D1 / D7<br>2015 / D1 / | Daro D<br>Dpm 1<br>Dpm 3   |
|--|---|--|---|--|
| e set to either turn OFF the<br>n or lower the temperature<br>the period.<br>kly timer setting may be tem<br>be restored once the Holida<br><b>iet timer</b><br>erate quietly during the<br>period.<br>erns may be set.<br>0 means the mode is off.<br><b>om heater</b><br>the room heater ON or<br><b>nk heater</b><br>the tank heater ON or  | > ON<br>Holiday s<br>Date<br>OFF or lowe<br>porarily disabled during<br>ay timer is completed.<br>Time to<br>Date<br>Level of<br>OFF  | and time<br>red temperature<br>Holiday timer setting but<br>start Quiet :<br>and time<br>f quietness:  | Cuict<br>Cuict<br>Cuict<br>Cuict<br>Pattern Lin<br>1 000<br>2 500<br>3 11:00<br>↓ Select [4]  | Hour : Min<br>10 : 00 ann<br>[++] Confinn<br>10:30am, Ma<br>10:30am, Ma<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>1 |
| the period.<br>kly timer setting may be tem<br>be restored once the Holida<br>iet timer<br>erate quietly during the<br>period.<br>erns may be set.<br>0 means the mode is off.<br>iom heater<br>the room heater ON or<br>nk heater<br>the tank heater ON or  | Holiday s<br>Date<br>OFF or lowe<br>porarily disabled during<br>sy timer is completed.<br>Time to<br>Date<br>Level of<br>OFF  | and time<br>red temperature<br>Holiday timer setting but<br>start Quiet :<br>and time<br>f quietness:  | Year/Month/Day<br>Poils/ D1 / D7<br>⇒ Select<br>Pattern Lin<br>1 050<br>2 5500<br>3 11500<br>3 11500<br>3 11500   | Hour : Min<br>10 : 00 ann<br>[++] Confinn<br>10:30am, Ma<br>10:30am, Ma<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>1 |
| kly timer setting may be tem<br>be restored once the Holida<br><b>iet timer</b><br>erate quietly during the<br>period.<br>erns may be set.<br>0 means the mode is off.<br><b>om heater</b><br>the room heater ON or<br><b>nk heater</b><br>the tank heater ON or   | Date<br>OFF or lowe<br>porarily disabled during<br>ay timer is completed.<br>Time to<br>Date<br>Level of<br>OFF   | and time<br>red temperature<br>Holiday timer setting but<br>start Quiet :<br>and time<br>f quietness:  | Year/Month/Day<br>Poils/ D1 / D7<br>⇒ Select<br>Pattern Lin<br>1 050<br>2 5500<br>3 11500<br>3 11500<br>3 11500   | Hour : Min<br>10 : 00 ann<br>[++] Confinn<br>10:30am, Ma<br>10:30am, Ma<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>10:30am<br>1 |
| be restored once the Holida<br>iet timer<br>erate quietly during the<br>period.<br>erns may be set.<br>0 means the mode is off.<br>iom heater<br>the room heater ON or<br>ink heater<br>the tank heater ON or  | OFF or lowe<br>porarily disabled during<br>ay timer is completed.<br>Time to<br>Date<br>Level of<br>OFF   | red temperature<br>Holiday timer setting but<br>start Quiet :<br>and time<br>f quietness:  | 2015 / D1 / D7<br>⇒ Select<br>Pattern Lin<br>1 0x0x<br>2 5x00<br>3 11x00<br>↓ Select [+-]1  | 10 : 00 ann<br>[++] Curi finin<br>14634am, Ma<br>is Level<br>Jaro 0<br>Jopn 1<br>Jopn 3  |
| be restored once the Holida<br>iet timer<br>erate quietly during the<br>period.<br>erns may be set.<br>0 means the mode is off.<br>iom heater<br>the room heater ON or<br>ink heater<br>the tank heater ON or  | oprarily disabled during<br>ay timer is completed.<br>Time to<br>Date<br>Level of<br>OFF  | Holiday timer setting but<br>start Quiet :<br>and time<br>f quietness:   | ⇒ Select<br>Cuict<br>Pattern Lin<br>Cook<br>Cook<br>Cook<br>Cook<br>Cook<br>Cook<br>Cook<br>Coo   | [+-] Curi finin<br>14c34am, Mr<br>15 Leve<br>Darn D<br>Jpm 1<br>Jpm 3  |
| iet timer<br>erate quietly during the<br>period.<br>erns may be set.<br>0 means the mode is off.<br>om heater<br>the room heater ON or<br>nk heater<br>the tank heater ON or   | Time to<br>Date<br>Level of<br>OFF  | and time<br>f quietness:   | Cuiet<br>Pattern Lin<br>1 Octo<br>2 Scoo<br>3 11:00<br>, Select [4-]1   | 100391am, Mr<br>10 Leve<br>Jam D<br>Jpm 1<br>Jpm 3   |
| erate quietly during the<br>period.<br>erns may be set.<br>0 means the mode is off.<br>om heater<br>the room heater ON or<br>nk heater<br>the tank heater ON or  | Date<br>Level of<br>OFF   | and time<br>f quietness:   | Pattern Lin<br>1 Ox02<br>2 SOX<br>3 11:00<br>- Select [-+]1   | na Leva<br>Dam D<br>Dam 1<br>Dam 3   |
| period.<br>erns may be set.<br>0 means the mode is off.<br><b>om heater</b><br>the room heater ON or<br><b>nk heater</b><br>the tank heater ON or  | Date<br>Level of<br>OFF   | and time<br>f quietness:   | i 0005<br>2 500<br>3 1100<br>56iett [4]i  | Dam D<br>Dpm 1<br>Dpm 3  |
| 0 means the mode is off.<br>om heater<br>the room heater ON or<br>nk heater<br>the tank heater ON or   | OFF   |  | 2 530<br>3 1130<br>, Select [+4]1   | )pm 1<br>Jpm 3   |
| the room heater ON or<br><b>nk heater</b><br>the tank heater ON or   |   |  |   |  |
| <b>nk heater</b><br>the tank heater ON or  |   |  | DN<br>▲<br>0F=  |  |
| the tank heater ON or  | OFF   |  |   |  |
|  | OFF   |  |   |  |
| able only if connected to the  |   |  |   |  |
| asis only in connected to the  | tank.   | 1  |   |  |
| erilization  |   |  |   |  |
| the auto sterilization ON  | OFF   |  |   |  |
| able only if connected to the<br>ot use the system during ste<br>an authorised dealer to dete<br>lations.  | rilization in order to prev   |  |   |  |
| ı check  |   |  |   |  |
| ergy monitor   |   |  |   |  |
| nt or historical chart of  | Present   |  |   |  |
| y consumption, generation  |   | and retrieve   |   |  |
| Ρ.   | Historical chart  | and ratriava   | Tank consumption (  | 1year)   |
| - Coofficient of Porformance   |   |  | kWh.  |  |
| nistorical chart, the period is  | selected from 1 day/1 w   |  | Jan, 2015: 0.0  | 7   8   9   10   11   12   CM<br>) kWh Approx  |
| total power consumption is a   | in estimated value base   |  | www.un ↓woue  |  |
| ater temperatures  |   |  | <u> </u>  |  |
|  |   |  | Water temperatures  | : 10:34am,Mo<br>: 0  |
| s all water temperatures in<br>area.   | tank / Solar / Pool   |  | 2. Outlet   | : 0'<br>: 0'   |
| -  |   | and vatriage   | 4. Zone 2   | : 0  |
| 1  | = Coefficient of Performance<br>istorical chart, the period is<br>gy consumption (kWh) of he<br>total power consumption is a<br>from value measured by pro-<br>ater temperatures<br>s all water temperatures in | Select a<br>= Coefficient of Performance.<br>istorical chart, the period is selected from 1 day/1 w<br>gy consumption (kWh) of heating, *I cooling, tank ar<br>iotal power consumption is an estimated value base<br>from value measured by precise equipment.<br>atter temperatures<br>all water temperatures in<br>area.<br>Actual water temperatures in<br>area.<br>Actual vater temperatures in<br>area. | Select and retrieve         = Coefficient of Performance.         istorical chart, the period is selected from 1 day/1 week/1year.         gy consumption (kWh) of heating, * cooling, tank and total may be retrieved.         total power consumption is an estimated value based on AC 230 V and may from value measured by precise equipment.         atter temperatures         all water temperatures in area.         Actual water temperature of 8 items: Inlet / Outlet / Zone 1 / Zone 2 / Tank / Buffer  | Select and retrieve       0.0         = Coefficient of Performance.       istorical chart, the period is selected from 1 day/1 week/1year.         gy consumption (kWh) of heating, * cooling, tank and total may be retrieved.       Jan, 2015: 0.0         total power consumption is an estimated value based on AC 230 V and may from value measured by precise equipment.       • Month \$Mode         atter temperatures       atter temperatures in area.       Actual water temperature of 8 items: Inlet / Outlet / Zone 1 / Zone 2 / Tank / Buffer tank / Solar / Pool       Water temperatures         Select and retrieve       4. Zone 2  |

| Ι | lenu   | Default Setting | Setting Options | s / Display   |   |
|---|--|-----------------|-----------------|---|---|
| 3 | > Error history  |                 |                 |   |   |
|   | <ul> <li>Refer to Troubleshooting for<br/>error codes.</li> <li>The most recent error code is<br/>displayed at the top.</li> </ul> | Select a        | and retrieve    | Errar history<br>1<br>2<br>3<br>4<br>[. ] Clear history                       | 10:39am, Mn                                   |
| 4 | > Compressor   |                 |                 | ·   |   |
|   | Shows the compressor performance.  | Select a        | and retrieve    | Compressor<br>1. Current frequence<br>2. (OFF-ON) counter<br>3. Total ON time |   |
| _ |  |                 |                 | [⊅]Back   |   |
| 5 | > Heater<br>Total hours of ON time for Room<br>heater/Tank heater.   | Select a        | and retrieve    | Heater<br>Total ON time<br>ऄॗऻऀ<br>ऄॖॗॗॗि                                     | 10:34am, Mor<br>: Oh<br>: Oh                  |
| _ |  |                 |                 |   |   |
|   | Personal setup   |                 |                 |   |   |
| 1 | >Touch sound<br>Turns the operation sound ON/<br>OFF.  | ON              |                 | ON<br>OFF   |   |
| 2 | >LCD contrast  |                 |                 |   |   |
|   | Sets the screen contrast.  |                 |                 | I CB contrast   | 10:3 <b>H</b> am, Mor                         |
|   |  | 3               |                 |   | High  |
|   |  |                 |                 | 1+Select [++]   | Coufirm                                       |
| 3 | > Backlight  |                 |                 |   |   |
|   | Sets the duration of screen backlight.   | 1 min           |                 | Harklight<br>OFF<br>15 secs<br>Contractor<br>Select L-J                       | 10k391am, Mm<br>5 mins<br>10 mins<br>Continun |
| 4 | > Backlight intensity  |                 | _               |   |   |
|   | Sets screen backlight brightness.  | 4               |                 | Barklight intensity<br>Dark<br>↓ Select [+-]                                  | 146391am, Mor<br>Bright<br>Coulfirm           |
| 5 | > Clock format   |                 | I               |   |   |
| J | Sets the type of clock display.  | 24h             |                 | Clock format<br>24F   |   |
|   |  |                 |                 | an/p<br>*Select [₊-]  | Continn                                       |

|   | Menu   | Default Setting                | Setting Options /  | Display   |   |
|---|--|--------------------------------|--|---|---|
| 6 | > Date & Time  |                                |  |   |   |
| - | Sets the present date and time.  | Year / Month                   | / Day / Hour / Min   | Date & Line<br>Year/Month/Day<br>2015/ D1 / 07                        | 10:39am, Mr<br>Hour : Min<br>10 : 00 am |
| 7 | > Language   |                                |  | \$> Select  | [+-]Confirm                             |
|   | <ul> <li>Sets the display language for the top screen.</li> <li>For Dutch, Greek, Finnish and Turkish, please refer to the English version.</li> </ul> | DEUTSCH<br>ESPAÑO<br>SWEDISH / | / FRANÇAIS /<br>/ ITALIANO /<br>L / DANISH /<br>NORWEGIAN /<br>I / CZECH | Language<br>ENGLISH<br>FRANÇAIS<br>DEUTSCH<br>ITALIANO<br>Select [+-] | 10:34am, Mo                             |
| 8 | > Unlock password  |                                |  |   |   |
|   | 4 digit password for all the settings.   | 0000                           |  | Unlork pasavord   | 10:34am, Mo                             |
|   |  |                                |  | ‡5elert [⊷)   | Confirm                                 |
| ļ | Service contact  |                                |  |   |   |
| 1 | > Contact 1 / Contact 2  |                                |  |   |   |
|   | Preset contact number for installer.   | Select a                       | and retrieve   | Service sctup<br>Contect 1<br>Name : Bryan A<br>T: 0681234<br>"Seleul |   |

| Ν | lenu   | Default Setting  | Setting Options / Dis                            | play   |                    |
|---|--|--|--|--|--------------------|
| I | nstaller setup > System setup  |  |  |  |                    |
| 1 | > Optional PCB connectivity  |  |  |  |                    |
|   | To connect to the external PCB required for servicing.   | No   | Yes<br>Nu  |  |                    |
|   | <ul> <li>If the external PCB is connected a</li> <li>Buffer tank connection and c</li> <li>Control over 2 zones (includi</li> <li>Solar function (the solar them</li> <li>External compressor switch.</li> <li>External error signal.</li> <li>SG ready control.</li> <li>Demand control.</li> <li>Heat-Cool SW</li> </ul> | ontrol over its function a ng the swimming pool a  | and temperature.<br>and the function to heat wat | er in it).   | or the Buffer Tank |
| 2 | >Zone & Sensor   |  |  |  |                    |
|   | To select the sensors and to select either 1 zone or 2 zone system.  | Zone • After selecting 1 or 2 the selection of room • If the swimming pool temperature must be | is selected, the                                 | Zone & Sensor 10634am,<br>Zone 1 Zone System<br>2 Zones System       |                    |
|   |  | $\triangle$ T temperature between 2 °C ~10 °C.   |  | _Select L+   | 4) Confirm         |
|   |  | Sensor   |  | Zone & Senson<br>Sensor  | 10c3Ham, Mon       |
|   |  | * For room thermostat selection of external  | -  | Watentam<br>Room the<br>Room the                                     | rmostat            |
| 3 | > Heater capacity  |  |  |  |                    |
|   | To reduce the heater power if<br>unnecessary.*<br>3 kW / 6 kW / 9 kW   | 3 kW / 6 kW / 9 kW   |  | Heater capacity<br>3 k<br>6 k  |                    |
|   | * Options of kW vary depending   |  |  | 9 k  | W                  |
|   | on the model.  |  |  | ^Select [+   | ]Confirm           |
| 4 | > Anti freezing  | 1  |  |  |                    |
|   | To activate or deactivate the<br>water freeze prevention when<br>the system is OFF   | Yes  |  | YIS<br>Vu  |                    |
| 5 | > Tank connection  | -  |  |  |                    |
|   | To connect tank to the system.   | No   |  | Yes<br>▲<br>No   |                    |
| 6 | > Buffer tank connection   |  |  |  |                    |
|   | To connect tank to the system and if selected YES, to set $\triangle$ T temperature.   | No   |  | Yes<br>A<br>No   |                    |
|   | The optional PCB connectivity  | > Yes  | 1  |  |                    |
|   | must be selected YES to<br>enable the function.<br>• If the optional PCB connectivity<br>is not selected, the function will  | 5 °C   | Set $\triangle$ T for Buffer Tank                | Buffer Tank<br>ΔT for Buffer Tan<br>Range: (0°C~10°C)<br>Steps: ±1°C |                    |
|   | not appear on the display.   |  |  | \$Select [+  | -]Confirm          |

|    | Menu  | Default Setting  | Setting Options / Dis  | splay   |   |
|----|---|--|--|---|---|
| 7  | > Tank heater   |  |  |   |   |
|    | To select external or internal<br>tank heater and if External is<br>selected, set a timer for the<br>heater to come on.<br>* This option is available if Tank<br>connection is selected (YES)                     | Internal   |  | In  | 10:34am,Mon<br>ternal<br>farrs)<br>[- i]Confirm |
|    | connection is selected (YES).   | > External   |  |   |   |
|    |   | 0:20   | Tank heater ON time<br>set.                                    | Lank heater<br>Tank heater: CN<br>Range: (0:20-9:<br>Steps: 40:05 |   |
| 8  | > Base pan heater   |  |  |   |   |
|    | To select whether or not optional base pan heater is connected.   | No   |  |   | res<br>▲  |
|    | <ul> <li>* Type A - The base pan heater<br/>activates only during<br/>deice operation.</li> <li>*Type B - The base pan heater<br/>activates when outdoor<br/>ambient temperature is<br/>5 °C or lower.</li> </ul> | > Yes  |  |   |   |
|    |   | A  | Set base pan heater<br>type*.                                  |   | type 10:34am,Man<br>A<br>▼<br>B<br>[- :]Confirm |
| 9  | > Alternative outdoor sensor  |  |  |   |   |
| J  | To select an alternative outdoor sensor.  | No   |  |   | ies<br>▲<br>No                                  |
| 10 | > Bivalent connection   |  |  |   |   |
|    | To select a bivalent connection to allow an additional heat   | No   |  |   | res<br>▲  |
|    | source such as a boiler to  | > Yes  | 1  |   |   |
|    | heat-up the buffer tank and<br>domestic hot water tank when<br>heatpump capacity is insufficient<br>at low outdoor temperature.<br>The bivalent feature can be  | -5 °C  | Set outdoor temperature<br>for turn ON Bivalent<br>connection. | Hern ON: Outdoo<br>Hange: (-15°0-85<br>Steps: ≛1°C                | ο <sup>τ</sup> ) <b>ε</b> τ                     |
|    | set-up either in alternative<br>mode (heatpump and boiler   | X  |  |   | -]Confirm                                       |
|    | operate alternately), or in parallel  |  | g the outdoor temperatur                                       | e   |   |
|    | mode (both heatpump and boilor operate simultaneously)  | Control pattern Alternative / Parallel / Advanced parallel |  | Rivalant connecti   | on 10:34am, Man                                 |
|    | boiler operate simultaneously),<br>or in advance parallel mode<br>(heatpump operates and boiler<br>turns on for buffer-tank and/or<br>domestic hot water depending<br>on the control pattern setting<br>options). |  | rallel for bivalent use of                                     | Control pattern<br>Alter<br>Par<br>Advance                        | native<br>allei<br>위 pac-liei<br>과 Confirm      |

| Menu | Default Setting                            | Setting Options / Dis  | splay  |  |  |  |
|------|--|--|--|--|--|--|
|      | Control pattern > Advanced parallel        |  |  |  |  |  |
|      | Heat                                       | Selection of the tank  | Bivalent connection _ 10:30am, Mor   |  |  |  |
|      |  |  | Advanced parallel  |  |  |  |
|      | "Heat" implies Buffe     Domestic Hot Wate | er Tank and "DHW" implies<br>r Tank.                                       | Lieut<br>DHW   |  |  |  |
|      |  |  | _ Select [هـ] Confirm  |  |  |  |
|      | Control pattern > A                        | dvanced parallel > Heat > 1  | Yes  |  |  |  |
|      |  | ated only after selecting  | Bivalent connection10:30am, Mon<br>Advanced parallel: Heat<br>Yes<br>ND  |  |  |  |
|      |  |  | "Select [+-] Confirm   |  |  |  |
|      |  |  | Bivalent connection 10:34am, Mon   |  |  |  |
|      | -8 °C                                      | Set the temperature threshold to start the bivalent heat source.           | Heat start: Target temp.<br>Range: (-10°C~0°C)<br>Steps: ±1°C  |  |  |  |
|      |  |  | \$Select [₊-]Confirm   |  |  |  |
|      |  |  | Rivalent connection 10:34am, Mor   |  |  |  |
|      |  | Dolay timor to start the   | Heat start: Delay time   |  |  |  |
|      | 0:30                                       | Delay timer to start the<br>bivalent heat source<br>(in hour and minutes). | Range: (0:00~1:30)<br>Steps: 40:05   |  |  |  |
|      |  |  | Şelect [+]Confirm  |  |  |  |
|      |  |  | Bivalent connection 10:34am, Mo  |  |  |  |
|      |  | Set the temperature  | Heat stop: Target temp.  |  |  |  |
|      | -2 °C                                      | threshold to stop the bivalent heat source.                                | Range: (-10°C~0°C)<br>Steps: ±1°C  |  |  |  |
|      |  |  | \$Select [₊-]Confirm   |  |  |  |
|      |  |  | Bivalent connection 10:34am, Mo  |  |  |  |
|      | 0:30                                       | Delay timer to stop the<br>bivalent heat source<br>(in hour and minutes).  | Heat stop: Belay time<br>Hange: (0:00–1:30)<br>Steps: \$0:05   |  |  |  |
|      |  |  | ‡Sele.t [+]Conlinu   |  |  |  |
|      | Control pattern > A                        | dvanced parallel > DHW > `   | Yes  |  |  |  |
|      | • DHW Tank is activa<br>"Yes".             | ted only after selecting   | Hivalent connection 10:39am, Mod<br>Advanced parallel: DHW<br>V99<br>ND  |  |  |  |
|      |  |  | -Select [+-]Confirm  |  |  |  |
|      | 0:30                                       | Delay timer to start the<br>bivalent heat source<br>(in hour and minutes). | Bivalent connection       10:34am, Mor         DHW: Delay time         Range: (0:30~1:30)         Steps: ±0:05 |  |  |  |
|      |  | ,                                    | \$Select [₊-]Confirm   |  |  |  |

| Ν  | lenu  | Default Setting       | Setting Options / Dis              | play  |              |
|----|---|-----------------------|------------------------------------|---|--------------|
| 11 | > External SW   |                       |                                    |   |              |
|    |   | No                    |                                    | Yes<br>▲<br>No  |              |
| 12 | > Solar connection  |                       |                                    |   |              |
|    | The optional PCB connectivity must be selected YES to                 | No                    |                                    | Yes<br>A<br>No  |              |
|    | enable the function.  | > Yes                 |                                    |   |              |
|    | • If the optional PCB connectivity is not selected, the function will |                       |                                    | Solar connection  | 10c3Mam, Mon |
|    | not appear on the display.  | Buffer tank           | Selection of the tank              | Bulfer  |              |
|    |   |                       |                                    | CHW G   | nĸ           |
|    |   |                       |                                    | <sub>च</sub> Selert []।   | Confirm      |
|    |   | > Yes > After selecti | ng the tank                        |   |              |
|    |   |                       |                                    | Solar connection  | 10:34am, Mon |
|    |   |                       |                                    | ΔT Turn ON  |              |
|    |   | 10 °C                 | Set ∆T ON temperature              | Range: (6°C~15°C)<br>Steps: ±1°C  | 10°C         |
|    |   |                       |                                    | \$Select [₊_]   | Confirm      |
|    |   | > Yes > After selecti | ng the tank > $	riangle T$ ON temp | erature   |              |
|    |   |                       |                                    | Solar connection  | 10:34am, Mon |
|    |   |                       |                                    | ΔT Turn OFF   |              |
|    |   | 5 °C                  | Set ∆T OFF                         | Range: (2°C~9°C)  |              |
|    |   |                       | temperature                        | Steps: ±1°C   | 5 ℃          |
|    |   |                       |                                    | \$Select [₊_](  | Confirm      |
|    |   | > Yes > After selecti | ng the tank≻ ∆T ON temp            | erature > <pre> <pre> </pre> <pre> <pre> </pre> <pre> </pre> <pre> To EF te</pre></pre></pre> | mperature    |
|    |   |                       |                                    | Solar connection  | 10:34am, Mon |
|    |   |                       |                                    | Anti freeze   |              |
|    |   | 5 °C                  | Set Antifreeze                     | Range: (-20°C~10°C)   |              |
|    |   | 0.0                   | temperature                        | Steps: ±1°C   | 5°C          |
|    |   |                       |                                    | \$Select [₊-](  | Confirm      |
|    |   | > Yes > After selecti | ⊔<br>ng the tank> ∆T ON temp       | •   |              |
|    |   |                       | ntifreeze temperature              |   | inperature   |
|    |   |                       |                                    | Solar connection  | 10:34am, Mon |
|    |   |                       |                                    | Hi limit  |              |
|    |   | 80 °C                 | Set Hi limit                       | Hange: (70°C-90°C)<br>Steps: ±5°C   |              |
|    |   |                       |                                    | ‡Select [₊-]!   | Confirm      |

| Ν  | lenu  | Default Setting | Setting Options / Di  | splay  |                     |
|----|---|-----------------|---|--|---------------------|
| 13 | > External error signal   |                 |   |  |                     |
|    |   | No              |   |  | Yes<br>A<br>No      |
| 14 | > Demand control  | 1               |   |  |                     |
|    |   | No              |   |  | Yes<br>▲<br>No      |
| 15 | >SG ready   | 1               |   |  |                     |
|    |   | No              |   |  | Yes<br>▲<br>No      |
|    |   | > Yes           | I   |  |                     |
|    |   | 120 %           | Capacity (1) & (2) of<br>Buffer Tank and DHW<br>Tank (in %) | SC marty<br>Capacity [1-0]<br>Range: (50%-<br>Steps: ±5% |                     |
|    |   |                 |   | \$Select   | []Confirm           |
| 16 | >External compressor SW   |                 |   |  |                     |
|    |   | No              |   |  | Yes<br>▲<br>No      |
| 17 | > Circulation liquid  |                 |   |  |                     |
|    | To select whether to circulate<br>water or glycol in the system.<br>Water       |                 | Circulation liq   | uid 10:34am, Mon   |                     |
|    |   | Water           |   | Water  |                     |
|    |   |                 |   | -Select  | [++] Confirm        |
| 18 | > Heat-Cool SW  |                 |   |  |                     |
|    |   | No              |   |  | Yes<br>No           |
| 19 | > Force Heater  | 1               | 1   |  |                     |
|    | To select use Auto turn ON<br>force heater mode or<br>Manual force heater mode. | Manual          |   | Force heater   | 10:34am,Mon<br>Auto |
|    |   | Manual          |   |  | Manual              |
|    |   |                 |   | ^Select  | [₊-]Confirm         |
| lı | nstaller setup > Operation setu   | ıp              |   |  |                     |
| 1  | To access to the four major functions or modes.                                 | <u>-</u>        | n modes   | Operation set<br>Heat<br>Coul                            | ip 125KDam, Mnn     |
|    |   | Heat / *1, *2 C | cool / Auto / Tank  | Auto<br>Tank<br>"Select                                  | (+J)Confirm         |

\*1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners. \*2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

| Menu   | Default Setting  | Setting Options / Dis  | splay  |  |
|--|--|--|--|--|
| Installer setup > Operation setu                         | ID ID  |  |  |  |
| 2 > Heat   | •  |  |  |  |
| To set various water & ambient temperatures for heating. | Water temp. for heating ON /<br>Outdoor temp. for heating OFF /<br>△T for heating ON /<br>Outdoor temp. for heater ON        |  | Operation setup         10:30am, Mm           Heat         Water leave for leading ON           Outdoor tamp, for heating OFF         1           A1 for heating ON         Select           Select         [] Continu |  |
|  | > Water temp. for he   | ating ON   |  |  |
|  | Compensation<br>curve  | Heating ON<br>temperatures in<br>compensation curve or<br>direct input.  | Operation setup 14634am, Mon<br>Heat ON: Water temp.<br>Compensation rorive<br>Direct  |  |
|  | > Water temp, for he   | ating ON > Compensation  |  |  |
|  | X axis: -5 °C, 15 °C<br>Y axis: 55 °C, 35 °C   | Input the 4 temperature<br>points<br>(2 on horizontal X axis,<br>2 on vertical Y axis).                            | Heat DN: Water temps Zone1 55'C 35'C 35'C 55'C 55'C 55'C 55'C 55'C   |  |
|  | Temperature range f     1. If High water temp     2. If High water temp     3. If High water temp     If 2 zone system is so | perature is NO: 20 °C ~ 55<br>perature is YES & Back up<br>perature is YES & Back up<br>elected, the 4 temperature |  |  |
|  | > Water temp. for he   | ating ON > Direct  |  |  |
|  | 35 °C  | Temperature for heating ON   | Operation setup10:34am, MonHeat ON: Water temp.: Zone2Range: (20°C~55°C)Steps: ±1°C  |  |
|  | 1. If High water temp<br>2. If High water temp   |  | Select [+-]Confirm °C heater is enabled: 25 °C ~ 65 °C heater is disabled: 35 °C ~ 65 °C   |  |
|  | > Outdoor temp. for  | •  |  |  |
|  | 24 °C  | Temperature for heating<br>OFF   | Operation setup     10:34am, Mon       Heat OFF: Outdoor temp.       Range: (5°C~35°C)       Steps: ±1°C       \$Select  |  |


| N | lenu   | Default Setting Setting Options / Display  |  |   |                           |  |
|---|--|--|--|---|---------------------------|--|
|   |  | > △T for heating ON  |  |   |                           |  |
|   |  | 5 °C   | Set ∆T for heating<br>ON.  | Operation setup<br>Heat ON: ΔT<br>Range: (1°C~15°C)<br>Steps: ±1°C  | 10:34am, Mon              |  |
|   |  | > Outdoor tomp for   | r haatar ON  | \$Select [₊-]   | Confirm                   |  |
|   |  | > Outdoor temp. for  | neater ON  | Operation setup   | 10:34am, Mon              |  |
|   |  | 0°C  | Temperature for<br>heater ON   | Heater ON: Outdoo<br>Range: (-15°C~20°C<br>Steps: ±1°C  | r temp.                   |  |
| 3 | > *1, *2 Cool  |  |  | \$Select [₊-]   | Confirm                   |  |
| J | To set various water & ambient temperatures for cooling. | Water temperatures for cooling ON and ∆T for cooling ON.                         |  | Operation setup<br>Cool<br>Water temps for ce<br>AT for cooling ON  |                           |  |
|   |  |  |  | "Select [)  | Contina                   |  |
|   |  | > Water temp. for co   | Cooling ON<br>temperatures in<br>compensation curve or                                 | Operation setup<br>Cool ON: Water ten<br>Componisti<br>Dire   | on curva                  |  |
|   |  |  | direct input.  | _Select ايجا  | Confirm                   |  |
|   |  | > Water temp. for co   | oling ON > Compensation  | n curve   |                           |  |
|   |  | X axis: 20 °C, 30 °C<br>Y axis: 15 °C, 10 °C                                     | Input the 4 temperature<br>points<br>(2 on horizontal X axis,<br>2 on vertical Y axis) | Cool ON: Water ten<br>19°C 0<br>10°C 0<br>- 70°C 0<br>10°C 0<br>- 70°C 0<br>- | npo Zone1                 |  |
|   |  | If 2 zone system is selected, the 4 temperature points must also be input for Zo |  |   | input for Zone 2          |  |
|   |  |  | 2" will not appear on the di   | splay if only 1 zone :  | system.                   |  |
|   |  | > Water temp. for co   | oling ON > Direct  |   |                           |  |
|   |  | 10 °C  | Set temperature for<br>Cooling ON  | Operation setup<br>Cool ON: Water ten<br>Range: (5°C~20°C)<br>Steps: ±1°C   | 10:34am,Mon<br>np.: Zone2 |  |
|   |  |  |  | \$Select [₊-]   | Confirm                   |  |
|   |  | > △T for cooling ON  |  |   |                           |  |
|   |  | 5 °C S   | Set $	riangle T$ for cooling ON  | Operation setup<br>Cool ON: ΔT<br>Range: (1°C~15°C)<br>Steps: ±1°C  | 10:34am, Mon              |  |
|   |  |  |  | \$Select [₊-]   | Confirm                   |  |

\*1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners. \*2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

|   | Menu  | Default Setting  | Setting Options / Dis  | play  |                             |
|---|---|--|--|---|-----------------------------|
| 1 | > Auto  |  |  |   |                             |
|   | Automatic switch from Heat to Cool or Cool to Heat.   | to Cool or Cool to Heat.   |  | Operation setup<br>Auto   | 10:34am, Mr                 |
|   |   |  |  | Outdoor temp. for<br>Outdoor temp. for  | (Cool to Heat)              |
|   |   |  | · · · ·  | -Select [+-   | ]Confirm                    |
|   |   | > Outdoor temp. for  | · (Heat to Cool)   |   |                             |
|   |   | 15 °C  | Set outdoor temperature<br>for switching<br>from Heat to Cool. | Operation setup<br>Auto: Outdoor tem<br>Range: (11°C~25°C)<br>Steps: ±1°C           | 15                          |
|   |   |  |  | \$Select [₊.]   | Confirm                     |
|   |   | > Outdoor temp. for<br>10 °C   | Set outdoor temperature<br>for switching<br>from Cool to Heat. | Operation setup<br>Auto: Outdoor tem<br>Range: (5°C~14°C)<br>Steps: ±1°C            | 10:34am,M<br>p.(Cool to Hea |
|   |   |  |  | \$Select [₊-]   | Confirm                     |
| 5 | > Tank  |  |  |   |                             |
|   | <ul> <li>Setting functions for the tank.</li> <li>Available only if connected to the tank.</li> </ul> | Floor operation time (max) /<br>Tank heat up time (max) /<br>Tank re-heat temp. /<br>Sterilization |  | iank<br>Miconcyenation()<br>Tank heat up time<br>Lank re-heat temp<br>, Select [بس] | (так)                       |
|   |   |  | w 3 functions at a time.                                       |   |                             |
|   |   | Floor operation tir  | me (max)   |   |                             |
|   |   | 8:00   | Maximum time for floor<br>operation<br>(in hours and minutes)  | Operation setup<br>Lank: Floor oper til<br>Hange: (0:30-10:0<br>Steps: ±0:30        |                             |
|   |   | > Tank heat up time  | (max)  |   |                             |
|   |   | 1:00   | Maximum time for<br>heating the tank<br>(in hours and minutes) | Operation setup<br>Lank: Heat up lime<br>Range: (0:05-4:00<br>Steps: +0:05          | •                           |
|   |   | Tonk to hoot tom   | -  | Ç5elact f.∙   | Continu                     |
|   |   | → Tank re-heat temp<br>-8 °C   | Set temperature to<br>perform reboil of tank                   | Operation setup<br>Tank: Ko-heat temp<br>Range: (-12°C2°C                           |                             |
|   |   | -0 0   | water.   | Steps: +1 C   | -8                          |


| N | lenu                                  | Default Setting  | Setting Options / Dis                             | play   |  |
|---|---------------------------------------|--|---|--|--|
|   |                                       | > Sterilization  |   |  |  |
|   |                                       | Sterilization may be set for 1 or<br>more days of the week.<br>Sun / Mon / Tue / Wed / Thu / Fri / Sat |   | Operation setup 10:30am, Mor<br>Sterilization: Day   |  |
|   |                                       |  |   | Sun Men Tuc ≡cd Thu Fri Sat<br>— ✓ — — — — —<br>1•Day ‡Z/⊡ [+]Confina  |  |
|   |                                       | > Sterilization: Time  |   | , and the first fi |  |
|   |                                       | Time of the selecte  | d day(s) of the week to<br>the tank               | Operation setup 10:34am, Mor<br>Sterilization: Lime  |  |
|   |                                       | 0:00   | ~ 23:59   | <b>6</b> :00 am  |  |
|   |                                       | Starilization: Baili   | ng temp   | \$• Select [+-] Confirm  |  |
|   |                                       | Sterilization: Boiling temp.       65 °C     Set boiling temperatures for sterilize the tank.          |   | Operation setup10:34am, MorSterilization: Boiling temp.Range: (55°C~75°C)Steps: ±1°C   |  |
|   |                                       |  |   | Select [↓]Confirm  |  |
|   |                                       | > Sterilization: Ope. time (max)   |   |  |  |
|   |                                       | 0:10   | Set sterilizing time<br>(in hours and minutes)    | Operation setup10:34am, MorSterilization: Ope. time (max)Range: (0:05~1:00)Steps: ±0:05  |  |
|   |                                       |  |   | \$Select [₊-]Confirm   |  |
| _ | Installer setup > Service setup       |  |   |  |  |
| 1 | > Pump maximum speed                  | <u></u>  |   |  |  |
| • | To set the maximum speed of the pump. |  | max. duty and operation of the pump.              | Service setup 10:34am, Mor<br>Flow rate Max. Duty Operation  |  |
|   |                                       | Max. Duty:   | e: XX:X L/min<br>: 0x40 ~ 0xFE,<br>/OFF/Air Purge | 0.0 L/min 0xCE 	Air Purge  |  |
| 2 | > Pump down                           |  |   |  |  |
|   | To set the pump down operation.       | Pump down operatio   | n<br>ON   | Specific action<br>P<br>Pump down operation<br>In progress:<br>(b)OFF  |  |

|   | Menu   | Default Setting  | Setting Options / Dis  | splay   |                                  |
|---|--|--|--|---|----------------------------------|
|   | Installer setup > Service setup  |  |  |   |                                  |
| 3 | > Dry concrete<br>To dry the concrete (floor, walls,<br>etc.) during construction. | Edit to set the temp   | erature of dry concrete.   | Service setup<br>Dry concrete<br>ON   | 10:34am,Mon                      |
|   | Do not use this menu for any other purposes and in period                          | ON / Edit  |  | Edit<br>"Select [+]Confirm  |                                  |
|   | other than during  | > Edit   |  | -Select [₊-]  | Comm                             |
|   | construction   | Stages: 1<br>Temperature: 25 °C                                      | Heating temperature for<br>drying the concrete.<br>Select the desired<br>stages: 1 ~ 10, | Service setup<br>Dry concrete: 1/10<br>Range: (25°C~55°C)<br>Steps: ±1°C                              | 10:34am, Mon                     |
|   |  |  | range: 1 ~ 99  | <sup>▲</sup> Select [+-]  | Confirm                          |
|   |  |  | g temperatures of dry<br>or each stage.  | Service setup<br>Dry concrete: Status   | 10:34am, Mon                     |
| _ |  |  | or outer stage.  | Stage<br>Water set temp.<br>Actual water temp.<br>[①]OFF  | : 1/10<br>: 25°C<br>:25°C/25°C   |
| 4 | > Service contact  | I  |  |   |                                  |
|   | To set up to 2 contact names<br>and numbers for the User.                          | Service engineer's name and contact number.<br>Contact 1 / Contact 2 |  | Service setup 14k34am, Ma<br>Service contact:<br>Contact 1<br>Contact 2                               |                                  |
|   |  |  |  | "Select [] Confirm  |                                  |
|   |  | > Contact 1 / Contac   | et 2   |   |                                  |
|   |  | Contact name or number.  |  | Service contact<br>Contact 1  | 10:34am, Mon                     |
|   |  | Name /   | phone icon   | Name : Bryan A<br><b>2</b> :0681234<br>_Select [+4]   |                                  |
|   |  | Input name and number  |  | Contact-1<br>ABC/sta<br>ABCDEFGHIJKLI<br>STUVWXY7 abro<br>jklmnopqrstu-<br>i <sub>g</sub> •Selact [,1 | MNOPGR <u>Space</u><br>defghi BS |
| _ |  |  | e: alphabet a ~ z.<br>number: 1 ~ 9  | Numher:<br>2 3<br>4 5 6<br>7 8 9<br><del>3</del> 0 7<br>4<br>• 0 7                                    | аў<br>Э. нас                     |




# 5. Dimensions

# 5.1 Mono Bloc Unit



# 6. Refrigeration and Water Cycle Diagram




Refrigerant Cycle (Heating)


----- Water Cycle

---- Refrigerant Cycle (Cooling)


# 6.1 Standard System (Optional PCB not connected)



6.2 Advance System (Optional PCB connected)





# 7. Block Diagram



# 8. Wiring Connection Diagram

# 8.1 Water System







REMARKS: N. WHITE R: RED B: BLUE P: PINK BL: BLACK Y: YELLOW BL: BROWN 0: ORANGE G: GREEN GR: GRAY YG: YELLOWGREEN

# 9. Electronic Circuit Diagram

# 9.1 Water System




# 9.2 Refrigerant System




# **10. Printed Circuit Board**

# 10.1 Water System

## 10.1.1 Main Printed Circuit Board




# 10.1.2 Optional Printed Circuit Board




# 10.2 Refrigerant System


## 10.2.1 Main Printed Circuit Board



# 10.2.2 Capacitor Printed Circuit Board







# 11.Installation Instruction

# 11.1 Mono Bloc Unit

| Attached Accessories |                   |      |  |
|----------------------|-------------------|------|--|
| No.                  | Accessories part  | Qty. |  |
| 1                    | Drain elbow       | 1    |  |
| 2                    | Rubber cap        | 8    |  |
| 3                    | Remote controller |      |  |

#### Optional Accessory

| No. | Accessories part                      |  |
|-----|---------------------------------------|--|
| 4   | Optional PCB (CZ-NS4P)                |  |
| 5   | Base Pan Heater (CZ-NE3P)             |  |
| 6   | Network Adaptor (CZ-TAW1)             |  |
| 7   | Network Adaptor Cable (CZ-TAW1-CBL) 1 |  |

#### Field Supply Accessories (Optional)

| No.  | Part               |                         | Mode               | Specification | Maker   |
|------|--------------------|-------------------------|--------------------|---------------|---------|
|      | 2-way valve kit    | Electromotoric Actuator | SFA21/18           | AC230V        | Siemens |
|      | 2-way valve Kit    | 2 port Valve            | VVI46/25           | -             | Siemens |
| ii   | 3-way valve kit    | Electromotoric Actuator | SFA21/18           | AC230V        | Siemens |
|      | o-way valve kit    | 3-port Valve            | VVI46/25           | -             | Siemens |
| iii  | Boom thermostat    | Wired                   | PAW-A2W-RTWIRED    | AC230V        |         |
| 101  | Room thermostat    | Wireless                | PAW-A2W-RTWIRELESS | AG230V        | -       |
| iv   | Mixing valve       | -                       | 167032             | AC230V        | Caleffi |
| v    | Pump               | -                       | Yonos 25/6         | AC230V        | Wilo    |
| vi   | Buffer tank sensor | -                       | PAW-A2W-TSBU       | -             | -       |
| vii  | Outdoor sensor     | -                       | PAW-A2W-TSOD       | -             | -       |
| viii | Zone water sensor  | -                       | PAW-A2W-TSHC       | -             | -       |
| ix   | Zone room sensor   | -                       | PAW-A2W-TSRT       | -             | -       |
| х    | Solar sensor       | -                       | PAW-A2W-TSSO       | -             | -       |

It is recommended to purchase the field supply accessories listed in above table.

- Handling of Mono bloc unit
  - Mono bloc unit is a large and heavy apparatus. The handling of the unit only to be done by lifting tools with slings. These slings can be fitted into sleeves at the unit's base frame.



#### 11.1.1 Select the Best Location

- Install the Mono bloc unit in outdoor locations only.
- Avoid installations in areas where the ambient temperature may drop below -20°C.
- The Mono bloc unit must be installed on a flat, solid surface.
- A place removed from any heat source or steam which may effect the operation of the Mono bloc unit.
- A place where air circulation is good.
- A place where drainage can be easily done.
- A place where Mono bloc unit's operation noise will not cause discomfort to the user.
- A place which is accessible for maintenance.
- Ensure to keep minimum distance of spaces as illustrated above from wall, ceiling, or other obstacles.
- A place where flammable gas leaking might not occur.


- A place where the Mono bloc unit's piping and wiring lengths come within reasonable ranges.
- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- Do not place any obstacles which may cause a short circuit of the discharged air.
- Avoid installing the Mono bloc unit at a location where suction side may be exposed directly to wind.
- If Mono bloc unit installed near sea, region with high content of sulphur or oily location (e.g. machinery oil, etc.), it lifespan maybe shorten.
- When installing the product in a place where it will be affected by typhoon or strong wind such as wind blowing between buildings, including the rooftop of a building and a place where there is no building in surroundings, fix the product with an overturn prevention wire, etc. (Overturn prevention fitting model number: K-KYZP15C)



## 11.1.2 Mono Bloc Unit Installation

Mono bloc unit will become heavy when filled with water. Please install the unit on a strong concrete floor and consider the weight of the unit and water.

- Fix Mono bloc unit on the concrete floor with M12 anchor bolt at 4 locations.
- Pull-out strength of these anchor bolts must be above 15000N.



## 11.1.2.1 Disposal of Mono Bloc Unit Drain Water

- When a Drain elbow is used, please ensure to follow below:
  - The unit should be placed on a stand which is taller than 50mm.
  - Cover the 8 holes (ø20mm) with Rubber cap (refer to illustration below)
  - o Use a tray (field supply) when necessary to dispose the Mono bloc unit drain water.



• If the unit is used in an area where temperature falls below 0°C for 2 or 3 consecutive days, it is recommended not to use the Drain elbow and Rubber cap, for the drain water freezes and the fan will not rotate.

## 11.1.3 Piping Installation

#### 🕂 WARNING

This section is for authorized and licensed electrician / water system installer only. Work behind the front plate secured by screws must only be carried out under supervision of qualified contractor, installation engineer or service person.

Please engage a licensed water circuit installer to install this water circuit.

- This water circuit must comply with relevant European and national regulations (including EN61770), and local building regulation codes.
- Ensure the components installed in the water circuit could withstand water pressure during operation.
- Do not apply excessive force to piping that may damage the pipes.
- Use Rp 1<sup>1</sup>/<sub>4</sub>" nut for both water inlet and water outlet connection and clean all piping with tap water before connecting to the Mono bloc unit.
- Cover the pipe end to prevent dirt and dust when inserting it through a wall. If an existing tank is to be connected to this Mono bloc unit, ensure the pipes are clean before water pipe installation is carried out.
- Choose proper sealer which can withstand the pressures and temperatures of the system.
- Make sure to use two spanners to tighten the connection. Tighten the nuts with torque wrench: 117.6 N•m.
- If non-brass metallic piping is used for installation, make sure to insulate the piping to prevent galvanic corrosion.
- Do not use pipes that are crushed or deformed. If these inferior pipes are used, it may cause unit malfunction.
- Make sure to insulate the water circuit piping (insulator thickness : 20mm or more) to prevent condensation during cooling operation and reduction of heating capacity, as well as avoid freezing of the outdoor water circuit piping during winter season.
- After installation, check the water leakage condition in connection area during test run.
- In case of a power supply failure or pump operating failure, drain the system (as suggested in the figure below).






When water is idle inside the system, freezing up is very likely to happen which could damage the system.

#### Drainage piping installation

- Use a drain hose with inner diameter of 15 mm.
- The hose must be installed in a continuously downward direction and left open to the frost-free atmosphere.
- If drain hose is long, use a metal support fixture along the way to eliminate the wavy pattern of drain tube.
- Water will drip from this hose, therefore the outlet of this hose must be installed in an area where the outlet cannot become blocked.
- Do not insert this hose into sewage or drain pipe that may generate ammonia gas, sulfuric gas, etc.
- If necessary, use a hose clamp to tighten the hose at drain hose connector to prevent it from leaking.




## 11.1.4 Connect the Cable to Mono Bloc Unit

#### 

This section is for authorised and licensed electrician only. Work behind the cabinet front plate secured by screws must only be carried out under supervision of qualified contractor, installation engineer or service person.

## 11.1.4.1 Remove The Cabinet Front Plate

- 1. Remove the 4 mounting screws as shown in the illustration.
- 2. Slide the cabinet front plate downward to release the pawls. Then, pull it toward front to remove it.




## 11.1.4.2 Fixing of Power Supply Cord

(REFER TO WIRING DIAGRAM AT UNIT FOR DETAIL)


- 1. An isolating device must be connected to the power supply cable.
  - Isolating device (Disconnecting means) should have minimum 3.0 mm contact gap.
  - Connect the approved polychloroprene sheathed power supply 1 cord and power supply 2 cord and type designation 60245 IEC 57 or heavier cord to the terminal board, and to the other end of the cord to isolating device (Disconnecting means). See below table for cable size requirement.

| Model                           | Power Supply Cord | Cable Size                  | Isolating Devices | Recommended RCD   |
|---------------------------------|-------------------|-----------------------------|-------------------|-------------------|
| WH-MDC012H6E5 and WH-MDC016H6E5 | 1                 | 3 x min 4.0 mm <sup>2</sup> | 30A               | 30mA, 2P, type A  |
|                                 | 2                 | 3 x min 4.0 mm <sup>2</sup> | 30A               | 30mA, 2P, type AC |

- 2. To avoid the cable and cord being damaged by sharp edges, the cable and cord must be passed through the designated holes before being connected to the terminal block.
- 3. Secure the cable onto the control board with the holder (clamper).



## 11.1.4.3 Wire Stripping and Connecting Requirement




## 11.1.4.4 Connecting Requirement

For WH-MDC12H6E5 and WH-MDC16H6E5

- This equipment's power supply 1 complies with IEC/EN 61000-3-12 provided that the short circuit power S<sub>sc</sub> is greater than or equal to 1100kW at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short circuit power S<sub>sc</sub> greater than or equal to 1100kW.
- The equipment's Power Supply 1 complies with IEC/EN 61000-3-11 and shall be connected to a suitable supply network, having services current capacity ≥ 100A per phase. Please liaise with supply authority that the service current capacity at the interface point is sufficient for the installation of the equipment.
- The equipment's Power Supply 2 complies with IEC/EN 61000-3-12.
- The equipment's Power Supply 2 complies with IEC/EN 61000-3-11 and shall be connected to suitable supply network, with the following maximum permissible system impedance  $Z_{max} = 0.193$  ohm ( $\Omega$ ) at the interface. Please liaise with supply authority to ensure that the Power Supply 2 is connected only to a supply of that impedance or less.


## 11.1.4.5 Connecting with external device (optional)

- All connections shall follow to the local national wiring standard.
- It is strongly recommended to use manufacturer-recommended parts and accessories for installation.
- For connection to main PCB
  - 1 Two-way valve shall be spring and electronic type, refer to "Field Supply Accessories" table for details. Valve cable shall be (3 x min 1.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
    - \* note: Two-way Valve shall be CE marking compliance component.
      - Maximum load for the valve is 9.8VA.
  - 2 Three-way valve shall be spring and electronic type. Valve cable shall be (3 x min 1.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
    - \* note: Shall be CE marking compliance component.
      - It shall be directed to heating mode when it is OFF.
      - Maximum load for the valve is 9.8VA.
  - 3 Room thermostat cable must be (4 or 3 x min 0.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier cord, or similarly double insulation sheathed cable.
  - 4 Maximum output power of booster heater shall be ≤ 3 kW. Booster heater cable must be (3 x min 1.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier.
  - 5 Extra pump cable shall be (2 x min 1.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier.
  - 6 Boiler contact cable shall be (2 x min 0.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier.
  - 7 External control shall be connected to 1-pole switch with min 3.0 mm contact gap. Its cable must be (2 x min 0.5 mm<sup>2</sup>), double insulation layer of PVC-sheathed or rubber-sheathed cable.
    - \* note: Switch used shall be CE compliance component.
      - Maximum operating current shall be less than 3Arms.
  - 8 Tank sensor shall be resistance type, please refer to graph below for the characteristic and details of sensor. Its cable shall be (2 x min 0.3 mm<sup>2</sup>), double insulation layer (with insulation strength of min 30V) of PVCsheathed or rubber-sheathed cable.




- 9 Room sensor zone 1 cable shall be (2 x min 0.3 mm<sup>2</sup>) double insulation layer of PVC-sheathed or rubbersheathed.
- 10 Outdoor air sensor cable shall be (2 x min 0.3 mm<sup>2</sup>) double insulation layer of PVC-sheathed or rubbersheathed.

11 Tank OLP cable must be (2 x min 0.5 mm<sup>2</sup>), double insulation layer of PVC-sheathed or rubber-sheathed cable.




How to guide optional cables and power supply cords to Bushing 15




How to guide optional ca bles and p ower supply cords (view without inte rnal wiring)

- For connection to optional PCB
  - 1 By connecting optional PCB, 2 Zone temperature control can be achieved. Please connect mixing valves, water pumps and thermistors in zone 1 and zone 2 to each terminals in optional PCB. Temperature of each zone can be controlled independently by remote controller.
  - 2 Pump zone 1 and zone 2 cable shall be (2 x min 1.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier.
  - 3 Solar pump cable shall be  $(2 \text{ x min } 1.5 \text{ mm}^2)$ , of type designation 60245 IEC 57 or heavier.
  - 4 Pool pump cable shall be  $(2 \text{ x min } 1.5 \text{ mm}^2)$ , of type designation 60245 IEC 57 or heavier.
  - 5 Room thermostat zone 1 and zone 2 cable shall be (4 x min 0.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier.
  - 6 Mixing valve zone 1 and zone 2 cable shall be (3 x min 1.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier.
  - 7 Room sensor zone 1 and zone 2 cable shall be (2 x min 0.3 mm<sup>2</sup>), double insulation layer (with insulation strength of minimum 30V) of PVC-sheathed or rubber-sheathed cable.
  - 8 Buffer tank sensor, pool water sensor and solar sensor cable shall be (2 x min 0.3 mm<sup>2</sup>), double insulation layer (with insulation strength of minimum 30V) of PVC-sheathed or rubber-sheathed cable.

- 9 Water sensor zone 1 and zone 2 cable shall be (2 x min 0.3 mm<sup>2</sup>), double insulation layer of PVC-sheathed or rubber-sheathed cable.
- 10 Demand signal cable shall be (2 x min 0.3 mm<sup>2</sup>), double insulation layer of PVC-sheathed or rubbersheathed cable.
- 11 SG signal cable shall be (3 x min 0.3 mm<sup>2</sup>), double insulation layer of PVC-sheathed or rubber-sheathed cable.
- 12 Heat/Cool switch cable shall be (2 x min 0.3 mm<sup>2</sup>), double insulation layer of PVC-sheathed or rubbersheathed cable.
- 13 External compressor switch cable shall be (2 x min 0.3 mm<sup>2</sup>), double insulation layer of PVC-sheathed or rubber-sheathed cable.



How to guide optional cables to bushing 15



How to guide optional cables (view without internal wiring)


| Terminal screw on PCB | Maximum tightening torque cN•m {kgf•cm} |
|-----------------------|---|
| M3                    | 50 {5.1}                                |
| M4                    | 120 {12.24}                             |

## 11.1.5 Installation of Remote Controller

## 11.1.5.1 Installation Location

- Install at the height of 1 to 1.5 m from the floor (Location where average room temperature can be detected).
- Install vertically against the wall.
- Avoid the following locations for installation.
  - 1 By the window, etc. exposed to direct sunlight or direct air.
  - 2 In the shadow or backside of objects deviated from the room airflow.
  - 3 Location where condensation occurs (The Remote Controller is not moisture proof or drip proof.)
  - 4 Location near heat source.
  - 5 Uneven surface.
- Keep distance of 1 m or more from the TV, radio and PC. (Cause of fuzzy image or noise)

## 11.1.5.2 Remote Controller Wiring




- Remote Controller cable shall be (2 x min 0.3 mm<sup>2</sup>), of double insulation PVC-sheathed or rubber sheathed cable. Total cable length shall be 50 m or less.
- Be careful not to connect cables to other terminals (e.g. power source wiring terminal). Malfunction may occur.
- Do not bundle together with the power source wiring or store in the same metal tube. Operation error may occur.


# 11.1.5.3 Mounting The Remote Controller

#### For exposed type

Preparation: Make 2 holes for screws using a driver.




# For embedded type **Preparation:** Make 2 holes for screws using a driver.




## 11.1.6 Installation of Network Adaptor and Base Pan Heater

### 11.1.6.1 Network Adaptor and Installation (Optional)

- 1. Open the Cabinet front plate, then connect the Network Adaptor Cable to the CN-CNT connector on the printed circuit board.
  - Pull the cable out of the Mono bloc unit so that there is no pinching.
  - If an optional PCB has been install in the Mono bloc unit, connect the CN-CNT connector to Optional PCB.




2. Insert a flat head screwdriver into the slot on the top of the adaptor and remove the cover. Connect the other end of the CN-CNT cable connector to the connector inside the adaptor.




- 11.1.6.2 Base Pan Heater (Optional)
- It is strongly recommended to install a Base Pan Heater (optional) if the Mono bloc unit is installed in cold climate area. Refer the Base Pan Heater (optional) installation instruction for details of installation.

## 11.1.7 Charging the Water


- Make sure all the piping installations are properly done before carry out below steps.
  - 1 Open Cabinet front plate to access to the Pressure Relief Valve and Air Purge Valve.
  - 2 Turn the plug on the Air Purge Valve outlet anticlockwise by one complete turn from fully closed position.



3. On the wall near the Mono bloc unit, attach the adaptor by screwing screws through the holes in the back cover.




4. Pull the CN-CNT cable through the hole in the bottom of the adaptor and re-attach the front cover to the back cover.




5. Use the included cord clamp to fix the CN-CNT cable to the wall.

Pull the cable around as shown in the diagram so that external forces cannot act on the connector in the adaptor. Use the included cable tie to fix the cables together.



3 Set the Pressure Relief Valve level "DOWN".



- 4 Start filling water (with pressure more than 0.1 MPa (1 bar)) to the Mono bloc unit via water inlet. Stop filling water if the free water flow through Pressure Relief Valve drain hose.
- 5 Turn ON the power supply and make sure Water Pump is running.
- 6 Check and make sure no water leaking at the tube connecting points.
- 7 Reinstall the Cabinet front plate by tightening the 2 mounting screws.

### 11.1.8 Reconfirmation

#### 

Be sure to switch off all power supply before performing each of the below checkings. Before obtaining access to terminals, all supply circuits must be disconnected.

#### 11.1.8.1 Check Water Pressure \*(0.1 MPa = 1 bar)

Water pressure should not lower than 0.05 MPa (with inspects the Water Pressure Gauge). If necessary add tap water into the water circuit.

### 11.1.8.2 Check Pressure Relief Valve

- Check for correct operation of Pressure Relief Valve by turning on the lever to become horizontal.
- If you do not hear a clacking sound (due to water drainage), contact your local authorized dealer.
- Push down the lever after finish checking.
- In case the water keeps drained out from the unit, switch off the system, and then contact your local authorized dealer.

#### 11.1.8.3 Expansion Vessel Pre Pressure Checking

[Upper limit water volume of the system] The Mono bloc unit has a build-in Expansion Vessel with 10 L air capacity and initial pressure of 1 bar.

• Without antifreeze agent condition

Total amount of water in the system should be below 200 L.

If the total amount of water is more than 200 L, please add expansion vessel (field supply).

• With antifreeze agent condition

In the case of using antifreeze agent, expansion rate  $\epsilon$  is different depending on its maker.

Please refer to the antifreeze agent maker for the expansion rate  $\varepsilon$  before calculate the upper limit water volume of the system.

The expansion vessel capacity required for the system can be calculated from the formula below.

$$V = \frac{\epsilon x V_0}{1 - \frac{98 + P_1}{98 + P_2}}$$

- V : Required gas volume <expansion vessel volume L>
- Vo : System total water volume <L>
- $\epsilon$  : Expansion rate  $5 \rightarrow 60\,^\circ C$  = (depends on antifreeze agent used)
- $P_1$ : Expansion tank filling pressure = (100) kPa
- $P_2$ : System maximum pressure = 300 kPa
- ( ) Please confirm at actual place
- The gas volume of the sealed type expansion vessel is presented by <V;</li>
   O It's advised to add 10% margin for required gas volume of calculation.

[Adjustment of the initial pressure of the expansion vessel when there is a difference in installation height] If the height difference between the Mono bloc unit and the highest point of the system water circuit (H) is more than 7m, please adjust the initial pressure of the expansion vessel (Pg) according to the following formula.

# 11.1.8.4 Check RCCB

Ensure the RCCB set to "ON" condition before check RCCB.

Turn on the power supply to the Mono bloc unit. This testing could only be done when power is supplied to the Mono bloc unit.

### 🔨 warning

Be careful not to touch parts other than RCCB test button when the power is supplied to Mono bloc unit. Else, electrical shock may happen.

- Push the "TEST" button on the RCCB. The lever would turn down and indicate "0", if it functions normal.
- Contact authorized dealer if the RCCB malfunction.
- Turn off the power supply to the Mono bloc unit.
- If RCCB functions normal, set the lever to "ON" again after testing finish.

This product contains fluorinated greenhouse gasses. Refrigerant type : R410A (GWP=2088) For WH-MDC12H6E5 & WH-MDC16H6E5 Amount : 2.1 kg (4.385 ton  $CO_2$  equivalent)

### 11.1.9 Test Run

- 1. Before test run, make sure below items have been checked:-
  - Pipework are properly done.
  - Electric cable connecting work are properly done.
  - Mono bloc unit is filled up with water and trapped air is released.
- Antifreeze agent must be added into water circuit to prevent freezing of water when outdoor ambient temperatures is low. Recommended antifreeze: Propylene glycol: 40% (equivalent to -20°C)
- 3. Set ON to the Mono bloc unit and RCCB. Then, for remote control operation please refers to (Mono bloc) Air-to-Water Heatpump's operation instruction.
- 4. For normal operation, pressure gauge reading should be in between 0.05 MPa and 0.3 MPa.
- 5. After test run, please clean the Water filter. Reinstall it after finish cleaning.

## 11.1.9.1 Reset Overload Protector

Overload Protector serves the safety purpose to prevent the water over heating. When the Overload Protector trip at high water temperature, take below steps to reset it.

- 1. Take out the cover.
- 2. Use a test pen to push the centre button gently in order to reset the Overload Protector.
- 3. Fix the cover to the original fixing condition.




#### 11.1.10 Maintenance

• In order to ensure optimal performance of the unit, seasonal inspections on the unit, functional check of RCCB, field wiring and piping have to be carried out at regular intervals. This maintenance should be carried out by authorized dealer.

#### 11.1.10.1 Maintenance for Water Filter Set

- 1. Remove the Cover by loosening the mounting screws to access to the Water Filter Set.
- 2. Turn OFF power supply.
- 3. Set the two valves for the Water Filter Set to "CLOSE".
- 4. Take off the clip, then gently pull out the mesh. Beware of small amount water drain out from it.
- 5. Clean the mesh with warm water to remove all the stain. Use soft brush if necessary.
- 6. Reinstall the mesh to the Water Filter Set and set back the clip on it.
- 7. Set the two valves for the Water Filter Set to "OPEN".
- 8. Turn ON power supply.
- 9. After cleaning, reinstall the Cover by tightening the mounting screws properly.

#### WARNING Do not add or replace other than R410A type. It may cause product damage, burst, injury and etc. Use compatible R410A tools for refrigerant piping work and refrigerant charging during installation or servicing.




# 11.2 Variation of system

This section introduces variation of various systems using Air-To-Water Heatpump and actual setting method.

## 11.2.1 Introduce application related to temperature setting.


## 11.2.1.1 Temperature setting variation for heating

1. Remote Controller




Connect floor heating or radiator directly to the Mono bloc. This is the basic form of the most simple system.

#### 2. Room Thermostat



Connect floor heating or radiator directly to the Mono bloc. Install the remote controller in the room where floor heating is installed. This is an application that uses remote controller as Room Thermostat.

#### 3. External Room Thermostat



| Setting of remote controller  |   |
|---|---|
| Installer setting<br>System setup<br>Optional PCB connectivity - No | ) |
| Zone & Sensor:<br>Room thermostat<br>(External)                     |   |


Connect floor heating or radiator directly to Mono bloc. Install separate external Room Thermostat (field supply) in the room where floor heating is installed. This is an application that uses external Room Thermostat.


| Setting of remote controller  |
|---|
| Installer setting<br>System setup<br>Optional PCB connectivity - No |
| Zone & Sensor:<br>Water temperature                                 |

| g of remote controller |
|------------------------|
|------------------------|


Installer setting System setup Optional PCB connectivity - No Zone & Sensor: Room thermostat Internal

#### 4. Room Thermistor






Connect floor heating or radiator directly to Mono bloc. Install separate external room thermistor (specified by Panasonic) in the room where floor heating is installed. This is an application that uses external room thermistor.



# 11.2.1.2 Examples of installations

#### Floor heating 1 + Floor heating 2



Connect floor heating to 2 circuits through buffer tank as shown in the figure.

Install mixing valves, pumps and thermistors (specified by Panasonic) on both circuits.

Install the remote controller in one of the circuit and use it as Room Thermostat.


Install external Room Thermostat (field supply) in another circuit.

Both circuits can set circulation water temperature independently.

Install buffer tank thermistor on buffer tank.

It requires connection setting of buffer tank and  $\Delta T$  temperature setting at heating operation separately. This system requires optional PCB (CZ-NS4P).

#### Floor heating + Radiator



Connect floor heating or radiator to 2 circuits through buffer tank as shown in figure.

Install pumps and thermistors (specified by Panasonic) on both circuits.

Install mixing valve in the circuit with lower temperature among the 2 circuits.

(Generally, if install floor heating and radiator circuit at 2 zones, install mixing valve in floor heating circuit.)

For temperature setting, select circulation water temperature for both circuits.


Both circuits can set circulation water temperature independently.

Install buffer tank thermistor on buffer tank.

It requires connection setting of buffer tank and  $\Delta T$  temperature setting at heating operation separately. This system requires the optional PCB (CZ-NS4P).

Mind that if there is no mixing valve at the secondary side, the circulation water temperature may get higher than setting temperature.

#### Floor heating + Swimming pool



Connect floor heating and swimming pool to 2 circuits through buffer tank as shown in figure.

Install mixing valves, pumps and thermistors (specified by Panasonic) on both circuits.

Then, install additional pool heat exchanger, pool pump and pool sensor on pool circuit.

Install the remote controller in room where floor heating is installed. Circulation water temperature of floor heating and swimming pool can be set independently.


Install buffer tank sensor on buffer tank.

It requires connection setting of buffer tank and  $\Delta T$  temperature setting at heating operation separately. This system requires the optional PCB (CZ-NS4P).

\* Must connect swimming pool to "Zone 2".

If it is connected to swimming pool, operation of pool will stop when "Cooling" is operated.

#### Swimming pool only



This is an application that connects to the swimming pool only.

Connects pool heat exchanger directly to Mono bloc without using buffer tank.

Install pool pump and pool sensor (specified by Panasonic) at secondary side of the pool heat exchanger.


Install the remote controller in room where floor heating is installed.

Temperature of swimming pool can be set independently.

This system requires the optional PCB (CZ-NS4P).

In this application, cooling mode cannot be selected. (not display on remote controller)

#### Simple 2 zone (Floor heating + Radiator)



This is an example of simple 2 zone control without using buffer tank.

Built-in pump from Mono bloc served as a pump in zone 1.

Install mixing valve, pump and thermistor (specified by Panasonic) on zone 2 circuit.

Please be sure to assign high temperature side to zone 1 as temperature of zone 1 cannot be adjusted.

Zone 1 thermistor is required to display temperature of zone 1 on remote controller.

Circulation water temperature of both circuits can be set independently.

(However, temperature of high temperature side and low temperature side cannot be reversed) This system requires the optional PCB (CZ-NS4P).

#### (CAUTION)


• Thermistor 1 does not affect operation directly. But error happens if it is not installed.

Please adjust flow rate of zone 1 and zone 2 to be in balance. If it is not adjusted correctly, it may affects the performance.

(If zone 2 pump flow rate is too high, there is possibility that no hot water flowing to zone 1.) Flow rate can be confirmed by "Actuator Check" from maintenance menu.


## 11.2.2 Introduce applications of system that uses optional equipment.

DHW (Domestic Hot Water) Tank connection



This is an application that connects the DHW tank to the Mono bloc through 3-way valve. DHW tank's temperature is detected by tank thermistor (specified by Panasonic).

#### Tank + Solar connection




This is an application that connects the DHW tank to the Mono bloc through 3-way valve before connect the solar water heater to heat up the tank. DHW tank's temperature is detected by tank thermistor (specified by Panasonic). Solar panel's temperature is detected by solar thermistor (specified by Panasonic).

DHW tank shall use tank with built-in solar heat exchange coil independently.


Heat accumulation operates automatically by comparing the temperature of tank thermistor and solar thermistor. During winter season, solar pump for circuit protection will be activated continuously. If does not want to activate the solar pump operation, please use glycol and set the anti-freezing operation start temperature to -20°C. This system requires optional PCB (CZ-NS4P).

#### **Buffer tank connection**



This is an application that connects the buffer tank to the Mono bloc. Buffer tank's temperature is detected by buffer tank thermistor (specified by Panasonic). This system requires optional PCB (CZ-NS4P).

#### Buffer tank + Solar



This is an application that connects the buffer tank to the Mono bloc before connecting to the solar water heater to heat up the tank.

Buffer tank's temperature is detected by buffer tank thermistor (specified by Panasonic).


Solar panel's temperature is detected by solar thermistor (specified by Panasonic).

Buffer tank shall use tank with built-in solar heat exchange coil independently.

During winter season, solar pump for circuit protection will be activated continuously. If does not want to activate the solar pump operation, please use glycol and set the anti-freezing operation start temperature to -20°C.

Heat accumulation operates automatically by comparing the temperature of tank thermistor and solar thermistor. This system requires optional PCB (CZ-NS4P).

#### **Boiler connection**



This is an application that connects the boiler to the Mono bloc, to compensate for insufficient capacity by operate boiler when outdoor temperature drops & heat pump capacity is insufficient.

Boiler is connected parallel with heat pump against heating circuit.

There are 3 modes selectable by remote controller for boiler connection.

Besides that, an application that connects to the DHW tank's circuit to heat up tank's hot water is also possible.

(Operation setting of boiler shall be responsible by installer.)

This system requires optional PCB (CZ-NS4P).

Depending on the settings of the boiler, it is recommended to install buffer tank as temperature of circulating water may get higher. (It must connect to buffer tank especially when selecting Advanced Parallel setting.)

#### 

Panasonic is NOT responsible for incorrect or unsafe situation of the boiler system.

### $\bigwedge$ caution

Make sure the boiler and its integration in the system complies with applicable legislation. Make sure the return water temperature from the heating circuit to the indoor unit does NOT exceed 55°C. Boiler is turned off by safety control when the water temperature of the heating circuit exceed 85°C.


# 11.3 How to Fix External Device

## 11.3.1 Connecting Cables Length

When connecting cables between Mono bloc and external devices, the length of the said cables must not exceed the maximum length as shown in the table.

| External device            | Maximum cables length (m) |
|----------------------------|---------------------------|
| Two-way valve              | 50                        |
| Three-way valve            | 50                        |
| Mixing valve               | 50                        |
| Room thermostat            | 50                        |
| Booster heater             | 50                        |
| Extra pump                 | 50                        |
| Solar pump                 | 50                        |
| Pool pump                  | 50                        |
| Pump                       | 50                        |
| Boiler contact             | 50                        |
| External control           | 50                        |
| Tank sensor                | 30                        |
| Room sensor                | 30                        |
| Outdoor air sensor         | 30                        |
| Tank OLP                   | 30                        |
| Buffer tank sensor         | 30                        |
| Pool water sensor          | 30                        |
| Solar sensor               | 30                        |
| Water sensor               | 30                        |
| Demand signal              | 50                        |
| SG signal                  | 50                        |
| Heat/Cool switch           | 50                        |
| External compressor switch | 50                        |

# 11.3.1.1 Connection of the main PCB



#### Signal inputs

| Optional<br>Thermostat       | L N =AC230V, Heat, Cool=Thermostat heat, Cool<br>terminal<br>*It does not function when using the optional PCB                      |
|------------------------------|---|
| OLP for<br>booster<br>heater | Dry contact Vcc-Bit1, Vcc-Bit2 open/short (System<br>setup necessary)<br>It is connected to the safety device (OLP) of DHW<br>tank. |
| External control             | Dry contact Open=not operate, Short=operate<br>(System setup necessary)<br>Able to turn ON/OFF the operation by external<br>switch  |
| Remote controller            | Connected (Please use 2 cores wire for relocation<br>and extension. Total cable length shall be 50m or<br>less.)                    |


#### Outputs

| 3-way valve       | AC230V N=Neutral Open, Close=direction (For circuit switching when connected to DHW tank) |  |
|-------------------|---|--|
| 2-way valve       | AC230V N=Neutral Open, Close (Prevent water<br>circuit pass through during cooling mode)  |  |
| Extra pump        | AC230V (Used when Mono bloc pump capacity is insufficient)                                |  |
| Booster<br>heater | AC230V (Used when using booster heater in DHW tank)                                       |  |
| Boiler<br>contact | Dry contact (System setup necessary)  |  |

#### Thermistor inputs

| Zone 1 room sensor    | PAW-A2W-TSRT  |
|-----------------------|---|
| Outdoor air<br>sensor | AW-A2W-TSOD (Total cable length shall be 30m or less) |
| Tank sensor           | Please use Panasonic specified part                   |

# 11.3.1.2 Connection of Optional PCB (CZ-NS4P)



#### Signal inputs

| Optional<br>Thermostat | L N =AC230V, Heat, Cool=Thermostat heat, Cool terminal   |  |
|------------------------|--|--|
| SG signal              | Dry contact Vcc-Bit1, Vcc-Bit2 open/short (System<br>setup necessary)<br>Switching SW (Please connect to the 2 contacts<br>controller) |  |
| Heat/Cool<br>SW        | Dry contact Open=Heat, Short=Cool (System setup necessary)   |  |
| External comp.SW       | Dry contact Open=Comp.ON, Short=Comp.OFF (System setup necessary)  |  |
| Demand signal          | DC 0~10V (System setup necessary)<br>Please connect to the DC 0~10V controller.  |  |

#### Outputs

| Mixing valve        | AC230V N=Neutral Open, Close=mixture<br>direction<br>Operating time: 30s~120s |
|---------------------|---|
| Pool pump           | AC230V  |
| Solar pump          | AC230V  |
| Zone pump<br>heater | AC230V  |


#### Thermistor inputs

| Zone room sensor   | PAW-A2W-TSRT    |  |
|--------------------|-----------------|--|
| Buffer tank sensor | PAW-A2W-TSBU    |  |
| Pool water sensor  | PAW-A2W-TSHC    |  |
| Zone water sensor  | I PAW-A2W-I SHC |  |
| Solar sensor       | PAW-A2W-TSSO    |  |

### 11.3.1.3 Recommended External Device Specification


- This section explains about the external devices (optional) recommended by Panasonic. Please always ensure to use the correct external device during system installation.
- For optional sensor.
  - 1 Buffer tank sensor: PAW-A2W-TSBU Use for measurement of the buffer tank temperature.

Insert the sensor into the sensor pocket and paste it on the buffer tank surface.




2 Zone water sensor: PAW-A2W-TSHC Use to detect the water temperature of the control zone.

Mount it on the water piping by using the stainless steel metal strap and contact paste (both are included).




3 Outdoor sensor: PAW-A2W-TSOD If the installation location of the outdoor unit is exposed to direct sunlight, the outdoor air temperature sensor will be unable to measure the actual outdoor ambient temperature correctly.

In this case, optional outdoor temperature sensor can be fixed at a suitable location to more accurately measure ambient temperature.




4 Room sensor: PAW-A2W-TSRT Install the room temperature sensor to the room which requires room temperature control.



5 Solar sensor: PAW-A2W-TSSO Use for measurement of the solar panel temperature.

Insert the sensor into the sensor pocket and paste it on the solar panel surface.



6 Please refer to the table below for sensor characteristic of the sensors mentioned above.

| Temperature (°C) | Resistance (kΩ) |
|------------------|-----------------|
| 150              | 0.147           |
| 140              | 0.186           |
| 130              | 0.236           |
| 120              | 0.302           |
| 110              | 0.390           |
| 100              | 0.511           |
| 90               | 0.686           |
| 80               | 0.932           |
| 70               | 1.279           |
| 65               | 1.504           |
| 60               | 1.777           |
| 55               | 2.106           |
| 50               | 2.508           |
| 45               | 3.003           |
| 40               | 3.615           |
| 35               | 4.375           |
| 30               | 5.326           |
| 25               | 6.523           |
| 20               | 8.044           |
| 15               | 9.980           |
| 10               | 12.443          |
| 5                | 15.604          |
| 0                | 19.70           |
| -5               | 25.05           |
| -10              | 32.10           |
| -15              | 41.45           |
| -20              | 53.92           |
| -25              | 70.53           |
| -30              | 93.05           |
| -35              | 124.24          |
| -40              | 167.82          |

For optional pump.
 Power supply: AC230V/50Hz, <500W</li>
 Recommended part: Yonos 25/6: made by Wilo




 For optional mixing valve. Power supply: AC230V/50Hz (input open/output close)
 Operating time: 30s~120s
 Recommended part: 167032: made by Caleffi




# 11.4 System Installation


# 11.4.1 Remote Controller Outline




|    | Name            | Function              |
|----|-----------------|-----------------------|
| A: | Main screen     | Display information   |
| B: | Menu            | Open/Close main menu  |
| C: | Triangle (Move) | Select or change item |
| D: | Operate         | Start/Stop operation  |
| E: | Back            | Back to previous item |
| F: | Quick Menu      | Open/Close Quick menu |
| G: | ОК              | Confirm               |




#### First time of power ON (Start of installation)



## 11.4.2 Installer Setup





## 11.4.3 System Setup

| 1. Optional PCB connectivity Initial setting: No   | System setup 17:26, Wed   |
|--|---|
| If function below is necessary, please purchase and install optional PCB. Please select Yes after installing optional PCB.   | Optional PCB connectivity<br>Zone & Sensor<br>Heater capacity   |
| 2-zone control   | Anti freezing   |
| <ul><li>Pool</li><li>Buffer tank</li></ul>   | ✓ Select [↓] Confirm  |
| <ul><li>Solar</li><li>External error signal output</li></ul>   |   |
| External control signal output     Demand control     SG ready     Stop heat source unit by external SW  |   |
|  |   |
| 2. Zone & Sensor Initial setting: Room and Water temp.   | System setup 17:26, Wed   |
|  | Optional PCB connectivity   |
| If no Optional PCB connectivity<br>Select sensor of room temperature control from the following 3 items  | Zone & Sensor   |
| <ul> <li>Water temperature (circulation water temperature)</li> <li>Room thermostat (Internal or External)</li> </ul>  | Heater capacity   |
| <ul><li>3 Room thermistor</li></ul>  | Anti freezing   |
| When there is Optional PCB connectivity  |   |
| ① Select either 1 zone control or 2 zone control. If it is 1 zone control or 2 zone control.   |   |
| If it is 1 zone, select either room or pool, select sensor<br>If it is 2 zone, after select sensor of zone 1, select either room or pool for zone  |   |
| 2, select sensor<br>(CAUTION) In 2 zone system, pool function can be set at zone 2 only.   |   |
|  |   |
|  | <b>_</b>  |
|  |   |
| 3. Heater capacity Initial setting: Depend on model  | System setup 17:26, Wed   |
| 3. Heater capacity     Initial setting: Depend on model       If there is built-in Heater, set the selectable heater capacity.   | Optional PCB connectivity   |
| If there is built-in Heater, set the selectable heater capacity.   | Optional PCB connectivity<br>Zone & Sensor  |
|  | Optional PCB connectivity   |
| If there is built-in Heater, set the selectable heater capacity.   | Optional PCB connectivity<br>Zone & Sensor<br>Heater capacity   |
| If there is built-in Heater, set the selectable heater capacity.   | Optional PCB connectivity<br>Zone & Sensor<br>Heater capacity<br>Anti freezing  |
| If there is built-in Heater, set the selectable heater capacity.<br>(CAUTION) There are models which cannot select heater.   | Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ♦ Select  |
| If there is built-in Heater, set the selectable heater capacity.   | Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ♦ Select       [ ← J] Confirm         System setup       17:26, Wed   |
| If there is built-in Heater, set the selectable heater capacity.<br>(CAUTION) There are models which cannot select heater.<br>4. Anti freezing Initial setting: Yes<br>Operate anti-freezing of water circulation circuit.   | Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ♦ Select  |
| If there is built-in Heater, set the selectable heater capacity.         (CAUTION) There are models which cannot select heater.         4. Anti freezing         Initial setting: Yes  | Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ◆ Select         [←] Confirm         System setup         17:26, Wed         Optional PCB connectivity  |
| If there is built-in Heater, set the selectable heater capacity.<br>(CAUTION) There are models which cannot select heater.<br>4. Anti freezing Initial setting: Yes<br>Operate anti-freezing of water circulation circuit.<br>If select Yes, when the water temperature is reaching its freezing temperature, the  | Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ◆ Select [←] Confirm         System setup         17:26, Wed         Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing  |
| If there is built-in Heater, set the selectable heater capacity.<br>(CAUTION) There are models which cannot select heater.<br>4. Anti freezing Initial setting: Yes<br>Operate anti-freezing of water circulation circuit.<br>If select Yes, when the water temperature is reaching its freezing temperature, the<br>circulation pump will start up. If the water temperature does not reach the pump<br>stop temperature, back-up heater will be activated.<br>(CAUTION) If set No, when the water temperature is reaching its freezing   | Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ◆ Select [←] Confirm         System setup         17:26, Wed         Optional PCB connectivity         Zone & Sensor         Heater capacity  |
| If there is built-in Heater, set the selectable heater capacity.<br>(CAUTION) There are models which cannot select heater.<br>4. Anti freezing Initial setting: Yes<br>Operate anti-freezing of water circulation circuit.<br>If select Yes, when the water temperature is reaching its freezing temperature, the<br>circulation pump will start up. If the water temperature does not reach the pump<br>stop temperature, back-up heater will be activated.   | Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ◆ Select [←] Confirm         System setup         17:26, Wed         Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing  |
| If there is built-in Heater, set the selectable heater capacity.<br>(CAUTION) There are models which cannot select heater.<br>4. Anti freezing Initial setting: Yes<br>Operate anti-freezing of water circulation circuit.<br>If select Yes, when the water temperature is reaching its freezing temperature, the<br>circulation pump will start up. If the water temperature does not reach the pump<br>stop temperature, back-up heater will be activated.<br>(CAUTION) If set No, when the water temperature is reaching its freezing<br>temperature or below 0°C, the water circulation circuit may freeze and   | Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ◆ Select [←] Confirm         System setup         17:26, Wed         Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing  |
| If there is built-in Heater, set the selectable heater capacity.<br>(CAUTION) There are models which cannot select heater.<br>4. Anti freezing Initial setting: Yes<br>Operate anti-freezing of water circulation circuit.<br>If select Yes, when the water temperature is reaching its freezing temperature, the<br>circulation pump will start up. If the water temperature does not reach the pump<br>stop temperature, back-up heater will be activated.<br>(CAUTION) If set No, when the water temperature is reaching its freezing<br>temperature or below 0°C, the water circulation circuit may freeze and   | Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ◆ Select [←] Confirm         System setup         17:26, Wed         Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing  |
| If there is built-in Heater, set the selectable heater capacity.         (CAUTION) There are models which cannot select heater.         4. Anti freezing       Initial setting: Yes         Operate anti-freezing of water circulation circuit.         If select Yes, when the water temperature is reaching its freezing temperature, the circulation pump will start up. If the water temperature does not reach the pump stop temperature, back-up heater will be activated.         (CAUTION) If set No, when the water temperature is reaching its freezing temperature or below 0°C, the water circulation circuit may freeze and cause malfunction.         5. Tank connection       Initial setting: No   | Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ◆ Select         [↓] Confirm         System setup         17:26, Wed         Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ◆ Select         [↓] Confirm   |
| If there is built-in Heater, set the selectable heater capacity.         (CAUTION) There are models which cannot select heater.         4. Anti freezing       Initial setting: Yes         Operate anti-freezing of water circulation circuit.       If select Yes, when the water temperature is reaching its freezing temperature, the circulation pump will start up. If the water temperature does not reach the pump stop temperature, back-up heater will be activated.         (CAUTION) If set No, when the water temperature is reaching its freezing temperature or below 0°C, the water circulation circuit may freeze and cause malfunction.         5. Tank connection       Initial setting: No         Select whether it is connected to hot water tank or not.  | Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing <ul> <li>Select</li> <li>Confirm</li> </ul> System setup       17:26, Wed         Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing   |
| If there is built-in Heater, set the selectable heater capacity.         (CAUTION) There are models which cannot select heater.         4. Anti freezing       Initial setting: Yes         Operate anti-freezing of water circulation circuit.         If select Yes, when the water temperature is reaching its freezing temperature, the circulation pump will start up. If the water temperature does not reach the pump stop temperature, back-up heater will be activated.         (CAUTION) If set No, when the water temperature is reaching its freezing temperature or below 0°C, the water circulation circuit may freeze and cause malfunction.         5. Tank connection       Initial setting: No   | Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ◆ Select [↓] Confirm         System setup       17:26, Wed         Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ◆ Select [↓] Confirm         System setup         17:26, Wed         Zone & Sensor         Heater capacity         Anti freezing         ◆ Select [↓] Confirm         System setup         17:26, Wed         Zone & Sensor         Heater capacity         Anti freezing         17:26, Wed         Zone & Sensor         Heater capacity         Anti freezing |
| If there is built-in Heater, set the selectable heater capacity.<br>(CAUTION) There are models which cannot select heater.<br>(CAUTION) There are models which cannot select heater.<br>(I select Yes, when the water circulation circuit.<br>If select Yes, when the water temperature is reaching its freezing temperature, the<br>circulation pump will start up. If the water temperature does not reach the pump<br>stop temperature, back-up heater will be activated.<br>(CAUTION) If set No, when the water temperature is reaching its freezing<br>temperature or below 0°C, the water circulation circuit may freeze and<br>cause malfunction.<br><b>5. Tank connection</b><br>Initial setting: No<br>Select whether it is connected to hot water tank or not.<br>If set Yes, it becomes setting that uses hot water function. | Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ◆ Select [↓] Confirm         System setup       17:26, Wed         Optional PCB connectivity         Zone & Sensor         Heater capacity         Anti freezing         ◆ Select [↓] Confirm         System setup         17:26, Wed         Zone & Sensor         Heater capacity         Anti freezing         ◆ Select [↓] Confirm         System setup       17:26, Wed         Zone & Sensor         Heater capacity  |

| 6. Buffer Tank connection Initial setting: No  |                           | System setup           | 17:26, Wed                |
|--|---------------------------|------------------------|---------------------------|
|  |                           | Heater capacity        |                           |
| Select whether it is connected to buffer tank for heating or not.<br>If buffer tank is used, please set Yes.   |                           | Anti freezing          |                           |
| Connect buffer tank thermistor and set, $\Delta T$ ( $\Delta T$ use to increase prima  | ary side temp             | Tank connection        |                           |
| against secondary side target temp).   |                           | Buffer tank connect    | ction                     |
| (CAUTION) Does not display if there is no Optional PCB.<br>If the buffer tank capacity is not so large, please set larger value for  | ΔΤ.                       | Select                 | [←] Confirm               |
|  |                           | <u></u>                |                           |
|  |                           |                        |                           |
| 7. Tank heater Initial setting: Internal   |                           | System setup           | 17:26, Wed                |
|  |                           | Anti freezing          | -,                        |
| Select to use either built-in heater or external heater as heater for ho   | t water tank.             | Tank connection        |                           |
| If heater is installed on tank, please select External.  |                           | Buffer tank connection | ction                     |
| (CAUTION) Does not display if there is no tank for hot water supply.   |                           | Tank heater            | Clion                     |
|  |                           | Select                 | [₊] Confirm               |
| Please set "Tank heater" to "ON" in the "Function setup" from remote<br>when using heater to boil the tank.  | e controller              |                        |                           |
| External A setting which is using booster heater installed on<br>DHW tank to boil the tank.<br>The permissible heater capacity is 3kW and below.<br>The operation to boil the tank with heater is as below.<br>In addition, be sure to set suitable "Tank heater: ON<br>time"<br>For 65°C setting<br>Tank temp.<br>65<br>53<br>HP thermo OFF | boil<br>The<br>Tank ten   | For 65°C s             | etting A<br>HP thermo OFF |
| HP<br>Booster heater<br>Pump<br>8. Base pan heater Initial setting: No   | HP<br>Booster hea<br>Pump | ater                   | 17:26, Wed                |
|  |                           | Tank connection        |                           |
| Select whether Base pan heater is installed or not.  |                           | Buffer tank connection | ction                     |
| If set Yes, select to use either heater A or B.  |                           | Tank heater            |                           |
| A: Turn on Heater when heating with defrost operation only   |                           | Base pan heater        |                           |
| B: Turn on Heater at heating   |                           | Select                 | [₊] Confirm               |
|  |                           |                        |                           |
|  |                           |                        |                           |
|  |                           |                        |                           |
| 9. Alternative outdoor sensor Initial setting: No  |                           | System setup           | 17:26, Wed                |
|  |                           | Buffer tank conne      | ction                     |
| Set Yes if outdoor sensor is installed.  | noor of k+                | Tank heater            |                           |
| Controlled by optional outdoor sensor without reading the outdoor sen<br>pump unit.  | ISUI UI IIEAL             | Base pan heater        |                           |


Alternative outdoor sensor

[🖵] Confirm

Select

| 10. Bivalent Initial setting: No  | System setup 17:26, Wed   |
|---|---|
|   | Tank heater   |
| Set if heat pump linked with boiler operation.  | Base pan heater   |
| Connect the start signal of the boiler in boiler contact terminal (main PCB).<br>Set Bivalent connection to YES.  | Alternative outdoor sensor  |
| After that, please begin setting according to remote controller instruction.  | Bivalent  |
| Boiler icon will be displayed on remote controller top screen.  | Select [↓] Confirm  |
| There are 3 different modes in the boiler operation. Movement of each modes a<br>① Alternative (switch to boiler operation when drops below setting temperature<br>② Parallel (allow boiler operation when drops below setting temperature)<br>③ Advanced Parallel (able to slightly delay boiler operation time of parallel ope                      | e)  |
| When the boiler operation is "ON", "boiler contact" is "ON", "_"(underscore) will<br>Please set target temperature of boiler to be the same as heat pump temperatu<br>When boiler temperature is higher than heat pump temperature, zone temperat<br>This product only allows one signal to control the boiler operation. Operation set               | ure.<br>ture cannot be achieved if mixing valve is not instal led.      |
| Alternative mode Parallel   | I mode  |
|   | operate boiler and heat operate heat pump only                          |
| Outdoor temp.   | pump simultaneously   |
|   | Outdoor temp  |
| -10°C (setting from remote controller)  | -10°C (setting from remote controller)                                  |
| Advanced Parallel mode  |   |
| For heating   | For DHW tank  |
| operate boiler and heat<br>pump simultaneously  | operate boiler and heat operate heat pump only                          |
| Outdoor temp.   |   |
|   | Cutdoor temp.   |
| -10°C (setting from remote controller)  | -10°C (setting from remote controller)                                  |
| Although heat pump operates AND but water temperature does  | AND   |
| not reach this temperature for<br>more than 30 mins (setting  | If actual tank temp. does When tank<br>not achieve the setting temp. is |
| from remote controller)   | temp. within 30min achieved, both                                       |
| Lowering  | g thermo ON controller), the boiler stop                                |
| Circulation water temp.   | Boiling initial Tank setting temp.                                      |
| Boiler temp. ON         Boiler temp. OFF         Setting temp         temp.           = Setting -8°C         = Setting -2°C         pump-           (setting from         (setting from         Boiler           remote controller)         remote controller)         Boiler   | 30 min (setting from the remote control)                                |
|   | time  |
| In Advanced Parallel mode, setting for both heating and tank can<br>be made simultaneously. During operation of "Heating/Tank" mode,<br>when each time the mode is switched, the boiler output will be<br>reset to OFF. Please have good understanding on the boiler control<br>characteristic in order to select the optimal setting for the system. |   |
| ·   |   |
| 11. External SW Initial setting: No   | System setup 17:26, Wed   |
|   | Base pan heater   |
| Able to turn ON/OFF the operation by external switch.   | Alternative outdoor sensor  |
|   | Bivalent  |
|   | External SW   |
|   | Select  [↓] Confirm   |
|   |   |
|   |   |
| 12. Solar connection Initial setting: No  | System setup 17:26, Wed   |
|   | Alternative outdoor sensor  |
| Set when solar water heater is installed.   |   |
|   | Bivalent  |
| Setting include items below.<br>Set either buffer tank or DHW tank for connection with solar water heater.  | External SW   |
| <ul> <li>Set entrer burler tank of DHW tank for connection with solar water heater.</li> <li>Set temperature difference between solar panel thermistor and buffer tank of</li> </ul>  | Solar connection  |
| DHW tank thermistor to operate the solar pump.  | Select [] Confirm   |

- Set temperature difference between solar panel thermistor and buffer tank or DHW tank thermistor to stop the solar pump.
  Anti-freezing operation start temperature (please change setting based on usage of glycol.)
  Solar pump stop operation when it exceeds high limit temperature (when tank temperature exceed designated temperature (70~90°C))



If follow Swiss standard power connection, need to turn on DIP SW of main unit PCB. ON/OFF signal used to ON/OFF tank heater (for sterilization purpose)

| 17. Circulation Liquid Initial se   | etting: Water                                  | System setup   | 17:26, Wed |
|---|--|--|------------|
|   |  | Demand control   |            |
| Set circulation of heating water.   |  | SG ready   |            |
| There are 2 types of settings, water and anti-  | -freeze function.                              | External compressor SW   |            |
| (CALITION) Places set sheet when using an   | ati franza function                            | Circulation liquid   |            |
| (CAUTION) Please set glycol when using ar<br>It may cause error if setting is w   |  | 🗘 Select 🛛 [ 🚽   | ] Confirm  |
|   |  |  |            |
|   |  |  |            |
|   |  |  |            |
| 18. Heat-Cool SW Initial setting  | j: Disable                                     | System setup   | 17:26, Wed |
|   | ,  | System setup<br>SG ready   | 17:26, Wed |
| 18. Heat-Cool SW       Initial setting         Able to switch (fix) heating & cooling by extermine  | ,  | · · · · ·  | 17:26, Wed |
|   | rnal switch.                                   | SG ready   | 17:26, Wed |
| Able to switch (fix) heating & cooling by exte<br>(Short) : Fix at Heating (Heating +DHW<br>(Open) : Fix at Cooling (Cooling +DHW)  | rnal switch.<br>/)<br>)                        | SG ready<br>External compressor SW                                       | 17:26, Wed |
| Able to switch (fix) heating & cooling by exte<br>(Short) : Fix at Heating (Heating +DHW<br>(Open) : Fix at Cooling (Cooling +DHW)<br>(CAUTION) This setting is disabled for mode | rnal switch.<br>/)<br>)<br>el without Cooling. | SG ready<br>External compressor SW<br>Circulation liquid<br>Heat-Cool SW | 17:26, Wed |
| Able to switch (fix) heating & cooling by exte<br>(Short) : Fix at Heating (Heating +DHW<br>(Open) : Fix at Cooling (Cooling +DHW)  | rnal switch.<br>/)<br>)<br>el without Cooling. | SG ready<br>External compressor SW<br>Circulation liquid<br>Heat-Cool SW |            |

System setup

Circulation liquid Heat-Cool SW

Force heater

Select

External compressor SW

17:26, Wed

[+] Confirm

19. Force Heater Initial setting: Manual

Under manual mode, user can turn on force heater through quick menu.

If selection is 'auto', force heater mode will turn automatically if pop up error happen during operation. Force heater will operate follow the latest mode selection, mode selection is dsiable under force heater operation.

Heater source will ON during force heater mode


## 11.4.4 Operation Setup

#### Heat


| 20. Water temp. for heating ON       Initial setting: compensation curve         Set target water temperature to operate heating operation.       Compensation curve: Target water temperature change in conjunction with outdoor ambient temperature change.         Direct: Set direct circulation water temperature.       In 2 zone system, zone 1 and zone 2 water temperature can be set separately. | 55°C<br>► Decide temperature<br>of 4 points as shown<br>in diagram<br>▲<br>35°C<br>► C<br>► C<br>► C<br>► C<br>► C<br>► C<br>► C<br>► |
|--|---|
|  |   |
| 21. Outdoor temp. for heating OFF Initial setting: 24°C  | ON  |
| Set outdoor temp to stop heating.<br>Setting range is 5°C ~ 35°C   | OFF<br>24°C ►   |
|  | 24 07   |
|  |   |
| 22. $\Delta T$ for heating ON Initial setting: 5°C   | Out   |
| Set temp difference between out temp & return temp of circulating water of Heating operation.<br>When temp gap is enlarged, it is energy saving but less comfort. When the gap gets smaller, energy saving effect gets worse but it is more comfortable. Setting range is $1^{\circ}C \sim 15^{\circ}C$  | $\frac{\text{Returm}}{\text{Out} - \text{Returm}} = 1^{\circ}\text{C} \sim 15^{\circ}\text{C}$  |
|  |   |
| 23. Outdoor temp. for heater ON Initial setting: 0°C   | ON  |
| Set outdoor temp when back-up heater starts to operate.<br>Setting range is $-15^{\circ}$ C ~ 20°C   | OFF   |
| User shall set whether to use or not to use heater.  | <ul><li>◀ 0°C ►</li></ul>   |


## Cool


| 24. Water temp. for cooling ON  | Initial setting: compensation curve    | 20°C  |
|---|--|---|
| Set target water temperature to operate of<br>Compensation curve: Target water temper<br>outdoor ambient temperature change.<br>Direct : Set direct circulation water tempe           | erature change in conjunction with     | 5°C   |
| In 2 zone system, zone 1 and zone 2 wa  | ter temperature can be set separately. | 20°C 30°C   |
|   |  | compensation curve  |
|   |  |   |
| 25. $\Delta T$ for cooling ON Initial set   | tting: 5°C                             | Out   |
| Set temp difference between out temp &<br>Cooling operation.<br>When temp gap is enlarged, it is energy s<br>gap gets smaller, energy saving effect ge<br>Setting range is 1°C ~ 15°C | saving but less comfort. When the      | $\begin{array}{c c} \text{Returm} & \longleftarrow \\ \text{Returm} & - \text{Out} = 1^{\circ}\text{C} \sim 15^{\circ}\text{C} \end{array}$ |
| Auto  |  |   |
| 26. Outdoor temp. for (Heat to Cool)  | Initial setting: 15°C                  | Heat Outdoor temp. rising   |
| Set outdoor temp that switches from heat Setting range is $5^{\circ}C \sim 25^{\circ}C$   | ing to cooling by Auto setting.        |   |
| Timing of judgement is every 1 hour   |  | ▲ 15°C ►  |
|   |  |   |
| 27. Outdoor temp. for (Cool to Heat)  | Initial setting: 10°C                  | Heat Outdoor temp. dropping   |
| Set outdoor temp that switches from Coo<br>Setting range is $5^{\circ}C \sim 25^{\circ}C$   | ling to Heating by Auto setting.       |   |
| Timing of judgement is every 1 hour   |  | Cool<br>◀ 10°C ►  |
| Tank  |  |   |
| 28. Floor operation time (max)  | Initial setting: 8h                    |   |
| Set max operating hours of heating.<br>When max operation time is shortened, it   | can boil the tank more frequently.     | Heat  |
| It is a function for Heating + Tank operation   | on.                                    |   |
|   | -                                      | Tank  |
| · · · ·   |  |   |
| 29. Tank heat up time (max)   | Initial setting: 60min                 | Heat  |
| Set max boiling hours of tank.<br>When max boiling hours are shortened, it  |  |   |
| operation, but it may not fully boil the tan  | ς.                                     | Tank  |
|   |  | 5min ~ 4h   |



### 11.4.5 Service Setup







| 35. Service contact  | Service setup    | 17:26, Wed | Contact-1: Bryan Ac | dams       |
|--|------------------|------------|---------------------|------------|
|  | Service contact: |            | ABC/ abc            | 0-9/ Other |
| Able to set name & tel no. of contact person when there is breakdown | Contact 1        |            | ABCDEFGHIJ          | KLMNOPQR   |
| etc. or client has trouble. (2 items)                                | Contact 2        |            | STUVWXYZ            | abcdefghi  |
|  |                  |            | jklmnopqrstu        | v w x y z  |
|  | Select [4] Cont  | irm        | ↓ Select            | [🖵] Enter  |

## 12. Operation and Control

## 12.1 Basic Function

Inverter control, which equipped with a microcomputer in determining the most suitable operating mode as time passes, automatically adjusts output power for maximum comfort always. In order to achieve the suitable operating mode, the microcomputer maintains the set temperature by measuring the temperature of the environment and performing temperature shifting. The compressor at outdoor unit is operating following the frequency instructed by the microcomputer at indoor unit that judging the condition according to internal water setting temperature and water outlet temperature.

## 12.1.1 Internal Water Setting Temperature

Once the operation starts, control panel setting temperature will be taken as base value for temperature shifting processes. These shifting processes are depending on the Air-to-Water Heat pump settings and the operation environment. The final shifted value will be used as internal water setting temperature and it is updated continuously whenever the electrical power is supplied to the unit.

## 12.1.2 Heating Operation

### 12.1.2.1 Thermostat Control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature > 2°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) <-3°C.

## 12.1.2.2 Thermostat Control (Outdoor Ambient Temperature)

Stops provide heating to room side during high outdoor ambient condition. Control content:

 Heating operation and water pump will turn OFF when outdoor ambient temperature > outdoor thermo off temperature + 3°C.

(Outdoor thermo off set temperature is set by control panel. Thermo off set temperature is between 5°C ~ 35°C)

Heating operation will resume when Outdoor ambient temperature < Outdoor thermo OFF set temperature + 1°C.</li>

## 12.1.2.3 Heat Mode Operation

Operation of heat pump provide heating capacity to room side by hot water through heating panel, floor heating or fan coil unit.

- 1 3 ways valve control:
- $\circ$  3 ways valve switch and fix to heating side.
- 2 Heat pump operates follow normal heating operation.
- 3 Back up heater operate follow normal operation.
- 4 2 ways valve control:
  - 2 ways valve opens.

## 12.1.3 Cooling Operation

### 12.1.3.1 Thermostat control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature > -1.5°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) >3°C.

### 12.1.3.2 Cool Mode Operation

- 1 3 ways valve control:
- 3 ways valve switch and fix to cooling side.
- 2 Heat pump operates follow normal cooling operation.
- 3 Room heater DOES NOT operate during cool mode.
- 4 2 ways valve control:
  - 2 ways valve is closed.

## 12.1.4 Target Water Temperature Setting

# 12.1.4.1 Target Water Temperature Control of Standard System (Optional PCB not connected)

There are 2 types of temperature control selection which are Compensation and Direct.

- Temperature control type selection by installer:
  - 1 Compensation : Wlo, WHi, ODLo, ODHi can be set at installer menu.
  - 2 Direct : Direct Water Temperature Set
- Remote control setting by user:
  - 1 Compensation : Shift value ± 5°C from the compensation curve
  - 2 Direct : Direct water temperature set change

\*This setting only able to set when room sensor select as Water Temperature. \*Instead of water temperature, user will set target room temperature when room sensor select as Room Thermistor OR Internal Room Thermostat.

- Target water temperature is calculated as below condition.
  - Target water temperature = A (Base temperature) + B (shift temperature)

| A (Base Temperature) | Compensation                                | Direct                         |
|----------------------|---|--------------------------------|
| A (Base Temperature) | Value from the curve + User shift value set | Direct value from user setting |

o B (shift temperature) value is depend on the room sensor selection at remote controller as below table:


| B (Shift Temp.)                            | B shift value depend on the room sensor selection at remocon as table below  |  |
|--|--|--|
| Sensor selection                           |  |  |
| Water temperature                          | B = 0  |  |
| External Room thermostat                   | B = 0  |  |
| Internal Room thermostat & Room Thermistor | Cool Mode:<br>B = 0 ; when Zone OFF or Zone Room Thermo OFF<br>B = B = 1* (room set temp (R/C) - actual room temp)<br>Max/Min Regulation of B: (Max = 5 ; Min = -5)<br>Heat Mode:<br>B = 0 ; when Zone OFF or Zone Room Thermo OFF<br>B = follow Heating Room Temperature PI control logic |  |

• Maximum/minimum regulation of Target Water Temperature.

|     | Heating | Cooling |
|-----|---------|---------|
| Max | 55°C    | 20°C    |
| Min | 20°C    | 5°C     |

Compensation Type: (Operation under Heat Mode and Cool Mode)


• The set temperature defines the parameters for the ambient (Outdoor temperature) dependent operation of the unit. The water temperature is determined automatically depending on the outdoor temperature. Default setting is the colder outdoor temperature will result in warmer water and vice versa. The user has the possibility to shift up and shift down the target water by remote control setting.



- Outdoor ambient is updated every 30 minutes when operation ON.
- Setting water outlet temperature always follow W<sub>(LO)</sub> or W<sub>(HI)</sub> whenever is higher if outdoor ambient sensor or indoor comminication error happen.

However, when powerful mode is requested by remote control during heating mode, the higher value of HLo or Whi will be used for A calculation.

- \* There are 2 compensation curves (for heating and cooling). During heating mode, the heating curve is used and during cooling mode, the cooling curve is use.
- Compensation curve set shift value:



### 12.1.5 Target Water Temperature at Extension System (Optional PCB is connected)

Target water temperature is calculated as below.

- Heat Mode:
  - o Target water temperature setting:
  - Max= <u>55°C</u> Min= <u>20°C</u>
- When buffer tank selection is "YES:" Target water temperature = Target buffer tank temperature + [2°C]
- When buffer tank selection is "NO"
  - If both zone 1 and zone 2 is active Target Water Temperature = Higher zone target water temperature of Zone 1 and Zone 2.
  - If only one zone is active Target Water Temperature = Zone target water temperature of active zone.
- Cool mode:
- When buffer tank selection is "YES"
  - If both zone 1 and zone 2 active
  - Target Water Temperature = Lower Zone Target Water Temperature of Zone 1 and Zone 2 o If only one zone is active
  - Target Water Temperature = Zone Target Water Temperature of active zone
- When buffer tank selection is "NO"
  - If both zone 1 and zone 2 active
  - Target Water Temperature = Lower Zone Target Water Temperature of Zone 1 and Zone 2 o If only one zone is active
    - Target Water Temperature = Zone Target Water Temperature of active zone

\*Cool Mode does not have SG ready control

## 12.1.6 Target Zone Water Temperature Control

Purpose:- To control zone mixing and zone pump according to the zone sensor temperature

## 12.1.6.1 Target Zone 1 water temperature setting control

- Start condition
  - Heating zone 1 is ON by remote control or Timer or Auto Mode OR
  - Cooling zone 1 is ON by remote control or Timer or Auto Mode.
- Cancel condition
  - $\circ$  Heating zone 1 is OFF by remote control or Timer or Auto mode AND
  - Cooling zone 1 is OFF by remote control or Timer or Auto mode.
- Target Zone 1 water temperature is calculated as below condition.
  - Target Zone 1 water temperature = A (Base temperature) + B (shift temperature)

| A (Base Temperature)  | Compensation                                | Direct                         |
|-----------------------|---|--------------------------------|
| A (base reinperature) | Value from the curve + User shift value set | Direct value from user setting |

- <sup>1</sup> During heat mode and compensation select, if powerful mode is activated, higher value of WLo or WHi will be use as curve value.
  - o B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

| B (Shift Temp.)                            | B shift value depend on the room sensor selection at remocon as table below  |  |
|--|--|--|
| Sensor selection                           |  |  |
| Water temperature                          | B = 0  |  |
| External Room thermostat                   | B = 0  |  |
| Internal Room thermostat & Room Thermistor | Cool Mode:<br>B = 0 ; when Zone OFF or Zone Room Therma OFF<br>B = B = 1* (room set temp (R/C) - actual room temp)<br>Max/Min Regulation of B: (Max = 5 ; Min = -5)<br>Heat Mode:<br>B = 0 ; when Zone OFF or Zone Room Thermo OFF<br>B = follow Heating Room Temperature PI control logic |  |
| Pool Function Selected                     | B = Delta value setting from remocon   |  |

- \* B = 0 regardless of which sensor selection, if SHP control bit is enable except Pool function select (maintain Pool "B" value)
- \*\* Pool function also can be select at Zone 1 when optional PCB is connected and Zone 1 system is select.
- Maximum/minimum regulation of Target Water Temperature.

| Heating |      | Cooling |
|---------|------|---------|
| Max     | 55°C | 20°C    |
| Min     | 20°C | 5°C     |

- Target Zone 1 Water Temperature (Heat mode only) during SG ready control
  - $\circ$   $\;$  If buffer tank selection is "NO" then following shift is carried out.
    - While digital input is "10" or "11" then,
      - Final Target Zone 1 water temperature
        - = Target Zone 1 water temperature\* (SG ready % setting (remote control menu))%
  - o If buffer tank selection is "YES"
    - No shift of Target Zone 1 Water Temperature. Target Buffer Tank Temperature will change accordingly.
       \* Refer to "Buffer tank temperature control"

## 12.1.6.2 Target Zone 2 water temperature setting control

### Start condition

- $\circ$   $\;$  Heating zone 2 is ON by remote control or Timer or Auto Mode OR
- Cooling zone 2 is ON by remote control or Timer or Auto Mode.
- Cancel condition
  - Heating zone 2 is OFF by remote control or Timer or Auto mode AND
  - Cooling zone 2 is OFF by remote control or Timer or Auto mode.
  - Target Zone 2 water temperature is calculated as below condition.
  - Target Zone 2 water temperature = A (Base temperature) + B (shift temperature)

| A (Base Temperature) | Compensation                                | Direct                         |  |
|----------------------|---|--------------------------------|--|
|                      | Value from the curve + User shift value set | Direct value from user setting |  |

- \* During heat mode and compensation select, if powerful mode is activated, higher value of WLo or WHi will be use as curve value.
  - o B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

| B (Shift Temp.) B shift value depend on the room sensor selection at remocon as table below |   |  |
|---|---|--|
| Sensor selection  |   |  |
| Water temperature B = 0   |   |  |
| External Room thermostat  | B = 0   |  |
| Internal Room thermostat & Room thermistor  | Cool Mode:<br>B = 0 ; when Zone OFF or Zone Room Thermo OFF<br>B = B = 1* (room set temp (R/C) - actual room temp)<br>Max/Min Regulation of B: (Max = 5 ; Min = -5) |  |
|   | Heat Mode:<br>B = 0 ; when Zone OFF or Zone Room Thermo OFF<br>B = follow Heating Room Temperature PI control logic   |  |
| Pool Function Selected  | B = Delta value setting from remocon  |  |

- \* B = 0 regardless of which sensor selection, if SHP control bit is enable except Pool function select (maintain Pool "B" value)
- \*\* Pool function also can be select at Zone 2 when optional PCB is connected and Zone 2 system is select.
- Maximum/minimum regulation of Target Water Temperature.

|     | Heating | Cooling |
|-----|---------|---------|
| Max | 55°C    | 20°C    |
| Min | 20°C    | 5°C     |


- Target Zone 2 Water Temperature (Heat mode only) during SG ready control
  - If buffer tank selection is "NO" then following shift is carried out.
    - While digital input is "10" or "11" then,
      - Final Target Zone 2 water temperature
      - = Target Zone 1 water temperature\* (SG ready % setting (remote control menu))%
  - o If buffer tank selection is "YES"
    - No shift of Target Zone 2 Water Temperature. Target Buffer Tank Temperature will change accordingly. \* Refer to "Buffer tank temperature control"

## 12.1.6.3 Zone Temperature Control Contents

- During Standard System (Optional PCB not connected)
  - Only 1 zone temperature control is available
  - This zone room temperature is control by either one of the 4 room sensor (Room Th, Int/Ext Room Thermostat, Water temperature)
  - Target Zone Water Temperature is calculated based on selected temperature control type (Compensation or Direct) and selected room sensor. Target Water Temperature will set same as Target Zone Water Temperature
  - o Target Water Temperature is the temperature for heat pump to operate refer to indoor water outlet sensor.
  - Heat pump and water pump OFF when ROOM Thermo OFF (Zone thermo OFF by Room Th or Room Thermostat).
- \* There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.
- During Extension System (Optional PCB connected)
- Buffer Tank connection select "NO" &
  - One zone system is select
    - This zone room temperature control by either one of the 4 room sensor (Room Th, Int/Ext Room Thermostat, Water temp.)
    - Target Zone Water Temperature calculate base on selected temperature control type (Compensation or Direct) and selected room sensor.
    - Target Water Temperature will set same as Target Zone Water Temperature
    - Target Water Temperature is a temperature for heat pump to operate refer to indoor water outlet sensor.
    - Heat pump and water pump OFF when ROOM Thermo OFF (Zone thermo OFF by Room Th or Room Thermostat).
- \* There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.
  - 2 zone system select
    - Each zone room temperature is control by each sensor which select from either one of the 4 room sensor
    - Target Zone 1 & 2 Water Temperature is calculated based on selected temperature control type (Compensation or Direct) and selected room sensor.
       \* Zone Mixing Valve & Zone pump will operate to achieve Target Zone Water Temperature which refer to zone sensor.
      - \* Zone Sensor will detect if zone sensor is open or short.
    - Target Water Temperature will set same as the active & higher zone water temperature setting. (When cooling mode, lower zone water temp setting)
    - Target Water Temperature is the temperature for heat pump to operate refer to indoor water outlet sensor.
    - Heat pump and water pump OFF when ROOM Thermo OFF (Both Zone thermo OFF by Room Th or Room Thermostat).
- Buffer Tank Connection select "YES" &
  - 1 zone system or 2 zone system select
    - Each zone control by each sensor which select from either one of the 4 room sensor
    - Target Zone 1 & 2 Water Temperature calculate base on selected temperature control type (Compensation or Direct) and selected room sensor. Each zone have their own Target Zone Water Temperature.


\* Zone Mixing Valve & Zone pump will operate to achieve each Target Zone Water Temperature which refer to zone sensor

- \* Zone Sensor will detect if zone sensor is open or short.
- Target Buffer Tank Temperature will be set as active & higher zone water temperature setting + Buffer Delta T. (Heating) Target Buffer Tank Temperature will be set as active & lower zone water temperature setting (Cooling).
- Target Water Temperature will set as Target Buffer Tank Temperature + [2°C] (Heating) Target Water Temperature will set as Lower or Active Target Zone Water Temp. + [-3°C] (Cooling)
- Target Water Temperature is a temperature for heat pump to operate refer to indoor water outlet sensor.
- Heat pump and water pump OFF when ROOM thermo OFF
  - Heat mode: ROOM thermo OFF (Buffer Tank Temperature > Target Buffer Tank + [0°C]
  - Cool mode: ROOM Thermo OFF (Both Zone thermo OFF by Room Th or Room Thermostat)



- Control details:
  - To enable the unit to operate either heat or cool mode automatically, heat to cool set temperature and cool to heat set temperature can be set by control panel.
  - Automatic operation is judged based on control panel setting temperature and outdoor ambient temperature.
  - \* Minimum setting of heat to cool set temperature is 1°C higher than cool to heat set temperature.
- Judgement control:
  - If outdoor ambient temperature < Heat to Cool Set Temperature, unit will operate in Heat Mode or else the unit will operate in Cool Mode.
  - If current operation is Cool mode, outdoor ambient temperature > Cool to Heat Temperature, unit will maintain Cool mode operation or else the unit will operate Heat mode.
  - If current operation is Heat mode, outdoor ambient temperature > Heat to Cool Temperature, unit will maintain Heat mode operation or else the unit will operate Cool mode.
  - Every 60 minutes the outdoor ambient temperature is judged.
  - When Auto + Tank mode is selected, operation mode switching is judged by both outdoor ambient temperature and indoor air temperature.

## 12.1.8 Auto Cooling Mode Operation Limit



- Auto Mode Cooling Only operation will start once the outdoor ambient temperature reaches 19°C and compressor will continue to run until the outdoor ambient temperature drops to 16°C.
- Due to this limitation, If Heat to Cool temperature is set lower than 19°C, the compressor will not operates until the outdoor ambient temperature reaches 19°C or higher.

## 12.1.9 Tank Mode Operation

- 3 ways valve direction
  - 3 ways valve switch to tank side during Tank Thermo ON condition. Switch 3 ways valve to room side when tank achieve Tank Thermo OFF temperature.
- Tank Thermo ON/OFF Characteristic

o Tank Thermo OFF

Case 1: Internal Tank Heater is select and Tank Heater ON

- Tank temperature > Tank Set Temperature continuously for 15 seconds.
- Water outlet >75°C

- Case 2: Tank Heater OFF OR External Heater is select
  - When heat pump OFF due to water thermos & Tank temperature > Tank water set temperature for continuously 20 seconds. OR
  - Tank temperature > Tank set temperature + 1°C for continuously 20 seconds.
  - Tank Thermo ON

Case 1: Tank Heater ON (Internal Tank Heater)

• Tank temperature < Tank set temperature + R/C (Tank re-heat temperature)

Case 2: Tank Heater OFF (Internal Tank Heater)

• Tank temperature < Tank water set temperature + R/C (Tank re-heat temperature)

\* When tank thermo ON, water pump will ON for 3 minutes then only heat pump turn ON. \* Tank water set temperature = tank set temperature or 51°C whichever lower.

- 2 ways valve close
- Heat pump Thermostat Characteristic
  - Heat pump Water Outlet set temperature is set to below table:

| Outdoor ambient temperature | Heat pump water outlet temperature |  |
|-----------------------------|------------------------------------|--|
| < 5°C                       | 55°C                               |  |
| > 5°C                       | 57°C                               |  |

Characteristic of heat pump thermos ON/OFF under tank mode condition:

Water Outlet Thermo Condition

- Heat pump thermos OFF temperature:
- 1 Heat pump thermo OFF temperature = Target Water outlet temperature + (2°C)
- 2 Water outlet temperature > heat pump thermo OFF temperature for continuously 3 minutes, heat pump OFF but water pump continue ON.
- Heat pump thermo ON temperature:
  - 1 Heat pump thermo ON temperature = water inlet during thermo OFF time + [-3°C]
  - 2 When water outlet temperature < heat pump thermo ON temperature, heat pump ON.

Water inlet thermo protection condition

- Heat pump thermo OFF temperature:
  - 1 Water inlet temperature > [57°C/55°C] for continuously 30 seconds, heat pump OFF, water pump continue ON.
- Heat pump thermo ON temperature:
  - 1 Heat pump thermos ON temp = water inlet temperature <  $[57^{\circ}C/55^{\circ}C]$ .

| Outdoor ambient temperature | Water inlet temperature |  |
|-----------------------------|-------------------------|--|
| < 5°C                       | 55°C                    |  |
| >= 5°C                      | 57°C                    |  |

Thermo ON/OFF for Heat Pump in Tank Operation:

When tank temperature achieve heat pump OFF condition, refer below condition:

Condition 1: Tank Heater ON (Internal Tank Heater)

 Heat pump will turn OFF, water pump continue ON and room heater will continue ON if tank temperature below tank heater thermo ON condition. 3 ways valve will only switch to room side after tank temperature reach tank heater thermo OFF condition.

#### Condition 2: Tank Heater OFF (Internal Tank Heater)

• If tank temperature achieve tank thermo OFF, heat pump turn OFF, water pump turn OFF, room heater OFF and 3 ways valve switch to room side.

When tank temperature achieve heat pump ON condition, water pump ON, heat pump ON and room heater turn OFF.

#### Heat pump OFF condition at Tank Mode

- Tank temperature > tank water set temperature continuously for 20 seconds after heat pump thermos OFF due to water thermo. (Heat pump turn OFF but water pump continue ON and room heater turn ON to achieve tank set temperature) OR
- Tank temperature > tank set temperature + [1°C] for continuously 20 seconds. (Heat pump OFF, water pump OFF, room heater OFF and 3 ways valve switch to room side)

#### Heat pump ON condition at Tank Mode

 Tank temperature < tank water set temperature + R/C setting (Tank re-heat temp) (Water pump turn ON OR continue ON, heat pump ON and 3 ways valve switch to tank side or maintain at tank side)

Tank heater control

• Internal heater only operates to tank side if Tank heater ON and backup heater is enable.

#### Internal heater turn ON condition:

- Tank temperature < tank set temperature **AND**
- Heat pump thermos OFF AND
- 20 minutes from previous heater off AND
- Internal tank heater selects USE from control panel.

#### Internal heater turn OFF condition:

- Tank temperature > tank set temperature for continuously 15 seconds OR
- Heat pump thermo ON **OR**
- Mode change or operation is off by control panel.

## 12.1.10 Heat + Tank Mode Operation

- 1 3 ways valve control:
  - 3 ways valve switch to room side during room heat-up interval and switch to tank side during tank heatup interval. Both modes will switch alternately. Tank mode is the initial running mode of Heat + Tank mode.
- 2 Heat pump operation control:
  - During room heat-up interval
    - Follow normal heating operation.
      - Switching to tank side depends to below cases: Case 1:
      - [Previous switch from tank interval to room interval due to thermo OFF]
    - Switch to tank heat-up interval when Tank temp < Tank thermos ON temp (Room heat-up interval ends)
      - Case 2:

[If heating operation at room side is less than 30 minutes and switch to tank side 3 times consecutively]

 Maintain at room heat-up interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank thermo ON temperature. Case 3:

[Previous switch from tank interval to room interval due to tank interval timer is complete]

- Maintain at room heat-up interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** tank temperature < Tank thermo ON temperature.</li>
- During Tank heat-up interval
  - Tank interval is the first mode running when heat + tank mode is select.
  - Switch to room interval only when tank achieve tank thermo OFF **OR** tank heat-up interval timer is complete.
  - Heat pump operates according to normal tank mode operation.

### 3 Room heater control:

- o During heating heat-up interval
  - Follow normal room heater control operation.
- 4 Tank heater control:
  - o During heating heat-up interval
    - Internal tank heater will not function under heating heat-up interval.
  - During tank heat-up interval
    - Internal tank heater will turn ON after heat puMp thermo off to boil tank temperature to tank set temperature.
  - 2ways valve control is open
  - Indoor water pump control:
    - Indoor water pump always turn ON if room heat pump thermo ON **OR** Tank thermo ON.

## 12.1.11 Cool + Tank Mode Operation

- 1 3 ways valve control:
  - 3 ways valve switch to room side during room cooling interval and switch to tank side during tank heat-up interval. Both mode will switch alternately. Tank mode is the initial mode of cool + tank mode.

#### 2 Heat pump operation control:

- o During room heat-up interval
  - Follow normal cooling operation.
     Switching to tank side depends to below cases: Case 1:
    - [Previous switch from tank interval to room interval due to thermo OFF]
  - Switch to tank heat-up interval when Tank temperature < Tank Thermo ON temperature (Room interval will ends)
    - Case 2:

[If cooling operation at room side is less than 30 minutes and switch to tank side for 3 times consecutively]

 Maintain at room cooling interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank thermo ON temperature. Case 3:

[Previous switch from tank interval to room interval is due to tank interval timer is complete]

 Maintain at room cooling interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** tank temperature < Tank thermo ON temperature.</li>

\*Tank Thermo ON temperature:

| Internal Tank Heater select USE | <tank (tank="" +="" c="" r="" re-heat="" set="" setting="" temperature="" temperature)<="" th=""></tank>          |
|---------------------------------|---|
| Others                          | <tank (tank="" +="" c="" r="" re-heat="" set="" setting="" td="" temperature="" temperature)<="" water=""></tank> |

#### o During tank heat-up interval

- Tank interval is the first mode running when the cool + tank mode is select.
- Switch to room interval only when tank achieve tank thermo OFF **OR** tank heat-up interval timer is complete.
- Heat pump operates according to normal tank mode operation.


#### 3 Room heater control:

- During room cooling interval
  - Room heater is OFF and not operates.
- 4 Tank heater control:
  - During room cooling interval
    - Internal tank heater will not function under room cooling interval.
  - During tank heat-up interval
    - Internal tank heater will turn ON after heat pump thermos off to boil tank temperature to tank set temperature.

- 5 2 ways vale is close.
- 6 Indoor water pump control:
  - o Indoor water pump always turn ON if room heat pump thermo ON **OR** Tank thermo ON.

## 12.1.12 Outdoor Fan Motor Operation


Outdoor fan motor is adjusted according to operation condition. It starts when compressor starts operation and it stops 30 seconds after compressor stops operation.



## 12.2 Water Pump

## 12.2.1 Water Pump Control

- Once the indoor unit is ON, the water pump will be ON immediately and no error judgment for 70 seconds. However, during this 70 seconds operation, if there is any abnormality cause at outdoor or malfunction, the compressor should be OFF immediately and restart delay after 3 minutes.
- The system will start checking on the water flow level after operation start for 70 seconds. If water flow level is
  detected low continuously 60 seconds, the water pump and the compressor will be OFF permanently and
  OFF/ON control panel LED will blink (H62 error occurs).
- When error happens, the power has to be reset to clear the error.
- If there is no error indication, the water pump shall be continuously running.
- The water pump will remain ON when compressor OFF due to thermostat OFF setting is reached.
- Water pump will OFF when room thermo OR tank thermo OR buffer tank thermo OFF.
- Water pump will delay 15 seconds to turn OFF when request to OFF except during anti-freeze deice activate or air purge mode.




### Maximum pump speed setting on remote control

 Standard pump speed is automatically controlled to get the designed water temperature different between water inlet and outlet (ΔT). Instead of setting the standard pump speed, maximum pump speed is manually adjusted by the installer according to water circuit pressure drop.

However, the following sequences do not follow maximum pump duty setting by remote control.


- Pump down mode
- Air purge mode
- Normal deice



## 12.2.2 Zone Water Pump Control

Purpose:

Water pump install at each zone to circulate the water inside each zone during buffer tank connection selected "YES" or 2 zone systems.



Content:

- AC type water pump install for this zone water pump control. When optional PCB connected, 230V output will drive this zone pump.
- There are three pump can be connected through Optional PCB. (Zone 1 Pump, Zone 2 Pump, & Pool Pump)

\* Zone 1 pump [P1] use to circulate zone 1 water circuit & Zone 1 mixing valve [M1] adjust to control the Zone 1 target water temperature.

\* Zone 2 pump [P2] use to circulate zone 2 water circuit & Zone 2 mixing valve [M2] adjust to control the Zone 2 target water temperature.

\* When Pool Function select as Zone 2 circuit, [P2] use to circulate water to heat exchanger which use to transfer heat to pool water.

\* Pool pump [P3] circulates the pool water through the heat exchanger to get warm water.

- Zone 1 and Zone 2 water pump start condition:
  - Zone room request ON (eg. Zone 1 thermo ON, only zone 1 pump will turn ON)
- Zone 1 and Zone 2 water pump stop condition:
- Zone room request OFF
- Pool water pump start condition: • Pool Zone request ON AND
- Pool Zone request ON A
   Pool function is selected
- Pool water pump stop condition
- Pool zone: Zone room request OFF OR
- Pool function is cancel

\* Zone 1 & Zone 2 water pump need to turn OFF when antifreeze deice pump stop control activate and turn ON back after the antifreeze deice pump stop control end under setting of "NO" buffer tank connection.

### Zone Pump Prohibit ON control:

- Start condition: Zone 1 water temperature ≥ 75°C continuously for 5 minutes \*stop zone water pump operates if the zone water fulfilled.
- Cancel condition: After 30 minutes from start condition fulfilled.
   \*zone water pump operates according to normal condition.

#### Zone Pump Control during Anti-Freeze

Zone pump control during Zone Anti-Freeze Control:

- When Zone Anti-Freeze Flag=1, Zone Pump Turn ON.
- When Zone Anti-Freeze Flag=0, Zone Pump Turn OFF.
- Zone pump control during Indoor Anti-Freeze Control:
- Zone pump only ON/OFF if the Extension PCB connected and Buffer Tank select "NO" condition


When Indoor Anti-Freeze flag=1, Zone Pump Turn ON

When Indoor Anti-Freeze flag=0, Zone Pump Turn OFF

\* Pool Water Pump will not affected by both Indoor anti-freeze control or zone anti-freeze control.

### 12.2.3 Water Pump Speed Feedback Error

- Basically pump speed feedback is control by micon.
- When pump speed is below low limit or over high limit for a few seconds, micon detect pump error and system is stopped.
- Error detection conditions:
  - o Detect abnormal water pump speed for continuous 10 secs.
  - Current pump speed < 700 rpm or
  - Current pump speed > 6000 rpm for 10 seconds.
- Control contents:
- o When error occurs, water pump, heating and heater is stopped for 30 seconds then restart again (Retry control).
- o When micon detect error again, system is stopped and error code [H20] is displayed at control panel.




## 12.3 Indoor Unit Safety

## 12.3.1 Indoor Unit Safety Control

- 1 When water pump is ON, the system will start checking flow switch status (ON/OFF).
- 2 If the flow switch ON for 10 seconds, the system will check on the water inlet temperature for 10 seconds. If the water inlet temperature not exceeds 80°C, the water pump shall be continuously running with normal mode.

If the water inlet temperature exceeds 80°C for continuously 10 seconds, the water pump will be OFF immediately.

3 After water pump OFF for more than 10 minutes, it will be ON back and the indoor unit safety control checking is restarted.



## 12.4 Auto Restart Control

1 When the power supply is cut off during the operation of Air-to-Water Heatpump, the compressor will reoperate after power supply resumes.

## 12.5 Indication Panel

| LED       | Operation     |
|-----------|---------------|
| Color     | Green         |
| Light ON  | Operation ON  |
| Light OFF | Operation OFF |

### Note:

• If Operation LED is blinking, there is an abnormality operation occurs.

## 12.6 Indoor Back-Up Heater Control

## 12.6.1 Indoor Electric Heater Control

- 1 Normal Heating Mode
  - Heater On condition:
    - a. Heater switch is ON
    - b. After Heatpump thermo ON for [30] mins
    - c. After water pump operate [9] mins
    - d. Outdoor air temperature < Outdoor set temperature for heater
    - e. When water outlet temperature < Water set temperature + [-4°C]
    - f. [20] minutes since previous Backup heater Off
      - \* When heatpump cannot operate due to error happens during normal operation, heater will go into force mode automatic
      - \* Heater need to operate during deice operation
  - Heater Stop Condition:
    - a. When outdoor set temperature > outdoor set temperature + [+2°C] for continuous 15 secs OR
    - b. When water out temp> water set temperature + [-2°C] for continuous 15 secs OR
    - c. Heater switch is Off OR
    - d. Heatpump thermo-off or OFF condition
- 2 Force Heater Mode
  - o Heater On condition:
    - a. After water pump operate [9] mins
    - b. When water outlet temperature < water set temperature + [-4°C]
    - c. [20] minutes since previous Backup heater Off
  - o Heater Stop condition
    - a. Force mode off **OR**
    - b. When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs
- \* Do not operate heater at the following situation
- 1 Water outlet temperature sensor, and water inlet sensor abnormal
- 2 Flow switch abnormal
- 3 Circulation pump stop condition

### 12.6.2 Room Heater Operation during Deice

#### Purpose:

• To protect the indoor Heat Exchanger from ice forming and prevent heat exchanger plate breakage.

#### **Control content:**

- This Heater protection control will activate only if the backup heater is enable at custom setup by remote controller. Once fulfil the start condition, room heater will turn ON together (base on max heater capacity selection) and stop together if stop condition is fulfilled.
  - \* If the heater is request to turn ON OLP feedback will be detected.

#### Starting conditions:


- During normal deice operation 4~9
- Water outlet temperature < 10°C or Outdoor air temperature < -10°C or Water inlet temperature < 27°C</li>

Heater operates when 1 ~2 fulfilled **OR** When 1 and 3 ~ 4 is fulfilled. However, this control does not relate to Heater ON/OFF button on remote control.

#### Stop condition:

- When normal deice end or
- Water outlet temperature > 45°C

However, room heater keeps ON if indoor electric heater control activate.



\* Backup heater must Turn OFF if the water pump turn OFF.

## 12.7 Tank Heater Control

## 12.7.1 Tank Heater Remote Control Setting

- Tank heater selection:
   External: Booster Heater use to heat up tank when select external
   Internal: Backup Heater use to heat up tank when select internal
   \* When select External Tank Heater, Heater Delay ON Timer need to set. (range 20 min ~ 3 hrs)
- 2 Tank Heater ON/OFF selection by user.


The remote control Tank set Temperature range will change according to the External and Internal Tank Heater use.

| Tank Heater Selection | Range     |
|-----------------------|-----------|
| External              | 40 ~ 75°C |
| Internal              | 40 ~ 65°C |

### 12.7.2 Internal Heater Control at Tank Mode


- Internal heater turn On condition:
  - 1 Internal Heater select for Tank heater by remote controller
  - 2 Tank Heater select ON by user.
  - 3 Backup Heater Enable
  - 4 Tank Temperature < Tank Set Temperature
  - 5 Heat Pump Thermo OFF
  - 6 20 minutes from previous heater off.
- Internal heater turn OFF condition:
  - 1 Tank Temperature > Tank Set Temperature + [0°C] for continuous 15 seconds. OR
  - 2 Heat Pump Thermo ON **OR**
  - 3 Mode Change or Operation OFF by remote controller OR

\* Backup Heater Turn ON/OFF all together according to the selected heater capacity.



## 12.7.3 External Heater Control at Tank mode

Heating operation condition:



- Tank heater Turn On condition:
  - 1 External Heater selected for Tank heater by remote controller.
  - 2 Tank Heater select ON by user.
  - 3 Tank mode operation ON (Tank mode, Heat + Tank, or Cool + Tank).
  - 4 After TANK HEATER DELAY TIMER fulfill during heat pump startup time in tank mode, or during switching from heating heat-up interval to tank heat + up interval in heat + tank mode.
  - 5 Tank temperature < tank set temperature +[Remote controller Set Tank Re-heat Temp] + [-1°C].
  - 6 20 minutes since previous heater off.

- Tank heater Turn Off condition:
  - 1 Tank temperature > tank set temperature + [0°C] for continuous 15 seconds.
  - 2 When BOOSTER HEATER DELAY TIMER start count after switch from heating heat-up interval to tank heatup interval.
  - 3 Tank Heater select OFF by user.
  - 4 Tank Mode Operation OFF.

<sup>\*</sup> TANK HEATER DELAY TIMER is clear when tank heat-up interval end.

## 12.8 Base Pan Heater Control (Optional)

- To enable the base pan heater function, control panel initial setting has to be manually adjusted by activating Base Pan Heater menu.
- There are 2 optional start condition can be selected, Type A or Type B.
- Control details:
  - 1 Type A: (Default Auto Mode)
    - Start conditions:
    - $\overline{\circ}$  When outdoor air temperature  $\leq 3^{\circ}$ C during heating and deice operation is ON.

Control contents:

• Base pan heater is ON during deice operation and continues ON for 10 minutes after deice operation ends.

#### Cancel condition:

- $\overline{\circ}$  When outdoor temperature > 6°C after deice end or
- o When operation is not at heating mode or
- Base pan heater ON timer count is completed.
- 2 Type B: (ON Mode)

Start conditions:

 $\overline{\circ}$  When outdoor air temperature is  $\leq$  5°C and operates in heating mode, base pan heater is ON.

Cancel conditions:

- When outdoor air temperature is > 7°C or
- When operation is not at heating mode.

## 12.9 Force Heater Mode

Purpose of Force Heater Mode

- As a backup heat source when heat pump error. Force heater Mode control backup heater to heat up the room circuit, and turn ON back up heater or booster heater to boil up tank water base on the tank heater selection (internal or external)

Force Heater Control start condition:

- Force heater request ON by user OR auto turn ON by remote controller during error AND (Force Heater mode can be operate regardless of mode selection, remocon will send the lastest mode selection and force bit to indoor. Indoor will judge to turn ON heater to room side if it is heat mode selected, and turn ON heater to heat up tank water base on tank heater selection)
- During Error Happen (exclude the error list below)

#### Error List not allow Force Heater Operation

| H12           | Capacity Mismatch  | H76 Indoor-Remote Controller Communication Error |  |  |
|---------------|--|--|--|--|
| H20           | Abnormal Water Pump  | H95 Abnormal Voltage Connection                  |  |  |
| H62           | Abnormal Water Flow  | F37 Abnormal Water Inlet sensor                  |  |  |
| H70           | Abnormal Back-up Heater OLP  | F45 Abnormal Water Outlet sensor                 |  |  |
| H74           | PCB Communication Error  |  |  |  |
| [ When tank r | [When tank mode operate with external heater selected & tank heater select ON] |  |  |  |
| H72           | Abnormal tank sensor   | H91 Abnormal tank heater OLP                     |  |  |

Force Heater Control Stop Condition:

- Force Heater request OFF OR
- Operation OFF request OR
- Power reset OR
- Error of above list happens during force heater operation.

Control contents:

- 1) After fulfil start condition, indoor will operate the force heater operation according to below mode condition
  - Heat mode Only : Turn ON backup heater to achieve room heat pump target water temperature.
  - Heat + Tank mode : Turn ON backup heater to heat up room OR Turn ON Heater to Boil up tank water. Cool mode Only
    - : Water pump and backup heater will OFF in force heater mode
  - Cool + Tank mode : Operate pump and internal Heater OR External heater to Boil up tank water.
  - Tank mode Only : Operate pump and internal Heater OR External heater to Boil up tank water.
  - \* For heat mode condition, backup heater will only turn ON if the backup heater is enable regardless of Room Heater Selection

\* For tank mode condition, If internal heater selected backup heater will turn ON to boil up tank water. If external heater selected, booster heater will turn ON to boil up tank water regardless of tank heater selection

#### Room Side: (Heat Mode)

- 1) When force heater mode start condition fulfilled, turn ON water pump and turn ON backup heater follow below control.
- 2) Operate the 3 ways valve at room side only and turn ON 2 ways valve as heat mode operation.
- 3) Turn ON the zone pump and mixing valve if system select 2 zone system or Buffer tank connect YES, control according to normal zone pump and mixing valve control.
- 4) When Force heater mode stop condition fulfilled, turn OFF heater as below condition and turn OFF water pump after pump delay time.

#### Backup Heater On Condition:

- a) When Force Heater Control start condition fulfill AND
- b) After water pump operate 2 minute AND
- c) When water outlet temperature < water set temperature + [-4°C] AND
- d) 20 minutes since previous Backup heater Off AND
- e) Backup Heater Enable

#### Backup Heater Stop condition

- a) Force mode off OR
- b) Operation off OR
- c) When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs **OR** \* ON/OFF follow normal heater sequence.

### Tank side (Tank mode)

- 1) When tank mode select and force heater bit received, turn ON backup heater (INTERNAL) or Booster Heater (External) depend on the tank heater selection.
- 2) If tank heater selection is INTERNAL, follow normal thermo judgement to switch 3 ways valve to tank side and room side.
- If tank heater selection is EXTERNAL, only turn ON booster heater according to tank thermo.

### Tank Heater selection is INTERNAL:

### Backup Heater ON Condition:

- a) After water pump operate 2 mins AND
- b) When tank temperature < Tank set temperature [Remocon Set Tank Re-heat Temp] AND
- c) 20 minutes since previous backup heater OFF AND
- d) Backup heater enable

### Backup Heater OFF Condition:

- a) Force mode OFF OR
- b) When tank temperature > Tank set temperature for continuous 15 secs OR
- c) Tank Operation OFF

### Tank Heater selection is EXTERNAL:

- Backup Heater ON Condition:
- a) Force Heater mode ON AND
- b) Tank temperature < tank set temperature + [Remocon Set Tank Re-heat Temp] 1°C, AND
- c) 20 minutes since previous heater off.

#### Backup Heater OFF Condition:

- a) Tank temperature > tank set temperature for continuous 15 sec
- b) Force mode OFF
- c) Tank Mode Operation OFF (During tank interval or tank mode condition, water pump and 3 ways valve will OFF)

## 12.10 Powerful Operation

Powerful mode is use to increase the capacity of heat pump to achieve higher target temperature. Powerful mode is applicable when heat mode is operating.

#### **Remote control setting:**

On quick menu of remote control, there is 4 options of powerful mode can be select.

- OFF : Cancel powerful mode
- 30 minutes : Set powerful for 30 minutes
- 60 minutes : Set powerful for 60 minutes
- 90 minutes
   : Set powerful for 90 minutes

#### Control contents:

During the time set by remote control, powerful will activate according to 2 shift up controls. However, this function is applicable only for heating. Remote control will transmit the signal to indoor unit once this function is select then transmit OFF signal to indoor when the timer is complete. Indoor will transmit signal to outdoor for frequency control.

Indoor setting temperature shift

- If system is standard system (Optional PCB is not connected)
  - Target water temperature will shift up to WIo or Whi whichever higher.
- If system is extension system (Optional PCB is connected)
  - Target water Zone 1 and Zone 2 temperature will shift up to Wlo or Whi whichever higher.

\* If "Direct Type" temperature control is select, this powerful shift up setting is not effective.

- Start condition
  - o Powerful function is select by remote control.
- End Condition
  - OFF/ON button is pressed.
  - o Powerful function is OFF by remote control.

## 12.11 Quiet Operation

Quiet mode is use to reduce the noise of outdoor unit by reducing the frequency or fan speed.

#### Quiet level

There are 3 level (Level 1, Level 2, Level 3) to set by quick menu function on remote control.

#### **Control content**

Once the quiet function is select, the remote control will transmit the signal to indoor and outdoor unit.

#### Start condition

- Quiet mode is set on remote control.
- Quiet mode is request ON by weekly timer.

#### **Stop condition**

If any of below condition is achieve.

- OFF/ON button is pressed.
- Quiet mode is OFF by remote control.
- Quiet mode is request OFF by weekly timer.

## 12.12 Sterilization Mode


- Purpose:
  - $\circ$   $\,$  To sterilize water tank by setting the required boiling temperature.
- Remote control setting
  - Days for sterilization function to start can be select.
  - Time of selected day to start sterilization function.
  - Boiling temperature (Internal heater is 55°C ~ 65°C)
  - o Maximum operation time is 5 minutes to 1 hour.

- Start condition
  - $\circ$   $\hfill\hfilt$
  - o Sterilization function selects "YES".
  - o Sterilization signal received from remote controller by timer.
  - Tank mode request ON.
- Stop condition
  - When boiling timer is completed. Boiling timer (Remote control set maximum operation time) start counting once tank achieve boiling set temperature **OR**
  - o After 8 hours of operation since sterilization start.
  - o Tank mode request OFF.
- Control content:
  - During sterilization function activation time, target tank set temperature will internally change to boiling set temperature.
  - During sterilization activates, heat pump and heater (external or internal) will operate as normal tank mode to achieve the boiling set temperature.
  - o Sterilization operation will end when stop condition is fulfill.
  - o After sterilization is complete, tank set temperature will resume to normal operation.

\* Tank temperature may not achieve boiling set temperature if tank heater is select OFF **OR** external compressor switch.

## 12.13 Outdoor Ambient Thermo OFF Control

- Purpose
  - Stop provides heating to room side during high outdoor ambient condition.



- Control content
  - Heating outdoor ambient thermos OFF control only applicable when heat pump operate in heat mode. (This control will not activate when running in tank side)
  - Heat pump and water pump will turn OFF when outdoor ambient is higher than outdoor thermo OFF set temperature.
  - Heat pump thermos ON when outdoor ambient < outdoor thermos OFF set temperature + 1°C.

## 12.14 Alternative Outdoor Ambient Sensor Control

## Purpose of the Alternative Outdoor Ambient Sensor:

 It is some possibility that the air to water heat pump unit will install at a location where the original ambient sensor is expose to direct sunlight. Therefore, another optional ambient sensor can be connect to indoor PCB and locate at new and better reading location to improve the heat pump performance.

### Control Detail:

- Remocon can select either the extra outdoor ambient sensor is connected or not. (YES/NO)
- The alternative outdoor ambient sensor will connect to indoor unit main PCB terminal.
  - o when alternative sensor select NO
    - Original Outdoor temperature sensor will use for Indoor & Outdoor heat pump operation reference sensor.
    - Data communication direction : OUTDOOR send outdoor temperature reading to INDOOR.
    - Error judge : OUTDOOR will judge the original outdoor sensor error (F36 display if error detect). No judge error on alternative outdoor sensor
  - o when alternative sensor select YES
    - Alternative Outdoor temperature sensor will use for Indoor & Outdoor heat pump operation reference sensor.
    - Data communication direction : INDOOR send outdoor temperature reading to OUTDOOR.
    - Error judge : INDOOR will judge the Extra outdoor sensor error only after operation ON request received from remocon.

(F36 display if error detect). No judge error on original outdoor sensor.

## 12.15 Force DHW mode

Purpose:

When user want to use hot water now, user can press this force DWH mode under the quick menu to operate tank only mode to boil up the tank temperature.

Remocon setting:

Force DHW function can be activate under quick menu.

Control Content:

- when press the Force DHW function during operation OFF condition:
  - When receive this Force DHW bit from remocon, indoor will run tank only mode regardless of the mode selection.
  - After tank temperature achieve tank thermo off temperature, turn OFF force DHW bit and return to operation OFF with previous mode selection.
- When press the Force DHW function during operation ON condition:
  - When receive this Force DHW bit from remocon, indoor will memories the running mode and run tank only mode regardless of the mode selection.
  - After tank temperature achieve tank thermo off temperature, turn OFF force DHW bit and return to previous memories running mode.

\* when operation OFF or mode change request from remocon during force DHW mode operation, End force DHW mode and follow the new request operation.

\* Once receive force DHW mode from remocon, indoor direct start tank mode and consider tank thermo ON. Thermo OFF only when achieve tank thermo OFF depend on the Tank System Setting.

## 12.16 Anti Freeze Control

- Anti freeze protection control menu can be set YES or NO by control panel.
  - In heatpump system, there are 3 types of anti freeze control:
- 1. Expansion tank anti-freeze control
  - Expansion tank anti freeze heater ON condition:
    - Outdoor ambient temp. < 3°C</li>
  - Expansion tank anti freeze heater OFF condition:
    - Outdoor ambient temp. > 4°C
  - 2. Water pump circulation anti freeze control
    - Water pump turns ON when <u>ALL</u> below conditions are fulfilled:
      - Heatpump OFF (stand by) OR error occurs.
      - Water flowing flag is ON.
      - Water flow switch is not abnormal.
      - Outdoor ambient temp. < 3°C OR outdoor ambient temp. sensor is abnormal.
      - Water inlet/outlet temp. < 6°C.
      - After 5 minutes from previous water pump OFF.
      - Water pump turn OFF when ANY of below conditions is fulfilled:
      - Outdoor ambient temperature  $\geq 4^{\circ}$ C.
      - During -5°C < outdoor ambient temp. < 4°C
        - After water pump ON for 4 minutes, and water inlet temp. ≥ 8°C.
        - Else, shift to back up heater anti freeze control.
      - During outdoor ambient temp. <  $-5^{\circ}$ C
        - After water pump ON for 4 minutes, and water inlet/outlet ≥ 20°C.
        - Else, shift to back up heater anti freeze control.
    - However, if flow switch is abnormal (H62), then water pump circulation anti freeze control will not activate.
  - 3. Back up heater anti freeze control:
    - Back up heater turn ON when <u>ALL</u> below conditions is fulfilled:
      - Water inlet/outlet temp. <  $6^{\circ}$ C.
      - Water pump circulation anti freeze control activated and water pump ON for 4 minutes.
    - Back up heater turns OFF when ANY of below conditions is fulfilled:
      - Water inlet/outlet temp. > 28°C.
      - Water pump circulation anti freeze control deactivated/water pump OFF.
    - However, if back up heater is abnormal (H70) then back up heater anti freeze control will not activate.

## 12.16.1 Zone Anti-Freeze Control

 If buffer tank selection is "NO" and Anti- Freeze function select "NO" from remote control, this control cannot activate.

Start condition:

- After [5] min from previous Zone pump off. **AND**
- Outdoor air temp < [3] °C OR Outdoor sensor is abnormal. AND
- Zone water temperature < [6]°C **OR** Zone Sensor Short or Open

Cancel condition:

- After water Zone pump ON [4] min AND
- Outdoor air temp ≥ [4]°C OR
- During -5 °C ≤ Outdoor air temp < [4] °C OR Zone water temperature sensor > [8] °C
- During Outdoor air temp < [-5] °C</li>
   Zone water temperature sensor > [20] °C
   \*However, Zone water temperature sensor is Open or Short, Condition C and D is ignored.


## 12.17 Solar Operation (Optional)

## 12.17.1 Solar Operation:

Solar function:

 This function allow user to control the solar pump to operate depend on the solar sensor reading compare to the tank installed. Solar pump will circulate the hot water energy store at solar panel to heat up the DHW Tank or Buffer Tank.

Solar Connection Diagram:



- Solar function can only enable when the Optional PCB is connected.
- Few part as below need to install to control the solar operation:
  - Solar Panel
    - o Solar Pump
    - o Solar Panel Sensor
    - Tank Sensor (Buffer tank sensor OR DHW Tank sensor depend on the connection direction)
       \* During Solar Connection to the system, installer need to alert on the high water temperature may flow to the zone circuit or DHW piping circuit. Therefore pipe which withstand higher water temperature need to be installed.
- Solar remote control setting
  - 1 Solar Setting can only be set when the optional PCB connection is select "YES"
  - 2 By remote controller, Setting as below list can be set for solar function operation (Installer Menu)
    - Solar Function ("YES" or "NO)
    - Tank Connection Direction ("DHW TANK" or "BUFFER TANK")
    - Delta T turns ON: Difference temperature setting between solar panel sensor and Tank to turn on solar pump. (Range :5 ~ 15°C)
    - Delta T turns OFF: Difference temperature setting between solar panel thermistor and Tank to turn off solar pump. (Range :2 ~ 10°C)
    - Outdoor temp for Anti-Freeze : Outdoor temp to start Anti-Freeze control for solar circuit. (Range : -20 ~ 10°C)
    - Tank Temperature HI Limit Set (Range : 70 ~ 90°C)

## 12.17.2 Solar Operation Control

• Solar function can only be activate if the solar function selection "YES" from remote control. To achieve hot water from solar panel, indoor need to control the solar pump and circulate hot water from solar panel.

Under normal case:

- Solar pump start condition:
  - Solar panel temperature > Delta T turn on setting temp (R/C) + Tank temperature (depend on selection, DHW or Buffer) AND
    - Tank temperature (DHW or Buffer) < Solar HI Limit Temp (R/C) AND
    - Operation ON with heat mode (apply to solar connect to "Buffer Tank" case)

\* Condition c) ignore if the solar system is connect to DHW tank (control active under operation OFF time for Tank connection case)

- Solar pump stop condition:
  - Solar panel temperature < Delta T turn OFF setting temp (R/C) + Tank temperature (depend on selection, DHW or Buffer) OR
  - Tank hot water temp >= Solar HI Limit Temp (R/C) + [2]°C

Under solar Anti-freeze protection control:

- Solar pump start condition:
- Outdoor temp < Outdoor temp setting for Anti-Freeze (R/C)</li>
- Solar pump stop condition:

0

Outdoor temp > Outdoor temp setting for Anti-Freeze + [2]°C

\*\*However, During Cool mode this function cannot activate if Tank selection is "Buffer Tank".

\*\*Solar pump can operate even if Heat pump is under error stop.

- Solar operation during error:
  - During Tank sensor (DHW or Buffer depend on selection) abnormal, Solar operation will not able to function.
  - o During Solar Panel sensor detect OPEN (not include SHORT), Solar operation will not able to function too.

## 12.18 Boiler Bivalent Control

- Boiler is an additional or alternative heat source to heat up the room when necessary.
- Purpose of this control is to turn ON and turn OFF the Boiler output signal when boiler heating capacity needed in the system.
- Boiler is possible to connect to DHW Tank and Buffer Tank depends on the installer.
- Boiler operation parameter need to be set on Boiler itself, indoor do not control the boiler operation direction and operation.
- There are Alternative mode, Parallel mode, & Advance Parallel mode available to select by installer to fit to the total system.

#### Bivalent control selection by remote controller

Remote control setting value:

1 Outdoor Ambient Set = (Range:  $-15^{\circ}C \sim 15^{\circ}C$ )

#### • Alternative Mode

• Only one heat source operates at one time, either heat pump or boiler depends on condition.

### Control detail:

During Operation ON at Heat mode or Tank mode or Heat + Tank Mode

- Boiler signal turn ON and heat pump and water pump turn OFF when:
  - Outdoor ambient < Outdoor Ambient Set AND</li>
  - Boiler prohibit flag = 0

\*\* However indoor water pump can operate when Anti-freeze control condition fulfilled.

- Boiler signal turn OFF and heat pump and water pump turn ON when:
  - Outdoor ambient > Outdoor Ambient Set + [2°C] OR
  - Boiler prohibit flag = 1

### • Parallel Mode

• Parallel mode allows heat pump and boiler ON at the same time. Boiler operates as an additional heating capacity when low heat pump capacity at low ambient condition.

#### Control detail:

During operation ON at Heat mode or Tank mode or Heat + Tank mode

- Boiler signal turns ON when:
  - Outdoor ambient < Outdoor Ambient Set AND</li>
  - Boiler prohibit flag = 0
- Boiler signal turns OFF when:
  - Outdoor ambient > Outdoor Ambient Set + [2°C] OR
  - Boiler prohibit flag = 1

#### • Advance Parallel Mode

 Advance parallel mode allow heat pump to operate and turn ON boiler only when ambient and temperature condition is fulfilled.

Remote control setting value:

- 1 Outdoor Ambient Set = (Range :  $-15^{\circ}C \sim 15^{\circ}C$ )
- 2 Selection of boiler connection direction. (Heat only, DHW only, Heat & DHW)
- 3 Setting data under Heat Direction
  - Start Temperature | START\_TEMP |
  - Start Delay Timer | START\_TIMER |
  - Stop Temperature | STOP\_TEMP |
  - Stop Delay Timer | STOP\_TIMER |
- 4 Setting data under DHW Direction
  - Delay Timer | DELAY\_TIMER |

#### Control detail:

С

During operation ON at Heat Mode

- Boiler signal turns ON when
  - Outdoor ambient < Outdoor Ambient Set AND</li>
  - Buffer tank temperature < Target Buffer Tank Temperature + [START\_TEMP] for [START\_TIMER] AND</li>
  - Heat pump operate at room side AND
  - Connection of Boiler to Heating Select "YES" From installer menu AND
  - Buffer Tank connection select "YES" AND
  - Boiler prohibit flag = 0
  - Boiler signal turns OFF when
    - Outdoor ambient > Outdoor Ambient Set + [-2°C] OR
    - Buffer Tank temperature > Target Buffer Tank temperature + [STOP\_TEMP] for [STOP\_TIMER] OR
    - Heat pump not at room side. OR]
    - Boiler prohibit flag = 1

#### During operation ON at Tank Mode

• Boiler signal turns ON when

- Outdoor ambient < Outdoor Ambient Set AND</li>
- Heat pump operate at tank side for continuous | DELAY\_TIMER | AND
- Connection of Boiler to DWH Tank select "YES" from installer menu. AND
- Boiler prohibit flag = 0
- Boiler signal turns OFF when
  - Outdoor ambient > Outdoor Ambient Set + [2°C] OR
  - Heat pump not operates at tank side. OR
  - Boiler prohibit flag = 1

## Boiler prohibit flag control

Purpose:

• For product safety. Boiler signal is OFF when water temperature is too high.

Start condition:

- Water outlet  $\ge$  85°C continues for 5 minutes.
- Water inlet  $\geq$  85°C continues for 5 minutes.
- Zone1 water temp ≥  $75^{\circ}$ C continues for 5 minutes.
- Zone2 Water temp ≥  $75^{\circ}$ C continues for 5 minutes.

#### Contents:

After start condition fulfilled, set boiler prohibit flag = 1

Cancel condition:

o After 30 minutes from start condition fulfilled.

Contents:

Set boiler prohibit flag = 0

## 12.19 External Room Thermostat Control (Optional)

#### Purpose:


 Better room temperature control to fulfill different temperature request by external room thermostat. Recommended external room thermostat:

| Maker           | Characteristic |
|-----------------|----------------|
| Siemen (REV200) | Touch panel    |
| Siemen (RAA20)  | Analog         |

Connection of external room thermostat:

Wire Connection and thermo characteristic of Siemen REV200:


| Setting                | L/L1 (H)      | Heat Thermo | L/L2 (C)      | Cool Thermo |
|------------------------|---------------|-------------|---------------|-------------|
| Set Temp < Actual Temp | Open Circuit  | OFF         | Short Circuit | ON          |
| Set Temp > Actual Temp | Short Circuit | ON          | Open Circuit  | OFF         |



Connect only heating line for heating only model. And connect both heating and cooling line for heat + cool model.

Wire Connection and thermo characteristic of Siemen RAA20:

| Setting                | L/Y1 (H)      | Heat Thermo | L/Y2 (C)      | Cool Thermo |
|------------------------|---------------|-------------|---------------|-------------|
| Set Temp < Actual Temp | Open Circuit  | OFF         | Short Circuit | ON          |
| Set Temp > Actual Temp | Short Circuit | ON          | Open Circuit  | OFF         |



Connect only heating line for heating only model. And connect both heating and cooling line for heat + cool model.

Control Content:

- External room thermostat control activate only when remote thermostat connection select YES by Indoor control
  panel.
- When indoor running heat mode, refer thermo On/Off from heating line feedback. And when indoor running cool mode, refer thermo On/Off from cooling line feedback.
- Heat pump Off immediately when receive thermo off feedback.


## 12.20 Three Ways Valve Control

### Purpose:

- 3 ways valve is used to change flow direction of hot water from heat pump between heating side and tank side.

### Control contents:

- 1 3 ways valve switch Off:
  - o During 3 ways valve switch Off time, the hot water will provide heat capacity to heating side.
- 2 3 ways valve switch On:
  - o During 3 ways valve switch On time, the hot water will provide heat capacity to tank side.
- 3 Stop condition:
  - o During stop mode, 3 ways valve will be in switch off position.



\* During pump down and force mode, fix 3 ways valve in close condition.

\* Recommended Parts : SFA 21/18 (Siemens)


## 12.21 Two Ways Valve Control

Functionality of 2 ways valve:

• Use to allow hot water to floor heating panel or block cold water to floor heating panel.

Control contents:

- 1 When indoor running in heat mode, OPEN the 2 ways valve.
- 2 When indoor running in cool mode, CLOSE the 2 ways valve.
- 3 Stop condition:
  - a. During stop mode, fix 2 ways valve in close condition.




\* During pump down mode, fix 2 ways valve in close condition.

\* During force mode, open 2 ways valve.

\* Recommended Parts : SFA 21/18 (Siemens)

# 12.22 External OFF/ON Control


• Communication circuit between indoor unit and external controller is as per below.



- Maximum length of communication cable is 50 meter.
- Control content:

| External Control Switch | Control Panel OFF/ON | Control Panel Power LED | System Status |
|-------------------------|----------------------|-------------------------|---------------|
| ON                      | ON                   | ON                      | ON            |
| ON                      | OFF                  | OFF                     | OFF           |
| OFF                     | ON                   | ON                      | OFF           |
| OFF                     | OFF                  | OFF                     | OFF           |

Remocon Screen Display and Control Detail:



When External SW connection select "YES" from remocon installer menu:

- Heating or Cooling system will operate normally if the External Switch signal is ON.
- Once the External Switch turn OFF, System Turn OFF (Heat pump, water pump, heater etc...)
- Remocon LED remain ON or OFF according to the current operation request.
- Pop up menu at remocon main screen as above screen to inform customer system stop by External Switch.
- It is possible to press cancel and return to main screen to do change of operation setting while waiting the External Switch turn ON back.
- Remocon LED will always follow the latest changes from remocon.
- If no action on remocon for continuous 5 minutes, the pop up screen will show again on the screen.
- But once the External Switch Turn ON back, pop up screen will disappear and system can operate normally
  according to the latest operation setting and request.

# 12.23 External Compressor Switch (Optional PCB)

External compressor switch port can have two purpose of control as below:

- Heat source ON/OFF function (Dip switch Pin 3 on PCB "OFF")
- Heater ON/OFF function (Dip switch Pin 3 on PCB "ON")
- Heat source ON/OFF function

Purpose:

 Heat pump ON/OFF function is use to turn OFF the high power consumption device (Heat pump, & Heater) when there is energy or electric current limitation. Other optional function still can be operate under heat pump and heater OFF condition.

Control Detail:

- This External Compressor Switch is possible to connect to Optional PCB only.
- Once the remocon select External Compressor Switch connection "YES", & Dip Switch on PCB "OFF" This heat pump ON/OFF function will activate
- The ON/OFF signal of this External Compressor Switch is same as External Switch.
- When the External Compressor Switch is ON:
- Heat pump system operate normally
- When the External Compressor Switch is OFF:
  - o Heat pump, Indoor water pump & Heater ( Booster heater & Backup Heater ) need to turn OFF
  - $\circ$   $\,$  Solar, Boiler and zone control can be operate follow normal control condition.
    - \* pump delay OFF also included in this control

(There is NO pop up screen like External Switch when this External Compressor Switch is OFF.)

• Heater ON/OFF function

### Purpose:

Heater ON/OFF function is use to turn OFF the heater (backup heater & booster heater) when there is energy or
electric current limitation. Heat pump and other optional function still can operate.

Control detail:

- This External Compressor Switch is possible to connect to Optional PCB only.
- Once the remocon select External Compressor Switch connection "YES", & Dip Switch on PCB "ON" This heater ON/OFF function will activate
- When the External Compressor Switch is ON:
   Heat pump and heater operate normally
- When the External Compressor Switch is OFF:
  - Backup heater and booster heater cannot operate even heater request is ON.
    - Heat pump and option function (Solar, Boiler and zone control) can be operate follow normal control condition.

(There is NO pop up screen like External Switch when this External Compressor Switch is OFF.)

# 12.24 Heat/Cool Switch (Optional PCB)

### Purpose:

• User can switch the running mode from heat to cool or cool to heat through external installed Heat/Cool switch. This kind of heat / cool switch may built in inside the field supply room remocon as well.

Control contents:

- Heat/Cool Switch can only be set when Cool Function is "enable" at custom menu setting, & Extension PCB select "YES" & Zone 1 not set "Pool" condition.
- This heat/cool switch control will be activate only when installer set the Heat/Cool Switch "USE" through remocon.
- Once the Heat/Cool Switch Set "USE", remocon will check indoor send Signal to judge the option of mode select.
- When Heat/Cool Switch Contact Open : Remocon only can select Heat Mode, or Heat + Tank Mode, or Tank Mode
  - When Heat/Cool Switch Contact Close : Remocon only can select Cool Mode, or Cool + Tank Mode, or Tank Mode


- Operation ON/OFF will depend on remocon request.
- When Heat Mode is running with Contact Open, user change this setting to contact close, indoor will this signal to remocon judge and change mode to cool and send back to indoor. And it is same as from cool mode change to heat mode.
  - \* This switch have higher priority, remocon follow indoor send signal when control activated.
  - \* There is no effect to the operation when the mode running is only Tank Mode.

(Weekly Timer are ignored and cannot be set during Heat / Cool Switch is "Enable" Condition.)

# 12.25 SG Ready Control (Optional PCB)

Purpose:

• To set ON/OFF of heat pump and target temperature by digital input of third party device if necessary in field.



### Remote control setting

For this function, following items need to be set on R/C (installer menu) -

- SG control = YES or NO
- Capacity up setting 1
  - Heating capacity [50 ~ 150 %]
  - DHW capacity [50 ~ 150 %]
- Capacity up setting 2
  - Heating capacity [50 ~ 150 %]
  - DHW capacity [50 ~ 150 %]

### Control contents:

If SG control on remote control = "Yes", then following control only activate by digital input.

- While Digital input is " 00 " (Normal operation)
  - Normal operation. Once detect '00' system will operate back to normal condition.
     (All the target set temperature for heating side and DHW side will return back to previous set temperature when digital signal change from "10' or"11" back to "00".)
- While digital input is detected " 01 " (HP stop)
  - Heat pump & room heater & tank heater cannot operate.
    - (Solar control and Boiler back up and 2 Zone control can activate.)
- While digital input is detected " 10 " (Capacity 1)
  - Target temperature for heating and DHW Tank is changed according to the percentage set by Remote control setting. However, which setting temperature is change depend on system setting.
- While digital input is detected " 11 " (Capacity 2)
  - Target temperature for heating and DHW Tank is changed according to the percentage set by Remote control setting. However, which setting temperature is change depend on system setting.
- While digital input is detected " 10 " (Capacity 1)
  - Setting temperature for heating and Tank is changed.
     However, which setting temperature is change depend on system setting.

### If Buffer selection is "YES"

### Room side

New Target Buffer tank temperature = Current Target Buffer Tank Temperature \* Remote Control setting (" capacity 1) %

\* Max Min regulation is follow Target Buffer tank temperature control specification

\*\* No change of Target zone water temperature, only set higher buffer tank temperature.

### DHW Tank side

New Tank Set Temperature = Tank Set Temperature \* Remote Control setting for DHW ("Capacity 1) % \* (Max regulation depend on the tank max setting limit)

### If Buffer selection is "NO"

Room side

New Target Zone Water Temperature = Current Target Zone Water Temperature \* Remote Control Setting (\*Capacity 1) %

(Zone 1 and Zone 2 will change according to its own target zone water temperature.)

(Max regulation depend on the temperature control type select)

### DHW Tank side

New Tank Set Temperature = Tank Set Temperature \* Remote Control setting for DHW ("Capacity 1) % \* (Max regulation depends on the tank max setting limit)

### • While digital input is detected " 11 " (Capacity 2)

Setting temperature for heating and Tank is changed.
 However, which setting temperature is change depend on system setting.

### If Buffer selection is "YES"

### Room side

New Target Buffer tank temperature = Current Target Buffer Tank Temperature \* Remote Control setting (" capacity 2) %

\* Max Min regulation is follow Target Buffer tank temperature control specification

\*\* No change of Target zone water temperature, only set higher buffer tank temperature.

### DHW Tank side

New Tank Set Temperature = Tank Set Temperature \* Remote Control setting for DHW ("Capacity 2) % \* (Max regulation depends on the tank max setting limit)

### If Buffer selection is "NO"

### Room side

New Target Zone Water Temperature = Current Target Zone Water Temperature \* Remote Control Setting (\*Capacity 2) %

(Zone 1 and Zone 2 will change according to it's own target zone water temperature.)

(Max regulation depend on the temperature control type select)

### DHW Tank side

New Tank Set Temperature = Tank Set Temperature \* Remote Control setting for DHW ("Capacity 2) %

\* (Max regulation depends on the tank max setting limit) \*\* This function is not applicable for Cooling mode.

# 12.26 Demand Control (Optional PCB)

### Remote control setting:

• When Optional PCB connection select 'YES", Demand Control function can select "YES" or "NO".

### Purpose:

- After the demand control select YES, below control will activated.
  - o 0-10V Demand control

### 0-10V Demand control

• Demand control is use to reduce the current usage of heat pump unit by third party device.

## Control start condition:

- Select "YES" at Demand control at installer menu.
- 0-10V input for this electrical current control is detected.

Control content:

- If start condition is fulfilled, indoor will receive the voltage signal from optional PCB. Indoor will send the rate value to outdoor unit.
- Outdoor will change the current limit according to the percentage receive from indoor unit.

# 12.27 Holiday Mode

Purpose:

Promotes energy saving by allowing the user to stop the system during holiday and enables the system to resume at the preset temperature after holiday.

- Control details:
  - Indoor operate the unit according running mode request. Target temperature will follow holiday setting temperature.
    - If heat mode request is receive, Target Water Out Temperature will change according to holiday shift temperature set.
      - [If heat is set OFF at holiday, unit, water pump and zone control will OFF]
    - If tank mode request is receive, Target Tank Set Temperature will change according to the holiday tank shift temperature set.
      - [If tank is set OFF at holiday, heat pump and tank heater will OFF]
  - After days of holiday have been set, heat pump will stop and only resume operation at the end of holiday countdown.
- Start condition:
  - Holiday timer set and the holiday timer start
    - \* The day holiday mode was set is counted as day 1.
- Stop condition:
  - OFF/ON button is pressed.
  - Holiday timer is reached.

# 12.28 Dry Concrete

Purpose:

Provide heat to floor heating panel and dry the wet concrete during installation.

- Setting condition:
  - Dry concrete parameter can be set through remote control under system setup.
  - o Parameters are possible to set up to 99 days with different target set temperature
- Control details:
  - o Dry concrete mode will be activates when select ON from service setup.
  - Once start dry concrete function, remote control will send step 1 setting temperature to indoor unit.
     \* This temperature is set at zone temperature. If system is 2 zones, both zone target temperature is set as same temperature.
  - Heat pump will start heat mode operation to room side with received target water outlet temperature. \* Heat pump will operate according to Heat pump Target Water Temperature.
  - After complete day 1 setup operation, day 2 data will be send to indoor at 12.00am on the second day.
  - Each preset data will be send every day until dry concrete mode is complete, unit will turns OFF and exit dry concrete function.
  - o 3 ways valve and booster heater will turn OFF and 2 ways valve will turns ON.
- Cancel condition:
  - Dry concrete mode is complete and OFF signal is received.
  - OFF signal is received by pressing OFF/ON button.

# 12.29 Flow Sensor

- The water flow sensor serves as an overload protector that shuts down the unit when the water level is detected to below.
- Abnormal flow detection:

| Sequence                               | Abnormal flow                      | Normal flow |
|--|------------------------------------|-------------|
| Normal case                            | Flow rate < 11 I/min or ≥ 69 I/min | ≥ 11 I/min  |
| During status 2~6 on Anti-freeze deice | Flow rate ≥ 11 l/min               | < 11 l/min  |

# **13. Protection Control**

# 13.1 Protection Control for All Operations

# 13.1.1 Time Delay Safety Control

1 The compressor will not start for three minutes after stop of operation.

# 13.1.2 30 Seconds Forced Operation

- 1 Once the compressor starts operation, it will not stop its operation for 30 seconds.
- 2 However, it can be stopped using control panel at indoor unit.

# 13.1.3 Total Running Current Control

- 1 When the outdoor running current exceeds X value, the compressor frequency will decrease.
- 2 If the outdoor running current does not exceed X value, the compressor frequency will return to normal operating frequency.
- 3 If the outdoor running current continue to increase till exceed Y value, compressor will stop, and if this occurs 3 times within 20 minutes, system will stop operation and OFF/ON control panel LED will blink (F16 error occurs).


|                | WH-MDC | C12H6E5 | WH-MDC16H6E5 |       |  |
|----------------|--------|---------|--------------|-------|--|
| Operation Mode | X (A)  | Y (A)   | X (A)        | Y (A) |  |
| Heating        | 24.1   | 28.0    | 26.0         | 28.0  |  |
| Cooling        | 18.1   | 28.0    | 22.8         | 28.0  |  |

## A. DC Peak Current Control

- 1 When the current to IPM exceeds set value of 34 A, compressor will stop. Compressor will restart after three minutes.
- 2 If the set value exceeds again for more than 30 seconds after the compressor restarts, operation will restart after two minutes.
- 3 If the set value exceeds again for within 30 seconds after the compressor restarts, operation will restart after one minute. If this condition repeats continuously for seven times, system will stop operation and OFF/ON control panel LED will blink (F23 error occurs).

# 13.1.4 Compressor Overheating Prevention Control


 The compressor operating frequency is regulated in accordance to compressor tank temperature as shown in below figures. When the compressor tank temperature exceeds 107°C, compressor will stop, and if this occurs 4 times within 30 minutes, system will stop operation and OFF/ON control panel LED will blink (F20 error occurs).



# 13.1.5 High Pressure Sensor Control

- Purpose:
  - To protect the system operation.
- Detection period:
- After compressor on for 1 minute.
- Detection conditions:
- When abnormal high voltage detection, 5 V or when open circuit detection 0V for 5 seconds continuously.
- After detection:
  - When abnormality is detected 4 times within 120 minutes, unit stop operation.
  - OFF/ON control panel LED will blink (H64 error occurs).

# 13.1.6 Outside Temperature Current Control



# 13.1.7 Crank Case Heater Control

- Purpose:
- For compressor protection during low outdoor ambient operation (during heating low temperature operation).
   Control content:
  - a. Trigger heater START condition
    - When the outdoor air temperature is below than 4°C, and discharge temperature is 11°C or below.
  - b. Resetting heater STOP condition
    - 1. When the outdoor air temperature exceeds entry condition (2°C)
    - 2. When the discharge temperature exceeds entry condition (7°C)

# 13.2 Protection Control for Heating Operation

# 13.2.1 Outdoor Air Temperature Control


The maximum current value is regulated when the outdoor air temperature rises above 14°C in order to avoid compressor overloading.

# 13.2.2 Deice Operation

When outdoor pipe temperature and outdoor air temperature is low, deice operation start where outdoor fan motor stop.


• Deice judging condition

Outdoor Unit Deice Control



### Deice mode selection condition

• There are 2 deice modes, according to water inlet temperature and outdoor ambient temperature the deice mode is decided.




### Judgement details:

- 1 When water inlet temperature is more than 50°C, unit will operate deice mode 1.
- 2 When water inlet temperature is less than 27°C, unit will operate deice mode 2.
- 3 When water inlet temperature is less than 50°C and outdoor ambient temperature is less than -10°C, unit will operate deice mode 2.
- 4 When water outlet temperature sensor 2 detect temperature is less than 22°C, unit will operate deice mode 2.

### Deice operation time diagram

a. Deice mode 1 control:




b. Deice mode 2 control:

|                           | Normal<br>Deice | ◀  | Deice mode 2     max 30 minutes |   |   |   |   | Heating operation |   |      |
|---------------------------|-----------------|----|---------------------------------|---|---|---|---|-------------------|---|------|
| Sequence                  | 4~6             | 1  | 2                               | 3 | 4 | 5 | 6 | 7                 | 8 |      |
| Compressor                |                 |    |                                 |   |   |   |   |                   |   | Free |
| Four way valve            | OFF             | ON |                                 |   |   |   |   |                   |   | ON   |
| OD fan                    | OFF             |    | OFF                             |   |   |   |   |                   |   | Free |
| Main<br>Expansion valve   |                 |    |                                 |   |   |   |   |                   |   | Free |
| Bypass<br>Expansion valve | 0               |    |                                 |   |   |   |   |                   |   |      |
| Gas Bypass SV             | OFF             |    | ON                              |   |   |   |   |                   |   | OFF  |
| Pump                      | ON              |    | OFF                             |   |   |   |   |                   |   | ON   |
| p                         |                 |    |                                 |   |   |   |   |                   |   |      |

# 13.3 Protection Control for Cooling Operation

# 13.3.1 Outdoor Air Temperature Control

- The Compressor operating frequency is regulated in accordance to the outdoor air temperature as shown in the diagram below.
- This control will begin 1 minute after the compressor starts.
- Compressor frequency will adjust base on outdoor air temperature.



# 13.3.2 Freeze Prevention Control 1

- 1 When indoor heat exchanger temperature is lower than 0°C continuously for 10 seconds, compressor will stop operating.
- 2 Compressor will resume its operation three minutes after the indoor heat exchanger is higher than 1°C.
- 3 Indoor heat exchanger freeze prevention (H99) will memory in error history.

# 14. Servicing Mode

# 14.1 Expansion Vessel Pre Pressure Checking

[Upper limit water volume of the system] The Mono bloc unit has a build-in Expansion Vessel with 10 L air capacity and initial pressure of 1 bar.

• Without antifreeze agent condition

Total amount of water in the system should be below 200 L.

If the total amount of water is more than 200 L, please add expansion vessel (field supply).

With antifreeze agent condition

In the case of using antifreeze agent, expansion rate  $\boldsymbol{\epsilon}$  is different depending on its maker.

Please refer to the antifreeze agent maker for the expansion rate  $\varepsilon$  before calculate the upper limit water volume of the system.

The expansion vessel capacity required for the system can be calculated from the formula below.

$$\mathbf{V} = \frac{\varepsilon \times V_0}{\mathbf{1} - \frac{98 + P_1}{98 + P_2}}$$

V : Required gas volume <expansion vessel volume L>

Vo : System total water volume <L>  $\epsilon$  : Expansion rate  $5 \rightarrow 60^{\circ}C$ 

Expansion rate 
$$5 \rightarrow 60^{\circ}$$
C = (depends on antifreeze agent used)

$$P_2$$
: System maximum pressure = 300 kPa

() Please confirm at actual place

The gas volume of the sealed type expansion vessel is presented by <V:</li>
 It's advised to add 10% margin for required gas volume of calculation.

o it's advised to add 10% margin for required gas volume of calc


[Adjustment of the initial pressure of the expansion vessel when there is a difference in installation height] If the height difference between the Mono bloc unit and the highest point of the system water circuit (H) is more than 7m, please adjust the initial pressure of the expansion vessel (Pg) according to the following formula.

# 14.2 Maintenance

 In order to ensure optimal performance of the unit, seasonal inspections on the unit, functional check of RCCB, field wiring and piping have to be carried out at regular intervals. This maintenance should be carried out by authorized dealer.

# 14.2.1 Maintenance for Water Filter Set

- 1. Remove the Cover by loosening the mounting screws to access to the Water Filter Set.
- 2. Turn OFF power supply.
- 3. Set the two valves for the Water Filter Set to "CLOSE".
- 4. Take off the clip, then gently pull out the mesh. Beware of small amount water drain out from it.
- 5. Clean the mesh with warm water to remove all the stain. Use soft brush if necessary.
- 6. Reinstall the mesh to the Water Filter Set and set back the clip on it.
- 7. Set the two valves for the Water Filter Set to "OPEN".
- 8. Turn ON power supply.
- 9. After cleaning, reinstall the Cover by tightening the mounting screws properly.




### 


Do not add or replace other than R410A type. It may cause product damage, burst, injury and etc. Use compatible R410A tools for refrigerant piping work and refrigerant charging during installation or servicing.

# 14.3 Pump Down Procedures

Refer below steps for proper pump down procedure.




# 14.4 How To Adjust Pump Speed



Press ▲ or ▼ SW to select & confirm operation

# 14.5 How To Adjust Pump Speed




Press ▲ or ▼ SW to select & confirm operation

### NOTE:

- 1. Whenever at [Screen 5], if press 🕑 SW to OFF, pump operation should be turned OFF.
- 2. Whenever at [Screen 6], if press  $^{\textcircled{0}}$  SW to OFF, pump operation should be turned OFF.

# 14.6 How To Unlock Cool Mode

Operation must be OFF




Select

[+]Confirm

 $\blacksquare$ 


# 14.7 EEPROM Factory Default Data Setup Procedure




- EEPROM default data setup is only possible during initialization process.

- Press ( **A** , **V**, **(** , **)**) simultaneously for 5secs continuously, initialization process will stop & EEPROM default data setup process will start.


During EEPROM default data setup process, display should be as shown below.




- Once EEPROM default data setup process is complete, initialization process will re-start from beginning.



# 14.8 Dry Concrete Setup



Next Page



Return to [Screen 6]


# 15. Maintenance Guide

In order to ensure safety and optimal performance of the unit, seasonal inspections on the unit, functional check of RCCB/ELCB, field wiring and piping have to be carried out at regular intervals. This maintenance should be carried out by authorized dealer. Contact dealer for scheduled inspection.

1 Water pressure


Water pressure should not lower than 0.05 MPa (with inspects the Water Pressure Gauge). If necessary add tap water into Tank Unit. Refer to Tank unit installation instruction for details on how to add water.

- 2 Pressure relief valve
  - o Check for correct operation of Pressure Relief Valve by turning on the lever to become horizontal.
  - o If you do not hear a clacking sound (due to water drainage), contact your local authorized dealer.
  - Push down the lever after finish checking.
  - In case the water keeps drained out from the unit, switch off the system, and then contact your local authorized dealer.



3 Air purge valve

Air purge valve must be installed at all high points in a closed water circuit system. An automatic air purge valve is provided inside the indoor unit. To automatically purge the air from the system, turn the plug on the air outlet anticlockwise by one complete turn from fully closed position. Excessive air is automatically purged if the plug is kept in this position.



4 Indoor unit control board area

Thorough visual inspection of the control board and look for defects, i.e. loose connection, melting of wire insulator and etc.

5 RCCB/ELCB

Ensure the RCCB/ELCB set to "ON" condition before check RCCB/ELCB. Turn on the power supply to the Indoor Unit. This testing could only be done when power is supplied to the Indoor Unit.

🕂 WARNING


Be careful not to touch parts other than RCCB/ELCB test button when the power is supplied to Indoor Unit. Else, electrical shock may happen.

- Push the "TEST" button on the RCCB/ELCB. The lever would turn down and indicate "0", if it functions normal.
- o Contact authorized dealer if the RCCB/ELCB malfunction.
- Turn off the power supply to the Indoor Unit.
- o If RCCB/ELCB functions normal, set the lever to "ON" again after testing finish.

#### Reset overload protector 6

Overload Protector a serves the safety purpose to prevent the water over heating. When the Overload Protector a trip at high water temperature, take below steps to reset it.

- a. Take out the cover.
- b. Use a test pen to push the centre button gently in order to reset the Overload Protector.
- c. Fix the cover to the original fixing condition.



# 15.1 Maintenance Menu

#### 15.1.1 Service and maintenance

When connect CN-CNT connector with computer

Please use optional USB cable to connect with CN-CNT connector.

After connected, it requests for driver. If PC is under Windows Vista or later version, it automatically installs the driver under internet environment.

If PC uses Windows XP or earlier version and there is no internet access, please get FTDI Ltd's USB - RS232C conversion IC driver (VCP driver) and install. http://www.ftdichip.com/Drivers/VCP.htm

If forget Password and cannot operate remote controller

Press -+ + + for 5 sec.

Password unlock screen appears, press Confirm and it shall reset

Password will become 0000. Please reset it again.

(CAUTION) Only display when it is locked by password.

#### 15.1.2 Maintenance menu

| Setting met                    | nod of Mainte   | nance menu   |     |
|--------------------------------|---|--|-----|
| Maintenance                    | menu  | 17:26, W   | ed  |
| Actuator chec                  | k   |  |     |
| Test mode                      |   |  |     |
| Sensor setup                   |   |  |     |
| Reset passwo                   | ord   |  |     |
| <ul> <li>Select</li> </ul>     | )[لم]   | Confirm  |     |
| items that can                 | ←   | o sec.   |     |
| tems that can<br>① Actuator ch | be set<br>eck (Manual O<br>As there is no<br>careful not to<br>each part (do<br>water etc.) | N/OFF all func<br>protection act<br>cause any erro | · / |

④ Reset password (Reset password)

# 15.1.3 Custom menu

| Setting method of Custom menu   |
|---|
| Custom menu 17:26, Wed  |
| Cool mode   |
| Back-up heater  |
| Reset energy monitor  |
| Select [↓] Confirm  |
| Please press $\blacksquare$ + $\mathbf{\nabla}$ + $\mathbf{\triangleleft}$ for 10 sec.  |
| <ul> <li>Items that can be set</li> <li>Cool mode (Set With/Without Cooling function) Default is without</li> <li>(CAUTION) As with/without Cool mode may affect electricity application, please be careful and do not simply change it.<br/>In Cool mode, please be careful if piping is not insulated properly, dew may form on pipe and water may drip on the fl oor and damage the fl oor</li> </ul>  |
| <ul> <li>Backup heater (Use/Do not use Backup heater)         <ul> <li>(CAUTION) It is different from to use/not to use backup heater set by client. When this setting is used, heater power on due to protection against frost will be disabled. (Please use this setting when it is required by utility company.)<br/>By using this setting, it cannot defrost due to low Heating's setting temp and operation may stop (H75)</li> <li>Please set under the responsibility of installer.<br/>When it stops frequently, it may be due to insufficient circulation fl ow rate, setting temp of heating is too low etc.</li> </ul> </li> </ul> |
| ③ Reset energy monitor (delete memory of Energy monitor)<br>Please use when moving house and handover the unit.   |

# 15.1.4 Specifications

# 15.1.4.1 Specifications of fresh water was heat transfer medium in brazed heat exchanger

| Parameter    | Quality Limits for Tap Water on the Secondary Side              |
|--------------|---|
| Temperature  | Below 60°C  |
| рН           | 7 to 9  |
| Alkalinity   | 60mg/I <hco<sub>3 &lt;300mg/I</hco<sub>                         |
| Conductivity | < 500µS/cm  |
| Hardness     | [Ca <sup>+</sup> , Mg <sup>+</sup> ] / [HCO₃ <sup>-</sup> ] > 5 |
| Chloride     | < 200mg/l at 60°C   |
| Sulphate     | $[SO_4^2] > 100 mg/l and [HCO_3] / [SO_4^2] > 1$                |
| Nitrate      | NO <sub>3</sub> < 100mg/l                                       |
| Chlorine     | < 0.5mg/l   |

# 15.1.4.2 External filter

### Solids in the water must be filtered.

Minimum filter mesh size required for the field supply external filter in the water inlet is 20 mesh.

# 16. Troubleshooting Guide

# 16.1 Refrigeration Cycle System

In order to diagnose malfunctions, make sure that there are no electrical problems before inspecting the refrigeration cycle.


Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a fan.

The normal pressure of the refrigeration cycle depends on various conditions, the standard values for them are shown in the table on the right. Normal Pressure (Standard)

|              | Gas pressure<br>MPa (kg/cm²G) |
|--------------|-------------------------------|
| Heating Mode | 2.3 ~ 2.9 (23 ~ 29)           |
| Cooling Mode | 0.9 ~ 1.2 (9 ~ 12)            |

★ Condition: • Outdoor temperature 7°C at heating mode and 35°C at cooling mode.

• Compressor operates at rated frequency.



# 16.2 Relationship between the Condition of the Air-to-Water Heatpump Indoor and Outdoor Units and Pressure and Electric Current

|  |              | Heating Mode  |                                   |              | Cooling Mode  |                                   |
|--|--------------|---------------|-----------------------------------|--------------|---------------|-----------------------------------|
| Condition of the<br>Air-to-Water Heatpump<br>indoor and<br>outdoor units | Low Pressure | High Pressure | Electric current during operation | Low Pressure | High Pressure | Electric current during operation |
| Water leakage or<br>insufficient water flow<br>rate in the system        |              |               |                                   | 1            | *             | 1                                 |
| Excessive amount of refrigerant  |              |               |                                   | 1            | *             | 1                                 |
| Inefficient compression  |              | *             | 1                                 | 1            | *             | 1                                 |
| Insufficient refrigerant<br>(gas leakage)                                | *            | 1             | 1                                 | 1            | 1             | 1                                 |
| Outdoor heat exchange<br>deficiency                                      |              | 1             | *                                 | 1            |               |                                   |
| Clogged expansion valve<br>or Strainer                                   |              |               |                                   |              | *             | 1                                 |

• Carry out the measurements of pressure, electric current, and temperature fifteen minutes after an operation is started.

# 16.3 Breakdown Self Diagnosis Function

# 16.3.1 Self Diagnosis Function (Three Digits Alphanumeric Code)

- When abnormality occur during operation, the system will stop operation, and OFF/ON control panel LED will blink and error code will display on the control panel.
- Even error code is reset by turning OFF power supply or by selecting ERROR RESET, if the system abnormality
  is still unrepaired, system will again stop operation, and OFF/ON control panel LED will again blinks and error
  code will be display.
- The error code will store in IC memory.

### • To check the error code

- When an abnormality occurs, system will stop operation and OFF/ON control panel LED will blink.
- Error code of the abnormality will be display on the control panel.
- To determine the abnormality description, the error code table needs to be referred.

eg:


| Remote co | H75 H76 |          |   |              |
|-----------|---|----------|---|--------------|
|           |   | <br>│ :≡ |   | - Error numb |
|           | لہ  |          | - |              |
|           |   | ψ        |   | - Blinking   |


Press < 🍉 to select Close / Reset then press 🖵

- To display past/last error code
  - Turn ON power supply.
  - Refer below procedure to retrieve the error code history.

### • To permanently delete error code from IC memory

- Turn ON power supply.
- Refer below procedure to clear error history.





[+]Confirm

8 23am, Mon

Display last 4 error retrieved from EEPROM

\$Select

Error history

1. H76 (2015/05/18) 2. H15 (2015/05/18)

# 16.4 Error Codes Table

| Diagnosis display | Abnormality/Protection control                              | Abnormality judgement  | Primary location to verify  |
|-------------------|---|--|---|
| H00               | No abnormality detected                                     | _  |   |
| H12               | Indoor/Outdoor capacity unmatched                           | 90s after power supply   | <ul> <li>Indoor/outdoor connection wire</li> <li>Indoor/outdoor PCB</li> <li>Specification and combination table in catalogue</li> </ul>  |
| H15               | Outdoor compressor temperature sensor<br>abnormality        | Continue for 5 sec.  | <ul> <li>Compressor temperature sensor<br/>(defective or disconnected)</li> </ul>   |
| H20               | Water pump abnormality                                      | Continue for 10 sec.   | <ul><li>Indoor PCB</li><li>Water pump (malfunction)</li></ul>   |
| H23               | Indoor refrigerant liquid temperature<br>sensor abnormality | Continue for 5 sec.  | <ul> <li>Refrigerant liquid temperature sensor<br/>(defective or disconnected)</li> </ul>   |
| H27               | Service valve error   | Continue for 5 minutes   | <ul> <li>High pressure sensor (defective or<br/>disconnected)</li> </ul>  |
| H28               | Abnormal solar sensor                                       | Continue for 5 sec.  | <ul> <li>Solar temperature sensor (defective or<br/>disconnected)</li> </ul>  |
| H31               | Abnormal swimming pool sensor                               | Continue for 5 sec.  | <ul> <li>Pool temperature sensor (defective or<br/>disconnected)</li> </ul>   |
| H36               | Abnormal buffer tank sensor                                 | Continue for 5 sec.  | Buffer tank sensor (defective or disconnected)  |
| H38               | Brand code not match  | When indoor and outdoor<br>brand code not same                                     | _   |
| H42               | Compressor low pressure abnormality                         | _  | <ul> <li>Outdoor pipe temperature sensor</li> <li>Clogged expansion valve or strainer</li> <li>Insufficient refrigerant</li> <li>Outdoor PCB</li> <li>Compressor</li> </ul>         |
| H43               | Abnormal Zone 1 sensor                                      | Continue for 5 sec.  | Water temperature Zone 1 sensor   |
| H44               | Abnormal Zone 2 sensor                                      | Continue for 5 sec.  | Water temperature Zone 2 sensor   |
| H62               | Water flow switch abnormality                               | Continue for 1 min.  | Water flow switch   |
| H63               | Abnormal low pressure sensor                                | 4 times in 20 minutes  | <ul> <li>Low pressure sensor (defective or<br/>disconnect)</li> </ul>   |
| H64               | Refrigerant high pressure abnormality                       | Continue for 5 sec.  | <ul> <li>Outdoor high pressure sensor<br/>(defective or disconnected)</li> </ul>  |
| H65               | Abnormal deice water circulation                            | water flow > 7 l/min continously<br>for 20 second during anti<br>freeze deice      | Water pump  |
| H67               | Abnormal External Thermistor 1                              | Continue for 5 sec.  | <ul> <li>Room temperature Zone 1 sensor</li> </ul>  |
| H68               | Abnormal External Thermistor 2                              | Continue for 5 sec.  | <ul> <li>Room temperature Zone 2 sensor</li> </ul>  |
| H70               | Back-up heater OLP abnormality                              | Continue for 60 sec.   | <ul> <li>Back-up heater OLP<br/>(Disconnection or activated)</li> </ul>   |
| H72               | Tank sensor abnormal  | Continue for 5 sec.  | <ul> <li>Tank sensor</li> </ul>   |
| H74               | PCB communication error                                     | Communication or transfer<br>error   | <ul> <li>Indoor main PCB and Sub PCB</li> </ul>   |
| H75               | Low water temperature control                               | Room heater disable and deice<br>request to operate under low<br>water temperature | Heater operation must enable to<br>increase water temperature   |
| H76               | Indoor - control panel communication<br>abnormality         | —  | <ul> <li>Indoor - control panel<br/>(defective or disconnected)</li> </ul>  |
| H90               | Indoor/outdoor abnormal communication                       | > 1 min after starting operation   | <ul><li>Internal/external cable connections</li><li>Indoor/Outdoor PCB</li></ul>  |
| H91               | Tank heater OLP abnormality                                 | Continue for 60 sec.   | <ul> <li>Tank heater OLP<br/>(Disconnection or activated)</li> </ul>  |
| H95               | Indoor/Outdoor wrong connection                             | _  | Indoor/Outdoor supply voltage   |
| H98               | Outdoor high pressure overload protection                   | _  | <ul> <li>Outdoor high pressure sensor</li> <li>Water pump or water leakage</li> <li>Clogged expansion valve or strainer</li> <li>Excess refrigerant</li> <li>Outdoor PCB</li> </ul> |
| H99               | Indoor heat exchanger freeze prevention                     | —  | <ul><li>Indoor heat exchanger</li><li>Refrigerant shortage</li></ul>  |
| F12               | Pressure switch activate                                    | 4 times occurrence within 20 minutes   | Pressure switch   |
| F14               | Outdoor compressor abnormal revolution                      | 4 times occurrence within 20 minutes   | Outdoor compressor  |
| F15               | Outdoor fan motor lock abnormality                          | 2 times occurrence within 30 minutes   | Outdoor PCB     Outdoor fan motor   |
| F16               | Total running current protection                            | 3 times occurrence within 20 minutes   | <ul><li>Excess refrigerant</li><li>Outdoor PCB</li></ul>  |

| Diagnosis display | Abnormality/Protection control                           | Abnormality judgement                   | Primary location to verify  |
|-------------------|--|---|---|
| F20               | Outdoor compressor overheating protection                | 4 times occurrence within 30 minutes    | Compressor tank temperature sensor<br>Clogged expansion valve or strainer<br>Insufficient refrigerant<br>Outdoor PCB<br>Compressor  |
| F22               | IPM (power transistor) overheating<br>protection         | 3 times occurrence within 30 minutes    | Improper heat exchange     IPM (Power transistor)   |
| F23               | Outdoor Direct Current (DC) peak detection               | 7 times occurrence<br>continuously      | Outdoor PCB     Compressor  |
| F24               | Refrigeration cycle abnormality                          | 2 times occurrence within 20 minutes    | Insufficient refrigerant     Outdoor PCB     Compressor low compression   |
| F25               | Cooling/Heating cycle changeover<br>abnormality          | 4 times occurrence within 30 minutes    | <ul><li> 4-way valve</li><li> V-coil</li></ul>  |
| F27               | Pressure switch abnormality                              | Continue for 1 min.                     | Pressure switch   |
| F29               | Low Discharge Superheat                                  | 1 times occurrence within 2550 minutes  | Discharge Temperature sensor     Discharge Pressure Sensor     Pressure Switch     Outdoor PCB  |
| F30               | Water outlet sensor 2 abnormality                        | Continue for 5 sec.                     | Water outlet sensor 2 (defective or<br>disconnected)  |
| F32               | Abnormal Internal Thermostat                             | Continue for 5 sec.                     | Control panel PCB thermostat  |
| F36               | Outdoor air temperature sensor<br>abnormality            | Continue for 5 sec.                     | Outdoor air temperature sensor<br>(defective or disconnected)   |
| F37               | Indoor water inlet temperature sensor<br>abnormality     | Continue for 5 sec.                     | Water inlet temperature sensor<br>(defective or disconnected)   |
| F40               | Outdoor discharge pipe temperature<br>sensor abnormality | Continue for 5 sec.                     | <ul> <li>Outdoor discharge pipe temperature<br/>sensor (defective or disconnected)</li> </ul>   |
| F41               | PFC control  | 4 times occurrence within 10<br>minutes | Voltage at PFC  |
| F42               | Outdoor heat exchanger temperature<br>sensor abnormality | Continue for 5 sec.                     | <ul> <li>Outdoor heat exchanger temperature<br/>sensor (defective or disconnected)</li> </ul>   |
| F43               | Outdoor defrost sensor abnormality                       | Continue for 5 sec.                     | <ul> <li>Outdoor defrost sensor (defective or<br/>disconnected)</li> </ul>  |
| F45               | Indoor water outlet temperature sensor<br>abnormality    | Continue for 5 sec.                     | Water outlet temperature sensor<br>(defective or disconnected)  |
| F46               | Outdoor Current Transformer open<br>circuit              | _                                       | Insufficient refrigerant     Outdoor PCB     Compressor low   |
| F48               | Outdoor EVA outlet temperature sensor<br>abnormality     | Continue for 5 sec.                     | Outdoor EVA outlet temperature sen<br>(defective or disconnected)   |
| F49               | Outdoor bypass outlet temperature<br>sensor abnormality  | Continue for 5 sec.                     | Outdoor bypass outlet temperature<br>sensor (defective or disconnected)   |
| F95               | Cooling high pressure overload protection                | _                                       | <ul> <li>Outdoor high pressure sensor</li> <li>Water pump or water leakage</li> <li>Clogged expansion valve or strainer</li> <li>Excess refrigerant</li> <li>Outdoor PCB</li> </ul> |

# 16.5 Self-diagnosis Method

# 16.5.1 Connection Capability Rank Abnormality (H12)

### **Malfunction Decision Conditions:**

During startup operation of cooling and heating, the capability rank of indoor checked by the outdoor is used to determine connection capability rank abnormality.


### Malfunction Caused:

- 1 Wrong model interconnected.
- 2 Wrong indoor unit or outdoor unit PCB (main) used.
- 3 Faulty indoor unit or outdoor unit PCB (main).

### Abnormality Judgment:

Continue for 90 seconds.

# Troubleshooting:



# 16.5.2 Compressor Tank Temperature Sensor Abnormality (H15)

### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the compressor tank temperature sensor are used to determine sensor error.


### **Malfunction Caused:**

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

### Abnormality Judgment:

Continue for 5 seconds.

# **Troubleshooting:**



# 16.5.3 Water Pump Abnormality (H20)

### **Malfunction Decision Conditions:**


During startup and operation of cooling and heating, the rotation speed detected by the IPM of water pump motor during water pump operation is used to determine abnormal water pump (feedback of rotation > 6,000rpm or < 1,000rpm).

### Malfunction Caused:

- 1 Operation stop due to short circuit inside the water pump motor winding.
- 2 Operation stop due to breaking of wire inside the water pump motor.
- 3 Operation stop due to breaking of water pump lead wires.
- 4 Operation stop due to water pump motor IPM malfunction.
- 5 Operation error due to faulty indoor unit PCB.

### Abnormality Judgment:

Continue for 5 seconds.



# 16.5.4 Indoor Refrigerant Liquid Temperature Sensor Abnormality (H23)

### **Malfunction Decision Conditions:**


During startup and operation of cooling and heating, the temperatures detected by the indoor refrigerant liquid temperature sensor are used to determine sensor error.

### **Malfunction Caused:**

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

### Abnormality Judgment:

Continue for 5 seconds.



# 16.5.5 Service Valve Error (H27)

### **Malfunction Decision Conditions:**

During cooling operation, when:-


- [a] Indoor refrigerant pipe temperature at compressor startup present indoor refrigerant pipe temperature < 2°C
- [b] Present high pressure high pressure at compressor startup < 5kg/cm<sup>2</sup>
- \*\*Judgment only for first time cooling operation and not during pump down operation.

### Malfunction Caused:

- 1 3 way valves closed.
- 2 Faulty high pressure sensor.
- 3 Faulty indoor refrigerant pipe temperature sensor
- 4 Faulty outdoor unit PCB (main).

### Abnormality Judgment:

Continue for 5 minutes.




# 16.5.6 Abnormal Solar Sensor (H28)

### Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty solar sensor.
- 3 Faulty indoor sub PCB.

### Abnormality Judgment:

Continue for 5 seconds.



#### Abnormal Swimming Pool Sensor (H31) 16.5.7

## Malfunction Caused:

- 1 Faulty connector connection.
- Faulty swimming pool sensor. Faulty indoor sub PCB.
- 2 3

# Abnormality Judgment: Continue for 5 seconds.

| Abnormal swimming pool sensor  |     | Caution | For safety reason and to prevent<br>component breakdown, always switch<br>off the power before remove and<br>connect the component. |
|--|-----|---------|---|
|  | 7   |         |   |
| H31 happens check connector sensor at CN204 connection normal ?      |     | NO •    | Correct sensor connection   |
|  | YES |         |   |
| Measure sensor resistance match swimming pool sensor characteristic? |     | NO •    | Change swimming pool sensor   |
|  | YES |         |   |
| Change Indoor sub PCB  |     | ]       |   |


# 16.5.8 Abnormal Buffer Tank Sensor (H36)

### Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

### Abnormality Judgment:

Continue for 5 seconds.



# 16.5.9 Brand Code Not Matching (H38)

# Malfunction Caused:

1 Indoor and outdoor brand code not match.

| Brand code not match                                       |     |    | Caution    | For safety reason and to prevent<br>component breakdown, always switch<br>off the power before remove and |
|--|-----|----|------------|---|
|  |     |    |            | connect the component.  |
| Check the brand of indoor and outdoor unit both Panasonic? |     | NO | <b>→</b> • | Use only Panasonic units.<br>Change to Panasonic unit.  |
|  | YES |    |            | -   |
| Change PCB outdoor   |     | ]  |            |   |


### 16.5.10 Compressor Low Pressure Protection (H42)

#### **Malfunction Decision Conditions:**

During operation of heating and after 5 minutes compressor ON, when outdoor pipe temperature below -29°C or above 26°C is detected by the outdoor pipe temperature sensor.

#### **Malfunction Caused:**

- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 2 way valve partially closed.
- 4 Faulty outdoor unit fan motor.
- 5 Refrigerant shortage (refrigerant leakage).
- 6 Clogged expansion valve or strainer.
- 7 Faulty outdoor pipe temperature sensor.
- 8 Faulty outdoor unit main PCB (main).



### 16.5.11 Abnormal Zone 1 Sensor (H43)

### Malfunction Caused:

- 1 Faulty connector connection.
- Faulty buffer tank sensor.
   Faulty indoor sub PCB.

# Abnormality Judgment: Continue for 5 seconds.

| Abnormal zone 1 sensor  | 7   | Caution | For safety reason and to prevent<br>component breakdown, always switch<br>off the power before remove and<br>connect the component. |
|---|-----|---------|---|
| Check the turn off power check connector connection   |     |         |   |
|   |     |         |   |
| Normal?   |     | NO .    | Poor contact<br>Correct connection  |
|   | YES |         |   |
| Check plug out connector from zone 1 connector sub PCB in<br>the PCB measure resistance of zone 1 sensor characteristic<br>match? |     | NO •    | Defective zone sensor<br>Replace sensor   |
|   | YES | 1       |   |
| Defective PCB     Replace PCB   |     |         |   |


### 16.5.12 Abnormal Zone 2 Sensor (H44)

#### Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

### Abnormality Judgment:

Continue for 5 seconds.



### 16.5.13 Water Flow Switch Abnormality (H62)

### Malfunction Decision Conditions:


During operation of cooling and heating, the water flow detected by the indoor water flow switch is used to determine water flow error.

#### Malfunction Caused:

- 1 Faulty water pump.
- 2 Water leak in system.
- 3 Faulty connector connection.
- 4 Faulty water flow switch.
- 5 Faulty indoor unit PCB (main).

#### Abnormality Judgment:

Continue for 10 seconds (but no judgment for 9 minutes after compressor startup/restart).



### 16.5.14 Outdoor High Pressure Abnormality (H64)

#### **Malfunction Decision Conditions:**


During operation of cooling and heating, when the outdoor high pressure sensor output signal is 0 Vdc or 5 Vdc.

#### **Malfunction Caused:**

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

#### Abnormality Judgment:

Continue 4 times in 20 minutes.



### 16.5.15 Deice Circulation Error (H65)

#### **Malfunction Decision Conditions:**


During startup and operation of deice (mode 2), the water flow (> 10l/min) detected by the water flow switch is used to determine deice circulation error.

#### Malfunction Caused:

- 1 Water flow in air-to-water heatpump indoor unit circuitry.
- 2 Faulty indoor unit water flow switch.
- 3 Faulty indoor unit water pump.
- 4 Faulty indoor unit PCB.

#### Abnormality Judgment:

Continue for 10 seconds.




### 16.5.16 Abnoraml External Thermistor 1 (H67)

#### Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty room temperature zone 1 sensor.
- 3 Faulty indoor sub PCB.

#### Abnormality Judgment:

Continue for 5 seconds.




### 16.5.17 Abnoraml External Thermistor 2 (H68)

#### Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty room temperature zone 2 sensor.
- 3 Faulty indoor sub PCB.

#### Abnormality Judgment:

Continue for 5 seconds.



### 16.5.18 Indoor Backup Heater OLP Abnormality (H70)

#### **Malfunction Decision Conditions:**


During operation of indoor backup heater, when no power supplies to indoor backup heater or OLP open circuit.

#### **Malfunction Caused:**

- 1 Faulty power supply connector connection.
- 2 Faulty connector connection.
- 3 Faulty indoor backup heater overload protector (OLP).
- 4 Faulty indoor unit PCB (main).

#### Abnormality Judgment:

Continue for 60 seconds.



### 16.5.19 Tank Temperature Sensor Abnormality (H72)

#### **Malfunction Decision Conditions:**


When tank connection is set to ON, the temperatures detected by the tank temperature sensor are used to determine sensor error.

#### Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

#### Abnormality Judgment:

Continue for 5 seconds.



### 16.5.20 PCB Communication Error (H74)

#### **Malfunction Decision Conditions:**


When External PCB connection is select "YES" and no communication or transfer error between Main PCB and External PCB for 10 seconds and above.

#### Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty Indoor Main PCB.
- 3 Faulty External PCB.

#### Abnormality Judgment:

Continue for 10 seconds.



### 16.5.21 Low Water Temperature Control (H75)

### **Malfunction Decision Conditions:**


When Back-up heater disable and Deice request to operate under low water temperature.

#### Malfunction Caused:

1 Back-up heater "Disable" under custom menu.

### Abnormality Judgment:

HEX protection under Low water temperature HEX protection control.




### 16.5.22 Indoor-Control Panel Communication Abnormality (H76)

#### **Malfunction Decision Conditions:**

During standby and operation of cooling and heating, indoor-control panel error occur.

#### **Malfunction Caused:**

- 1 Faulty connector connection.
- 2 Faulty control panel.
- 3 Faulty indoor unit PCB (main).



### 16.5.23 Indoor/Outdoor Abnormal Communication (H90)

#### **Malfunction Decision Conditions:**


During operation of cooling and heating, the data received from outdoor unit in indoor unit signal transmission is checked whether it is normal.

#### Malfunction Caused:

- 1 Faulty outdoor unit PCB (main).
- 2 Faulty indoor unit PCB (main).
- 3 Indoor-outdoor signal transmission error due to wrong wiring.
- 4 Indoor-outdoor signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units.
- 5 Indoor-outdoor signal transmission error due to disturbed power supply waveform.

#### Abnormality Judgment:

Continue for 1 minute after operation.



### 16.5.24 Tank Booster Heater OLP Abnormality (H91)

### **Malfunction Decision Conditions:**


During operation of tank booster heater, and tank booster heater OLP open circuit.

### Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty tank booster heater overload protector (OLP).
- 3 Faulty indoor unit PCB (main).

### Abnormality Judgment:

Continue for 60 seconds.



### 16.5.25 Unspecified Voltage between Indoor and Outdoor (H95)

#### Malfunction Decision Conditions:

The supply power is detected for its requirement by the indoor/outdoor transmission.


#### **Malfunction Caused:**

- 1 Insufficient power supply.
- 2 Faulty outdoor unit PCB (noise filter/main).

## Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



### 16.5.26 Outdoor High Pressure Protection (H98)

#### **Malfunction Decision Conditions:**


During operation of heating, when pressure 4.0 MPa and above is detected by outdoor high pressure sensor.

For safety reason and to prevent component breakdown,

#### Malfunction Caused:

- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 2/3 way closed.
- 5 Clogged expansion valve or strainer.
- 6 Excessive refrigerant.
- 7 Faulty outdoor high pressure sensor.
- 8 Faulty outdoor unit PCB (main).

**Troubleshooting:** 




### 16.5.27 Indoor Freeze-up Protection (H99)

### Malfunction Decision Conditions:

During anti-freezing control in cooling operation, when the indoor refrigerant liquid temperature < 0°C.

### Malfunction Caused:

- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 2 way valve partially closed.
- 5 Clogged expansion valve or strainer.
- 6 Refrigerant shortage (refrigerant leakage).
- 7 Faulty indoor refrigerant liquid temperature sensor.
- 8 Faulty indoor unit PCB (main).



### 16.5.28 Outdoor High Pressure Switch Activate (F12)

#### **Malfunction Decision Conditions:**


During operation of cooling and heating, when pressure 4.5 MPa and above is detected by outdoor high pressure switch.

#### **Malfunction Caused:**


- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 Faulty water pump.
- 4 Insufficient water flow rate in system.
- 5 Water leak in system.
- 6 2/3 way valve closed.
- 7 Clogged expansion valve or strainer.
- 8 Excessive refrigerant.
- 9 Faulty outdoor high pressure sensor and switch.
- 10 Faulty outdoor unit PCB.

#### Abnormality Judgment:

Continue 4 times in 20 minutes.



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



### 16.5.29 Compressor Rotation Failure (F14)

#### **Malfunction Decision Conditions:**

A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

#### Malfunction Caused:


- 1 Compressor terminal disconnect.
- 2 Faulty outdoor unit PCB (main).
- 3 Faulty compressor.

#### Abnormality Judgment:

Continue 4 times in 20 minutes.

**Troubleshooting:** 

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



### 16.5.30 Outdoor Fan Motor (DC Motor) Mechanism Locked (F15)

#### **Malfunction Decision Conditions:**


The rotation speed detected by the Hall IC of the fan motor during fan motor operation is used to determine abnormal fan motor (feedback of rotation > 2550 rpm or < 50 rpm).

#### **Malfunction Caused:**

- 1 Operation stop due to short circuit inside the fan motor winding.
- 2 Operation stop due to breaking of wire inside the fan motor.
- 3 Operation stop due to breaking of fan motor lead wires.
- 4 Operation stop due to fan motor Hall IC malfunction.
- 5 Operation error due to faulty outdoor unit PCB.

#### **Abnormality Judgment:**

Continue 2 times in 30 minutes.



### 16.5.31 Input Over Current Detection (F16)

#### **Malfunction Decision Conditions:**


During operation of cooling and heating, when outdoor current above 24.1 A (Heating) and 16.4 A (Cooling) [UD07FE5)] and 28.1 A (Heating) and 18.1 A (Cooling) [UD09FE5)] is detected by the current transformer (CT) in the outdoor unit PCB.

#### Malfunction Caused:

- 1 Excessive refrigerant.
- 2 Faulty outdoor unit PCB (main).

#### Abnormality Judgment:

Continue 3 times in 20 minutes.



### 16.5.32 Compressor Overheating (F20)

#### **Malfunction Decision Conditions:**


During operation of cooling and heating, when temperature above 112°C is detected by the compressor tank temperature sensor.

#### **Malfunction Caused:**

- 1 Faulty compressor tank temperature sensor.
- 2 2/3 way valve closed.
- 3 Refrigerant shortage (refrigerant leakage).
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).
- 6 Faulty compressor.

#### Abnormality Judgment:

Continue 4 times in 30 minutes.



### 16.5.33 IPM Overheating (F22)

#### Malfunction Decision Conditions:


During operation of cooling and heating, when temperature 95°C is detected by the outdoor IPM temperature sensor.

#### Malfunction Caused:

- 1 Faulty outdoor unit fan motor.
- 2 Faulty outdoor unit PCB (main).

#### Abnormality Judgment:

Continue 3 times in 30 minutes.



### 16.5.34 Output Over Current Detection (F23)

#### **Malfunction Decision Conditions:**


During operation of cooling and heating, when outdoor DC current is above 34 A is detected by the IPM DC Peak sensing circuitry in the outdoor unit PCB (main).

#### **Malfunction Caused:**

- 1 Faulty outdoor unit PCB (main).
- 2 Faulty compressor.

#### Abnormality Judgment:

Continue for 7 times.



### 16.5.35 Refrigeration Cycle Abnormality (F24) (WH-UD03HE5-1 and WH-UD05HE-1)

#### Malfunction Decision Conditions:


- 1 During operation of cooling and heating, compressor frequency > Frated.
- 2 During operation of cooling and heating, running current: 0.65 A < I < 1.65 A.
- 3 During operation of cooling, water inlet temperature indoor refrigerant liquid temperature < 5°C.
- 4 During operation of heating, indoor refrigerant liquid temperature water inlet temperature < 5°C.

#### Malfunction Caused:

- 1 Faulty water inlet or indoor refrigerant liquid temperature sensors.
- 2 2/3 way valve closed.
- 3 Refrigerant shortage (refrigerant leakage).
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).
- 6 Poor compression of compressor.

#### Abnormality Judgment:

Continue 2 times in 20 minutes.



### 16.5.36 Refrigeration Cycle Abnormality (F24) (WH-UD07HE5-1 and WH-UD09HE-1)

#### **Malfunction Decision Conditions:**


- 1 During operation running (heating / cooling) for more than 10 minutes expect deice, pumpdown and test mode.
- 2 During heating / cooling, water outlet and water inlet difference is less than 1°C.
- 3 During heating / cooling, high pressure < 1MPa (143 Psi) for more than 10 minutes or < 0.2 MPa (28 Psi) for more than 5 minutes.
- 4 During heating / cooling, discharge temperature saturation temperature of high pressure  $\geq$  60°C.

#### **Malfunction Caused:**

- 1 Refrigerant shortage (refrigerant leakage).
- 2 Faulty indoor water inlet, indoor water outlet, compressor discharge temp sensor or high pressure sensor.
- 3 2/3 way valve closed.
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).

#### Abnormality Judgment:

Continue 2 times in 20 minutes.



### 16.5.37 Four Way Valve Abnormality (F25)

#### Malfunction Decision Conditions:


- 1 During heating operation, when the indoor pipe temperature of thermostat ON indoor unit < 0°C.
- 2 During cooling operation, when the indoor pipe temperature of thermostat ON indoor unit > 45°C.

#### **Malfunction Caused:**

- Faulty sensor.
- 2 Faulty connector connection.
- 3 Faulty outdoor unit PCB (noise filter/main).
- 4 Faulty four way valve.

#### Abnormality Judgment:

Continue 4 times in 30 minutes.



### 16.5.38 Outdoor High Pressure Switch Abnormal (F27)

#### **Malfunction Decision Conditions:**


During compressor stop, and outdoor high pressure switch is remain opened.

#### **Malfunction Caused:**

- 1 Faulty connector connection.
- 2 Faulty switch.
- 3 Faulty outdoor unit PCB (main).

#### Abnormality Judgment:

Continue for 1 minute.



### 16.5.39 Low Discharge Superheat (F29)

#### **Malfunction Decision Conditions:**


During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor error.

#### **Malfunction Caused:**

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).
- 4 Faulty High Pressure Switch
- 5 Refrigerant shortage (refrigerant leakage).

#### Abnormality Judgment:

1 times occurrence within 2550 minutes.



### 16.5.40 Indoor Water Outlet Temperature Sensor 2 Abnormality (F30)

#### **Malfunction Decision Conditions:**


During startup and operation of cooling and heating, the temperatures detected by the indoor water outlet temperature sensor 2 are used to determine sensor error.

#### **Malfunction Caused:**

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB.

#### Abnormality Judgment:

Continue for 5 seconds.



### 16.5.41 Abnormal Internal Thermostat (F32)

### **Malfunction Decision Conditions:**

When Zone 1 or Zone 2 room sensor select use internal thermostat AND

- Internal thermostat open circuit: less than °C continuously for 5 seconds OR
- Internal thermostat short circuit: 127°C or more continuously for 5 seconds .

### Malfunction Caused:

- 1 Faulty wiring connection
- 2 Faulty Indoor PCB
- 3 Faulty remote controller

### Abnormality Judgment:

Continue for 5 seconds.

| Is the abnormality happens during Zone sensor select Internal Thermostat?                      | For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component. |
|--|--|
| Check the Output voltage from indoor PCB. Does Indoor PCB generate 16VDC to Remote Controller? | NO • Replace Indoor PCB  |
| YES  | _  |
| Check internal thermostat wiring from indoor unit to room thermostat. Any abnormality?         | YES Correct or repair wiring   |
| NO   | _  |
| Check the Remote controller / Internal thermostat input voltage.<br>Does it received 16VDC?    | NO<br>• Correct or repair wiring<br>• Replace indoor PCB   |
| YES  | _  |
| Check the Remote controller internal thermistor. Does the thermistor short /open circuit?      |  |
| YES  | -  |
| Replace Remote Controller  | ]  |

### 16.5.42 Outdoor Air Temperature Sensor Abnormality (F36)

#### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the outdoor air temperature sensor are used to determine sensor error.

#### **Malfunction Caused:**

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).


#### Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



### 16.5.43 Indoor Water Inlet Temperature Sensor Abnormality (F37)

Caution

#### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the indoor water inlet temperature sensor are used to determine sensor error.

#### Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

#### Abnormality Judgment:

Continue for 5 seconds.

**Troubleshooting:** 

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



### **16.5.44** Outdoor Discharge Pipe Temperature Sensor Abnormality (F40)

#### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the outdoor discharge pipe temperature sensor are used to determine sensor error.

#### **Malfunction Caused:**

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

#### Abnormality Judgment:

Continue for 5 seconds.

 For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.

 Check the CN-DIS connector connection:

 - Turn OFF the power


 - Check the connector connection

 Is the CN-DIS connector

 Ves

 Check the outdoor discharge pipe temperature sensor:

 - Plug out connector from the outdoor unit PCB (main)



### 16.5.45 Power Factor Correction (PFC) Abnormality (F41)

#### **Malfunction Decision Conditions:**


During operation of cooling and heating, when the PFC protection circuitry in the outdoor unit PCB (main) senses abnormal high DC voltage level.

#### Malfunction Caused:

- 1 Power supply surge.
- 2 Compressor windings not uniform.
- 3 Faulty outdoor unit PCB (main).

#### Abnormality Judgment:

Continue 4 times in 10 minutes.



## 16.5.46 Outdoor Pipe Temperature Sensor Abnormality (F42)

### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor error.

### **Malfunction Caused:**

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).


#### Abnormality Judgment:

Continue for 5 seconds.

**Troubleshooting:** 

Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



## 16.5.47 Outdoor Defrost Temperature Sensor Abnormality (F43)

### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the outdoor defrost temperature sensor are used to determine sensor error.

#### Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).


### Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



### 16.5.48 Indoor Water Outlet Temperature Sensor Abnormality (F45)

### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the indoor water outlet temperature sensor are used to determine sensor errors.

#### **Malfunction Caused:**

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).


#### Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:

Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



## 16.5.49 Outdoor Current Transformer Open Circuit (F46)

### **Malfunction Decision Conditions:**


A current transformer (CT) open circuit is detected by checking the compressor running frequency ( ≥ rated frequency) and CT detected input current (< 0.65 A) for continuously 20 seconds.

### **Malfunction Caused:**

- 1 CT defective.
- 2 Faulty outdoor unit PCB (main).
- 3 Compressor defective (low compression).

### Abnormality Judgment:

Continue 3 times in 20 minutes.



### 16.5.50 Outdoor Eva Outlet Temperature Sensor Abnormality (F48)

#### **Malfunction Decision Conditions:**


During startup and operation of cooling and heating, the temperature detected by outdoor Eva outlet temperature sensor are used to determine sensor error.

#### Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty Indoor PCB.

### Abnormality Judgment:

Continue for 5 seconds.



### 16.5.51 Outdoor Bypass Outlet Temperature Sensor Abnormality (F49)

### Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperature detected by outdoor Bypass Outlet temperature sensor are used to determine sensor error.


#### **Malfunction Caused:**

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty Indoor PCB.

### Abnormality Judgment:

Temperature (°C)

Continue for 5 seconds.




## 16.5.52 Cooling High Pressure Overload Protection (F95)

### **Malfunction Decision Conditions:**

During operation of cooling, when pressure 4.0 MPa and above is detected by outdoor high pressure sensor.

### Malfunction Caused:

- 1 Dust accumulation in the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 2 way valve closed.
- 4 Faulty outdoor unit fan motor.
- 5 Clogged expansion valve or strainer.
- 6 Excessive refrigerant.
- 7 Faulty outdoor high pressure sensor.
- 8 Faulty outdoor unit PCB (main).




# 17. Disassembly and Assembly Instructions

### 🕂 WARNING

High Voltage are generated in the electrical parts area by the capacitor. Ensure that the capacitor has discharged sufficiently before proceeding with repair work. Failure to heed this caution may result in electric shocks.

Be sure to switch off all the power supply before performing each of the below action.


## 17.1 To Remove The Cabinet Front Plate




- 1. Remove 4 mounting screws.
- Slide the cabinet front plate downward to release the pawls. Then, pull it toward front to remove it.

## 17.2 To Remove The Cabinet Top Plate


- 1. Remove the 13 mounting screws
- 2. Lift the cabinet top plate
  - upward to remove it.




## 17.3 To Remove The Cabinet Rear Plate




## 17.4 To Remove Pressure Gauge




## 17.5 To Remove Water System Electronic Controller Board




## 17.6 To Remove Air Purge Valve





17.7 To Remove Flow Sensor






 $\bigwedge$  When reinstall the water pipe, use grease or water at the joining.








# 18. Technical Data

## 18.1 Operation Characteristics

### 18.1.1 WH-MDC12H6E5

### Heating Characteristics at Different Outdoor Air Temperature

Condition Outdoor air temperature : 7°C (DBT), 6°C (WBT) Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C



Outdoor Temperature (°C)


#### **Cooling Characteristics at Different Outdoor Air Temperature** Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C 12.500 11.500 Capacity (kW) 10.500 9.500 8.500 7.500 19 22 25 28 31 34 43 16 37 40 Outdoor Temperature (°C) 5.000 4.000 Input Power (kW) 3.000 2.000 1.000 0.000 16 19 22 25 28 31 34 37 43 40 Outdoor Temperature (°C)

### 18.1.2 WH-MDC16H6E5

### Heating Characteristics at Different Outdoor Air Temperature


Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT) Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C



### Cooling Characteristics at Different Outdoor Air Temperature

Condition Outdoor air temperature : 35°C (DBT), -°C (WBT) Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C



## 18.2 Heating Capacity Table

## 18.2.1 WH-MDC12H6E5

| Water Out<br>(°C)   | 3               | 0                     | 35 40           |                       | 0               | 45                    |                 | 50                    |                 | 55*                   |                 |                       |
|---------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|
| Outdoor Air<br>(°C) | Capacity<br>(W) | Input<br>Power<br>(W) |
| -15                 | 9300            | 3460                  | 8900            | 3620                  | 8500            | 3790                  | 8100            | 3950                  | 7500            | 4050                  | 7000            | 4100                  |
| -7                  | 10400           | 3370                  | 10000           | 3660                  | 9600            | 3950                  | 9200            | 4240                  | 8700            | 4290                  | 8200            | 4210                  |
| 2                   | 11800           | 3100                  | 11400           | 3310                  | 11000           | 3530                  | 10600           | 3740                  | 9800            | 3940                  | 9100            | 4080                  |
| 7                   | 12000           | 2100                  | 12000           | 2530                  | 12000           | 2960                  | 12000           | 3390                  | 12000           | 3780                  | 12000           | 4100                  |
| 25                  | 12000           | 1380                  | 12000           | 1660                  | 11800           | 1940                  | 11700           | 2230                  | 11500           | 2490                  | 11400           | 2740                  |

\* is rating based on  $\Delta T = 8$ 

### 18.2.2 WH-MDC16H6E5

| Water Out<br>(°C)   | 3               | 0                     | 3               | 5                     | 4               | 0                     | 4               | 5                     | 5               | 0                     | 55              | 5*                    |
|---------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|
| Outdoor Air<br>(°C) | Capacity<br>(W) | Input<br>Power<br>(W) |
| -15                 | 10600           | 4090                  | 10300           | 4380                  | 10000           | 4670                  | 9700            | 4960                  | 8800            | 4900                  | 7900            | 4840                  |
| -7                  | 11900           | 4030                  | 11400           | 4430                  | 10800           | 4830                  | 10300           | 5220                  | 9600            | 5050                  | 9000            | 4880                  |
| 2                   | 13500           | 3740                  | 13000           | 3960                  | 12400           | 4180                  | 11900           | 4400                  | 10800           | 4420                  | 9800            | 4440                  |
| 7                   | 16000           | 3210                  | 16000           | 3740                  | 16000           | 4270                  | 16000           | 4800                  | 15200           | 5065                  | 14500           | 5330                  |
| 25                  | 16000           | 2310                  | 16000           | 2690                  | 16000           | 3070                  | 16000           | 3450                  | 16000           | 3670                  | 15900           | 3890                  |

\* is rating based on  $\Delta T = 8$ 

## 18.3 Cooling Capacity Table

## 18.3.1 WH-MDC12H6E5


| Water 0 | Out (°C) |              | 7               | 14           |                 | 1            | 8               |
|---------|----------|--------------|-----------------|--------------|-----------------|--------------|-----------------|
|         | °C       | Capacity (W) | Input Power (W) | Capacity (W) | Input Power (W) | Capacity (W) | Input Power (W) |
| Ibient  | 16       | 7860         | 1180            | 13150        | 2050            | 10000        | 1730            |
| Amb     | 25       | 12080        | 2900            | 15700        | 3050            | 10000        | 1970            |
| OD      | 35       | 10000        | 3560            | 12000        | 3670            | 10000        | 2150            |
|         | 43       | 7800         | 3800            | 11100        | 3190            | 8000         | 2850            |

## 18.3.2 WH-MDC16H6E5

| Water 0 | Dut (°C) |              | 7               | 14           |                 | 1            | 8               |
|---------|----------|--------------|-----------------|--------------|-----------------|--------------|-----------------|
|         | °C       | Capacity (W) | Input Power (W) | Capacity (W) | Input Power (W) | Capacity (W) | Input Power (W) |
| nbient  | 16       | 9200         | 1620            | 16400        | 2580            | 12200        | 2450            |
| Amb     | 25       | 14400        | 3920            | 19200        | 3830            | 12200        | 2790            |
| OD      | 35       | 12200        | 4760            | 15000        | 4980            | 12200        | 2960            |
|         | 43       | 7750         | 3400            | 13800        | 5950            | 9700         | 4000            |


# **19. Exploded View and Replacement Parts List**

## 19.1 Water System




### Note:


The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.



The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.



The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.



The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.

### <Model: WH-MDC12H6E5>

| SAFETY                  | REF. NO. | DESCRIPTION & NAME                    | QTY. | WH-MDC12H6E5            | REMARK |
|-------------------------|----------|---------------------------------------|------|-------------------------|--------|
|                         | 1        | BASE PAN ASS'Y                        | 1    | CWD52K1276              |        |
|                         | 2        | BASE PAN ASS'Y                        | 1    | ACXD52K02760            |        |
| $\wedge$                | 3        | COMPRESSOR                            | 1    | 5JD420XCA22             | 0      |
|                         | 4        | LEADWIRE COMPRESSOR                   | 1    | ACXA60C62280            |        |
|                         | 5        | CRANKCASE HEATER                      | 1    | CWA341053               |        |
|                         | 6        | BUSHING - COMPRESSOR MOUNT            | 3    | CWH50055                |        |
|                         | 7        | NUT-COMPRESSOR MOUNT                  | 3    | CWH561049               |        |
|                         | 8        | GASKET FOR TERMINAL COVER             | 3    | CWB811017               |        |
|                         | 9        | CONDENSER COMPLETE                    | 1    | CWB32C3891              |        |
|                         | 10       | TUBE ASSY (CAP.TUBE)                  | 1    | CWT07K1606              |        |
|                         | 12       | 3-WAYS VALVE (GAS)                    | 1    | CWB011699               | 0      |
|                         | 13       | 4-WAYS VALVE                          | 1    | CWB001046               | 0      |
|                         | 14       | EXPANSION VALVE                       | 1    | CWB051049               | 0      |
|                         | 15       | STRAINER                              | 2    | CWB111032               |        |
|                         | 16       | HIGH PRESSURE SENSOR                  | 1    | CWA501463               | 0      |
|                         | 17       | DISCHARGE MUFFLER                     | 1    | CWB121014               |        |
|                         | 18       | 3-WAYS VALVE(LIQUID)                  | 1    | CWB011700               | 0      |
|                         | 19       | 2-WAYS VALVE(LIQUID)                  | 1    | CWB021637               | 0      |
|                         | 20       | SOUND PROOF MATERIAL                  | 1    | CWG302795               |        |
|                         | 21       | SOUND PROOF MATERIAL                  | 1    | CWG302266               |        |
|                         | 22       | SOUND PROOF MATERIAL HEATER           | 1    | ACXG30-07660            |        |
|                         | 23       | SOUND PROOF BOARD                     | 1    | CWH151085               |        |
|                         | 24       | V-COIL COMPLETE(4 WAY VALVE)          | 1    | CWA43C2169J             | 0      |
|                         | 25       | V-COIL COMPLETE(MAIN EXPANSION VALVE) | 1    | CWA43C2602              | 0      |
|                         | 27       | V-COIL COMPLETE(2-WAY VALVE)          | 1    | CWA43C2607              | 0      |
|                         | 28       | SENSOR-COMP.(OUTDOOR AIR,PIPE TEMP)   | 1    | CWA50C2730              | 0      |
|                         | 29       | SENSOR-COMP.(DEFROST TEMP)            | 1    | CWA50C2577              | 0      |
|                         | 30       | SENSOR-COMP.(DISCHARGE TEMP)          | 1    | CWA50C2576              | 0      |
|                         | 31       | SENSOR-COMP.(EVA EXIT)                | 1    | CWA50C3204              | 0      |
|                         | 32       | HOLDER COUPLING                       | 1    | ACXH35-01510A           |        |
|                         | 33       | CABINET REAR PLATE-COMPLETE           | 1    | ACXE02-02020A           |        |
|                         | 34       | CONTROL BOARD CASING                  | 1    | CWH10K1049              |        |
|                         | 35       | SOUND PROOF MATERIAL                  | 1    | CWG302598               |        |
| $\wedge$                | 36       | TERMINAL BOARD ASS'Y(U,V,W,A)         | 1    | CWA28K1335              | 0      |
| $\overline{\mathbb{A}}$ | 37       | TERMINAL BOARD ASS'Y(1,2,3)           | 1    | CWA28K1213              | 0      |
| $\overline{\mathbb{A}}$ | 38       | ELECTRONIC CO.(CAPACITOR)             | 1    | CWA746169               | 0      |
| $\overline{\mathbb{A}}$ | 39       | ELECTRONIC CO.(NOISE FILTER)          | 1    | CWA747856               | 0      |
| $\underline{\Lambda}$   | 40       | REF SYS ELECTRONIC CONTROLLER (MAIN)  | 1    | ACXA73C31820R           |        |
| $\underline{\Lambda}$   | 41       | REF SYS REACTOR                       | 1    | G0C592J00005            | 0      |
| $\underline{\Lambda}$   | 42       | ELECTRO MAGNETIC SWITCH               | 1    | K6C1AYY00003            | 0      |
|                         | 43       | FAN MOTOR BRACKET                     |      | CWD54K1084              | Ť      |
|                         | 44       | SCREW-FAN MOTOR BRACKET               | 2    | CWH551040J              |        |
|                         | 45       | FAN MOTOR(UPPER)                      | 1    | EHDS83LAC               | 0      |
| <u>/!\</u>              | 43       | FAN MOTOR(LOWER)                      | 1    | EHDS83MAC               | 0      |
| <u> </u>                | 40       | SCREW-FAN MOTOR MOUNT                 | 8    | CWH551323               | 0      |
|                         | 47       | PROPELLER FAN ASSY                    | 2    | CWH051323<br>CWH00K1006 |        |
|                         | 40       | NUT                                   | 2    | CWH561092               |        |
|                         | 49       |                                       | 2    | 00000092                |        |

| SAFETY                  | REF. NO. | DESCRIPTION & NAME                      | QTY. | WH-MDC12H6E5  | REMARK |
|-------------------------|----------|---|------|---------------|--------|
|                         | 50       | CABINET FRONT PLATE                     | 1    | CWE061098A    |        |
|                         | 51       | DISCHARGE GRILLE                        | 2    | CWE201073     | 0      |
|                         | 52       | CABINET SIDE PLATE ASSY                 | 1    | CWE04K1023A   |        |
|                         | 53       | WIRE NET                                | 1    | CWD041069     |        |
|                         | 54       | HIGH PRESSURE SWITCH                    | 1    | CWA101013     | 0      |
|                         | 55       | ACCESSORY CO.(RUBBER CAP)               | 1    | CWH82C1839    |        |
|                         | 56       | ACCESSORY CO.(DRAIN ELBOW)              | 1    | CWG87C900     |        |
| $\wedge$                | 57       | HEATER (RECEIVER)                       | 1    | CWA341071     | 0      |
|                         | 58       | SOUND PROOF MATERIAL                    | 1    | CWG302594     |        |
|                         | 59       | HOT WATER COIL-COMPLETE                 | 1    | ACXB90C00620  | 0      |
|                         | 60       | FILTER COMPLETE                         | 1    | CWB51C1021    |        |
| $\wedge$                | 62       | HEATER ASS'Y                            | 1    | ACXA34K00370  | 0      |
| $\overline{\mathbb{A}}$ | 63       | THERMOSTAT                              | 2    | CWA151074     | 0      |
|                         | 64       | AIR PURGE VALVE                         | 1    | ACXB62-00130  | 0      |
|                         | 65       | FLOW SWITCH                             | 1    | CWB621137     |        |
| Ŵ                       | 66       | PUMP                                    | 1    | CWB532116     |        |
|                         | 67       | PRESSURE GAUGE                          | 1    | CWB070003     |        |
|                         | 68       | PRESSURE RELIEF VALVE                   | 1    | ACXB62-00100  |        |
|                         | 69       | CABINET SIDE PLATE ASS'Y                | 1    | ACXE04-09480A |        |
| $\wedge$                | 70       | WATER SYS ELECTRONIC CONTROLLER (MAIN)  | 1    | ACXA73C31840R | 0      |
|                         | 72       | TERMINAL BOARD ASS'Y                    | 1    | CWA28K1238    | 0      |
| $\wedge$                | 73       | WATER SYS REACTOR                       | 1    | G0C103Z00003  | 0      |
| $\overline{\mathbb{A}}$ | 74       | CIRCUIT BREAKER                         | 2    | CWA181005     |        |
| $\overline{\Lambda}$    | 75       | TERMINAL BOARD ASS'Y(A,B)               | 1    | CWA28K1340    | 0      |
| $\overline{\Lambda}$    | 76       | TERMINAL BOARD ASS'Y(1.2,3,4,5,6)       | 1    | CWA28K1341    | 0      |
| $\overline{\Lambda}$    | 77       | TERMINAL BOARD ASS'Y(7,8,9,10,11,12)    | 1    | CWA28K1340    | 0      |
| $\overline{\Lambda}$    | 78       | TERMINAL BOARD ASS'Y(13,14,15,16,17,18) | 1    | CWA28K1343    | 0      |
| <u> </u>                | 79       | SENSOR-COMPLETE(WATER IN,OUT, REF TEMP) | 1    | ACXA50C13330  | 0      |
|                         | 80       | SENSOR-COMPLETE(HEX WATER OUTLET)       | 1    | ACXA50C13140  | 0      |
|                         | 81       | REMOTE CONTROL COMPLETE                 | 1    | CWA75C4681    | 0      |
|                         | 82       | RECEIVER                                | 1    | CWB141069     |        |
|                         | 83       | HANDLE                                  | 4    | CWE161014     |        |
|                         | 84       | SOUND PROOF MATERIAL                    | 1    | CWG302599     |        |
|                         | 85       | CABINET FRONT PLATE                     | 1    | CWE061274A    |        |
|                         | 86       | CABINET FRONT PLATE                     | 1    | ACXE06-03550A |        |
|                         | 88       | CABINET TOP PLATE                       | 1    | CWE03C1105    |        |
|                         | 89       | OPERATING INSTRUCTION                   | 1    | ACXF55-14590  |        |
|                         | 90       | OPERATING INSTRUCTION                   | 1    | ACXF55-14600  |        |
|                         | 91       | OPERATING INSTRUCTION                   | 1    | ACXF55-14610  |        |
|                         | 92       | OPERATING INSTRUCTION                   | 1    | ACXF55-14620  |        |
|                         | 93       | OPERATING INSTRUCTION                   | 1    | ACXF55-14630  |        |
|                         | 94       | OPERATING INSTRUCTION                   | 1    | ACXF55-14640  |        |
|                         | 95       | INSTALLATION INSTRUCTION                | 1    | ACXF60-23690  |        |
|                         | 96       | INSTALLATION INSTRUCTION                | 1    | ACXF60-17020  |        |
|                         | 97       | FLEXIBLE PIPE (L-TUBE)                  | 1    | CWH5850080    |        |
|                         | 98       | PACKING-L.TUBE                          | 1    | CWB81012      |        |

| SAFETY | REF. NO. | DESCRIPTION & NAME | QTY. | WH-MDC12H6E5 | REMARK |
|--------|----------|--------------------|------|--------------|--------|
|        | 99       | PANASONIC BADGE    | 1    | CWE373439    |        |
|        | 100      | INVERTER BADGE     | 1    | CWE373441    |        |

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488). "O" marked parts are recommended to be kept in stock. •
- •

### <Model: WH-MDC16H6E5>

| SAFETY                  | REF. NO. | DESCRIPTION & NAME                    | QTY. | WH-MDC16H6E5  | REMARK |
|-------------------------|----------|---------------------------------------|------|---------------|--------|
|                         | 1        | BASE PAN ASS'Y                        | 1    | CWD52K1276    |        |
|                         | 2        | BASE PAN ASS'Y                        | 1    | ACXD52K02760  |        |
| $\wedge$                | 3        | COMPRESSOR                            | 1    | 5JD420XCA22   | 0      |
|                         | 4        | LEADWIRE COMPRESSOR                   | 1    | ACXA60C62280  |        |
|                         | 5        | CRANKCASE HEATER                      | 1    | CWA341053     |        |
|                         | 6        | BUSHING - COMPRESSOR MOUNT            | 3    | CWH50055      |        |
|                         | 7        | NUT-COMPRESSOR MOUNT                  | 3    | CWH561049     |        |
|                         | 8        | GASKET FOR TERMINAL COVER             | 3    | CWB811017     |        |
|                         | 9        | CONDENSER COMPLETE                    | 1    | CWB32C3891    |        |
|                         | 10       | TUBE ASSY (CAP.TUBE)                  | 1    | CWT07K1606    |        |
|                         | 12       | 3-WAYS VALVE (GAS)                    | 1    | CWB011699     | 0      |
|                         | 13       | 4-WAYS VALVE                          | 1    | CWB001046     | 0      |
|                         | 14       | EXPANSION VALVE                       | 1    | CWB051049     | 0      |
|                         | 15       | STRAINER                              | 2    | CWB111032     |        |
|                         | 16       | HIGH PRESSURE SENSOR                  | 1    | CWA501463     | 0      |
|                         | 17       | DISCHARGE MUFFLER                     | 1    | CWB121014     |        |
|                         | 18       | 3-WAYS VALVE(LIQUID)                  | 1    | CWB011700     | 0      |
|                         | 19       | 2-WAYS VALVE(LIQUID)                  | 1    | CWB021637     | 0      |
|                         | 20       | SOUND PROOF MATERIAL                  | 1    | CWG302795     |        |
|                         | 21       | SOUND PROOF MATERIAL                  | 1    | CWG302266     |        |
|                         | 22       | SOUND PROOF MATERIAL HEATER           | 1    | ACXG30-07660  |        |
|                         | 23       | SOUND PROOF BOARD                     | 1    | CWH151085     |        |
|                         | 24       | V-COIL COMPLETE(4 WAY VALVE)          | 1    | CWA43C2169J   | 0      |
|                         | 25       | V-COIL COMPLETE(MAIN EXPANSION VALVE) | 1    | CWA43C2602    | 0      |
|                         | 27       | V-COIL COMPLETE(2-WAY VALVE)          | 1    | CWA43C2607    | 0      |
|                         | 28       | SENSOR-COMP.(OUTDOOR AIR,PIPE TEMP)   | 1    | CWA50C2730    | 0      |
|                         | 29       | SENSOR-COMP.(DEFROST TEMP)            | 1    | CWA50C2577    | 0      |
|                         | 30       | SENSOR-COMP.(DISCHARGE TEMP)          | 1    | CWA50C2576    | 0      |
|                         | 31       | SENSOR-COMP.(EVA EXIT)                | 1    | CWA50C3204    | 0      |
|                         | 32       | HOLDER COUPLING                       | 1    | ACXH35-01510A |        |
|                         | 33       | CABINET REAR PLATE-COMPLETE           | 1    | ACXE02-02020A |        |
|                         | 34       | CONTROL BOARD CASING                  | 1    | CWH10K1049    |        |
|                         | 35       | SOUND PROOF MATERIAL                  | 1    | CWG302598     |        |
| $\wedge$                | 36       | TERMINAL BOARD ASS'Y(U,V,W,A)         | 1    | CWA28K1335    | 0      |
| $\overline{\mathbb{A}}$ | 37       | TERMINAL BOARD ASS'Y(1,2,3)           | 1    | CWA28K1213    | 0      |
| $\overline{\Lambda}$    | 38       | ELECTRONIC CO.(CAPACITOR)             | 1    | CWA746169     | 0      |
| $\overline{\Lambda}$    | 39       | ELECTRONIC CO.(NOISE FILTER)          | 1    | CWA747856     | 0      |
| <u>/:\</u>              | 40       | REF SYS ELECTRONIC CONTROLLER (MAIN)  | 1    | ACXA73C31830R |        |
| <u>/:\</u>              | 40       | REF SYS REACTOR                       | 1    | G0C592J00005  | 0      |
| <u>!\</u><br>           | 41       | ELECTRO MAGNETIC SWITCH               | 1    | K6C1AYY00003  | 0      |
| Ŵ                       |          |                                       |      |               | 0      |
|                         | 43       | FAN MOTOR BRACKET                     | 1    | CWD54K1084    |        |
| ٨                       | 44       | SCREW-FAN MOTOR BRACKET               |      | CWH551040J    |        |
| <u>/!\</u>              | 45       |                                       | 1    | EHDS83LAC     | 0      |
| <u> </u>                | 46       | FAN MOTOR(LOWER)                      | 1    | EHDS83MAC     | 0      |
|                         | 47       | SCREW-FAN MOTOR MOUNT                 | 8    | CWH551323     |        |
|                         | 48       | PROPELLER FAN ASSY                    | 2    | CWH00K1006    |        |
|                         | 49       | NUT                                   | 2    | CWH561092     |        |

| SAFETY                  | REF. NO. | DESCRIPTION & NAME                      | QTY. | WH-MDC16H6E5  | REMARK |
|-------------------------|----------|---|------|---------------|--------|
|                         | 50       | CABINET FRONT PLATE                     | 1    | CWE061098A    |        |
|                         | 51       | DISCHARGE GRILLE                        | 2    | CWE201073     | 0      |
|                         | 52       | CABINET SIDE PLATE ASSY                 | 1    | CWE04K1023A   |        |
|                         | 53       | WIRE NET                                | 1    | CWD041069     |        |
|                         | 54       | HIGH PRESSURE SWITCH                    | 1    | CWA101013     | 0      |
|                         | 55       | ACCESSORY CO.(RUBBER CAP)               | 1    | CWH82C1839    |        |
|                         | 56       | ACCESSORY CO.(DRAIN ELBOW)              | 1    | CWG87C900     |        |
| $\wedge$                | 57       | HEATER (RECEIVER)                       | 1    | CWA341071     | 0      |
|                         | 58       | SOUND PROOF MATERIAL                    | 1    | CWG302594     |        |
|                         | 59       | HOT WATER COIL-COMPLETE                 | 1    | ACXB90C00620  | 0      |
|                         | 60       | FILTER COMPLETE                         | 1    | CWB51C1021    |        |
| $\wedge$                | 62       | HEATER ASS'Y                            | 1    | ACXA34K00370  | 0      |
| $\overline{\mathbb{A}}$ | 63       | THERMOSTAT                              | 3    | CWA151074     | 0      |
|                         | 64       | AIR PURGE VALVE                         | 1    | ACXB62-00130  | 0      |
|                         | 65       | FLOW SWITCH                             | 1    | CWB621137     |        |
| Ŵ                       | 66       | PUMP                                    | 1    | CWB532116     |        |
|                         | 67       | PRESSURE GAUGE                          | 1    | CWB070003     |        |
|                         | 68       | PRESSURE RELIEF VALVE                   | 1    | ACXB62-00100  |        |
|                         | 69       | CABINET SIDE PLATE ASS'Y                | 1    | ACXE04-09480A |        |
| $\wedge$                | 70       | WATER SYS ELECTRONIC CONTROLLER (MAIN)  | 1    | ACXA73C31850R | 0      |
|                         | 72       | TERMINAL BOARD ASS'Y                    | 1    | CWA28K1238    | 0      |
| $\Lambda$               | 73       | WATER SYS REACTOR                       | 1    | G0C103Z00003  | 0      |
| $\overline{\mathbb{A}}$ | 74       | CIRCUIT BREAKER                         | 2    | CWA181005     |        |
| $\overline{\mathbb{A}}$ | 75       | TERMINAL BOARD ASS'Y(A,B)               | 1    | CWA28K1340    | 0      |
| $\overline{\mathbb{A}}$ | 76       | TERMINAL BOARD ASS'Y(1,2,3,4,5,6)       | 1    | CWA28K1341    | 0      |
| $\overline{\mathbb{A}}$ | 77       | TERMINAL BOARD ASS'Y(7,8,9,10,11,12)    | 1    | CWA28K1340    | 0      |
| $\overline{\mathbb{A}}$ | 78       | TERMINAL BOARD ASS'Y(13,14,15,16,17,18) | 1    | CWA28K1343    | 0      |
|                         | 79       | SENSOR-COMPLETE(WATER IN,OUT, REF TEMP) | 1    | ACXA50C13330  | 0      |
|                         | 80       | SENSOR-COMPLETE(HEX WATER OUTLET)       | 1    | ACXA50C13140  | 0      |
|                         | 81       | REMOTE CONTROL COMPLETE                 | 1    | CWA75C4681    | 0      |
|                         | 82       | RECEIVER                                | 1    | CWB141069     |        |
|                         | 83       | HANDLE                                  | 4    | CWE161014     |        |
|                         | 84       | SOUND PROOF MATERIAL                    | 1    | CWG302599     |        |
|                         | 85       | CABINET FRONT PLATE                     | 1    | CWE061274A    |        |
|                         | 86       | CABINET FRONT PLATE                     | 1    | ACXE06-03550A |        |
|                         | 88       | CABINET TOP PLATE                       | 1    | CWE03C1105    |        |
|                         | 89       | OPERATING INSTRUCTION                   | 1    | ACXF55-14590  |        |
|                         | 90       | OPERATING INSTRUCTION                   | 1    | ACXF55-14600  |        |
|                         | 91       | OPERATING INSTRUCTION                   | 1    | ACXF55-14610  |        |
|                         | 92       | OPERATING INSTRUCTION                   | 1    | ACXF55-14620  |        |
|                         | 93       | OPERATING INSTRUCTION                   | 1    | ACXF55-14630  |        |
|                         | 94       | OPERATING INSTRUCTION                   | 1    | ACXF55-14640  |        |
|                         | 95       | INSTALLATION INSTRUCTION                | 1    | ACXF60-23690  |        |
|                         | 96       | INSTALLATION INSTRUCTION                | 1    | ACXF60-17020  |        |
|                         | 97       | FLEXIBLE PIPE (L-TUBE)                  | 1    | CWH5850080    |        |
|                         | 98       | PACKING-L.TUBE                          | 1    | CWB81012      |        |

| SAFETY | REF. NO. | DESCRIPTION & NAME | QTY. | WH-MDC16H6E5 | REMARK |
|--------|----------|--------------------|------|--------------|--------|
|        | 99       | PANASONIC BADGE    | 1    | CWE373439    |        |
|        | 100      | INVERTER BADGE     | 1    | CWE373441    |        |

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.