
# Service Manual

Air-to-Water Heatpump



Indoor Unit WH-SDC09H3E8 WH-SDC12H9E8 WH-SDC16H9E8 Outdoor Unit WH-UD09HE8 WH-UD12HE8 WH-UD16HE8

> Destination Europe Turkey



## WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the products dealt with in this service information by anyone else could result in serious injury or death.

#### IMPORTANT SAFETY NOTICE

There are special components used in this equipment which are important for safety. These parts are marked by  $\triangle$  in the Schematic Diagrams, Circuit Board Diagrams, Exploded Views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent shock, fire or other hazards. Do not modify the original design without permission of manufacturer.

#### ↑ PRECAUTION OF LOW TEMPERATURE

In order to avoid frostbite, be assured of no refrigerant leakage during the installation or repairing of refrigerant circuit.



## **TABLE OF CONTENTS**

1.	Saf	ety Precautions	4	12.15	Alternative Outdoor Ambient Sensor Cont	
2.	Spo	ecifications	7	12.16	Force DHW mode	
	_			12.17	7 Anti Freeze Control	. 126
	2.1	WH-SDC09H3E8 WH-UD09HE8		12.18	Solar Operation (Optional)	. 127
	2.2	WH-SDC12H9E8 WH-UD12HE8			Boiler Bivalent Control	
2	2.3	WH-SDC16H9E8 WH-UD16HE8	13		External Room Thermostat Control (Optio	
3.	Fea	atures	16			
				12.21	Three Ways Valve Control	
4.	Loc	cation of Controls and Components	17		2Two Ways Valve Control	
_	4.1	Indoor Unit	17		BExternal OFF/ON Control	
	4.2	Outdoor Unit			External Compressor Switch (Optional PC	
5.	Din	nensions	42	12.25	Heat/Cool Switch (Optional PCB)	. 135
į	5.1	Indoor Unit	42		SSG Ready Control (Optional PCB)	
	5.2	Outdoor Unit			Demand Control (Optional PCB)	
					BHoliday Mode	
6.	Ref	frigeration and Water Cycle Diagram	44		Dry Concrete	
6	6.1	Standard System (Optional PCB not			)Flow Sensor	
•	o	connected)	45			
6	6.2	Advance System (Optional PCB connecte		13. Pro	otection Control	. 140
•	0.2	Advance Cystem (Optional 1 OB connected		13.1	Protection Control for All Operations	. 140
					Protection Control for Heating Operation	
7.	Blo	ock Diagram	46		Protection Control for Cooling Operation	
-	7.1	WH-SDC09H3E8 WH-UD09HE8	46		• .	
		WH-SDC12H9E8 WH-UD12HE8		14. Sei	rvicing Mode	. 144
,		WH-SDC16H9E8 WH-UD16HE8	47	14.1	How to Take Out Front Plate	. 144
					Test Run	
8.	Wii	ring Connection Diagram	48		Expansion Vessel Pre Pressure Checking	
9	8.1	Indoor Unit	48			
	8.2	Outdoor Unit		14.4	Pump Down Procedures	
					How To Adjust Pump Speed	
9.	Ele	ctronic Circuit Diagram	51		How To Adjust Pump Speed	
(	9.1	Indoor Unit	51		How To Unlock Cool Mode	
	9.2	Outdoor Unit			EEPROM Factory Default Data Setup	
					Procedure	. 149
10	. Pri	nted Circuit Board	54	14.9	Dry Concrete Setup	. 150
	10 1	Indoor Unit	54		intenance Guide	
	-	Outdoor Unit	-			
				15.1	Maintenance for Water Filter Set	. 153
11	. Ins	tallation Instruction	58	16 Tua	ublachacting Cuida	455
	11 1	Indoor Unit	58	16. 110	oubleshooting Guide	. 155
		Variation of system		16.1	Refrigeration Cycle System	. 155
		System Installation			Relationship between the Condition of the	
		Service and maintenance			to-Water Heatpump Indoor and Outdoor L	
		Outdoor Unit			and Pressure and Electric Current	
				16.3	Breakdown Self Diagnosis Function	. 157
12	. Ор	eration and Control	97		Error Codes Table	
	12 1	Basic Function	97	16.5	Self-diagnosis Method	. 161
		Water Pump			_	
		Indoor Unit Safety		17. DIS	assembly and Assembly Instructions	. 200
		Auto Restart Control		17.1	To Remove Front Plate	. 208
		Indication Panel			To Remove Pressure Gauge	
		Indoor Back-Up Heater Control			To Open Control Board Cover	
		Tank Heater Control			To Remove Control Panel	
		Base Pan Heater Control (Optional)			To Remove RCCB	
		Heater Turn ON/OFF priority Control			To Remove Transformer and Electronic	
		Force Heater Mode			Controller Board	. 210
		Profest leater Mode		17.7	To Open Control Board	
		2 Quiet Operation			To Remove Pressure Relief Valve, Air Pu	
		Sterilization Mode			Valve and Flow Sensor	
		Osternization Mode				

17.9	To Remove Water Pump and E	•
17.10	To Remove Filter	
18. Te	chnical Data	214
18.2	Operation Characteristics Heating Capacity Table Cooling Capacity Table	232
19. Ex	oloded View and Replacement	
	Indoor Unit	234

## 1. Safety Precautions

- Read the following "SAFETY PRECAUTIONS" carefully before installation.
- Electrical work must be installed by a licensed electrician. Be sure to use the correct rating and main circuit for the model to be installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below. Incorrect installation due to ignoring of the instruction will cause harm or damage, and the seriousness is classified by the following indications.
- Please leave this installation manual with the unit after installation.

<u></u> MARNING	This indication shows the possibility of causing death or serious injury.
<b>A</b> CAUTION	This indication shows the possibility of causing injury or damage to properties only.

• The items to be followed are classified by the symbols:

$\Diamond$	Symbol with white background denotes item that is PROHIBITED from doing.
0 0	Symbol with dark background denotes item that must be carried out.

• Carry out test run to confirm that no abnormality occurs after the installation. Then, explain to user the operation, care and maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.

	<u></u> WARNING	
1.	Do not use unspecified cord, modified cord, joint cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire.	(
2.	Do not tie up the power supply cord into a bundle by band. Abnormal temperature rise on power supply cord may happen.	(
3.	Keep plastic bag (packaging material) away from small children, it may cause suffocation.	(
4.	Do not use pipe wrench to install refrigerant piping. It might deform the piping and cause the unit to malfunction.	(
5.	Do not purchase unauthorized electrical parts for installation, service, maintenance and etc. They might cause electrical shock or fire.	(
6.	Do not modify the wiring of Indoor Unit for installation of other components (i.e. heater, etc). Overloaded wiring or wire connection points may cause electrical shock or fire.	(
7.	Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury etc.	(
8.	Do not use joint cable for Indoor / Outdoor Unit connection cable. Use specified Indoor / Outdoor Unit connection cable, refer to instruction <b>CONNECT THE CABLE TO THE INDOOR UNIT</b> and connect tightly for Indoor / Outdoor Unit connection. Clamp the cable so that no external force will be acted on the terminal. If connection or fixing is not perfect, it will cause heat up or fire at the connection.	(
9.	Do not install outdoor unit near handrail of veranda. When installing outdoor unit at veranda of high rise building, child may climb up to outdoor unit and cross over the handrail and causing accident.	(
0.	Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury.	(
1.	Do not sit or step on the unit, you may fall down accidentally.	(
2.	For electrical work, follow local wiring standard, regulation and this installation instruction. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in electrical work, it will cause electrical shock or fire.	(
3.	For water circuit installation work, follow to relevant European and national regulations (including EN61770) and local plumbing and building regulation codes.	(
4.	Engage dealer or specialist for installation. If installation done by the user is defective, it will cause water leakage, electrical shock or fire.	
5.	<ul> <li>This is a R410A model, when connecting the piping, do not use any existing (R22) pipes and flare nuts. Using such same may cause abnormally high pressure in the refrigeration cycle (piping), and possibly result in explosion and injury. Use only R410A refrigerant.</li> <li>Thickness or copper pipes used with R410A must be 0.8 mm or more. Never use copper pipes thinner than 0.8 mm.</li> <li>It is desirable that the amount of residual oil is less than 40mg/10m.</li> </ul>	ı
16.	When install or relocate Indoor Unit / Outdoor Unit, do not let any substance other than the specified refrigerant, e.g. air etc. mix into refrigerant cycle (piping). Mixing of air etc. will cause abnormal high pressure in refrigeration cycle and result in explosion, injury etc	(
7.	Install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electrical shock or fire.	

	<u></u> WARNING	
18.	Install at a strong and firm location which is able to withstand the set's weight. If the strength is not enough or installation is not properly done, the set will drop and cause injury.	•
19.	This equipment is strongly recommended to be installed with Residual Current Device (RCD) on-site according to the respective national wiring rules or country–specific safety measures in terms of residual current.	
20.	During installation, install the refrigerant piping properly before run the compressor. Operation of compressor without fixing refrigeration piping and valves at opened condition will cause suck-in of air, abnormal high pressure in refrigeration cycle and result in explosion, injury etc.	9
21.	During pump down operation, stop the compressor before remove the refrigeration piping. Removal of refrigerant piping while compressor is operating and valves are opened will cause suck-in of air, abnormal high pressure in refrigerant cycle and result in explosion, injury etc.	Ð
22.	Tighten the flare nut with torque wrench according to specified method. If the flare nut is over tightened, after a long period, the flare may break and cause refrigerant gas leakage.	9
23.	After completion of installation, confirm there is no leakage of refrigerant gas. It may generate toxic gas when the refrigerant contacts with fire.	Ð
24.	Ventilate the room if there is refrigerant gas leakage during operation. Extinguish all fire sources if present. It may cause toxic gas when the refrigerant contacts with fire.	Ð
25.	Only use the supplied or specified installation parts, else, it may cause unit vibrate loose, water leakage, electrical shock or fire.	9
26.	The unit is only for use in closed water system. Utilization in an open water circuit may lead to excessive corrosion of water piping and risk of incubating bacteria colonies, particularly Legionella, in water.	<b>D</b>
27.	If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.	<b>D</b>
28.	Select a location where in case of water leakage, the leakage will not cause damage to other properties.	9
29.	When installing electrical equipment at wooden building of metal lath or wire lath, in accordance with electrical facility standard, no electrical contact between equipment and building is allowed. Insulator must be installed in between.	9
30.	Any work carried out on the Indoor Unit / Outdoor Unit after removing any panels which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor.	Ð
31.	This unit must be properly earthed. The electrical earth must not be connected to a gas pipe, water pipe, the earth of lightening rod or a telephone. Otherwise there is a danger of electrical shock in the event of an insulation breakdown or electrical earth fault in the outdoor unit.	•
32.	Do not use joint cable for outdoor connection cable. Use specified outdoor connection cable, refer to instruction <b>CONNECT THE CABLE TO THE OUTDOOR UNIT</b> and connect tightly for outdoor connection. Clamp the cable so that no external force will be acted on the terminal. If connection or fixing is not perfect, it will cause heat up or fire at the connection.	Ð

	<u>^</u> CAUTION	
1.	Do not install the Indoor Unit / Outdoor Unit at place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the unit, it may cause fire.	0
2.	Do not release refrigerant during piping work for installation, re-installation and during repairing a refrigeration parts. Take care of the liquid refrigerant, it may cause frostbite.	$\Diamond$
3.	Do not install this appliance in a laundry room or other high humidity location. This condition will cause rust and damage to the unit.	$\Diamond$
4.	Make sure the insulation of power supply cord does not contact hot part (i.e. refrigerant piping) to prevent from insulation failure (melt).	$\Diamond$
5.	Do not apply excessive force to water pipes that may damage the pipes. If water leakage occurs, it will cause flooding and damage to other properties.	$\Diamond$
6.	Do not touch the sharp aluminium fin, sharp parts may cause injury.	$\Diamond$
7.	Do not release refrigerant into the atmosphere. The product contains fluorinated greenhouse gases and that its functioning relies upon such gases.	$\Diamond$
8.	Select an installation location which is easy for maintenance.	0
9.	Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water may enter the room and damage the furniture.	0

#### **A** CAUTION

Power supply connection to Indoor Unit.

- Power supply point should be in easily accessible place for power disconnection in case of emergency.
- Must follow local national wiring standard, regulation and this installation instruction.
- Strongly recommended to make permanent connection to a circuit breaker.

- Power supply 1: Use approved 20A 4-poles circuit breaker with a minimum contact gap of 3.0 mm.

Power supply 2: Use approved 15/16A 2-poles circuit breaker with a minimum contact gap of 3.0 mm. (Only applicable for S\*C09\*3E8)

0

or

Use approved 20A 4-poles circuit breaker with a minimum contact gap of 3.0mm. (Only applicable for  $$^*C12^*9E8/$^*C16^*9E8$ )

11. Ensure the correct polarity is maintained throughout all wiring. Otherwise, it will cause electrical shock or fire.



12. After installation, check the water leakage condition in connection area during test run. If leakage occurs, it will cause damage to other properties.

0

Installation work.

10.

13. It may need two or more people to carry out the installation work. The weight of Indoor Unit / Outdoor Unit might cause injury if carried by one person.

0

## 2. Specifications

## 2.1 WH-SDC09H3E8 WH-UD09HE8

Item		Unit	Outdoor Unit			
Performance Test C	Condition			EN 14511		
		Condition (Ambient/Water)		A35W7		
Caslina Canasitu		kW		7.00		
Cooling Capacity		BTU/h				
		kcal/h		23900 6020		
		W/W		3.17		
Cooling EER		kcal/hW		2.72		
		Condition	A7W35		A2W35	
		(Ambient/Water) kW	9.00		9.00	
Heating Capacity		BTU/h	30700		30700	
		kcal/h	7740		7740	
		W/W	4.84		3.59	
Heating COP		kcal/hW	4.16		3.08	
	Low Temperature Appl		4.10		3.00	
	Application	Climate	Warmer	Average	Colder	
_	Pdesign	kW	9.0	9.0	10.0	
	Tbivalent / TOL	°C	2 / 2	-10 / -10	-15 / -22	
	SCOP / ns	(W/W) / %	6.21 / 245	4.81 / 190	4.28 / 168	
	Annual Consumption	kWh	1936	3863	5757	
	Class	KVVII	A++	A++	A++	
Heating ErP —	Medium Temperature Ap	plication (W55)	711		Aii	
	Application	Climate	Warmer	Average	Colder	
_	Pdesign	kW	9.0	8.0	8.0	
	Tbivalent / TOL	°C	2/2	-10 / -10	-15 / -22	
	SCOP / ns	(W/W) / %	4.05 / 159	3.41 / 133	3.10 / 121	
	Annual Consumption	kWh	2967	4844	6368	
	Class		A++	A++	A+	
<u> </u>		Condition (Ambient/Water)	A35W7	A7W35	A2W35	
Noise Level		dB (A)	Cooling: 49	Heating: 51	_	
		Power Level dB	Cooling: 67	Heating: 68	_	
Air Flow		m³/min (ft³/min)		Cooling: 89.5 (3160) Heating: 76.8 (2710)		
Refrigeration Contro	ol Device			Expansion Valve	<u> </u>	
Refrigeration Oil		cm <sup>3</sup>		FV50S (1200)		
Refrigerant (R410A)	)	kg (oz)		2.55 (90.0)		
	GV			2088		
F-GAS CO2eq (ton) (Precha		narged / Maximum)	5.324 / 7.412			
	Height	mm (inch)		1340 (52-3/4)		
Dimension	Width	mm (inch)	900 (35-7/16)			
Depth		mm (inch)	320 (12-19/32)			
Net Weight		kg (lbs)		107 (236)		
Pipe Diameter Liquid		mm (inch)		9.52 (3/8)		
	Gas	mm (inch)		15.88 (5/8)		
Standard Length		m (ft)	7 (23.0)			
Pipe Length Range		m (ft)	3 (9.8) ~ 30 (98.4)			
I/D & O/D Height Di	fference	m (ft)	20 (65.6)			

Item		Unit	Outdoor Unit			
Additional Gas Amount		g/m (oz/ft)		50 (0.5)		
Refrigeration Charge Less		m (ft)	10 (32.8)			
Туре			Hermetic Motor			
Compressor	Motor Type		Brushless (4-poles)			
	Rated Output	kW		4.50		
Туре				Propeller Fan		
	Material			PP		
F	Motor Type			DC (8-poles)		
Fan	Input Power	W		_		
	Output Power	W		60		
	Fan Speed	rpm		ng: 550 (Top), 590 (Bo ng: 490 (Top), 530 (Bo		
	Fin material			Aluminium (Pre Coat)		
Heat Exchanger	Fin Type			Corrugated Fin		
Trout Exoriarigor	Row × Stage × FPI			2 × 51 × 18		
	Size (W × H × L)	mm	903.7 × 1295.4 × 38.1			
		Ø	Three			
Power Source (Phase, Volta	age, Cycle)	V	400			
		Hz	50			
Input Power		Condition (Ambient/Water)	A35W7	A7W35	A2W35	
		kW	Cooling: 2.21	Heating: 1.86	Heating: 2.51	
Maximum Input Power For I	Heatpump System	kW		5.85		
Power Supply 1 : Phase (Ø)	) / Max. Current (A) / Max. Ir	nput Power (W)				
Power Supply 2 : Phase (Ø)	` ,	. ,	1Ø / 13.0 / 3.00k			
Power Supply 3 : Phase (Ø)	) / Max. Current (A) / Max. Ir	nput Power (W)		<b>—/—/—</b>		
Starting Current		Α		3.4		
Running Current		Condition (Ambient/Water)	A35W7	A7W35	A2W35	
ŭ		Α	Cooling: 3.4	Heating: 2.8	Heating: 3.8	
Maximum Current For Heat	pump System	Α	8.8			
Power Factor Power factor means total figure of compressor and outdoor fan motor.		%	Cooling: 95 Heating: 96			
Power Cord	Number of core		_			
1 OWGI GOIG	Length	m (ft)				
Thermostat			Electronic Control			
Protection Device				Electronic Control		

Ite	em		Unit	Indoor Unit		
Performance Test Condition	n				EN 14511	
Operation Range	Outdoor A	mbient	°C		Cooling: 16 ~ 43 Heating: -20 ~ 35	
Operation Nange	Water Out	let	°C		Cooling: 5 ~ 20 Heating: 20 ~ 55	
Internal Pressure Differentia	al		kPa	Cooling: 19 Heating: 30		
			Condition (Ambient/Water)	A35W7	A7W35	A2W35
Noise Level			dB (A)	Cooling: 33	Heating: 33	_
			Power Level dB	Cooling: 46	Heating: 46	_
	Height		mm (inch)		892 (35-1/8)	
Dimension	Width		mm (inch)		500 (19-11/16)	
	Depth		mm (inch)		340 (13-13/32)	
Net Weight		kg (lbs)		43 (95)		
Refrigerant Pipe Diameter	Liquid		mm (inch)	9.52 (3/8)		
Kemgerant Fipe Diameter	Gas		mm (inch)	15.88 (5/8)		
Water Pipe Diameter			mm (inch)	28 (1-3/32)		
Water Fipe Diameter	Outlet		mm (inch)	28 (1-3/32)		
Water Drain Hose Inner Dia	meter		mm (inch)	15 (19/32)		
	Motor Typ	е		DC Motor		
Pump	No. of Speed			7 (Software Selection)		
	Input Power		W	58		
	Туре			Brazed Plate		
	No. of Plat	tes		36		
Hot Water Coil	Size (W ×	H×L)	mm		65 × 120 × 376	
	Water Flov	w Rate	l/min (m³/h)		Cooling: 20.1 (1.2) Heating: 25.8 (1.5)	
Pressure Relief Valve Water Circuit			kPa	Oper	n: 300, Close: 266 and be	elow
Flow Switch				Electronic Sensor		
Protection Device		А	Residual Current Circuit Breaker (25)		er (25)	
Expansion Vessel		Volume	I	10		
LAPANSION VESSEI		MWP	bar	3		
Capacity of Integrated Elec	tric Heater		kW	3.00		

#### Note:

- Cooling capacities are based on outdoor air temperature of 35°C Dry Bulb with controlled indoor water inlet temperature of 12°C and water outlet temperature of 7°C.
- Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled indoor water inlet temperature of 30°C and water outlet temperature of 35°C.
- Specification are subjected to change without prior notice for further improvement.
- Flow rate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and  $\Delta T$  = 5°C.

## 2.2 WH-SDC12H9E8 WH-UD12HE8

	Item	Unit	Outdoor Unit				
Performance Tes	t Condition	·		EN 14	511		
		Condition (Ambient/Water)		A35V	N7		
Cooling Consoits		kW		10.0	00		
Cooling Capacity		BTU/h	34100				
		kcal/h		860	0		
		W/W		2.8	5		
Cooling EER		kcal/hW		2.4	5		
		Condition (Ambient/Water)	A7W35			A2W35	
Haatina Canasitu		(Ambient/Water)	12.00			11.40	
Heating Capacity		BTU/h	41000			38900	
		kcal/h	10320			9800	
		W/W	4.74			3.44	
Heating COP		kcal/hW	4.08			2.96	
	Low Temperature App	ication (W35)	14/			0.11	
	Application	Climate	Warmer	Avera	age	Colder	
	Pdesign	kW	11.0	10.	0	11.0	
	Tbivalent / TOL	°C	2/2	-10 /	-10	-15 / -22	
	SCOP / ns	(W/W) / %	6.21 / 245	4.82 /	190	4.29 / 168	
	Annual Consumption	kWh	2368	428	6	6327	
Heating ErP	Class		A++	A+-	+	A++	
rieating Lir	Medium Temperature Ap	pplication (W55)	Warmer	Average		Colder	
	Application	Climate	wannei	Average		Coldei	
	Pdesign	kW	9.0	8.0	)	9.0	
	Tbivalent / TOL	°C	2/2	-10 / -10		-15 / -22	
	SCOP / ns	(W/W) / %	4.05 / 159	3.42 / 134		3.10 / 121	
	Annual Consumption	kWh	2970	484	0	7147	
	Class		A++	A++		A+	
		Condition (Ambient/Water)	A35W7	A7W	35	A2W35	
Noise Level		dB (A)	Cooling: 50	Heating	g: 52	_	
		Power Level dB	Cooling: 68	Heating	g: 69	_	
Air Flow		m³/min (ft³/min)	Cooling: 93.3 (3290) Heating: 80.0 (2830)				
Refrigeration Cor	ntrol Device			Expansion			
Refrigeration Oil		cm <sup>3</sup>		FV50S (	(1200)		
Refrigerant (R410	DA)	kg (oz)		2.55 (9	90.0)		
F-GAS	G\	WP			2088		
r-GAS	CO2eq (ton) (Prec	harged / Maximum)	5.324 / 7.412				
	Height	mm (inch)		1340 (5	2-3/4)		
Dimension	Width	mm (inch)	900 (35-7/16)				
	Depth	mm (inch)		320 (12-	19/32)		
Net Weight		kg (lbs)		107 (2	236)		
Pipe Diameter	Liquid	mm (inch)	9.52 (3/8)				
Gas		mm (inch)	15.88 (5/8)				
Standard Length		m (ft)		7 (23			
Pipe Length Rang	-	m (ft)		3 (9.8) ~ 3			
I/D & O/D Height		m (ft)	20 (65.6)				
Additional Gas A		g/m (oz/ft)	50 (0.5)				
Refrigeration Cha	arge Less	m (ft)		10 (32	2.8)		

	Item	Unit	Outdoor Unit			
	Туре			Hermetic Motor		
Compressor	Motor Type		Brushless (4-poles)			
	Rated Output	kW	4.50			
	Туре			Propeller Fan		
	Material			PP		
_	Motor Type		DC (8-poles)			
Fan	Input Power	W		_		
	Output Power	W		60		
	Fan Speed	rpm	Cooli Heati	ng: 600 (Top), 640 (Bo ng: 510 (Top), 550 (Bo	ottom) ottom)	
	Fin material			Aluminium (Pre Coat)		
Heat Exchanger	Fin Type			Corrugated Fin		
leat Exchange	Row × Stage × FPI			2 × 51 × 18		
Size (W × H × L)		mm		903.7 × 1295.4 × 38.1		
		Ø	Three			
Power Source (Phase, \	/oltage, Cycle)	V	400			
		Hz	50			
nput Power		Condition (Ambient/Water)	A35W7	A7W35	A2W35	
		kW	Cooling: 3.51	Heating: 2.53	Heating: 3.31	
Maximum Input Power F	or Heatpump System	kW	5.85			
Power Supply 1 : Phase	e (Ø) / Max. Current (A) / Max. I	nput Power (W)		3Ø / 8.8 / 5.85k		
Power Supply 2 : Phase	e (Ø) / Max. Current (A) / Max. I	nput Power (W)		3Ø / 13.0 / 9.00k		
Power Supply 3 : Phase	e(Ø) / Max. Current (A) / Max. I	nput Power (W)		<b>—</b> / <b>—</b> / <b>—</b>		
Starting Current		Α		5.3		
Running Current		Condition (Ambient/Water)	A35W7	A7W35	A2W35	
		А	Cooling: 5.3	Heating: 3.8	Heating: 5.0	
Maximum Current For H	leatpump System	Α		8.8		
Power Factor Power factor means total figure of compressor and outdoor fan motor.		%	Cooling: 96	Heating: 96	Heating: 96	
Power Cord	Number of core			_		
Ower Colu	Length	m (ft)		_		
Thermostat			Electronic Control			
Protection Device				Electronic Control		

Item		Unit	Indoor Unit			
Performance Test Condition	1			EN 14511		
Operation Range	Outdoor A	mbient	°C	Cooling: 16 ~ 43 Heating: -20 ~ 35		
Operation Nange	Water Out	et	°C		Cooling: 5 ~ 20 Heating: 20 ~ 55	
Internal Pressure Differentia	ıl		kPa		Cooling: 36 Heating: 52	
			Condition (Ambient/Water)	A35W7	A7W35	A2W35
Noise Level			dB (A)	Cooling: 33	Heating: 33	_
			Power Level dB	Cooling: 46	Heating: 46	<u> </u>
	Height		mm (inch)		892 (35-1/8)	
Dimension	Width		mm (inch)		500 (19-11/16)	
	Depth		mm (inch)		340 (13-13/32)	
Net Weight			kg (lbs)		44 (97)	
Refrigerant Pipe Diameter	Liquid		mm (inch)	9.52 (3/8)		
Reingerant Fipe Diameter	Gas		mm (inch)	15.88 (5/8)		
Water Pipe Diameter	Inlet		mm (inch)	28 (1-3/32)		
Water Fipe Diameter	Outlet		mm (inch)	28 (1-3/32)		
Water Drain Hose Inner Dia	meter		mm (inch)		15 (19/32)	
	Motor Type	Э		DC Motor		
Pump	No. of Speed			7 (Software Selection)		
	Input Power		W	92		
	Туре				Brazed Plate	
	No. of Plat	es		36		
Hot Water Coil	Size (W ×	H × L)	mm		65 × 120 × 376	
	Water Flow	v Rate	l/min (m³/h)		Cooling: 28.7 (1.7) Heating: 34.4 (2.1)	
Pressure Relief Valve Water Circuit			kPa	Open: 300, Close: 266 and below		elow
Flow Switch					Electronic Sensor	
Protection Device		A	Residual Current Circuit Breaker (25)		er (25)	
Expansion Vessel		Volume	I		10	
LAPATISIUTI VESSEI		MWP	bar	3		
Capacity of Integrated Elect	ric Heater		kW		9.00	

#### Note:

- Cooling capacities are based on outdoor air temperature of 35°C Dry Bulb with controlled indoor water inlet temperature of 12°C and water outlet temperature of 7°C.
- Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled indoor water inlet temperature of 30°C and water outlet temperature of 35°C.
- Specification are subjected to change without prior notice for further improvement.
- Flow rate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and  $\Delta \tau$  = 5°C.

## 2.3 WH-SDC16H9E8 WH-UD16HE8

	Item	Unit		Outdoor Unit	
Performance Test	Condition	<u> </u>	EN 14511		
		Condition (Ambient/Water)		A35W7	
		kW	12.20		
Cooling Capacity		BTU/h		41600	
		kcal/h		10490	
		W/W		2.56	
Cooling EER		kcal/hW		2.20	
		Condition	A7W35		A2W35
		(Ambient/Water) kW	16.00		13.00
Heating Capacity		BTU/h	54600		44300
		kcal/h	13760		11180
		W/W	4.28		3.28
Heating COP		kcal/hW	3.68		2.82
	Low Temperature Appl	1	3.00		2.02
-	Application	Climate	Warmer	Average	Colder
_	Pdesign	kW	13.0	12.0	12.0
<u> </u>	Tbivalent / TOL	°C	2/2	-10 / -10	-15 / -22
-	SCOP / ns	(W/W) / %	6.20 / 245	4.82 / 190	4.28 / 168
<u> </u>	Annual Consumption	kWh	2801	5146	6911
-	Class		A++	A++	A++
Heating ErP	Medium Temperature Ap	plication (W55)	Warmer		
-	Application	Climate		Average	Colder
-	Pdesign	kW	10.0	13.0	10.0
	Tbivalent / TOL	°C	2/2	-3 / -10	-15 / -22
	SCOP / ns	(W/W) / %	4.30 / 169	3.33 / 130	3.10 / 121
	Annual Consumption	kWh	3104	8076	7955
	Class		A++	A++	A+
<u> </u>		Condition (Ambient/Water)	A35W7	A7W35	A2W35
Noise Level		dB (A)	Cooling: 54	Heating: 55	_
		Power Level dB	Cooling: 72	Heating: 72	_
Air Flow		m³/min (ft³/min)		Cooling: 97.8 (3450)	
		111 /111111 (11 /111111)		Heating: 90.0 (3180)	
Refrigeration Contr	ol Device	3		Expansion Valve	
Refrigeration Oil		cm <sup>3</sup>		FV50S (1200)	
Refrigerant (R410A		kg (oz)		2.55 (90.0)	
F-GAS	GV	harged / Maximum)	2088		
	., , ,	mm (inch)		5.324 / 7.412 1340 (52-3/4)	
Dimension	Height Width	mm (inch)		900 (35-7/16)	
Difficusion	Depth	mm (inch)		320 (12-19/32)	
Net Weight		kg (lbs)		107 (236)	
Pipe Diameter Liquid		mm (inch)		9.52 (3/8)	
Standard Length		` ′			
	<b>;</b>				
Pipe Diameter  Gas  Standard Length  Pipe Length Range  I/D & O/D Height Difference  Additional Gas Amount  Refrigeration Charge Less		mm (inch) m (ft) m (ft) m (ft) g/m (oz/ft) m (ft)	9.52 (3/8) 15.88 (5/8) 7 (23.0) 3 (9.8) ~ 30 (98.4) 20 (65.6) 50 (0.5) 10 (32.8)		

Item		Unit	Outdoor Unit			
Туре			Hermetic Motor			
Compressor	Motor Type		Brushless (4-poles)			
	Rated Output	kW		4.50		
	Туре			Propeller Fan		
	Material			PP		
_	Motor Type		Г	OC / Transistor (8-poles	s)	
Fan	Input Power	W		_		
	Output Power	W		60		
	Fan Speed	rpm		ng: 630 (Top), 670 (Bo ng: 580 (Top), 620 (Bo		
	Fin material			Aluminium (Pre Coat)		
Heat Exchanger	Fin Type			Corrugated Fin		
roat Exonanger	Row × Stage × FPI			2 × 51 × 18		
	Size (W × H × L)	mm		903.7 × 1295.4 × 38.1		
		Ø	Three			
Power Source (Phase, Vo	Itage, Cycle)	V	400			
		Hz	50			
Input Power		Condition (Ambient/Water)	A35W7	A7W35	A2W35	
· 		kW	Cooling: 4.76	Heating: 3.74	Heating: 3.96	
Maximum Input Power Fo	r Heatpump System	kW	6.59			
Power Supply 1 : Phase (	Ø) / Max. Current (A) / Max. I	nput Power (W)	3Ø / 9.9 / 6.59k			
Power Supply 2 : Phase (	Ø) / Max. Current (A) / Max. I	nput Power (W)		3Ø / 13.0 / 9.00k		
Power Supply 3 : Phase (	Ø) / Max. Current (A) / Max. I	nput Power (W)		<b>—</b> / <b>—</b> / <b>—</b>		
Starting Current		Α		7.1		
Running Current		Condition (Ambient/Water)	A35W7	A7W35	A2W35	
ŭ		Α	Cooling: 7.1	Heating: 5.7	Heating: 6.0	
Maximum Current For Hea	atpump System	A		9.9		
Power Factor Power factor means total t	figure of compressor and	%	A35W7	A7W35	A2W35	
outdoor fan motor.	igure or compressor and	70	Cooling: 97	Heating: 95	Heating: 96	
Power Cord	Number of core			_		
- Owel Colu	Length	m (ft)		_		
Thermostat				Electronic Control		
Protection Device				Electronic Control		

Item		Unit	Indoor Unit			
Performance Test Condition	n			EN 14511		
Operation Range	Outdoor Ambient		°C	Cooling: 16 ~ 43 Heating: -20 ~ 35		
Operation Nange	Water Out	let	°C		Cooling: 5 ~ 20 Heating: 20 ~ 55	
Internal Pressure Differentia	al		kPa		Cooling: 48 Heating: 82	
			Condition (Ambient/Water)	A35W7	A7W35	A2W35
Noise Level			dB (A)	Cooling: 33	Heating: 33	_
			Power Level dB	Cooling: 46	Heating: 46	_
1	Height		mm (inch)		892 (35-1/8)	
Dimension	Width		mm (inch)		500 (19-11/16)	
	Depth		mm (inch)		340 (13-13/32)	
Net Weight			kg (lbs)		45 (99)	
Refrigerant Pipe Diameter	Liquid		mm (inch)	9.52 (3/8)		
Reingerant Pipe Diameter	Gas		mm (inch)	15.88 (5/8)		
Water Pipe Diameter	Inlet		mm (inch)	28 (1-3/32)		
water Pipe Diameter	Outlet		mm (inch)	28 (1-3/32)		
Water Drain Hose Inner Dia	meter		mm (inch)		15 (19/32)	
	Motor Typ	е		DC Motor		
Pump	No. of Spe	ed		7 (Software Selection)		
	Input Power		W	142		
	Туре				Brazed Plate	
	No. of Plat	es		44		
Hot Water Coil	Size (H × \	N×L)	mm		65 × 120 × 376	
	Water Flov	v Rate	l/min (m³/h)		Cooling: 35.0 (2.1) Heating: 45.9 (2.8)	
Pressure Relief Valve Water Circuit		kPa	Oper	n: 300, Close: 266 and b	elow	
Flow Switch	low Switch				Electronic Sensor	
Protection Device			A	Residual Current Circuit Breaker (25)		er (25)
Expansion Vessel		Volume	I		10	
LAPANSION VESSEI		MWP	bar	3		
Capacity of Integrated Elec	tric Heater		kW		9.00	

#### Note:

- Cooling capacities are based on outdoor air temperature of 35°C Dry Bulb with controlled indoor water inlet temperature of 12°C and water outlet temperature of 7°C.
- Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled indoor water inlet temperature of 30°C and water outlet temperature of 35°C.
- Specification are subjected to change without prior notice for further improvement.
- Flow rate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and  $\Delta T$  = 5°C.

#### 3. Features

#### **Inverter Technology**

- Energy saving

#### **High Efficiency**

#### **Environment Protection**

- Non-ozone depletion substances refrigerant (R410A)

#### Long Installation Piping

- Long piping up to 30 meter with height difference 20 meter
   Flexible 4-way piping for outdoor unit

#### Easy to use control panel

- Auto mode
- Holiday mode
- Dry concrete function
- Weekly timer setting

#### A-class energy efficiency pump

- Water pump speed can be set by selection at control panel

#### Improved deice cycle

#### **Protection Feature**

- Random auto restart after power failure for safety restart operation

- Gas leakage protection
  Prevent compressor reverse cycle
  Inner protector to protect compressor


#### Serviceability Feature


- Breakdown Self Diagnosis function
- System Status Check Buttons for servicing purpose
- System Pumpdown Button for servicing purpose
- Front maintenance design for outdoor unit


## 4. Location of Controls and Components

#### 4.1 Indoor Unit


#### 4.1.1 Location of Control








#### Display





Operation icons

The status of operation is displayed.

Icon will not display (under operation OFF screen) whenever operation is OFF except weekly timer.



Holiday operation status



Weekly Timer operation status



Quiet operation status



Zone:Room Thermostat →Internal sensor status



Powerful operation status



Demand Control or SG ready or SHP status



Room Heater status



\*2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

Tank Heater status



Solar status



(Boiler) \*1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.

- Temperature of each zone
- (4) Time and day
- Water Tank temperature
- **Outdoor temperature**
- Sensor type/Set temperature type icons

Room Thermostat

→External



Water Temperature →Compensation curve



Water Temperature →Direct



Room Thermostat →Internal



#### 4.1.2 Initialization

Before starting to install the various menu settings, please initiate the Remote Controller by selecting the language of operation and installing the date and time correctly.

It is recommended that the installer conducts the following initialization of the Remote Controller.


#### Selecting the language

Press and wait while the display is initializing.

- 1) Scroll with  $\overline{\mathbf{v}}$  and  $\mathbf{A}$  to select the language.
- 2 Press Uto confirm the selection.

#### Setting the clock


- Select with ▼ or ▲ how to display the time, either 24h or am/pm format (for example, 15:00 or 3 pm).
- ③ Use ▼ and ▲ to select year, month, day, hour and minutes. (Press ← to confirm the selection each time.)
- Once the time is set, time and day will appear on the display even if the Remote Controller is turned OFF.



#### 4.1.3 Quick Menu

After the initial settings have been completed, you can select a quick menu from the following options and edit the setting.


1 Press to display the quick menu.



















- ② Use ▲ ▼ ◀ ▶ to select menu.
- 3 Press to turn on/off the select menu.


#### 4.1.3.1 Before Use


This Quick Guide explains how to use the Quick Menu.

Please read the Operating Instructions thoroughly before using the Quick Menu.

#### 4.1.3.2 How to use the Quick Menu

After the initial settings have been completed, you can select a quick menu from the following options and edit the setting.






#### To return to the Main Screen,

Press or .

#### ■ Note:

 If the system is not connected to the tank (Tank Connection is OFF), the Quick Menu screen will be displayed as right. Make sure the Tank Connection is ON.



#### Notes on operation icon


#### Example:



• Operation icon indicate with "....." = OFF



• Operation icon indicate with "----" = ON



#### Select this icon to turn the Tank DHW on or off.

#### Press — to confirm your selection.



Force DHW is turned off.

#### **Force DHW**

#### ■ Note:

• Force DHW is disabled when Force Heater is turned on.

· Force DHW is turned on.

• When Force DHW is turned off, operation & mode should change back to the previous memorized status.

#### Select this icon to operate the heating/cooling system powerfully.

#### Press Uto confirm your selection.

(The powerful operation starts approximately 1 minute after  $\longrightarrow$  is pressed.)



· Powerful mode is set off.



 $\downarrow$ 

4

 $\downarrow$ 



• The Powerful mode operates for 30 minutes.



• The Powerful mode operates for 60 minutes.




• The Powerful mode operates for 90 minutes.

#### ■ Note:

• Powerful is disabled when operation is turned OFF.

## **Powerful**




## Quiet


#### Select this icon to operate quietly.


#### Press Uto confirm your selection.


(The quiet operation starts approximately 1 minute after  $\begin{tabular}{ll} \end{tabular}$  is pressed.)



• Select this to set a timer for the Quiet mode operation.







## Force Heater

#### Select to force the Heater on.

#### Press — to confirm your selection.

(The Force Heater mode starts approximately 1 minute after  $\begin{tabular}{ll} \end{tabular}$  is pressed.)



• Force Heater is turned off.

• Force Heater is turned on.

#### ■ Note:

 Force Heater is disabled whenever operation is already on and 'Disabled due to Operation ON!' will be displayed.

Disabled due to Operation DNI

[⊅] Close



Do you want to edit

Weekly timer pattern?

Sum Han The West This Frit Sat

All 6 parterns are not set it.

Do you want to edit?

Nο


## Weekly Timer

limer setur Timer copy

Yes

Select this icon to delete (cancel) or change the pre-set Weekly Timer.

Press — to confirm your selection.






• If you select "No", the screen will return to the Main Screen.

- Timer Setup: Select Timer setup to edit the Weekly Timer.
- Timer copy: Select to copy a timer setting.

#### [Example of a Timer setup]


Select the day(s) which you wish to edit using A V buttons.

If all 6 patterns are not preset, this screen will be displayed.



4 No


- 1 Select pattern "1" ~ "6".
- 2) Set the hour and minutes of the Timer.
- (3) Select ON/OFF of the Timer.
- 4 Select the operation mode.
  - A/A戶/※/※戶/戶/器戶/器
  - Select mode using ▲ ▼ buttons.
- (5) Set the temperature for both Zone 1 and 2 (if your system has the 2-Zone setting).



6 Set the Tank temperature.

#### ■ Note:

- Timer is disabled when Force Heater is turned on or Heat-Cool SW is enabled.
- If you have preset the Weekly Timer on 2 zones, you must repeat the same procedure with Zone 2.



#### Select to defrost the frozen pipes.


Press Uto confirm your selection.

(When the mode is accepted, below screen will be displayed.)

Request accepted i

[±] Closs

# Force Defrost



## Select to restore the previous settings when error has occurred.

Press Uto confirm your selection.

(When the mode has been accepted, below screen will be displayed.)

Request accepted l

[±] Closs

 Make sure all units are turned off before selecting this mode which restores the whole system to the previous settings.

#### **Error Reset**



#### Select to lock the Remote Controller.

Press — to confirm your selection.

(When the mode has been accepted, below screen will be displayed.)

Select "Yes".

Do you want to lock remote control?

(The Main Screen will be locked.)

• If "No" is selected, the screen will return to the Main Screen.

## **R/C Lock**

## To unlock the Remote Controller Press any key.

(When the mode has been accepted, below screen will be displayed.)



Enter any 4 digits of number (if the number is correct, the screen will be unlocked).

# To reset forgotten password (under operation OFF screen Press ⊃ , → and ► continuously for 5 seconds.

(When the mode has been accepted, below screen will be displayed.)

Reset password Select "Reset".

1.Password is reset to 0000
2.Remote control is unlocked

(The screen will be off after 3 seconds.)

#### 4.1.4 **Menus For user**

Select menus and determine settings according to the system available in the household. All initial settings must be done by an authorised dealer or a specialist. It is recommended that all alterations of the initial settings are also done by an authorised dealer or a


- After initial installation, you may manually adjust the settings.
- The initial setting remains active until the user changes it.
- The Remote Controller can be used for multiple installations.
- Ensure the operation indicator is OFF before setting.
- The system may not work properly if set wrongly. Please consult an authorised dealer.

To display <Main Menu>: ⋮≡

To select menu: ▲ ▼ ◀ ▶

To confirm the selected content:





Menu	Default Setting	g Setting Options / Display		
1 Function setup 1.1 > Weekly timer				
Once the weekly timer is set up, User can edit from Quick Menu. To set up to 6 patterns of operation on a weekly basis.  • Disabled if Heat-Cool SW is pressed or if Force Heater is on.	set the par (Time / Operation	of the week and tterns needed on ON/OFF / Mode) y of the week	Weekly timer	

IVI	enu	Default Setting	Setting Options / Disp	olay	
1.2	> Holiday timer				
	To save energy, a holiday period may be set to either turn OFF the system or lower the	OFF		OF: DN	
	temperature during the period.	Date	tart and end. and time red temperature	Holiday: End Year/Month/Day	19:34am, Mon Hour : Min 10 : 00 am
	Weekly timer setting may be ten but it will be restored once the h			Ç►Select	[_]Corilirni
1.3	> Quiet timer				
	To operate quietly during the preset period. 6 patterns may be set.		start Quiet : and time	Quiet Paltern Tim 1 800 2 5:00	am D
	Level 0 means the mode is off.		f quietness: ) ~ 3	3 11:00 <b>-Se</b> lect <b>[</b> -√16	ipm 3
1.4	> Room heater				
	To set the room heater ON or OFF.	OFF		OF:	
1.5	> Tank heater				
	To set the tank heater ON or OFF.	OFF		CF=	
	Available only if connected to the	ne tank.			
1.6	> Sterilization				
	To set the auto sterilization ON or OFF.	OFF		OF:	
	<ul> <li>Available only if connected to the Do not use the system during sets.</li> <li>Ask an authorised dealer to det regulations.</li> </ul>	terilization in order to pr	revent scalding with hot wate ilization function field setting	er, or overheating of s according to the lo	shower. ocal laws and
2	System check				
2.1					
	Present or historical chart of energy consumption, generation or COP.	Historical chart	and retrieve	Total consumption (	1year)
	COP= Coefficient of Performan     For historical chart, the period is     Energy consumption (kWh) of h     The total power consumption is differ from value measured by p	ce. s selected from 1 day/1 neating,*1 cooling, tank an estimated value bas	and total may be retrieved	11year 1 1 2 3 1 4 1 5 1 6 1 Jan, 2015: 0.0 ◆Month \$Mode	7   8   9   10   11   12   <b>6Mth</b> D kWh Approx.
2.2	> Water temperatures				
	Shows all water temperatures in each area.	Actual water temperature of 8 items: Inlet / Outlet / Zone 1 / Zone 2 / Tank / Buffer tank / Solar / Pool  Select and retrieve		Water temperatures  1. Inlet 2. Outlet 3. Zone 1 4. Zone 2  Page	10:34am, Mon : 0°C : 0°C : 0°C

Me	enu	Default Setting	Setting Options / Dis	splay	
2.3	> Error history				
2.0	Refer to Troubleshooting for error codes. The most recent error code is displayed at the top.	Select a	and retrieve	1 2 3 4 [-] Clear history	10c3Ham, Mon
2.4	> Compressor				
	Shows the compressor performance.	Select a	and retrieve	Compressor  1. Current frequency 2. (OFF-ON) counter 3. Total ON time   □ Back	
2.5	> Heater				
	Total hours of ON time for Room heater/Tank heater.	Select a	and retrieve	Heater  Total ON time	10:34am, Mon : 0h : 0h
_	D I (				
3	Personal setup > Touch sound				
3.1	Turns the operation sound ON/OFF.	ON		ON V OFF	I
3.2	> LCD contrast				
	Sets the screen contrast.	3		Low	High
3.3	> Backlight				
	Sets the duration of screen backlight.	1 min		Barklight  OFF  15 secs  1 min  *Select [□]Oc	10:30am, Mon 5 mins 10 mins
3.4	> Backlight intensity				
	Sets screen backlight brightness.	4		Dark   L+J C	Hright
3.5	> Clock format				
	Sets the type of clock display.	24h		Clock format  /4h  **m/pm  **Select [⊷]Co	10:34am, Mon

Me	enu	Default Setting	Setting Options /	Display	
3.6	> Date & Time				
	Sets the present date and time.	Year / Month	/ Day / Hour / Min	Cate & Time  Year/Month/Day  2015 / D1 / D7  ⇒ Select	10:34am, Mn Hour : Min 10 : 00 am [44] Confirm
3.7	> Language				
	Sets the display language for the top screen.  • For Dutch, Greek, Finnish and Turkish, please refer to the English version.	ENGLISH / FRANÇAIS / DEUTSCH / ITALIANO / ESPAÑOL / DANISH / SWEDISH / NORWEGIAN / POLISH / CZECH		ENGLISH FRANÇAIS DEUTSCH ITALIANO	10:34am, Mo
3.8	> Unlock password				
	4 digit password for all the settings.	0000		<b>~</b>	10:34am, Mo
				<del>-</del>	
4	Service contact				
4.1	> Contact 1 / Contact 2				
	Preset contact number for installer.	Select and retrieve		Service setup Contact 1 Name : Bryan Ar T : 0681234  Select	

#### 4.1.5 **Menus For installer**

Menu	Default Setting	Setting Options / Display					
	5 Installer setup > System setup						
5.1 > Optional PCB connectivity							
To connect to the external PCB required for servicing.	No	Y IS W					

- If the external PCB is connected (optional), the system will have following additional functions:
- Buffer tank connection and control over its function and temperature.
  Control over 2 zones (including the swimming pool and the function to heat water in it).
  Solar function (the solar thermal panels connected to either the DHW (Domestic Hot Water) Tank or the Buffer Tank.
  External compressor switch.
  Signed control.

- 7 Demand control.

  8 Heat-Cool SW

	8 Heat-Cool SW				
5.2 >	Zone & Sensor				
To	select the sensors and to	Zone		Zone & Serson	10c3Mam, Mnn
	lect either 1 zone or 2 zone stem.	<ul> <li>After selecting 1 or 2 the selection of room</li> <li>If the swimming pool temperature must be \(\triangle T\) temperature beto</li> </ul>	is selected, the selected for	Zone System 2 Zones System 2 Zones System  Select I  Confirm	
		Sensor		Zone & Sensor	10:34am, Mon
		* For room thermostat selection of external		Room t Room t	mperature hermostat hermistor [] Confirm
5.3	Heater capacity				
	reduce the heater power if inecessary.*  3 kW / 6 kW / 9 kW	3	3 kW	_	10:34am,Mon
	Options of kW vary lepending on the model.	or 9 kW*		g	kW [] Confirm
5.4 >	Anti freezing				
wa	activate or deactivate the ater freeze prevention when a system is OFF.	Yes			<u>~</u> √
5.5 >	> Tank connection				
To	connect tank to the system.	No			es A
5.6 >	Buffer tank connection				
an	connect tank to the system	No			es A
△T temperature. • The optional PCB		> Yes			
ci Y • If ci th	reconnectivity must be selected /ES to enable the function. If the optional PCB connectivity is not selected, the function will not appear on the display.	5 °C	Set △T for Buffer Tank	Buffer Tank  ΔT for Buffer Ta  Range: (0°C~10°  Steps: ±1°C  \$Select	

Me	enu	Default Setting	Setting Options / Dis	splay	
5.7	> Tank heater				
	To select external or internal tank heater and if External is selected, set a timer for the heater to come on.  * This option is available if	Internal		Exter Exter Inter	
	Tank connection is selected (YES).	> External			
	(TES).	0:20	Tank heater ON time set.	Tank heater: CN til Range: (0:20~3:00 Steps: 40:05	
5.8	> Base pan heater			¥	
	To select whether or not optional base pan heater is	No		Yes No	
	connected.	> Yes			
	*Type A -The base pan heater activates only during deice operation.  *Type B-The base pan heater activates when outdoor ambient temperature is 5 °C or lower.	A	Set base pan heater type*.	Base pan heater tyr  A B  Select [=-	
5.9	> Alternative outdoor sensor				
	To select an alternative outdoor sensor.	No		Yes No	
5.10	> Bivalent connection				
	To select a bivalent connection to allow an additional heat	No		Yes No	
	source such as a boiler to	> Yes			
	heat-up the buffer tank and domestic hot water tank when heatpump capacity is insufficient at low outdoor temperature. The bivalent	-5 °C	Set outdoor temperature for turn ON Bivalent connection.	Hivalent connection form ON: Cutdoor t Hange: (-15°C-35°C) Steps: ±1°C	emp ) -\$-rc
	feature can be set-up either in alternative mode (heatpump	Voc \ After colocting	the outdoor temperature		Confirm
	and boiler operate alternately),	Control pattern	g the outdoor temperature	<b>G</b>	
	or in parallel mode (both	•	lel / Advanced parallel	Hivalent connection	10c3Mam. Mno
	heatpump and boiler operate simultaneously), or in advance parallel mode (heatpump operates and boiler turns on for buffer-tank and/or domestic hot water depending on the control pattern setting options).	Alternative / Parallel / Advanced parallel     Select advanced parallel for bivalent use of the tanks.		Control pattern Alterna Parall Advanced	tive el

Menu	Default Setting	Setting Options / Dis	play
	Control pattern > Ad	Ivanced parallel	
	Heat	Selection of the tank	Hivalent connection 10:34am, Mon
		Tank and "DHW" implies	Advanced parallel    Heat     DHW    Select   [] Confirm
	Control pattern > Ad		
	• Buffer Tank is activated only after selecting "Yes".		Hivalent connection 10k34am, Mon Advanced parallel: Heat Yes No Jelect [44] Confirm
			Bivalent connection 10:34am, Mon
	-8 °C	Set the temperature threshold to start the bivalent heat source.	Heat start: Target temp.  Range: (-10°C~0°C)  Steps: ±1°C  -8 °C
			\$Select [] Confirm
	0:30	Delay timer to start the bivalent heat source (in hour and minutes).	Bivalent connection 10:34am, Mon Heat start: Delay time Range: (0:00-1:30) Steps: 40:05
		(iii iiodi dila iiiiidtoo).	\$Select [+]Confirm
	-2 °C	Set the temperature threshold to stop the bivalent heat source.	Bivalent connection 10:34am, Mon Heat stop: Target temp. Range: (-10°C-0°C) Steps: ±1°C  \$\_2\circ\$C
			Hivalent connection 10:34am, Mon
	0:30	Delay timer to stop the bivalent heat source (in hour and minutes).	Heat stop: Belay time Hange: (0:00-1:30) Steps: ±0:05
			\$Select [⊿]Confirm
	Control pattern > Ad	Ivanced parallel > DHW > '	
	DHW Tank is activate     "Yes".	ed only after selecting	Hivalent connection 10k34am, Mon Advanced parallel: DHW Yes No  _Select [] Confirm
	0:30	Delay timer to start the bivalent heat source (in hour and minutes).	Bivalent connection 10:34am, Mon DHW: Delay time Range: (0:30~1:30) Steps: ±0:05  \$\times\$ Select [\times] Confirm

Menu	Default Setting	Setting Options / Dis	play		
5.11 > External SW					
	No		Yes No		
5.12 > Solar connection					
The optional PCB connectivity must be selected	No		Yes A No		
YES to enable the function.	> Yes				
<ul> <li>If the optional PCB connectivity is not selected, the function will not appear on the display.</li> </ul>	Buffer tank	Selection of the tank	Solar connection 10k34:	am, Mnn	
, ,			DHW tank		
			_Select (⊶) Confirm		
	> Yes > After selection	ng the tank			
	10 °C	Set △T ON temperature	Solar connection 10:34s ΔT Turn ON Range: (6°C~15°C)	am, Mon	
			Steps: ±1°C	10 °C	
			*		
	> Yes> After selecting the tank> △T ON temperature				
		Set △T OFF temperature	Solar connection 10:34	am, Mon	
	5 °C		Range: (2°C~9°C) Steps: ±1°C	<b>5</b> ℃	
			\$Select [₄-]Confirm		
	> Yes > After selection	ng the tank>△T ON temp	erature > △T OFF temperat	ure	
		Set Antifreeze temperature	Solar connection 10:34	am, Mon	
			Anti freeze		
	5°C		Range: (-20°C~10°C) Steps: ±1°C	<b>5</b> ℃	
			\$Select [←]Confirm		
	> Yes > After selecting the tank > △T ON temperature > △T OFF temperature > After setting the antifreeze temperature				
	80 °C	Set Hi limit	Solar connection 100346 Hi limit	am, Mnn	
			Hange: (70°C-90°C) Steps: ±5°C	g <mark>o</mark> c	
			\$Select [₽] Confirm		

5.13 > External error signal  No  5.14 > Demand control  No  5.15 > SG ready  No  > Yes  120 %  5.16 > External compressor SW  No  5.17 > Circulation liquid  To select whether to circulate			Yes A No	
5.14 > Demand control  No  5.15 > SG ready  No  > Yes  120 %  5.16 > External compressor SW  No  5.17 > Circulation liquid				
No  5.15 → SG ready  No  No  Yes  120 %  5.16 → External compressor SW  No  5.17 → Circulation liquid				
5.15 > SG ready  No  Yes  120 %  5.16 > External compressor SW  No  5.17 > Circulation liquid				
No  > Yes  120 %  5.16 > External compressor SW  No  5.17 > Circulation liquid			Yes No	
5.16 > External compressor SW  No  5.17 > Circulation liquid				
5.16 > External compressor SW  No  5.17 > Circulation liquid			Yes No	
5.16 > External compressor SW  No  5.17 > Circulation liquid				
No 5.17 > Circulation liquid	Capacity ( Buffer Tan Tank (in %	ik and DHW Range: (1 Sirps: ±!	[1-0]: DHW 50%150%) 5% 120%	
No 5.17 > Circulation liquid		\$ Select	[] Confirm	
•			Yes No	
To coloct whother to circulate				
water or glycol in the system.  Water		Circulatio	n liquid 10:34am, Mon Water Glycol	
		_Select	[44] Confirm	
5.18 > Heat-Cool SW				
No			Yes No	
5.19 > Force Heater				
To select use Auto turn ON force heater mode or Manual force heater mode. Manual		Force hea	Force heater 10:34am,Mor	
		^Select	[+-] Confirm	
6 Installer octup > Oraștian actus				
6 Installer setup > Operation setup  To access to the four major	4 main modes  Heat / *1, *2 Cool / Auto / Tank		setup 12500am, Mon	
functions or modes.				

 $^{\star}2$  Only displayed when COOL mode is unlocked (This means when COOL mode is available).

<sup>\*1</sup> The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised serviceartners.

Menu	Default Setting	Setting Options / Dis	splay			
Installer setup > Operation se	tup					
6.1 > Heat						
To set various water & ambient temperatures for heating.	Water temp. for heating ON / Outdoor temp. for heating OFF / △T for heating ON / Outdoor temp. for heater ON		Operation setup 10c34am, Mor Heat Water temp. for heating ON Outdoor temp. for heating OFF A1 for heating ON -Select [] Continu			
	> Water temp. for he	> Water temp. for heating ON				
	Compensation curve	Heating ON temperatures in compensation curve or direct input.	Operation setup 146:94am, Mon Heat ON: Water temp. Compensation curve Direct  _Select [+] Confirm			
	> Water temp, for he	eating ON > Compensation				
	X axis: -5 °C, 15 °C Y axis: 55 °C, 35 °C	Input the 4 temperature points (2 on horizontal X axis, 2 on vertical Y axis).	Heat ON: Water temps /one1			
	<ul> <li>Temperature range: X axis: -15 °C ~ 15 °C, Y axis: See below</li> <li>Temperature range for the Y axis input depends on the model: <ol> <li>WH-SDC model: 20°C ~ 55°C</li> <li>WH-SHF model &amp; Back up heater is enabled: 25°C ~ 65°C</li> <li>WH-SHF model &amp; Back up heater is disabled: 35°C ~ 65°C</li> <li>WH-SXC model: 20°C ~ 60°C</li> <li>If 2 zone system is selected, the 4 temperature points must also be input for Zone 2.</li> <li>"Zone 1" and "Zone 2" will not appear on the display if only 1 zone system.</li> </ol> </li> </ul>					
	> Water temp. for heating ON > Direct					
	35 °C	Temperature for heating ON	Operation setup 10:34am, Mon Heat ON: Water temp.: Zone2 Range: (20°C~55°C) Steps: ±1°C  \$\_{\text{Select}} \text{Confirm}			
	• Min. ~ Max. range is conditional as follows:  1. WH-SDC model: 20°C ~ 55°C  2. WH-SHF model & Back up heater is enabled: 25°C ~ 65°C  3. WH-SHF model & Back up heater is disabled: 35°C ~ 65°C  4. WH-SXC model: 20°C ~ 60°C					
	> Outdoor temp. for heating OFF					
	24 °C	Temperature for heating OFF	Operation setup 10:34am, Mon Heat OFF: Outdoor temp. Range: (5°C~35°C) Steps: ±1°C  \$\_{\text{Select}} \text{[4-] Confirm}			

Menu	Default Setting	Setting Options / Dis	splay	
	> △T for heating ON			
	5 °C	Set △T for heating ON.	Operation setup Heat ON: ΔT Range: (1°C~15°C) Steps: ±1°C	10:34am, Mon
			\$Select [+	-]Confirm
	> Outdoor temp. for	r heater ON		
	0 °C	Temperature for heater ON	Operation setup  Heater ON: Outdo  Range: (-15°C~20°  Steps: ±1°C	
			\$Select [+	-]Confirm
6.2 > *1, *2 Cool				
To set various water & ambient temperatures for cooling.	Water temperatures for cooling ON and $\triangle T$ for cooling ON.		Operation setup  Cool  Water temps for o  AT for cooling of	
			"Select [-	u] Continn
	> Water temp. for co	> Water temp. for cooling ON		
	Compensation curve	Cooling ON temperatures in compensation curve or direct input.	Operation setup 10c3Mam, Mor Cool ON: Water temp. Compensation curve Direct  Select [] Confirm	
	> Water temp. for cooling ON > Compensation curve			
	X axis: 20 °C, 30 °C Y axis: 15 °C, 10 °C	Input the 4 temperature points (2 on horizontal X axis, 2 on vertical Y axis)	Cool DN: Water to   15°C	
	• If 2 zone system is selected, the 4 temperature points must also be input for Zone 2. • "Zone 1" and "Zone 2" will not appear on the display if only 1 zone system.			
	> Water temp. for cooling ON > Direct			
	10 °C	Set temperature for Cooling ON	Operation setup  Cool ON: Water te  Range: (5°C~20°C)  Steps: ±1°C	•
	>△T for cooling ON			
	5 °C	Set △T for cooling ON	Operation setup  Cool ON: $\Delta T$ Range: (1°C~15°C)  Steps: ±1°C	<b>5</b> ℃
			\$Select [+	-]Confirm

<sup>\*1</sup> The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised serviceartners.


 $<sup>^{*}2\,</sup>$  Only displayed when COOL mode is unlocked (This means when COOL mode is available).


Me	nu	Default Setting	Setting Options / Dis	play	
6.3	> Auto				
	Automatic switch from Heat to Cool or Cool to Heat.	Outdoor temperatures for switching from Heat to Cool or Cool to Heat.		Operation setup Auto	10:34am, Mnn
			for (Heat to Cool) / . for (Cool to Heat)	Outdoor temp. for Outdoor temp. for	(Conl to Heat)
		> 0 (de (e fe .	(1111-01)	_Select [↔]	Confirm
		> Outdoor temp. for	(Heat to Cool)		40.04
		15 °C	Set outdoor temperature for switching from Heat to Cool.	Operation setup Auto: Outdoor temp Range: (11°C~25°C) Steps: ±1°C	15 °c
				\$Select [←]	Confirm
		> Outdoor temp. for	(Cool to Heat)		
		10 °C	Set outdoor temperature for switching from Cool to Heat.	Operation setup Auto: Outdoor temp Range: (5°C~14°C) Steps: ±1°C	10:34am, Mon o.(Cool to Heat)
				\$Select [←]	Confirm
6.4	> Tank				
	Setting functions for the tank.  • Available only if connected to the tank.	Floor operation time (max) / Tank heat up time (max) / Tank re-heat temp. / Sterilization		Operation setup Tank Floor operation (17 Tank heat up time Tank re-heat temp	(так)
		The display will also	2 f	"Sefect [a-]	Confirm
		. ,	v 3 functions at a time.		
		> Floor operation tin	ne (max)		
		8:00	Maximum time for floor operation (in hours and minutes)	Operation setup Lank: Floor ope, tir Hange: (0:30-10:00 Steps: ±0:30	
				‡Select [⊷]	Confirm
		> Tank heat up time	(max)		
1		1:00	Maximum time for heating the tank (in hours and minutes)	Operation setup Lank: Heat up time Range: (0:05-4:00) Steps: +0:05	
			(	‡Selact [- 4	Continu
		> Tank re-heat temp		+2-mar. 1-1	
	-8 °C		Set temperature to perform reboil of tank	Operation setup Lank: Re-heat temp Range: (-12°C2°C) Steps: +1°C	
			water.	‡Select [•1	Continu

Menu	Default Setting	Setting Options / Dis	splay	
	> Sterilization			
	Sterilization may be set for 1 or more days of the week.		Operation setup Sterilization: Day	10:34am, Mnn
	Sun / Mon / Tue / Wed / Thu / Fri / Sat		Sun Mon Tue ¥ed - ✓ 1•Day ‡☑/⊡	Thu Fri Sat  — — —
	> Sterilization: Time	)	-	
	Time of the selected day(s) of the week to sterilize the tank.		Operation setup Sterilization: Lime	10:34am, Mnn
	0:00	0:00 ~ 23:59		() am
			⊅ Select [⊷]	Confirm
	> Sterilization: Boili	ng temp.		
		Cat hailing tamparatures	Operation setup Sterilization: Boilin	
	65 °C	Set boiling temperatures for sterilize the tank.	Range: (55°C~75°C) Steps: ±1°C	65 °C
			\$ Select [←]	Confirm
	> Sterilization: Ope. time (max)  Set sterilizing time (in hours and minutes)			
			Operation setup Sterilization: Ope. t	10:34am, Mon
			Range: (0:05~1:00) Steps: ±0:05	
			\$Select [←]	Confirm
7 1 (1) ( .0 '				
7 Installer setup > Service se 7.1 > Pump maximum speed	tup			
To set the maximum speed of		, max. duty and operation	Service setup	10:34am, Mon
the pump.	ON/OFF of the pump.  Flow rate: XX:X L/min Max. Duty: 0x40 ~ 0xFE, Pump: ON/OFF/Air Purge  Pump down operation  ON		Flow rate Max. D	uty Operation
			0.0 L/min 0xCl	Air Purge
7.2 \ D da			4 Select	
7.2 > Pump down			Canada anton	445-18 17
To set the pump down operation.			Pi Pump down o	ress!
			(t)]u	

Menu	Default Setting	Setting Options / Dis	splay	
Installer setup > Service setup				
7.3 > Dry concrete				
To dry the concrete (floor, walls, etc.) during construction.	Edit to set the temperature of dry concrete.		Service setup Dry concrete ON	10:34am,Mor
Do not use this menu for any other purposes and in period	AO NO	I / Edit	Edit	
other than during			Select [₄-] Confirm	
construction.	> Edit			
	Stages: 1 Temperature: 25 °C	Heating temperature for drying the concrete. Select the desired stages: 1 ~ 10,	Dry concrete: 1/10 Range: (25°C~55°C) Steps: ±1°C	10:34am, Mor
		range: 1 ~ 99	^Select [←]	Confirm
	> ON			
	Confirm the settin	g temperatures of dry	Service setup  Dry concrete: Status	10:34am, Mor
	concrete for each stage.		Stage Water set temp. Actual water temp.  [①] OFF	: 1/10 : 25°C :25°C/25°C
.4 > Service contact				
To set up to 2 contact names and numbers for the User.	Service engineer's name and contact nur		Service setup Service contact: Contac	10c34am, Mnd
	Contact 1 / Contact 2		Contac	12
	> Contact 1 / Contact	w ?	,Select [⊷]	Confirm
	_		Service contact	10:34am, Mor
	Contact na	me or number.	Contact 1 Name : Bryan Ar	·
	Name /	phone icon	<b>₹</b> : 0681234 _Select (+4)	5878
	Input name and number.		Contact-1  ABC/alx ( ABCDEFGHIJKLM STUWWXY7 above	19/Other INOPGR <u>Space</u> Lefgh I BS
	Contact name: alphabet a ~ z. Contact number: 1 ~ 9		Number: 2 3 4 5 6 7 8 9 9 0 8	Emfer ( i ) Has


## 4.1.6 Main Components






- 1 Cabinet front plate
- 2 Cabinet side plate (2 pieces)
- (3) Remote controller
- 4 PCB
- (5-1) 3 Phase RCCB/ELCB (Main Power)
- Single Phase RCCB/ELCB (Booster Heater) for S\*C09\*3E8
  3 Phase RCCB/ELCB for S\*C12\*9E8,
  S\*C16\*9E8
- 6 Control board cover
- Ontrol board
- (8) Flow sensor
- Air purge valve
- 10 Backup heater
- ① Overload protector (4 pieces)
- (12) Expansion vessel
- (13) Pressure relief valve
- (14) Water pressure gauge
- 15 Water filter
- 16 Water pump

# 4.2 Outdoor Unit




# 5. Dimensions


# 5.1 Indoor Unit



# 5.2 Outdoor Unit



# 6. Refrigeration and Water Cycle Diagram



<sup>→</sup> Refrigerant Cycle (Heating)

<sup>- - - ►</sup> Refrigerant Cycle (Cooling)


Model	Piping	g size	Rated Le	ength (m)	Max	Min. Piping	Max. Piping	Additional
UX09*E5*, UX12*E5*, UD12*E5*, UD16*E5*, UX09*E8*,	Gas	Liquid	For Heat Pump Indoor Unit	For Hydromodule + Tank	Elevation (m)	. •	Length (m)	Refrigerant (g/m)
UX12*E8*, UX16*E8*, UD09*E8*, UD12*E8*, UD16*E8*	Ø15.88 mm (5/8")	Ø9.52 mm (3/8")	7	5	20	3	30	50

## Example:


If piping length is 30m, the quantity of additional refrigerant should be 1000g. [(30-10)m x 50 g/m = 1000g] GWP (R410A) = 2088

<sup>──</sup> Water Cycle

# 6.1 Standard System (Optional PCB not connected)




# 6.2 Advance System (Optional PCB connected)




# 7. Block Diagram

# 7.1 WH-SDC09H3E8 WH-UD09HE8




# 7.2 WH-SDC12H9E8 WH-UD12HE8 WH-SDC16H9E8 WH-UD16HE8




# 8. Wiring Connection Diagram

## 8.1 Indoor Unit


### 8.1.1 WH-SDC09H3E8



### 8.1.2 WH-SDC12H9E8 WH-SDC16H9E8




# 8.2 Outdoor Unit




# 9. Electronic Circuit Diagram

# 9.1 Indoor Unit


## 9.1.1 WH-SDC09H3E8



### 9.1.2 WH-SDC12H9E8 WH-SDC16H9E8




# 9.2 Outdoor Unit




# 10. Printed Circuit Board

# 10.1 Indoor Unit

## 10.1.1 Main Printed Circuit Board




# 10.1.2 Sub Printed Circuit Board (Optional)




# 10.2 Outdoor Unit

## 10.2.1 Main Printed Circuit Board



# 10.2.2 Noise Filter Printed Circuit Board




## 11. Installation Instruction

#### 11.1 Indoor Unit


#### 11.1.1 Select the Best Location

- There should not be any heat source or steam near the unit.
- A place where air circulation in the room is good.
- A place where drainage can be easily done.
- A place where noise prevention is taken into consideration.
- Do not install the unit near the door way.
- Ensure the spaces indicated by arrows from the wall, ceiling, fence or other obstacles.
- Recommended installation height for indoor unit shall be at least 800 mm.
- Must install on a vertical wall.
- When install electrical equipment at wooden building of metal lath or wire lath, according to electrical facility technical standard, no electrical contact between equipment and building is allowed. Insulator must be installed in between.
- Do not install the unit at outdoor. This is designed for indoor installation only.



## 11.1.2 How To Fix Installation Plate

The mounting wall is strong and solid enough to prevent it from vibration.



The centre of installation plate should be at more than 375 mm at right and left of the wall.

The distance from installation plate edge to ground should more than 1556 mm.

- Always mount the installation plate horizontally plate by aligning the marking thread and using a level gauge.
- Mount the installation plate on the wall with 6 sets of plug, bolt and washer (all non-supply) with size M8.

# 11.1.3 To Drill A Hole In The Wall And Install A Sleeve Of Piping


- 1. Insert the piping sleeve to the hole.
- 2. Fix the bushing to the sleeve.
- 3. Cut the sleeve until it extrudes about 15 mm from the wall.

## **CAUTION**



When the wall is hollow, please be sure to use the sleeve for tube assembly to prevent dangers caused by mice biting the connection cable.

4. Finish by sealing the sleeve with putty or caulking compound at the final stage.



#### 11.1.4 Indoor Unit Installation

### 11.1.4.1 Access to Internal Components


#### **№** WARNING

This section is for authorized and licensed electrician/water system installer only. Work behind the front plate secured by screws must only be carried out under supervision of qualified contractor, installation engineer or service person.

Please follow the steps below for take out front plate. Before removing the front plate of indoor unit, always switch off all power supply (i.e. indoor unit power supply, heater power supply and Tank Unit power supply).


1. Remove the 2 mounting screws which located at bottom of the front plate.

- 2. Gently pull the lower section of the front plate towards you to remove the front plate from left and right hooks.
- 3. Hold the left edge and right edge of front plate to lift up front plate from hooks.



## 11.1.4.2 Install the indoor unit


- Engage the slots on the indoor unit to the hooks of installation plate . Ensure the hooks are properly seated on the installation plate by moving it left and right.
- 2. Fix the screws 5 to the holes on the hooks of installation plate 4, as illustrated below.




## 11.1.4.3 Water Piping Installation

- The minimum requirement of water in the system is 50 litres. If this value could not be achieved, please install additional buffer tank (field supply).
- Water inlet and water outlet in indoor unit are used for connection to water circuit. Please request a licensed technician to install this water circuit.

- This water circuit must comply with all relevant European and national regulations, i.e. IEC/EN 61770.
- Be careful not to deform the piping to excessive force when doing piping connection job.
- Use Rp 1 ¼" nut for both water inlet and outlet connection and clean all pipings with tap water before connecting to the indoor unit.
- Cover the pipe end to prevent dirt and dust when inserting it through a wall.
- Choose proper sealer which can withstand the pressures and temperatures of the system.
- If an existing tank is to be connected to this indoor unit, ensure the pipes are clean before water pipe installation is carried out.
- Be sure to use two spanners to tighten the connection. Tighten the nuts with torque wrench: 117.6N•m.



- If non-brass metallic piping is used for installation, make sure to insulate the pipes to prevent galvanic corrosion.
- Make sure to insulate the water circuit pipes to prevent reduction of heating capacity.
- After installation, check the water leakage condition in connection area during test run.




#### / CAUTION


Do not over tighten, over tightening cause water leakage.

## 11.1.4.4 Refrigerant Pipe Installation

- Please make flare after inserting flare nut (located at joint portion of tube assembly) onto the copper pipe. (In case of using long piping)
- 2 Do not use pipe wrench to open refrigerant piping. Flare nut may be broken and cause leakage. Use proper spanner or ring wrench.
- 3 Connect the piping:
  - Align the center of piping and sufficiently tighten the flare nut with fingers.
  - Be sure to use two spanners to tighten the connection.
    - Further tighten the flare nut with torque wrench in specified torque as stated in the table.



Piping size (Torque)		
Gas	Liquid	
ø15.88 mm (5/8") [65 N•m]	Ø9.52 mm (3/8") [42 N•m]	



#### CAUTION

Do not over tighten, over tightening cause water leakage.

#### **CAUTION**

Please take extra precaution when open the control board cover and control board for indoor unit installation and servicing. Failure to do so may cause injury.

#### **CUTTING AND FLARING THE PIPING**

- Please cut using pipe cutter and then remove the burrs
- Remove the burrs by using reamer. If burrs is not removed, gas leakage may be caused. Turn the piping end down to avoid the metal powder entering the pipe.
- 3. Please make flare after inserting the flare nut onto the copper pipes.






When properly flared, the internal surface of the flare will evenly shine and be of even thickness. Since the flare part comes into contact with the connections, carefully check the flare finish.

## 11.1.4.5 Drain Elbow and Hose Installation


- Fix the drain elbow 2 and packing 3 to the bottom of indoor unit, as shown in below illustration.
- Use inner diameter 17 mm drain hose in the market.
- This hose must to be installed in a continuously downward direction and in a frost-free environment.
- Guides this hose's outlet to outdoor only.
- Do not insert this hose into sewage or drain pipe that may generate ammonia gas, sulfuric gas, etc.

- If necessary, use hose clamp to further tighten the hose at drain hose connector to prevent leakage.
- Water will drip from this hose, therefore the outlet of this hose must be installed in an area where the outlet cannot become blocked.



# 11.1.4.6 Pressure Relief Valve Drainage Pipework

- Connect a drain hose to the pressure relief valve hose outlet.
- This hose must to be installed in a continuously downward direction and in a frost-free environment.
- Guides this hose's outlet to outdoor only.
- Do not insert this hose into sewage hose or cleaning hose that may generate ammonia gas, sulfuric gas, etc.
- If necessary, use hose clamp to further tighten the hose at drain hose connector to prevent leakage.
- Water will drip from this hose, therefore the outlet of this hose must be installed in an area where the outlet cannot become blocked.



# 11.1.5 Connect The Cable To The Indoor Unit


#### 

This section is for authorised and licensed electrician only. Work behind the Control Board Cover (6) secured by screws must only be carried out under supervision of qualified contractor, installation engineer or service person.

# 11.1.5.1 Open the Control Board Cover

Please follow the steps below to open control board cover. Before opening the control board cover of indoor unit, always switch off all power supply (i.e. indoor unit power supply, heater power supply and Tank Unit power supply).

- Remove the 6 mounting screws at the control board cover.
- Swing the control board cover to the right hand side.



# 11.1.5.2 Fixing of Power Supply Cord and Connecting Cable

- Connecting cable between Indoor Unit and Outdoor Unit shall be approved polychloroprene sheathed 4 × 1.5 mm<sup>2</sup> flexible cord, type designation 60245 IEC 57 or heavier cord.
  - Ensure the colour of wires of Outdoor Unit and the terminal no. are the same to the Indoor Unit respectively.
  - Earth wire shall be longer than other wires as shown in the figure for the electrical safety in case of the slipping out of the cord from the Holder (Clamper).
- 2. An isolating device must be connected to the power supply cable.
  - Isolating device (disconnecting means) should have minimum 3.0 mm contact gap.
  - Connect the approved polychloroprene sheathed power supply 1 cord and power supply 2 cord and type designation 60245 IEC 57 or heavier cord to the terminal board, and to the other end of the cord to isolating device (Disconnecting means). See below table for cable size requirement.

#### For model S\*C09\*3E8


Power Supply Cord	Cable Size	Isolating Devices	Recommended RCD
1	5 × minimum 1.5 mm <sup>2</sup>	20A	30mA, 4P, type A
2	3 × minimum 1.5 mm <sup>2</sup>	15/16A	30mA, 2P, type AC

#### For model S\*C12/16\*9E8


Power Supply Cord	Cable Size	Isolating Devices	Recommended RCD
1	5 × minimum 1.5 mm <sup>2</sup>	20A	30mA, 4P, type A
2	5 × minimum 1.5 mm <sup>2</sup>	20A	30mA, 4P, type AC


3. To avoid the cable and cord being damaged by sharp edges, the cable and cord must be passed through a bushing (located at the bottom of Control Board) before terminal board. The bushing must be used and must not be removed.

#### For model S\*C09\*3E8



#### For model S\*C12/16\*9E8






Terminal screw		Tightening torque cN•m {kgf•cm}		
	M4	157~196 {16~20}		
	M5	196~245 {20~25}		

<sup>\*1 -</sup> Earth wire must be longer than other cables for safety reasons

# 11.1.5.3 Wire Stripping and Connecting Requirement



### 11.1.5.4 Connecting Requirement

For S\*C09\*3E8

- The equipment's Power Supply 1 complies with IEC/EN 61000-3-2.
- The equipment's Power Supply 1 complies with IEC/EN 61000-3-3 and can be connected to current supply network.
- The equipment's Power Supply 2 complies with IEC/EN 61000-3-2.
- The equipment's Power Supply 2 complies with IEC/EN 61000-3-11 and shall be connected to suitable supply network, with the following maximum permissible system impedance  $Z_{\text{max}} = 0.426\Omega$  at the interface. Please liaise with supply authority to ensure that the Power Supply 2 is connected only to a supply of that impedance or less.

#### For S\*C12\*9E8/S\*C16\*9E8

- The equipment's Power Supply 1 complies with IEC/EN 61000-3-2.
- The equipment's Power Supply 1 complies with IEC/EN 61000-3-3 and can be connected to current supply network.
- The equipment's Power Supply 2 complies with IEC/EN 61000-3-2.
- The equipment's Power Supply 2 complies with IEC/EN 61000-3-3 and can be connected to current supply network.


# 11.1.6 Installation Of Remote Controller As Room Thermostat

 Remote Controller 3 mounted to the Indoor Unit can be moved to the room and serve as Room Thermostat.

#### 11.1.6.1 Installation Location

- Install at the height of 1 to 1.5 m from the floor (Location where average room temperature can be detected).
- Install vertically against the wall.
- Avoid the following locations for installation.
  - By the window, etc. exposed to direct sunlight or direct air.
  - In the shadow or backside of objects deviated from the room airflow.
  - Location where condensation occurs (The Remote Controller is not moisture proof or drip proof.)
  - 4. Location near heat source.
  - 5. Uneven surface.
- Keep distance of 1 m or more from the TV, radio and PC. (Cause of fuzzy image or noise)


### 11.1.6.2 Remote Controller Wiring




- Remote Controller cable shall be (2 × min 0.3 mm<sup>2</sup>), of double insulation PVC-sheathed or rubber sheathed cable. Total cable length shall be 50 m or less.
- Be careful not to connect cables to other terminals of Indoor Unit (e.g. power source wiring terminal).
   Malfunction may occur.
- Do not bundle together with the power source wiring or store in the same metal tube. Operation error may occur.

# 11.1.6.3 Remove The Remote Controller From Indoor Unit

Remove the top case from the bottom case.




 Remove the wiring between Remote controller and Indoor Unit terminal. Remove the bottom case from the Control board cover by loosening the screws. (3 pieces)



# 11.1.6.4 Mounting The Remote Controller


For exposed type

Preparation: Make 2 holes for screws using a driver.




For embedded type

**Preparation:** Make 2 holes for screws using a driver.




# 11.1.6.5 Replace The Remote Controller Cover

- Replace the existing Remote controller cover with Remote controller cover 6 to close the hole left after remove the Remote controller.
- 1. Release the Remote controller cover's hooks from behind the front plate.




Press from front to fix the Remote controller cover
 on the front plate.




## 11.1.7 Charging The Water

- Make sure all the piping installations are properly done before carry out below steps.
- Turn the plug on the Air Purge Valve <sup>(9)</sup> outlet anticlockwise by one complete turn from fully closed position.



2. Set the Pressure Relief Valve (13) level "DOWN".



- Start filling water (with pressure more than 0.1 MPa (1 bar)) to the Indoor Unit via water inlet.
   Stop filling water if the free water flow through Pressure Relief Valve drain hose.
- 4. Turn ON the power supply and make sure Water Pump (6) is running.
- 5. Check and make sure no water leaking at the tube connecting points.

#### 11.1.8 Reconfirmation

### ♠ WARNING

Be sure to switch off all power supply before performing each of the below checkings. Before obtaining access to terminals, all supply circuits must be disconnected.

#### 11.1.8.1 Check Water Pressure

\*(0.1 MPa = 1 bar)

Water pressure should not lower than 0.05 MPa (with inspects the Water Pressure Gauge (4)). If necessary add tap water into Tank Unit. Refer to Tank unit installation instruction for details on how to add water.

#### 11.1.8.2 Check Pressure Relief Valve 13

- If you do not hear a clacking sound (due to water drainage), contact your local authorized dealer.
- Push down the lever after finish checking.
- In case the water keeps drained out from the unit, switch off the system, and then contact your local authorized dealer.

## 11.1.8.3 Check RCCB/ELCB

Ensure the RCCB/ELCB set to "ON" condition before check RCCB/ ELCB.

Turn on the power supply to the Indoor Unit. This testing could only be done when power is supplied to the Indoor Unit.

#### **⚠** WARNING

Be careful not to touch parts other than RCCB/ELCB test button when the power is supplied to Indoor Unit. Else, electrical shock may happen. Before obtaining access to terminals, all supply circuits must be disconnected.

 Push the "TEST" button on the RCCB/ELCB. The lever would turn down and indicate "0", if it functions normal.

- Contact authorized dealer if the RCCB/ELCB malfunction.
- Turn off the power supply to the Indoor Unit.
- If RCCB/ELCB functions normal, set the lever to "ON" again after testing finish.

This product contains fluorinated greenhouse gasses. Refrigerant type: R410A (GWP=2088)

Amount: For SXC09\*3E8/SXC12\*9E8 2.85 kg (5.9508

ton CO2 equivalent)

For SXC16\*9E8 2.90 kg (6.0552 ton CO2

equivalent)

For SDC09\*3E8/SDC12\*9E8/SDC16\*9E8

2.55kg (5.3244 ton CO<sub>2</sub> equivalent)

(The amount do not include the additional refrigerant when refrigerating piping length extended. Please refer to adhered label on outdoor unit for exact amount of refrigerant used and actual tonnes of CO<sub>2</sub> equivalent.)


#### 11.1.9 Test Run

- Fill up the Tank Unit with water. For details refer to Tank Unit installation instruction and operation instruction.
- 2. Set ON to the Indoor Unit and RCCB/ELCB. Then, for control panel operation please refers to air-to-water heatpump operation instruction.
- 3. For normal operation, pressure gauge (1) reading should be in between 0.05 MPa and 0.3 MPa.
- 4. After test run, please clean the Water Filter Set 15. Reinstall it after finish cleaning.

## 11.1.9.1 Reset Overload Protector ①

Overload Protector ① serves the safety purpose to prevent the water over heating. When the Overload Protector ① trip at high water temperature, take below steps to reset it.

- 1. Take out the cover.
- 2. Use a test pen to push the centre button gently in order to reset the Overload Protector ①.
- 3. Fix the cover to the original fixing condition.



Use test pen to push this button for reset Overload protector (11).

### 11.1.10 Maintenance

 In order to ensure safety and optimal performance of the unit, seasonal inspections on the unit, functional check of RCCB/ELCB, field wiring and piping have to be carried out at regular intervals. This maintenance should be carried out by authorized dealer. Contact dealer for scheduled inspection.

# 11.1.10.1 Maintenance for Water Filter Set (5)

- 1. Turn OFF power supply.
- 2. Set the two valves for the Water Filter Set (5) to "CLOSE".
- 3. Take off the clip, then gently pull out the mesh. Beware of small amount water drain out from it.
- 4. Clean the mesh with warm water to remove all the stain. Use soft brush if necessary.
- 5. Reinstall the mesh to the Water Filter Set (15) and set back the clip on it.
- 6. Set the two valves for the Water Filter Set (15) to "OPEN".
- 7. Turn ON power supply.

### 11.1.10.2 Check Items

	Is there any gas leakage at flare nut connections?
	Has the heat insulation been carried out at flare nut connection?
	Is the connecting cable fixed to terminal board firmly?
	Is the connecting cable clamped firmly?
	Is the earth wire connection properly done?
	Is water pressure higher than 0.05 MPa?
	Is the pressure relief valve (3) operation normal?
	Is the RCCB/ELCB operation normal?
	Is the Indoor Unit properly hooked to the installation plate?
	Is the power supply voltage within the rated voltage range?
	Is there any abnormal sound?
	Is the heating operation normal?
	Is the thermostat operation normal?
	Is the remote controller 3 LCD operation normal?
	Is the Indoor Unit water leak free on test run?


# 11.2 Variation of system

This section introduces variation of various systems using Air-To-Water Heatpump and actual setting method.

## 11.2.1 Introduce application related to temperature setting.

## 11.2.1.1 Temperature setting variation for heating

#### 1. Remote Controller




Connect floor heating or radiator directly to the indoor unit.

Remote controller is installed on indoor unit.

This is the basic form of the most simple system.

#### Room Thermostat




Connect floor heating or radiator directly to the indoor unit.

Remove remote controller from indoor unit and install it in the room where floor heating is installed.

This is an application that uses remote controller as Room Thermostat.

#### 3. External Room Thermostat




Connect floor heating or radiator directly to indoor unit.

Remote controller is installed on indoor unit.

Install separate external Room Thermostat (field supply) in the room where floor heating is installed.

This is an application that uses external Room Thermostat.

#### 4. Room Thermistor



Connect floor heating or radiator directly to indoor unit.

Remote controller is installed on indoor unit.

Install separate external room thermistor (specified by Panasonic) in the room where floor heating is installed. This is an application that uses external room thermistor.

There are 2 kinds of circulation water temperature setting method.

Direct: set direct circulation water temperature (fixed value)

Compensation curve: set circulation water temperature depends on outdoor ambient temperature

In case of Room thermo or Room thermistor, compensation curve can be set.


In this case, compensation curve is shifted according to the thermo ON/OFF situation.

(Example) If room temperature increasing speed is;
 very slow → shift up the compensation curve

very fast → shift down the compensation curve

## 11.2.1.2 Examples of installations

### Floor heating 1 + Floor heating 2



Connect floor heating to 2 circuits through buffer tank as shown in the figure.

Install mixing valves, pumps and thermistors (specified by Panasonic) on both circuits.

Remove remote controller from indoor unit, install it in one of the circuit and use it as Room Thermostat.


Install external Room Thermostat (field supply) in another circuit.

Both circuits can set circulation water temperature independently.

Install buffer tank thermistor on buffer tank.

It requires connection setting of buffer tank and  $\Delta T$  temperature setting at heating operation separately. This system requires optional PCB (CZ-NS4P).

#### Floor heating + Radiator



Connect floor heating or radiator to 2 circuits through buffer tank as shown in figure.

Install pumps and thermistors (specified by Panasonic) on both circuits.

Install mixing valve in the circuit with lower temperature among the 2 circuits.

(Generally, if install floor heating and radiator circuit at 2 zones, install mixing valve in floor heating circuit.) Remote controller is installed on indoor unit.

For temperature setting, select circulation water temperature for both circuits.

Both circuits can set circulation water temperature independently.


Install buffer tank thermistor on buffer tank.

It requires connection setting of buffer tank and  $\Delta T$  temperature setting at heating operation separately.

This system requires the optional PCB (CZ-NS4P).

Mind that if there is no mixing valve at the secondary side, the circulation water temperature may get higher than setting temperature.

#### Floor heating + Swimming pool



Connect floor heating and swimming pool to 2 circuits through buffer tank as shown in figure.

Install mixing valves, pumps and thermistors (specified by Panasonic) on both circuits.

Then, install additional pool heat exchanger, pool pump and pool sensor on pool circuit.

Remove remote controller from indoor unit and install in room where floor heating is installed. Circulation water temperature of floor heating and swimming pool can be set independently.


Install buffer tank sensor on buffer tank.

It requires connection setting of buffer tank and  $\Delta T$  temperature setting at heating operation separately. This system requires the optional PCB (CZ-NS4P).

\*Must connect swimming pool to "Zone 2".

If it is connected to swimming pool, operation of pool will stop when "Cooling" is operated.

#### Swimming pool only



This is an application that connects to the swimming pool only.

Connects pool heat exchanger directly to indoor unit without using buffer tank.

Install pool pump and pool sensor (specified by Panasonic) at secondary side of the pool heat exchanger.


Remove remote controller from indoor unit and install in room where floor heating is installed.


Temperature of swimming pool can be set independently.

This system requires the optional PCB (CZ-NS4P).

In this application, cooling mode cannot be selected. (not display on remote controller)

#### Simple 2 zone (Floor heating + Radiator)





This is an example of simple 2 zone control without using buffer tank.

Built-in pump from indoor unit served as a pump in zone 1.

Install mixing valve, pump and thermistor (specified by Panasonic) on zone 2 circuit.

Please be sure to assign high temperature side to zone 1 as temperature of zone 1 cannot be adjusted.

Zone 1 thermistor is required to display temperature of zone 1 on remote controller.

Circulation water temperature of both circuits can be set independently.

(However, temperature of high temperature side and low temperature side cannot be reversed)

This system requires the optional PCB (CZ-NS4P).


#### (CAUTION)

- Thermistor 1 does not affect operation directly. But error happens if it is not installed.
- Please adjust flow rate of zone 1 and zone 2 to be in balance. If it is not adjusted correctly, it may affects the
  performance.

(If zone 2 pump flow rate is too high, there is possibility that no hot water flowing to zone 1.) Flow rate can be confirmed by "Actuator Check" from maintenance menu.

### 11.2.2 Introduce applications of system that uses optional equipment.

## **DHW (Domestic Hot Water) Tank connection**





Setting of remote controller

Installer setting
System setup
Optional PCB connectivity - No
Tank connection - Yes

This is an application that connects the DHW tank to the indoor unit through 3-way valve. DHW tank's temperature is detected by tank thermistor (specified by Panasonic).

### Tank + Solar connection






This is an application that connects the DHW tank to the indoor unit through 3-way valve before connect the solar water heater to heat up the tank. DHW tank's temperature is detected by tank thermistor (specified by Panasonic). Solar panel's temperature is detected by solar thermistor (specified by Panasonic).

DHW tank shall use tank with built-in solar heat exchange coil independently.

Heat accumulation operates automatically by comparing the temperature of tank thermistor and solar thermistor. During winter season, solar pump for circuit protection will be activated continuously. If does not want to activate the solar pump operation, please use glycol and set the anti-freezing operation start temperature to -20°C. This system requires optional PCB (CZ-NS4P).

#### **Buffer tank connection**





This is an application that connects the buffer tank to the indoor unit.

Buffer tank's temperature is detected by buffer tank thermistor (specified by Panasonic).

This system requires optional PCB (CZ-NS4P).

#### Buffer tank + Solar





This is an application that connects the buffer tank to the indoor unit before connecting to the solar water heater to heat up the tank.

Buffer tank's temperature is detected by buffer tank thermistor (specified by Panasonic).


Solar panel's temperature is detected by solar thermistor (specified by Panasonic).

Buffer tank shall use tank with built-in solar heat exchange coil independently.

During winter season, solar pump for circuit protection will be activated continuously. If does not want to activate the solar pump operation, please use glycol and set the anti-freezing operation start temperature to -20°C.

Heat accumulation operates automatically by comparing the temperature of tank thermistor and solar thermistor. This system requires optional PCB (CZ-NS4P).

#### **Boiler connection**



This is an application that connects the boiler to the indoor unit, to compensate for insufficient capacity by operate boiler when outdoor temperature drops & heat pump capacity is insufficient.

Boiler is connected parallel with heat pump against heating circuit.

There are 3 modes selectable by remote controller for boiler connection.

Besides that, an application that connects to the DHW tank's circuit to heat up tank's hot water is also possible. (Operation setting of boiler shall be responsible by installer.)

This system requires optional PCB (CZ-NS4P).

Depending on the settings of the boiler, it is recommended to install buffer tank as temperature of circulating water may get higher. (It must connect to buffer tank especially when selecting Advanced Parallel setting.)



#### 

Make sure the boiler and its integration in the system complies with applicable legislation.


Make sure the return water temperature from the heating circuit to the indoor unit does NOT exceed 55°C.

Boiler is turned off by safety control when the water temperature of the heating circuit exceed 85°C.


#### 11.2.3 How To Fix Cable

# 11.2.3.1 Connecting with external device (optional)


- All connections shall follow to the local national wiring standard.
- It is strongly recommended to use manufacturerrecommended parts and accessories for installation.
- For connection to main PCB 4.
- Two-way valve shall be spring and electronic type, refer to "Field Supply Accessories" table for details. Valve cable shall be (3 × min 1.5 mm²), of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
  - \* note: Two-way Valve shall be CE marking compliance component.
    - Maximum load for the valve is 9.8VA.
- Three-way valve shall be spring and electronic type. Valve cable shall be (3 × min 1.5 mm²), of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
  - \* note: Shall be CE marking compliance component.
    - It shall be directed to heating mode when it is OFF.
    - Maximum load for the valve is 9.8VA.
- Room thermostat cable must be (4 or 3 × min 0.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier cord, or similarly double insulation sheathed cable.
- Maximum output power of booster heater shall be ≤ 3 kW. Booster heater cable must be (3 × min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
- 5. Extra pump cable shall be (2 × min 1.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier.
- 6. Boiler contact cable shall be (2 × min 0.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier.
- External control shall be connected to 1-pole switch with min 3.0 mm contact gap. Its cable must be (2 × min 0.5 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
  - \* note: Switch used shall be CE compliance component.
    - Maximum operating current shall be less than  $3A_{\text{rms}}$ .
- Tank sensor shall be resistance type, please refer to Graph 7.1 for the characteristic and details of sensor. Its cable shall be (2 × min 0.3 mm²), double insulation layer (with insulation strength of min 30V) of PVC-sheathed or rubber-sheathed cable.




- Room sensor zone 1 cable shall be (2 × min 0.3 mm²) double insulation layer of PVC-sheathed or rubber-sheathed.
- Outdoor air sensor cable shall be (2 × min 0.3 mm²) double insulation layer of PVC-sheathed or rubber-sheathed.
- 11. Tank OLP cable must be (2 × min 0.5 mm<sup>2</sup>), double insulation layer of PVC-sheathed or rubber-sheathed cable.




How to guide the optional cables and power supply cord (view without internal wiring)



- For connection to optional PCB 7
- 1. By connecting optional PCB, 2 Zone temperature control can be achieved. Please connect mixing valves, water pumps and thermistors in zone 1 and zone 2 to each terminals in optional PCB. Temperature of each zone can be controlled independently by remote controller.
- Pump zone 1 and zone 2 cable shall be (2 × min 1.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier.
- 3. Solar pump cable shall be (2 × min 1.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier.
- Pool pump cable shall be (2 × min 1.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier.
- Room thermostat zone 1 and zone 2 cable shall be  $(4 \times min 0.5 mm^2)$ , of type designation 60245 IEC 57 or heavier.
- Mixing valve zone 1 and zone 2 cable shall be (3 × min 1.5 mm<sup>2</sup>), of type designation 60245 IEC 57 or heavier.
- 7. Room sensor zone 1 and zone 2 cable shall be (2 × min 0.3 mm<sup>2</sup>), double insulation layer (with insulation strength of minimum 30V) of PVCsheathed or rubber-sheathed cable.
- 8. Buffer tank sensor, pool water sensor and solar sensor cable shall be (2 × min 0.3 mm<sup>2</sup>), double insulation layer (with insulation strength of minimum 30V) of PVC-sheathed or rubbersheathed cable.
- 9. Water sensor zone 1 and zone 2 cable shall be (2 × min 0.3 mm<sup>2</sup>), double insulation layer of PVCsheathed or rubber-sheathed cable.
- 10. Demand signal cable shall be (2 × min 0.3 mm<sup>2</sup>), double insulation layer of PVC-sheathed or rubber-sheathed cable.
- 11. SG signal cable shall be (3 × min 0.3 mm<sup>2</sup>), double insulation layer of PVC-sheathed or rubber-sheathed cable.
- 12. Heat/Cool switch cable shall be (2 × min 0.3 mm<sup>2</sup>). double insulation layer of PVC-sheathed or rubber-sheathed cable.
- 13. External compressor switch cable shall be (2 × min 0.3 mm<sup>2</sup>), double insulation layer of PVCsheathed or rubber-sheathed cable.



How to guide the optional cables and power supply cord (view without internal wiring)



- Pool sensor cable
- Water sensor zone 1 cable Water sensor zone 2 cable
- Demand signal cable
- Solar sensor cable
- SG signal cable
- Heat/Cool switch cable External Compressor switch cable

Maximum tightening torque Terminal screw on PCB cN•m {kgf•cm} М3 50 (5.1) 120 {12.24} M4


from optional PCB

# 11.2.3.2 Connecting Cables Length

When connecting cables between Indoor Unit and external devices, the length of the said cables must not exceed the maximum length as shown in the table.

External device	Maximum cables length (m)				
Two-way valve	50				
Three-way valve	50				
Mixing valve	50				
Room thermostat	50				
Booster heater	50				
Extra pump	50				
Solar pump	50				
Pool pump	50				
Pump	50				
Boiler contact	50				
External control	50				
Tank sensor	30				
Room sensor	30				
Outdoor air sensor	30				
Tank OLP	30				
Buffer tank sensor	30				
Pool water sensor	30				
Solar sensor	30				
Water sensor	30				
Demand signal	50				
SG signal	50				
Heat/Cool switch	50				
External compressor switch	50				

# 11.2.3.3 Connection of the main PCB



### Signal inputs

Optional Thermostat	L N =AC230V, Heat, Cool=Thermostat heat, Cool terminal * It does not function when using the optional PCB	
OLP for booster heater	Dry contact Vcc-Bit1, Vcc-Bit2 open/short (System setup necessary) It is connected to the safety device (OLP) of DHW tank.	
External control	Dry contact Open=not operate, Short=operate (System setup necessary) Able to turn ON/OFF the operation by external switch	
Remote controller	Connected (Please use 2 cores wire for relocation and extension. Total cable length shall be 50m or less.)	


### Outputs

3-way valve	AC230V N=Neutral Open, Close=direction (For circuit switching when connected to DHW tank)
2-way valve	AC230V N=Neutral Open, Close (Prevent water circuit pass through during cooling mode)
Extra pump	AC230V (Used when indoor unit pump capacity is insufficient)
Booster heater	AC230V (Used when using booster heater in DHW tank)
Boiler contact	Dry contact (System setup necessary)

# Thermistor inputs

Zone 1 room sensor	PAW-A2W-TSRT  * It does not work when using the optional PCB
Outdoor air sensor	AW-A2W-TSOD (Total cable length shall be 30m or less)
Tank sensor	Please use Panasonic specified part

# 11.2.3.4 Connection of Optional PCB (CZ-NS4P)



### Signal inputs

Optional Thermostat	L N =AC230V, Heat, Cool=Thermostat heat, Cool terminal
SG signal	Dry contact Vcc-Bit1, Vcc-Bit2 open/short (System setup necessary) Switching SW (Please connect to the 2 contacts controller)
Heat/Cool SW	Dry contact Open=Heat, Short=Cool (System setup necessary)
External comp. SW	Dry contact Open=Comp.ON, Short=Comp.OFF (System setup necessary)
Demand signal	DC 0~10V (System setup necessary) Please connect to the DC 0~10V controller.

### Outputs

Mixing valve	AC230V N=Neutral Open, Close=mixture direction Operating time: 30s~120s		
Pool pump	AC230V		
Solar pump	AC230V		
Zone pump	AC230V		


### Thermistor inputs

Zone room sensor	PAW-A2W-TSRT
Buffer tank sensor	PAW-A2W-TSBU
Pool water sensor	PAW-A2W-TSHC
Zone water sensor	PAW-A2W-TSHC
Solar sensor	PAW-A2W-TSSO

# 11.2.3.5 Recommended External Device Specification


- This section explains about the external devices (optional) recommended by Panasonic. Please always ensure to use the correct external device during system installation.
- For optional sensor.
- Buffer tank sensor: PAW-A2W-TSBU
   Use for measurement of the buffer tank
   temperature.

Insert the sensor into the sensor pocket and paste it on the buffer tank surface.




Zone water sensor: PAW-A2W- TSHC Use to detect the water temperature of the control zone.


Mount it on the water piping by using the stainless steel metal strap and contact paste (both are included).



3. Outdoor sensor: PAW-A2W-TSOD If the installation location of the outdoor unit is exposed to direct sunlight, the outdoor air temperature sensor will be unable to measure the actual outdoor ambient temperature correctly. In this case, optional outdoor temperature sensor can be fixed at a suitable location to more accurately measure ambient temperature.




 Room sensor: PAW-A2W- TSRT Install the room temperature sensor to the room which requires room temperature control.



Solar sensor: PAW-A2W-TSSO
 Use for measurement of the solar panel temperature.

Insert the sensor into the sensor pocket and paste it on the solar panel surface.



6. Please refer to the table below for sensor characteristic of the sensors mentioned above.


Temperature	Resistance			
(°C)	(kΩ)			
30	5.326			
25	6.523			
20	8.044			
15	9.980			
10	12.443			
5	15.604			
0	19.70			
-5	25.05			
-10	32.10			
-15	41.45			
-20	53.92			
-25	70.53			
-30	93.05			
-35	124.24			
-40	167.82			

Temperature (°C)	Resistance (kΩ)			
150	0.147			
140	0.186			
130	0.236			
120	0.302			
110	0.390			
100	0.511			
90	0.686			
80	0.932			
70	1.279			
65	1.504			
60	1.777			
55	2.106			
50	2.508			
45	3.003			
40	3.615			
35	4.375			

For optional pump.

Power supply: AC230V/50Hz, <500W

Recommended part: Yonos 25/6: made by Wilo




For optional mixing valve.

Power supply: AC230V/50Hz (input open/output

Operating time: 30s~120s

Recommended part: 167032: made by Caleffi




### **⚠** WARNING

This section is for authorized and licensed electrician/water system installer only. Work behind the front plate secured by screws must only be carried out under supervision of qualified contractor, installation engineer or service person.


#### 11.2.3.6 Network Adaptor Installation (Optional)

- 1. Open the Control Board Cover 6, then connect the cable included with this adaptor to the CN-CNT connector on the printed circuit board.
- Pull the cable out of the Indoor Unit so that there is no pinching.
- If an optional PCB has been install in the Indoor Unit, connect the CN-CNT connector to Optional PCB ☑.

Connection examples: H series




Without Optional PCB




With Optional PCB


2. Insert a flat head screwdriver into the slot on the top of the adaptor and remove the cover. Connect the other end of the CN-CNT cable connector to the connector inside the adaptor.



On the wall near the Indoor Unit, attach the adaptor by screwing screws through the holes in the back cover.




Pull the CN-CNT cable through the hole in the bottom of the adaptor and re-attach the front cover to the back cover.



# 5. Use the included cord clamp to fix the CN-CNT cable to the wall.


Pull the cable around as shown in the diagram so that external forces cannot act on the connector in the adaptor.

Furthermore, on the Indoor Unit end, use the included cable tie to fix the cables together.




# 11.3 System Installation

# 11.3.1 Remote Controller Outline




	Name	Function
A:	Main screen	Display information
B:	Menu	Open/Close main menu
C:	Triangle (Move)	Select or change item
D:	Operate	Start/Stop operation
E:	Back	Back to previous item
F:	Quick Menu	Open/Close Quick menu
G:	OK	Confirm





	Name	Function						
1:	Function icon	isplay set function/status						
		Holiday mode Demand control						
		⊕ Weekly timer						
		Quiet mode						
		Remote controller room thermo						
		Powerful mode Boiler						
2:	Mode	Display set mode/current status of mode						
		Heating Cooling						
		Auto heating Auto cooling						
		Heap pump operating						
3:	Temp setting	Set room temp  Compensation curve  Set direct water temp  Set pool temp						
4:	Display Heat tank	Display current heating temperature (it is set temperature when enclosed by line)						
5:	Display tank temp	Display current tank temperature (it is set temperature when enclosed by line)						
6:	Outdoor temp	Display outdoor temp						

# First time of power ON (Start of installation)



# 11.3.2 Installer Setup








# 11.3.3 System Setup


· Stop heat source unit by external SW

1. Optional PCB connectivity 17:26. Wed System setup Initial setting: No Optional PCB connectivity If function below is necessary, please purchase and install optional PCB. Zone & Sensor Please select Yes after installing optional PCB. Heater capacity · 2-zone control Anti freezing Pool Select [←] Confirm Buffer tank Solar External error signal outputDemand control SG ready










17:26, Wed System setup 6. Buffer Tank connection Initial setting: No Heater capacity Select whether it is connected to buffer tank for heating or not. Anti freezing If buffer tank is used, please set Yes. Tank connection Connect buffer tank thermistor and set,  $\Delta T$  ( $\Delta T$  use to increase primary side temp against secondary side target temp). Buffer tank connection (CAUTION) Does not display if there is no Optional PCB. Select **←** Confirm If the buffer tank capacity is not so large, please set larger value for  $\Delta T.$ 



8. Base pan heater Initial setting: No

Select whether Base pan heater is installed or not. If set Yes, select to use either heater A or B.

A: Turn on Heater when heating with defrost operation only B: Turn on Heater at heating

System setup

Tank connection
Buffer tank connection
Tank heater

Base pan heater


Select


Confirm

9. Alternative outdoor sensor Initial setting: No
Set Yes if outdoor sensor is installed.
Controlled by optional outdoor sensor without reading the outdoor sensor of heat pump unit.


System setup 17:26, Wed Buffer tank connection
Tank heater
Base pan heater
Alternative outdoor sensor


Select 41 Confirm







Solar pump stop operation when it exceeds high limit temperature (when tank temperature exceed designated temperature (70~90°C))













5min ~ 4h







### 11.3.5 Service Setup









# 11.4 Service and maintenance

### When connect CN-CNT connector with computer

Please use optional USB cable to connect with CN-CNT connector

After connected, it requests for driver. If PC is under Windows Vista or later version, it automatically installs the driver under internet environment.

If PC uses Windows XP or earlier version and there is no internet access, please get FTDI Ltd's USB - RS232C conversion IC driver (VCP driver) and install.

http://www.ftdichip.com/Drivers/VCP.htm

### If forget Password and cannot operate remote controller


Press  $\longrightarrow$  +  $\longrightarrow$  +  $\blacktriangleright$  for 5 sec.

Password unlock screen appears, press Confirm and it shall reset.

Password will become 0000. Please reset it again. (CAUTION) Only display when it is locked by password.

### 11.4.1 Maintenance menu

### Setting method of Maintenance menu



Press  $\longrightarrow$  +  $\longrightarrow$  for 5 sec.


Items that can be set

- Actuator check (Manual ON/OFF all functional parts)
   (CAUTION) As there is no protection action, please be careful not to cause any error when operating each part (do not turn on pump when there is no water etc.)
- (2) Test mode (Test run) Normally it is not used.
- Sensor setup (offset gap of detected temp of each sensor within -2~2°C range)

(CAUTION) Please use only when sensor is deviated. It affects temperature control.

(4) Reset password (Reset password)

### 11.4.2 Custom menu



Items that can be set

Cool mode (Set With/Without Cooling function) Default is without

(CAUTION) As with/without Cool mode may affect electricity application, please be careful and do not simply change it.

In Cool mode, please be careful if piping is not insulated properly, dew may form on pipe and water may drip on the floor and damage the floor.

(2) Back-up heater (Use/Do not use Backup heater)
(CAUTION) It is different from to use/not to use backup
heater set by client. When this setting is used,
heater power on due to protection against frost
will be disabled. (Please use this setting when it
is required by utility company.)

By using this setting, it cannot defrost due to low Heating's setting temp and operation may stop (H75)

Please set under the responsibility of installer. When it stops frequently, it may be due to insufficient circulation flow rate, setting temp of heating is too low etc.

Reset energy monitor (delete memory of Energy monitor) Please use when moving house and handover the unit.

# 11.5 Outdoor Unit

### 11.5.1 Select the Best Location

- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- Avoid installations in areas where the ambient temperature may drop below -20°C for UD models and -28°C for UX models.
- Keep the spaces indicated by arrows from wall, ceiling, fence or other obstacles.
- Do not place any obstacles which may cause a short circuit of the discharged air.
- If outdoor unit installed near sea, region with high content of sulphur or oily location (e.g. machinary oil, etc), it lifespan maybe shorten.
- When installing the product in a place where it will be affected by typhoon or strong wind such as wind blowing between buildings, including the rooftop of a building and a place where there is no building in surroundings, fix the product with an overturn prevention wire, etc. (Overturn prevention fitting model number: K-KYZP15C)



• If piping length is over 10 m, additional refrigerant should be added as shown in the table.

Model	Piping size		Rated Length (m)		Max.	Min. Piping	Max. Piping	Additional
	Gas	Liquid	For Heat Pump Indoor Unit	For Hydromodule + Tank	Elevation	Length (m)	Length (m)	Refrigerant (g/m)
UX09*E5*, UX12*E5*, UD12*E5*, UD16*E5*, UX09*E8*, UX12*E8*, UX16*E8*, UD09*E8*, UD12*E8*, UD16*E8*	ø15.88 mm (5/8")	Ø9.52 mm (3/8")	7	5	20	3	30	50


### Example:


If piping length is 30 m, the quantity of additional refrigerant should be 1000g. [(30-10)m × 50 g/m = 1000g] GWP (R410A) = 2088

### 11.5.2 Install The Outdoor Unit

# 11.5.2.1 Installation Diagram

- It is advisable to avoid more than 2 blockage directions. For better ventilation & multiple-outdoor installation, please consult authorized dealer/specialist.
- This illustration is for explanation purposes only.






Model	Α	В	С	D	E	F
UX09*E5*,UX12*E5*, UD12*E5*,UD16*E5*, UX09*E8*,UX12*E8*, UX16*E8*,UD09*E8*, UD12*E8*,UD16*E8*	620	140	15	355	450	44

(Unit: mm)

- After selecting the best location, start installation according to Installation Diagram.
- 1. Fix the unit on concrete or rigid frame firmly and horizontally by bolt nut (ø10 mm).
- 2. When installing at roof, please consider strong wind and earthquake. Please fasten the installation stand firmly with bolt or nails.

### 11.5.2.2 Disposal of Outdoor Unit Drain Water

- When a Drain elbow 1 is used, please ensure to follow below:
  - the unit should be placed on a stand which is taller than 50 mm.
  - cover the ø20 mm holes with Rubber cap (refer to illustration below).
  - use a tray (field supply) when necessary to dispose the outdoor unit drain water.
- If the unit is used in an area where temperature falls below 0°C for 2 or 3 consecutive days, it is recommended not to use the Drain elbow 1 and Rubber cap 2, for the drain water freezes and the fan will not rotate.



#### **Connecting The Piping** 11.5.3

<u> </u>	
Do not over tighten, over tightening cause gas leakage.	

Model	Piping size (Torque)			
iviodei	Gas	Liquid		
UX09*E5*, UX12*E5*, UD12*E5*, UD16*E5*, UX09*E8*, UX12*E8*, UX16*E8*, UD09*E8*, UD12*E8*, UD16*E8*	ø15.88 mm (5/8") [65 N•m]	Ø9.52 mm (3/8") [42 N•m]		


#### 11.5.3.1 Connecting the Piping to **Outdoor Unit**

Decide piping length and then cut by using pipe cutter. Remove burrs from cut edge. Make flare after inserting the flare nut (locate at valve) onto the copper pipe. Align center of piping to valves and then tighten with torque wrench to the specified torque as stated in the table.

Local pipes can project in any of four directions.

- Make holes in the pipe panels for the pipes to pass through.
- Be sure to install the pipe panels to prevent rain from getting inside the outdoor unit. [Removing the service panel].
  - 1. Remove the three mounting screws.
  - Slide the service panel downward to release the pawls.

After this, pull the service panel toward you to remove



Close the tube joining area with putty heat insulator (local supply) without any gap as shown in right figure. (To prevent insects or small animal entering.)



Putty or Heat insulator (local supply)

### **CUTTING AND FLARING THE PIPING**

- Please cut using pipe cutter and then remove the burrs.
- Remove the burrs by using reamer. If burrs is not removed, gas leakage may be caused. Turn the piping end down to avoid the metal powder entering the pipe.

0 - 0.5 mm

Please make flare after inserting the flare nut onto the copper pipes.




1. To cut



Handle Reamer handle Red arrow mark


3. To flare



When properly flared, the internal surface of the flare will evenly shine and be of even thickness. Since the flare part comes into contact with the connections, carefully check the flare finish.

# 11.5.4 Evacuation Of The Equipment

WHEN INSTALLING AN AIR-TO-WATER HEAT PUMP, BE SURE TO EVACUATE THE AIR INSIDE THE UNIT AND PIPES in the following procedure.



- 1 Connect a charging hose with a push pin to the Low side of a charging set and the service port of the 3-way valve.
  - Be sure to connect the end of the charging hose with the push pin to the service port.
- 2 Connect the center hose of the charging set to a vacuum pump with check valve, or vacuum pump and vacuum pump adaptor.
- Turn on the power switch of the vacuum pump and make sure that the needle in the gauge moves from 0 cmHg (0 MPa) to –76 cmHg (–0.1 MPa). Then evacuate the air approximately ten minutes.
- 4 Close the Low side valve of the charging set and turn off the vacuum pump. Make sure that the needle in the gauge does not move after approximately five minutes.
  Note: BE SURE TO FOLLOW THIS PROCEDURE IN ORDER TO AVOID REFRIGERANT GAS LEAKAGE.
- 5 Disconnect the charging hose from the vacuum pump and from the service port of the 3-way valve.
- 6 Tighten the service port caps of the 3-way valve at a torque of 18 N·m with a torque wrench.
- Remove the valve caps of both of the 2-way valve and 3-way valve. Position both of the valves to "OPEN" using a hexagonal wrench (4 mm).
- 8 Mount valve caps onto the 2-way valve and the 3-way valve.
  - Be sure to check for gas leakage.

### / CAUTION

If gauge needle does not move from 0 cmHg (0 MPa) to -76 cmHg (-0.1 MPa), in step (3) above take the following measure:

- If the leak stops when the piping connections are tightened further, continue working from step ③.
- If the leak does not stop when the connections are retightened, repair the location of leak.
- Do not release refrigerant during piping work for installation and reinstallation. Take care of the liquid refrigerant, it may cause frostbite.


### 11.5.4.1 Air-Tightness Test on the Refrigerating System

Before system charged with refrigerant and before the refrigerating system in put into operation, below site test procedure and acceptance criteria shall be verified by the certified technicians, and/or the installer:-

Step 1: Pressure test for refrigerant leak detection:

- 1. Steps for pressure test, in accordance to ISO 5149.
- 2. Evacuate the system from refrigerant before the leak test, attach the gauge manifold set correctly and tightly. Charging hose of Low side connect to Gas side. (Charging hose of High side connect to Liquid side if applicable.)
- 3. Adjust the knob on the service valves, and regulator on the gauge set, so that test gas can be inserted through the centre manifold of the gauge set.
- 4. Insert Nitrogen gas into the system through the centre manifold and wait until the pressure within the system to reach about 1MPa (10 BarG) wait for a few hours and monitor the pressure reading on the gauges.
- 5. Please note that the system's pressure may rise slightly if the test is carried out on mid day, due to temperature rise. The inverse may happen when there is temperature drop at night. However, this variation will be minimal.
- 6. Waiting time depends on the size of the system. Larger systems may require 12 hours of waiting time. Leak detection within smaller system can be achieved in 4 hours.
- 7. Check if there is a constant pressure drop. Move to next step "Step 2: Refrigerant leak detection..." if there is any pressure drop. Otherwise, release the Nitrogen gas and, move to "Step 3: Vacuum test".

8. Next, insert a small amount of same refrigerant into the system through the centre hose, until the pressure reaches about 1MPa (10 BarG).



Step 2: Refrigerant leak detection through Electronic halogen leak detector and/or ultrasonic leak detector:

- 1. Use any one of below detector to check leaking.
  - Electronic halogen leak detector.
    - Switch on the unit.
    - Cover the test area from direct draft.
    - Pass the detection probe near test area and wait for audible and visible signals.
  - Ultrasonic Leak Detector
    - Make sure the area is guiet.
    - Switch on the ultrasonic leak detector.
    - Move the probe along your air conditioning system to test for leaks, and mark for repair.
- 2. Any leak detected at this level shall be repaired and retested, starting from "Step 1: Pressure test".

### NOTE:


- Always recover the refrigerant and Nitrogen gas into recovery cylinder after completion of a test.
- You must use the detection equipment with Detectable Leak Rate of 10-6 Pa.m₃/s or better.
- Do not use refrigerant as test medium for system with total refrigerant charge more than 5kg.
- Test shall be performed with dry Nitrogen or another non-flammable, non-reactive, dried gas. Oxygen, air or mixtures containing them shall not be used.

### Step 3: Vacuum test:

- 1. Perform Vacuum test to check leak / moisture if present.
- 2. Refer to section "EVACUATION OF THE EQUIPMENT" to vacuum gas out of the air conditioning system.
- 3. Wait for a few hours, depending on the size of the refrigerating system and monitor the pressure rise. If the pressure rises until 1 bar absolute, then there is leak.

  If the pressure rises, but it is lower than 1 bar absolute, then moisture is present.

Next, remove the moisture, or repair, and redo the refrigerant leak testing, starting from "Step 1: Pressure test".




An example illustrations of setup for refrigerant leak detection.

### 11.5.5 Connect The Cable To The Outdoor Unit


(FOR DETAIL REFER TO WIRING DIAGRAM AT UNIT)

- 1. Remove the control board cover from the unit by loosening the screw.
- 2. Connecting cable between indoor unit and outdoor unit shall be approved polychloroprene sheathed flexible cable (see below table), type designation 60245 IEC 57 or heavier cable.
- 3. Secure the cable onto the control board with the holder (clamper).
- 4. Attach the control board cover back to the original position with screw.




Models	Flexible cable specification
UX09*E5*, UX12*E5*, UD12*E5*, UD16*E5*	4 × min 4.0 mm <sup>2</sup> or 6.0 mm <sup>2</sup>

			3	
Colour of wires				
Terminals on the outdoor unit	1	2	3	




Models	Flexible cable specification
UX09*E8*, UX12*E8*, UX16*E8*, UD09*E8*, UD12*E8*, UD16*E8*	6 × min 1.5 mm²


Terminals on the indoor unit	1	2	3	4	5	
Colour of wires						
Terminals on the outdoor unit	1	2	3	4	5	



### **CAUTION**


- For three phase model never operate the unit by pressing the electromagnetic switch.
- Never correct the phase by switching over any of the wires inside the unit.
- · Select required direction and apply protective bushing provided in accessories to protect cables from sharp edges.
- Once all wiring work has been completed, tie the cable and cord together with the binding strap so that they do not touch other parts such as the
  compressor and bare copper pipes.





DETAIL OF CONNECTING CABLE GUIDING

### WIRE STRIPPING AND CONNECTING REQUIREMENT



### 11.5.6 Pipe Insulation

- 1. Please carry out insulation at pipe connection portion as mentioned in Indoor/Outdoor Unit Installation Diagram. Please wrap the insulated piping end to prevent water from going inside the piping.
- 2. If drain hose or connecting piping is in the room (where dew may form), please increase the insulation by using POLY-E FOAM with thickness 6 mm or above.

# 12. Operation and Control

### 12.1 Basic Function

Inverter control, which equipped with a microcomputer in determining the most suitable operating mode as time passes, automatically adjusts output power for maximum comfort always. In order to achieve the suitable operating mode, the microcomputer maintains the set temperature by measuring the temperature of the environment and performing temperature shifting. The compressor at outdoor unit is operating following the frequency instructed by the microcomputer at indoor unit that judging the condition according to internal water setting temperature and water outlet temperature.

# 12.1.1 Internal Water Setting Temperature

Once the operation starts, control panel setting temperature will be taken as base value for temperature shifting processes. These shifting processes are depending on the Air-to-Water Heat pump settings and the operation environment. The final shifted value will be used as internal water setting temperature and it is updated continuously whenever the electrical power is supplied to the unit.

### 12.1.2 Heating Operation

### 12.1.2.1 Thermostat Control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature > 2°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) <-3°C.</li>

### 12.1.2.2 Thermostat Control (Outdoor Ambient Temperature)

Stops provide heating to room side during high outdoor ambient condition. Control content:

- Heating operation and water pump will turn OFF when outdoor ambient temperature > outdoor thermo off temperature + 3°C.
  - (Outdoor thermo off set temperature is set by control panel. Thermo off set temperature is between 5°C ~ 35°C)
- Heating operation will resume when Outdoor ambient temperature < Outdoor thermo OFF set temperature + 1°C.</li>

### 12.1.2.3 Heat Mode Operation

Operation of heat pump provide heating capacity to room side by hot water through heating panel, floor heating or fan coil unit.

- 1 3 ways valve control:
  - o 3 ways valve switch and fix to room side.
- 2 Heat pump operates follow normal heating operation.
- 3 Room heater operate follow normal operation.
- 4 2 ways valve control:
  - o 2 ways valve opens.

# 12.1.3 Cooling Operation

### 12.1.3.1 Thermostat control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature > -1.5°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) >3°C.

### 12.1.3.2 Cool Mode Operation

- 1 3 ways valve control:
  - 3 ways valve switch and fix to cooling side.
- 2 Heat pump operates follow normal cooling operation.
- 3 Room heater DOES NOT operate during cool mode.
- 4 2 ways valve control:
  - o 2 ways valve is closed.

### 12.1.4 Target Water Temperature Setting

# 12.1.4.1 Target Water Temperature Control of Standard System (Optional PCB not connected)

There are 2 types of temperature control selection which are Compensation and Direct.

Temperature control type selection by installer:

1) Compensation: Wlo, WHi, ODLo, ODHi can be set at installer menu.

2) Direct : Direct Water Temperature Set

Remote control setting by user:

1) Compensation : Shift value ±5°C from the compensation curve

2) Direct : Direct water temperature set change

- Target water temperature is calculated as below condition.
  - Target water temperature = A (Base temperature) + B (shift temperature)

A (Base Temperature)	Compensation	Direct		
A (base reinperature)	Value from the curve + User shift value set	Direct value from user setting		

B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value is depend on the room sensor selection at remocon as table below		
Sensor Selection			
Water temperature	B = 0		
External Room Thermostat	B = 0		
	Cool Mode:		
	B = 0; when Zone OFF or Zone Room Thermo OFF		
Internal Room Thermostat	B = 1 * (room set temp. (R/C) – actual room temp.)		
&	Max/Min Regulation of B: (Max: 5°C; Min: -5°C)		
Room Thermistor	Heat Mode:		
	B = 0; when Zone OFF or Zone Room Thermo OFF		
	B = follow Heating PI control contents		

<sup>\*</sup>This setting at is only able to set when the room sensor select as Water Temperature.


<sup>\*</sup>Instead of water temperature, user will set target room temperature when room sensor select as Room Thermistor or Internal Room Thermostat.

Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
Max	55°C	20°C
Min	20°C	5°C

### Compensation Type: (Operation under Heat Mode and Cool Mode)

The set temperature defines the parameters for the ambient (Outdoor temperature) dependent operation of the unit. The water temperature is determined automatically depending on the outdoor temperature. Default setting is the colder outdoor temperature will result in warmer water and vice versa. The user has the possibility to shift up and shift down the target water by remote control setting.




- Outdoor ambient is updated every 30 minutes when operation ON.
- Setting water outlet temperature always follow W<sub>(LO)</sub> or W<sub>(HI)</sub> whenever is higher if outdoor ambient sensor or indoor comminication error happen.

However, when powerful mode is requested by remote control during heating mode, the higher value of HLo or Whi will be used for A calculation.

\*There are 2 compensation curves (for heating and cooling). During heating mode, the heating curve is used and during cooling mode, the cooling curve is use.

- Compensation curve set shift value:



# 12.1.5 Target Water Temperature at Extension System (Optional PCB is connected)

Target water temperature is calculated as below.

### Heat Mode:

- Target water temperature setting:

Max= 55°C Min= 20°C

- When buffer tank selection is "YES:"

Target water temperature = Target buffer tank temperature + [2°C]

- When buffer tank selection is "NO"
  - o If both zone 1 and zone 2 is active

Target Water Temperature = Higher zone target water temperature of Zone 1 and Zone 2.

o If only one zone is active

Target Water Temperature = Zone target water temperature of active zone.

### Cool mode:

Target water temperature setting:

 $Max = 20^{\circ}C$  Min=  $5^{\circ}C$ 

- When buffer tank selection is "YES"
  - o If both zone 1 and zone 2 is active

Target Water Temperature = Lower Zone Target Water Temperature of Zone 1 and Zone 2 + [-3°C]

o If only one zone is active

Target Water Temperature = Zone Target Water Temperature of active zone + [-3°C]

- When buffer tank selection is "NO"
  - o If both zone 1 and zone 2 active

Target Water Temperature = Lower Zone Target Water Temperature of Zone 1 and Zone 2

 $\circ$  If only one zone is active

Target Water Temperature = Zone Target Water Temperature of active zone

\*Cool Mode does not have SG ready control

### 12.1.6 Target Zone Water Temperature Control

Purpose:- To control zone mixing and zone pump according to the zone sensor temperature

# 12.1.6.1 Target Zone 1 water temperature setting control

- Start condition
  - Heating zone 1 is ON by remote control or Timer or Auto Mode OR
  - Cooling zone 1 is ON by remote control or Timer or Auto Mode.
- Cancel condition
  - Heating zone 1 is OFF by remote control or Timer or Auto mode AND
  - Cooling zone 1 is OFF by remote control or Timer or Auto mode.
- Target Zone 1 water temperature is calculated as below condition.
  - Target Zone 1 water temperature = A (Base temperature) + B (shift temperature)

A (Base Temperature)	Compensation	Direct		
A (base reinperature)	Value from the curve + User shift value set	Direct value from user setting		

<sup>\*</sup> During heat mode and compensation select, if powerful mode is activated, higher value of WLo or WHi will be use as curve value.

B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value is depend on the room sensor selection at remocon as table below	
Sensor Selection		
Water temperature	B = 0	
External Room Thermostat	B = 0	
	Cool Mode:	
	B = 0; when Zone OFF or Zone Room Thermo OFF	
Internal Room Thermostat	B = 1 * (room set temp. (R/C) – actual room temp.)	
&	Max/Min Regulation of B: (Max: 5°C; Min: -5°C)	
Room Thermistor	Heat Mode:	
	B = 0 ; when Zone OFF or Zone Room Thermo OFF	
	B = follow Heating PI control contents	
Pool Function Selected	B = Delta value setting from remocon	

<sup>\*</sup>B = 0 regardless of which sensor selection, if SHP control bit is enable except Pool function select (maintain Pool "B" value)

• Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
Max	55°C	20°C
Min	20°C	5°C

- Target Zone 1 Water Temperature (Heat mode only) during SG ready control
  - If buffer tank selection is "NO" then following shift is carried out.
    - While digital input is "10" or "11" then,
       Final Target Zone 1 water temperature
      - = Target Zone 1 water temperature\* (SG ready % setting (remote control menu))%
  - If buffer tank selection is "YES"
    - No shift of Target Zone 1 Water Temperature. Target Buffer Tank Temperature will change accordingly.
      - \* Refer to "Buffer tank temperature control"

<sup>\*\*</sup> Pool function also can be select at Zone 1 when optional PCB is connected and Zone 1 system is select.

### 12.1.6.2 Target Zone 2 water temperature setting control

- Start condition
  - Heating zone 2 is ON by remote control or Timer or Auto Mode OR
  - Cooling zone 2 is ON by remote control or Timer or Auto Mode.
- Cancel condition
  - Heating zone 2 is OFF by remote control or Timer or Auto mode AND
  - Cooling zone 2 is OFF by remote control or Timer or Auto mode.
- Target Zone 2 water temperature is calculated as below condition.
  - Target Zone 2 water temperature = A (Base temperature) + B (shift temperature)

A (Base Temperature)	Compensation	Direct
	Value from the curve + User shift value set	Direct value from user setting

<sup>\*</sup> During heat mode and compensation select, if powerful mode is activated, higher value of WLo or WHi will be use as curve value.

- B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value is depend on the room sensor selection at remocon as table below		
Sensor Selection			
Water temperature	B = 0		
External Room Thermostat	B = 0		
Internal Room Thermostat & Room Thermistor	Cool Mode:		
	B = 0; when Zone OFF or Zone Room Thermo OFF		
	B = 1 * (room set temp. (R/C) – actual room temp.)		
	Max/Min Regulation of B: (Max: 5°C; Min: -5°C)		
	Heat Mode:		
	B = 0; when Zone OFF or Zone Room Thermo OFF		
	B = follow Heating PI control contents		
Pool Function Selected	B = Delta value setting from remocon		

<sup>\*</sup>B = 0 regardless of which sensor selection, if SHP control bit is enable except Pool function select (maintain Pool "B" value)

- \*\* Pool function also can be select at Zone 2 when optional PCB is connected and Zone 2 system is select.
- Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
Max	55°C	20°C
Min	20°C	5°C


- Target Zone 2 Water Temperature (Heat mode only) during SG ready control
  - If buffer tank selection is "NO" then following shift is carried out.
    - While digital input is "10" or "11" then,
       Final Target Zone 2 water temperature
      - = Target Zone 1 water temperature\* (SG ready % setting (remote control menu))%
  - If buffer tank selection is "YES"
    - o No shift of Target Zone 2 Water Temperature. Target Buffer Tank Temperature will change accordingly.
      - \* Refer to "Buffer tank temperature control"

### 12.1.6.3 Zone Temperature Control Contents

- During Standard System (Optional PCB not connected)
  - a) Only 1 zone temperature control is available
  - b) This zone room temperature is control by either one of the 4 room sensor (Room Th, Int/Ext Room Thermostat, Water temperature)
  - Target Zone Water Temperature is calculated based on selected temperature control type (Compensation or Direct) and selected room sensor. Target Water Temperature will set same as Target Zone Water Temperature
  - d) Target Water Temperature is the temperature for heat pump to operate refer to indoor water outlet sensor.
  - e) Heat pump and water pump OFF when ROOM Thermo OFF (Zone thermo OFF by Room Th or Room Thermostat).
  - \* There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.
- During Extension System (Optional PCB connected)
- 1) Buffer Tank connection select "NO" &
  - o One zone system is select
  - a) This zone room temperature control by either one of the 4 room sensor (Room Th, Int/Ext Room Thermostat, Water temp.)
  - b) Target Zone Water Temperature calculate base on selected temperature control type (Compensation or Direct) and selected room sensor.
  - c) Target Water Temperature will set same as Target Zone Water Temperature
  - d) Target Water Temperature is a temperature for heat pump to operate refer to indoor water outlet sensor.
  - e) Heat pump and water pump OFF when ROOM Thermo OFF (Zone thermo OFF by Room Th or Room Thermostat).
  - \* There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.
  - o 2 zone system select
  - a) Each zone room temperature is control by each sensor which select from either one of the 4 room sensor
  - b) Target Zone 1 & 2 Water Temperature is calculated based on selected temperature control type (Compensation or Direct) and selected room sensor.
    - \* Zone Mixing Valve & Zone pump will operate to achieve Target Zone Water Temperature which refer to zone sensor
    - \* Zone Sensor will detect if zone sensor is open or short.
  - c) Target Water Temperature will set same as the active & higher zone water temperature setting. (When cooling mode, lower zone water temp setting)
  - d) Target Water Temperature is the temperature for heat pump to operate refer to indoor water outlet sensor.
  - e) Heat pump and water pump OFF when ROOM Thermo OFF (Both Zone thermo OFF by Room Th or Room Thermostat).

- 2) Buffer Tank Connection select "YES" &
  - 1 zone system or 2 zone system select
  - a) Each zone control by each sensor which select from either one of the 4 room sensor
  - b) Target Zone 1 & 2 Water Temperature calculate base on selected temperature control type (Compensation or Direct) and selected room sensor. Each zone have their own Target Zone Water Temperature.
    - \* Zone Mixing Valve & Zone pump will operate to achieve each Target Zone Water Temperature which refer to zone sensor
    - \* Zone Sensor will detect if zone sensor is open or short.
  - Target Buffer Tank Temperature will be set as active & higher zone water temperature setting + Buffer Delta
     T. (Heating) Target Buffer Tank Temperature will be set as active & lower zone water temperature setting
     (Cooling).
  - d) Target Water Temperature will set as Target Buffer Tank Temperature + [2°C] (Heating) Target Water Temperature will set as Lower or Active Target Zone Water Temp. + [-3°C] (Cooling)
  - e) Target Water Temperature is a temperature for heat pump to operate refer to indoor water outlet sensor.
  - f) Heat pump and water pump OFF when ROOM thermo OFF
    - Heat mode: ROOM thermo OFF (Buffer Tank Temperature > Target Buffer Tank + [0°C]
    - Cool mode: ROOM Thermo OFF (Both Zone thermo OFF by Room Th or Room Thermostat)

# 12.1.7 Auto Mode Operation




### Control details:

- To enable the unit to operate either heat or cool mode automatically, heat to cool set temperature and cool to heat set temperature can be set by control panel.
- Automatic operation is judged based on control panel setting temperature and outdoor ambient temperature.
- \* Minimum setting of heat to cool set temperature is 1°C higher than cool to heat set temperature.

### Judgement control:

- o If outdoor ambient temperature < Heat to Cool Set Temperature, unit will operate in Heat Mode or else the unit will operate in Cool Mode.
- o If current operation is Cool mode, outdoor ambient temperature > Cool to Heat Temperature, unit will maintain Cool mode operation or else the unit will operate Heat mode.
- If current operation is Heat mode, outdoor ambient temperature > Heat to Cool Temperature, unit will maintain Heat mode operation or else the unit will operate Cool mode.
- o Every 60 minutes the outdoor ambient temperature is judged.
- When Auto + Tank mode is selected, operation mode switching is judged by both outdoor ambient temperature and indoor air temperature.

# 12.1.8 Auto Cooling Mode Operation Limit



- Auto Mode Cooling Only operation will start once the outdoor ambient temperature reaches 19°C and compressor will continue to run until the outdoor ambient temperature drops to 16°C.
- Due to this limitation,
   If Heat to Cool temperature is set lower than 19°C, the compressor will not operates until the outdoor ambient temperature reaches 19°C or higher.

### 12.1.9 Tank Mode Operation

- 3 ways valve direction
  - 3 ways valve switch to tank side during Tank Thermo ON condition. Switch 3 ways valve to room side when tank achieve Tank Thermo OFF temperature.
- Tank Thermo ON/OFF Characteristic
  - Tank Thermo OFF

### Case 1: Internal Tank Heater is select and Tank Heater ON

- a) Tank temperature > Tank Set Temperature continuously for 15 seconds.
- b) Water outlet >75°C

### Case 2: Tank Heater OFF OR External Heater is select

- a) When heat pump OFF due to water thermos & Tank temperature > Tank water set temperature for continuously 20 seconds. **OR**
- b) Tank temperature > Tank set temperature + 1°C for continuously 20 seconds.
- o Tank Thermo ON

### Case 1: Internal Tank Heater is select and Tank Heater ON

a) Tank temperature < Tank set temperature + R/C (Tank re-heat temperature)

### Case 2: Tank Heater select OFF OR External Heater is select

- a) Tank temperature < Tank water set temperature + R/C (Tank re-heat temperature)
- \* When tank thermo ON, water pump will ON for 3 minutes then only heat pump turn ON.
- \* Tank water set temperature = tank set temperature or 51°C whichever lower.
- 2 ways valve close
- Heat pump Thermostat Characteristic
  - Heat pump Water Outlet set temperature is set to below table:

Outdoor ambient temperature	Heat pump water outlet temperature
< 5°C	55°C
> 5°C	57°C

### Characteristic of heat pump thermos ON/OFF under tank mode condition:

- 1) Water Outlet Thermo Condition
- Heat pump thermos OFF temperature:
  - 1. Heat pump thermo OFF temperature = Target Water outlet temperature + (2°C)
  - 2. Water outlet temperature > heat pump thermo OFF temperature for continuously 3 minutes, heat pump OFF but water pump continue ON.
- Heat pump thermo ON temperature:
  - 1. Heat pump thermo ON temperature = water inlet during thermo OFF time + [-3°C]
  - 2. When water outlet temperature < heat pump thermo ON temperature, heat pump ON.
- 2) Water inlet thermo protection condition
- Heat pump thermo OFF temperature:
  - 1. Water inlet temperature > [57°C/55°C] for continuously 30 seconds, heat pump OFF, water pump continue ON
- Heat pump thermo ON temperature:
  - 1. Heat pump thermos ON temp = water inlet temperature < [57°C/55°C].

Outdoor ambient temperature	Water inlet temperature
< 5°C	55°C
>= 5°C	57°C

### Thermo ON/OFF for Heat Pump in Tank Operation:

1) When tank temperature achieve heat pump OFF condition, refer below condition:

Condition 1: When Internal Tank Heater is select and Tank Heater ON

 Heat pump will turn OFF, water pump continue ON and room heater will continue ON if tank temperature below tank heater thermo ON condition. 3 ways valve will only switch to room side after tank temperature reach tank heater thermo OFF condition.

### Condition 2: When Tank Heater select OFF OR when External Tank Heater is select and Tank heater ON

- If tank temperature achieve tank thermo OFF, heat pump turn OFF, water pump turn OFF, room heater OFF and 3 ways valve switch to room side.
- 2) When tank temperature achieve heat pump ON condition, water pump ON, heat pump ON and room heater turn OFF.

### Heat pump OFF condition at Tank Mode

- a) Tank temperature > tank water set temperature continuously for 20 seconds after heat pump thermos OFF due to water thermo. (Heat pump turn OFF but water pump continue ON and room heater turn ON to achieve tank set temperature) **OR**
- b) Tank temperature > tank set temperature + [1°C] for continuously 20 seconds. (Heat pump OFF, water pump OFF, room heater OFF and 3 ways valve switch to room side)

### Heat pump ON condition at Tank Mode

- a) Tank temperature < tank water set temperature + R/C setting (Tank re-heat temp)</li>
   (Water pump turn ON OR continue ON, heat pump ON and 3 ways valve switch to tank side or maintain at tank side)
- Room heater control
  - Room heater only operates to tank side if the Internal Tank Heater is select, Tank heater ON and room heater is enable.

### Room heater turn ON condition:

- 1) Tank temperature < tank set temperature AND
- 2) Heat pump thermos OFF AND
- 3) 20 minutes from previous heater off AND
- 4) Internal tank heater selects USE from control panel.

# Room heater turn OFF condition:

- 1) Tank temperature > tank set temperature for continuously 15 seconds **OR**
- 2) Heat pump thermo ON **OR**
- 3) Mode change or operation is off by control panel.
- Tank Heater control
  - Tank heater only operate to tank side if tank heater ON.

### 12.1.10 Heat + Tank Mode Operation

- 1. 3 ways valve control:
- 3 ways valve switch to room side during room heat-up interval and switch to tank side during tank heat-up interval. Both modes will switch alternately. Tank mode is the initial running mode of Heat + Tank mode.
- 2. Heat pump operation control:
- a) During room heat-up interval
- Follow normal heating operation.
  - Switching to tank side depends to below cases:

Case 1

[Previous switch from tank interval to room interval due to thermo OFF]

Switch to tank heat-up interval when Tank temp < Tank thermos ON temp (Room heat-up interval ends)</li>
 Case 2:

[If heating operation at room side is less than 30 minutes and switch to tank side 3 times consecutively]

Maintain at room heat-up interval regardless of the tank temperature. Switch to tank heat-up interval only
when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank
thermo ON temperature.</li>

Case 3:

[Previous switch from tank interval to room interval due to tank interval timer is complete]

- Maintain at room heat-up interval regardless of the tank temperature. Switch to tank heat-up interval only
  when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** tank temperature < Tank
  thermo ON temperature.</li>
- b) During Tank heat-up interval
- Tank interval is the first mode running when heat + tank mode is select.
- Switch to room interval only when tank achieve tank thermo OFF **OR** tank heat-up interval timer is complete.
- Heat pump operates according to normal tank mode operation.
- 3. Room heater control:
- a) During heating heat-up interval
- Follow normal room heater control operation.
- 4. Tank heater control:
- a) During heating heat-up interval
  - i. If External tank heater is select.
  - External heater ON/OFF according to external tank heater operation control.
  - ii. If internal tank heater is select.
    - Internal tank heater will not function under heating heat-up interval.
- b) During tank heat-up interval
  - i. If External tank heater is select.
    - Once heating heat-up interval switched to tank heat-up interval, tank heater is turn OFF and tank heater delay timer will start counting.
    - Tank heater will turn ON after tank heater delay timer is fulfill and tank temperature is lower than tank set temperature.
  - Tank heater delay timer is clear when switching to heating heat-up interval.
  - If internal tank heater is select.
    - Internal tank heater will turn ON after heat punp thermo off to boil tank temperature to tank set temperature.
- c) 2 ways valve control is open
- d) Indoor water pump control:
- Indoor water pump always turn ON if room heat pump thermo ON OR Tank thermo ON.

## 12.1.11 Cool + Tank Mode Operation

- 1. 3 ways valve control:
- 3 ways valve switch to room side during room cooling interval and switch to tank side during tank heat-up interval. Both mode will switch alternately. Tank mode is the initial mode of cool + tank mode.
- 2. Heat pump operation control:
- a) During room operation interval
- Follow normal cooling operation.

Switch to Tank side depends on below case:

Case 1:

[Previous switch from tank interval to room interval is due to tank thermo OFF.]

 Switch to tank heat-up interval when Tank temperature < Tank Thermo ON temperature (Room interval will ends)

Case 2:

[If cooling operation at room side is less than 30 minutes and switch to tank side for 3 times consecutively]

Maintain at room cooling interval regardless of the tank temperature. Switch to tank heat-up interval only
when (Room interval timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank
thermo ON temperature.</li>

Case 3:

[Previous switch from tank interval to room interval is due to tank interval timer is complete]

Maintain at room cooling interval regardless of the tank temperature. Switch to tank heat-up interval only
when (Room interval timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank
thermo ON temperature.</li>

## \*Tank Thermo ON temperature:


Internal Tank Heater select USE	<tank (tank="" +="" c="" r="" re-heat="" set="" setting="" temperature="" temperature)<="" th=""></tank>
Others	<tank (tank="" +="" c="" r="" re-heat="" set="" setting="" td="" temperature="" temperature)<="" water=""></tank>

- b) During tank heat-up interval
- Tank interval is the first mode running when the cool + tank mode is select.
- Switch to room interval only when tank achieve tank thermo OFF **OR** tank heat-up interval timer is complete.
- Heat pump operates according to normal tank mode operation.
- 3. Room heater control:
- a) During room cooling interval
- Room heater is OFF and not operates.
- 4. Tank heater control:
- a) During room cooling interval
  - i. If external tank heater is select.
  - External heater ON/OFF according to external tank heater operation control.
  - ii. If internal tank heater is select and tank heater ON
    - Internal tank heater will not function under room cooling interval.
- b) During tank heat-up interval
  - i. If external tank heater is select
  - Once room cooling interval switch to tank heat-up interval, tank heater will turn OFF and tank heater delay timer will start counting.
  - Tank heater turns ON after tank heater delay timer is fulfill and tank temperature is lower than tank set temperature.
  - Tank heater delay timer is clear when switch to room cooling interval.
  - ii. If internal tank heater is select and tank heater ON.
    - Internal tank heater will turn ON after heat pump thermos off to boil tank temperature to tank set temperature.

- 5. 2 ways vale is close.
- 6. Indoor water pump control:
  - Indoor water pump always turn ON if room heat pump thermo ON **OR** Tank thermo ON.

# 12.1.12 Outdoor Fan Motor Operation


Outdoor fan motor is adjusted according to operation condition. It starts when compressor starts operation and it stops 30 seconds after compressor stops operation.



# 12.2 Water Pump

## 12.2.1 Water Pump Control

- Once the indoor unit is ON, the water pump will be ON immediately and no error judgment for 70 seconds.
   However, during this 70 seconds operation, if there is any abnormality cause at outdoor or malfunction, the compressor should be OFF immediately and restart delay after 3 minutes.
- The system will start checking on the water flow level after operation start for 70 seconds. If water flow level is detected low continuously 60 seconds, the water pump and the compressor will be OFF permanently and OFF/ON control panel LED will blink (H62 error occurs).
- When error happens, the power has to be reset to clear the error.
- If there is no error indication, the water pump shall be continuously running.
- The water pump will remain ON when compressor OFF due to thermostat OFF setting is reached.
- Water pump will OFF when room thermo OR tank thermo OR buffer tank thermo OFF.
- Water pump will delay 15 seconds to turn OFF when request to OFF except during anti-freeze deice activate or air purge mode.




## Maximum pump speed setting on remote control

• Standard pump speed is automatically controlled to get the designed water temperature different between water inlet and outlet (ΔT). Instead of setting the standard pump speed, maximum pump speed is manually adjusted by the installer according to water circuit pressure drop.


However, the following sequences do not follow maximum pump duty setting by remote control.

- Pump down mode
- Air purge mode
- Normal deice
- 1) P-Q graph for different pump HEX duty

## WH-SDC09H3E8 & WH-SDC12H9E8




### WH-SDC16H9E8



## 12.2.2 Zone Water Pump Control

#### Purpose:

 Water pump install at each zone to circulate the water inside each zone during buffer tank connection selected "YES" or 2 zone systems.



#### Content:

- AC type water pump install for this zone water pump control. When optional PCB connected, 230V output will
  drive this zone pump.
- There are three pump can be connected through Optional PCB. (Zone 1 Pump, Zone 2 Pump, & Pool Pump)
  - \* Zone 1 pump [P1] use to circulate zone 1 water circuit & Zone 1 mixing valve [M1] adjust to control the Zone 1 target water temperature.
  - \* Zone 2 pump [P2] use to circulate zone 2 water circuit & Zone 2 mixing valve [M2] adjust to control the Zone 2 target water temperature.
  - \* When Pool Function select as Zone 2 circuit, [P2] use to circulate water to heat exchanger which use to transfer heat to pool water.
  - \* Pool pump [P3] circulates the pool water through the heat exchanger to get warm water.
- Zone 1 and Zone 2 water pump start condition:
  - Zone room request ON (eg. Zone 1 thermo ON, only zone 1 pump will turn ON)
- Zone 1 and Zone 2 water pump stop condition:
  - Zone room request OFF
- Pool water pump start condition:
  - Pool Zone request ON AND
  - Pool function is selected
- Pool water pump stop condition
  - Pool zone: Zone room request OFF OR
  - Pool function is cancel
    - \* Zone 1 & Zone 2 water pump need to turn OFF when antifreeze deice pump stop control activate and turn ON back after the antifreeze deice pump stop control end under setting of "NO" buffer tank connection.

## **Zone Pump Prohibit ON control:**

Start condition:

Zone 1 water temperature ≥ 75°C continuously for 5 minutes

\*stop zone water pump operates if the zone water fulfilled.

· Cancel condition:

After 30 minutes from start condition fulfilled.

\*zone water pump operates according to normal condition.

## **Zone Pump Control during Anti-Freeze**

Zone pump control during Zone Anti-Freeze Control:

When Zone Anti-Freeze Flag=1, Zone Pump Turn ON.

When Zone Anti-Freeze Flag=0, Zone Pump Turn OFF.


Zone pump control during Indoor Anti-Freeze Control:

- Zone pump only ON/OFF if the Extension PCB connected and Buffer Tank select "NO" condition

When Indoor Anti-Freeze flag=1, Zone Pump Turn ON When Indoor Anti-Freeze flag=0, Zone Pump Turn OFF

## 12.2.3 Water Pump Speed Feedback Error

- Basically pump speed feedback is control by micon.
- When pump speed is below low limit or over high limit for a few seconds, micon detect pump error and system is stopped.
- Error detection conditions:
  - Detect abnormal water pump speed for continuous 10 secs.
  - Current pump speed < 700 rpm or
  - Current pump speed > 6000rpm for 10 seconds.
- Control contents:
  - When error occurs, water pump, heating and heater is stopped for 30 seconds then restart again (Retry control).
  - When micon detect error again, system is stopped and error code [H20] is displayed at control panel.




<sup>\*</sup> Pool Water Pump will not affected by both Indoor anti-freeze control or zone anti-freeze control.

# 12.3 Indoor Unit Safety

## 12.3.1 Indoor Unit Safety Control

- 1 When water pump is ON, the system will start checking flow switch status (ON/OFF).
- 2 If the flow switch ON for 10 seconds, the system will check on the water inlet temperature for 10 seconds. If the water inlet temperature not exceeds 80°C, the water pump shall be continuously running with normal mode.
  - If the water inlet temperature exceeds 80°C for continuously 10 seconds, the water pump will be OFF immediately.
- 3 After water pump OFF for more than 10 minutes, it will be ON back and the indoor unit safety control checking is restarted.



## 12.4 Auto Restart Control

1 When the power supply is cut off during the operation of Air-to-Water Heatpump, the compressor will reoperate after power supply resumes.

## 12.5 Indication Panel

LED	Operation	
Color	Green	
Light ON	Operation ON	
Light OFF	Operation OFF	

#### Note:

• If Operation LED is blinking, there is an abnormality operation occurs.

## 12.6 Indoor Back-Up Heater Control

## 12.6.1 Indoor Electric Heater Control

- 1 Normal Heating Mode
  - Heater On condition:
    - a. Heater switch is ON
    - b. After Heatpump thermo ON for [30] mins
    - c. After water pump operate [9] mins
    - d. Outdoor air temperature < Outdoor set temperature for heater
    - e. When water outlet temperature < Water set temperature + [-4°C]
    - f. [20] minutes since previous Backup heater Off
      - When heatpump cannot operate due to error happens during normal operation, heater will go into force mode automatic
      - \* Heater need to operate during deice operation
  - Heater Stop Condition:
  - a. When outdoor set temperature > outdoor set temperature + [+2°C] for continuous 15 secs OR
  - b. When water out temp> water set temperature + [-2°C] for continuous 15 secs OR
  - c. Heater switch is Off OR
  - d. Heatpump thermo-off or OFF condition

## 2 Force Heater Mode

- Heater On condition:
  - a. After water pump operate [9] mins
  - b. When water outlet temperature < water set temperature + [-4°C]
  - c. [20] minutes since previous Backup heater Off
- Heater Stop condition
- a. Force mode off OR
- b. When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs
- \* Do not operate heater at the following situation
- 1 Water outlet temperature sensor, and water inlet sensor abnormal
- 2 Flow switch abnormal
- 3 Circulation pump stop condition

## 12.6.2 Room Heater Operation during Deice

### Purpose:

- To protect the indoor Heat Exchanger from ice forming and prevent heat exchanger plate breakage.

#### **Control content:**

 This Heater protection control will activate only if the backup heater is enable at custom setup by remote controller. Once fulfil the start condition, room heater will turn ON together (base on max heater capacity selection) and stop together if stop condition is fulfilled.

\* If the heater is request to turn ON OLP feedback will be detected.

## **Starting conditions:**

- 1. During normal deice operation 4~9
- Water outlet temperature < 10°C or Outdoor air temperature < -10°C or Water inlet temperature < 27°C</li>


Heater operates when 1 ~2 fulfilled **OR** When 1 and 3 ~ 4 is fulfilled. However, this control does not relate to Heater ON/OFF button on remote control.

#### Stop condition:

- 1. When normal deice end or
- 2. Water outlet temperature > 45°C

However, room heater keeps ON if indoor electric heater control activate.

< Deice operation time chart >



<sup>\*</sup> Backup heater must Turn OFF if the water pump turn OFF.

## 12.7 Tank Heater Control

## 12.7.1 Tank Heater Remote Control Setting

1) Tank heater selection:

External: - Booster Heater use to heat up tank when select external Internal: - Backup Heater use to heat up tank when select internal

\* When select External Tank Heater, Heater Delay ON Timer need to set. (range 20 min ~ 3 hrs)


2) Tank Heater ON/OFF selection by user.

The remote control Tank set Temperature range will change according to the External and Internal Tank Heater use.

Tank Heater Selection	Range
External	40 ~ 75°C
Internal	40 ~ 65°C

#### 12.7.2 External Heater Control at Tank Side


Heating operation condition:



- a) Tank heater Turn On condition:
- External Heater select for Tank heater by remote controller.
- Tank Heater select ON by user.
- Tank mode operation ON ( Tank mode, Heat + Tank, or Cool + Tank )
- After TANK HEATER DELAY TIMER fulfil during heat pump startup time in tank mode, or during switching from heating heat-up interval to tank heat-up interval in heat + tank mode
- Tank temperature < tank set temperature + [Remote controller Set Tank Re-heat Temp] + [-1°C]</li>
- 20 minutes since previous heater off.
  - \* TANK HEATER DELAY TIMER is clear when tank heat-up interval end.
- b) Tank heater Turn Off condition:-
- Tank temperature > tank set temperature + [0°C] for continuous 15 seconds.
- When BOOSTER HEATER DELAY TIMER start count after switch from heating heat-up interval to tank heat-up interval.
- Tank Heater select OFF by user
- Tank Mode Operation OFF

## 12.7.3 Internal Heater Control at Tank Mode

- Internal heater turn ON condition:
  - 1) Internal Heater select for Tank heater by remote controller
  - 2) Tank Heater select ON by user.
  - 3) Backup Heater Enable
  - 4) Tank Temperature < Tank Set Temperature
  - 5) Heat Pump Thermo OFF
  - 6) 20 minutes from previous heater off.
- Room heater turn OFF condition:
  - 1) Tank Temperature > Tank Set Temperature + [0°C] for continuous 15 seconds. **OR**
  - 2) Heat Pump Thermo ON OR
  - 3) Mode Change or Operation OFF by remote controller OR
    - \* Backup Heater Turn ON/OFF all together according to the selected heater capacity.



## 12.8 Base Pan Heater Control (Optional)

- To enable the base pan heater function, control panel initial setting has to be manually adjusted by activating Base Pan Heater menu.
- There are 2 optional start condition can be selected, Type A or Type B.
- Control details:
  - 1 Type A: (Default Auto Mode)

## Start conditions:

 $\circ$  When outdoor air temperature ≤ 3°C during heating and deice operation is ON.

#### Control contents:

 Base pan heater is ON during deice operation and continues ON for 10 minutes after deice operation ends.

## Cancel condition:

- When outdoor temperature > 6°C after deice end or
- When operation is not at heating mode or
- o Base pan heater ON timer count is completed.

#### 2 Type B: (ON Mode)

## Start conditions:

○ When outdoor air temperature is ≤ 5°C and operates in heating mode, base pan heater is ON.

## **Cancel conditions:**

- When outdoor air temperature is > 7°C or
- When operation is not at heating mode.

# 12.9 Heater Turn ON/OFF priority Control

## Purpose:

 To allow only one heater between room and tank heater to turn ON at the same time due to both heater power supplies is sharing the same ELCB. Prohibit two heater sources to turn ON at the same time to avoid overcurrent.

#### Start condition:

Tank heater function select YES by remote controller

#### Control contents:

- a) When there is only one heater source (Room Heater or Tank Heater) request to turn ON, operate same as normal room heater and tank heater operation.
- b) When both backup heater and booster heater request to turn ON at same time, will turn ON only ONE heater source. Under normal condition, tank heater has priority to turn ON except below condition.
  - i. Backup Heater Priority to Turn ON when
    - Request Backup heater turn ON at Hex Protection control during deice.
    - Request Backup Heater turn ON at Hex Protection Control during low water temperature.
    - Reguest Backup Heater turn ON at Anti-frost control.
    - Heat pump error and Force Mode operate.
- c) When switching from booster heater to backup heater **OR** backup heater to booster heater, need to delay 5 seconds in between Turn OFF one heater source and Turn ON another heater source.

## 12.10 Force Heater Mode

### Purpose of Force Heater Mode

As a backup heat source when heat pump error. Force heater Mode control backup heater to heat up the room circuit, and turn ON back up heater or booster heater to boil up tank water base on the tank heater selection (internal or external)

## Force Heater Control start condition:

- Force heater request ON by user OR auto turn ON by remote controller during error AND (Force Heater mode can be operate regardless of mode selection, remocon will send the lastest mode selection and force bit to indoor. Indoor will judge to turn ON heater to room side if it is heat mode selected, and turn ON heater to heat up tank water base on tank heater selection)
- During Error Happen (exclude the error list below)

## Error List which not allow Force Heater Operation

H12	Capacity Mismatch	H76	Indoor-Remote Controller Communication Error
H20	Abnormal Water Pump	H95 Abnormal Voltage Connection	
H62	Abnormal Water Flow	F37 Abnormal Water Inlet sensor	
H70	Abnormal Back-up Heater OLP	F45 Abnormal Water Outlet sensor	
H74	PCB Communication Error		
[ When tank mode operate with external heater selected & tank heater select ON]			
H72	Abnormal tank sensor	H91 Abnormal tank heater OLP	

#### Force Heater Control Stop Condition:

- Force Heater request OFF **OR**
- Operation OFF request **OR**
- Power reset **OR**
- Error of above list happens during force heater operation.

#### Control contents:

1) After fulfil start condition, indoor will operate the force heater operation according to below mode condition Heat mode Only : Turn ON backup heater to achieve room heat pump target water temperature. Heat + Tank mode : Turn ON backup heater to heat up room **OR** Turn ON Heater to Boil up tank water.

: Water pump and backup heater will OFF in force heater mode Cool mode Only

Cool + Tank mode : Operate pump and internal Heater OR External heater to Boil up tank water. : Operate pump and internal Heater OR External heater to Boil up tank water. Tank mode Only

- \* For heat mode condition, backup heater will only turn ON if the backup heater is enable regardless of Room **Heater Selection**
- \* For tank mode condition, If internal heater selected backup heater will turn ON to boil up tank water. If external heater selected, booster heater will turn ON to boil up tank water regardless of tank heater selection

#### Room Side: (Heat Mode)

- 1) When force heater mode start condition fulfilled, turn ON water pump and turn ON backup heater follow below control.
- 2) Operate the 3 ways valve at room side only and turn ON 2 ways valve as heat mode operation.
- 3) Turn ON the zone pump and mixing valve if system select 2 zone system or Buffer tank connect YES, control according to normal zone pump and mixing valve control.
- 4) When Force heater mode stop condition fulfilled, turn OFF heater as below condition and turn OFF water pump after pump delay time.

#### Backup Heater On Condition:

- a) When Force Heater Control start condition fulfill AND
- b) After water pump operate 2 minute AND
- c) When water outlet temperature < water set temperature + [-4°C] AND
- d) 20 minutes since previous Backup heater Off AND
- e) Backup Heater Enable

## **Backup Heater Stop condition**

- a) Force mode off OR
- b) Operation off **OR**
- When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs OR \* ON/OFF follow normal heater sequence.

#### Tank side (Tank mode)

- 1) When tank mode select and force heater bit received, turn ON backup heater (INTERNAL) or Booster Heater (External) depend on the tank heater selection.
- 2) If tank heater selection is INTERNAL, follow normal thermo judgement to switch 3 ways valve to tank side and room side.
- 3) If tank heater selection is EXTERNAL, only turn ON booster heater according to tank thermo.

#### **Tank Heater selection is INTERNAL:**

#### Backup Heater ON Condition:

- a) After water pump operate 2 mins AND
- b) When tank temperature < Tank set temperature [Remocon Set Tank Re-heat Temp] AND
- c) 20 minutes since previous backup heater OFF AND
- d) Backup heater enable

#### Backup Heater OFF Condition:

- a) Force mode OFF OR
- b) When tank temperature > Tank set temperature for continuous 15 secs OR
- c) Tank Operation OFF

#### Tank Heater selection is EXTERNAL:

## Backup Heater ON Condition:

- a) Force Heater mode ON AND
- b) Tank temperature < tank set temperature + [Remocon Set Tank Re-heat Temp] 1°C, AND
- c) 20 minutes since previous heater off.

## **Backup Heater OFF Condition:**

- a) Tank temperature > tank set temperature for continuous 15 sec
- b) Force mode OFF
- Tank Mode Operation OFF
   (During tank interval or tank mode condition, water pump and 3 ways valve will OFF)

## 12.11 Powerful Operation

Powerful mode is use to increase the capacity of heat pump to achieve higher target temperature. Powerful mode is applicable when heat mode is operating.

#### Remote control setting:

On quick menu of remote control, there is 4 options of powerful mode can be select.

OFF : Cancel powerful mode
 30 minutes : Set powerful for 30 minutes
 60 minutes : Set powerful for 60 minutes
 90 minutes : Set powerful for 90 minutes

#### **Control contents:**

During the time set by remote control, powerful will activate according to 2 shift up controls. However, this function is applicable only for heating. Remote control will transmit the signal to indoor unit once this function is select then transmit OFF signal to indoor when the timer is complete. Indoor will transmit signal to outdoor for frequency control.

Indoor setting temperature shift

- If system is standard system (Optional PCB is not connected)
  - Target water temperature will shift up to Wlo or Whi whichever higher.
- If system is extension system (Optional PCB is connected)
  - Target water Zone 1 and Zone 2 temperature will shift up to Wlo or Whi whichever higher.
  - \* If "Direct Type" temperature control is select, this powerful shift up setting is not effective.

#### Start condition

Powerful function is select by remote control.

#### **End Condition**

- OFF/ON button is pressed.
- Powerful function is OFF by remote control.

## 12.12 Quiet Operation

Quiet mode is use to reduce the noise of outdoor unit by reducing the frequency or fan speed.

#### **Quiet level**

There are 3 level (Level 1, Level 2, Level 3) to set by quick menu function on remote control.

#### **Control content**

Once the quiet function is select, the remote control will transmit the signal to indoor and outdoor unit.

#### Start condition

- Quiet mode is set on remote control.
- Quiet mode is request ON by weekly timer.

#### Stop condition

If any of below condition is achieve.

- OFF/ON button is pressed.
- Quiet mode is OFF by remote control.
- Quiet mode is request OFF by weekly timer.

## 12.13 Sterilization Mode

#### Purpose:

- To sterilize water tank by setting the required boiling temperature.

#### Remote control setting

- Days for sterilization function to start can be select.
- Time of selected day to start sterilization function.
- Boiling temperature (External heater is 55°C ~ 75°C, Internal heater is 55°C ~ 65°C)
- Maximum operation time is 5 minutes to 1 hour.

#### Start condition

- Tank connection set to "YES" by remote control
- Sterilization function selects "YES".
- Sterilization signal received from remote controller by timer.
- Tank mode request ON.

#### Stop condition

- When boiling timer is completed. Boiling timer (Remote control set maximum operation time) start counting once tank achieve boiling set temperature OR
- After 8 hours of operation since sterilization start.
- Tank mode request OFF.

#### Control content:


- During sterilization function activation time, target tank set temperature will internally change to boiling set temperature.
- During sterilization activates, heat pump and heater (external or internal) will operate as normal tank mode to achieve the boiling set temperature.
- Sterilization operation will end when stop condition is fulfill.
- After sterilization is complete, tank set temperature will resume to normal operation.

<sup>\*</sup> Tank temperature may not achieve boiling set temperature if tank heater is select OFF **OR** external compressor switch.

# 12.14 Outdoor Ambient Thermo OFF Control

## Purpose

- Stop provides heating to room side during high outdoor ambient condition.



## Control content

- Heating outdoor ambient thermos OFF control only applicable when heat pump operate in heat mode. (This
  control will not activate when running in tank side)
- Heat pump and water pump will turn OFF when outdoor ambient is higher than outdoor thermo OFF set temperature.
- Heat pump thermos ON when outdoor ambient < outdoor thermos OFF set temperature + 1°C.

## 12.15 Alternative Outdoor Ambient Sensor Control

### Purpose of the Alternative Outdoor Ambient Sensor:

 It is some possibility that the air to water heat pump unit will install at a location where the original ambient sensor is expose to direct sunlight. Therefore, another optional ambient sensor can be connect to indoor PCB and locate at new and better reading location to improve the heat pump performance.

#### Control Detail:

- Remocon can select either the extra outdoor ambient sensor is connected or not. (YES/NO)
- The alternative outdoor ambient sensor will connect to indoor unit main PCB terminal.
- a) when alternative sensor select NO
  - Original Outdoor temperature sensor will use for Indoor & Outdoor heat pump operation reference sensor.
  - Data communication direction: OUTDOOR send outdoor temperature reading to INDOOR.
  - Error judge: OUTDOOR will judge the original outdoor sensor error (F36 display if error detect). No judge error on alternative outdoor sensor
- b) when alternative sensor select YES
  - Alternative Outdoor temperature sensor will use for Indoor & Outdoor heat pump operation reference sensor.
  - Data communication direction: INDOOR send outdoor temperature reading to OUTDOOR.
  - Error judge: INDOOR will judge the Extra outdoor sensor error only after operation ON request received from remocon.
    - (F36 display if error detect). No judge error on original outdoor sensor.

## 12.16 Force DHW mode

#### Purpose:

When user want to use hot water now, user can press this force DWH mode under the quick menu to operate tank only mode to boil up the tank temperature.

#### Remocon setting:

Force DHW function can be activate under quick menu.

## **Control Content:**

- a) when press the Force DHW function during operation OFF condition:
- When receive this Force DHW bit from remocon, indoor will run tank only mode regardless of the mode selection.
- After tank temperature achieve tank thermo off temperature, turn OFF force DHW bit and return to operation OFF with previous mode selection.
- b) When press the Force DHW function during operation ON condition:
- When receive this Force DHW bit from remocon, indoor will memories the running mode and run tank only mode regardless of the mode selection.
- After tank temperature achieve tank thermo off temperature, turn OFF force DHW bit and return to previous memories running mode.
- \* when operation OFF or mode change request from remocon during force DHW mode operation, End force DHW mode and follow the new request operation.
- \* Once receive force DHW mode from remocon, indoor direct start tank mode and consider tank thermo ON. Thermo OFF only when achieve tank thermo OFF depend on the Tank System Setting.

## 12.17 Anti Freeze Control

- Anti freeze protection control menu can be set YES or NO by control panel.
- In heatpump system, there are 3 types of anti freeze control:
  - 1. Expansion tank anti-freeze control
    - Expansion tank anti freeze heater ON condition:
      - o Outdoor ambient temp. < 3°C
    - Expansion tank anti freeze heater OFF condition:
      - Outdoor ambient temp. > 4°C
  - 2. Water pump circulation anti freeze control
    - Water pump turns ON when **ALL** below conditions are fulfilled:
      - Heatpump OFF (stand by) OR error occurs.
      - Water flowing flag is ON.
      - Water flow switch is not abnormal.
      - o Outdoor ambient temp. < 3°C OR outdoor ambient temp. sensor is abnormal.
      - Water inlet/outlet temp. < 6°C.</li>
      - After 5 minutes from previous water pump OFF.
    - Water pump turn OFF when <u>ANY</u> of below conditions is fulfilled:
      - Outdoor ambient temperature ≥ 4°C.
      - During -5°C < outdoor ambient temp. < 4°C</li>
        - After water pump ON for 4 minutes, and water inlet temp. ≥ 8°C.
        - Else, shift to back up heater anti freeze control.
      - During outdoor ambient temp. < -5°C</li>
        - After water pump ON for 4 minutes, and water inlet/outlet ≥ 20°C.
        - Else, shift to back up heater anti freeze control.
    - However, if flow switch is abnormal (H62), then water pump circulation anti freeze control will not activate.
  - Back up heater anti freeze control:
    - Back up heater turn ON when <u>ALL</u> below conditions is fulfilled:
      - Water inlet/outlet temp. < 6°C.
      - o Water pump circulation anti freeze control activated and water pump ON for 4 minutes.
    - Back up heater turns OFF when ANY of below conditions is fulfilled:
      - Water inlet/outlet temp. > 28°C.
      - Water pump circulation anti freeze control deactivated/water pump OFF.
    - However, if back up heater is abnormal (H70) then back up heater anti freeze control will not activate.

## 12.17.1 Zone Anti-Freeze Control

If buffer tank selection is "NO" and Anti- Freeze function select "NO" from remote control, this control cannot
activate.

#### Start condition:

- a) After [5] min from previous Zone pump off. AND
- b) Outdoor air temp < [3] °C **OR** Outdoor sensor is abnormal. **AND**
- c) Zone water temperature < [6] °C **OR** Zone Sensor Short or Open

## Cancel condition:

- a) After water Zone pump ON [4] min AND
- b) Outdoor air temp ≥ [4]°C **OR**
- c) During -5 °C ≤ Outdoor air temp < [4] °C **OR**Zone water temperature sensor > [8] °C
- d) During Outdoor air temp < [-5] °C
  - Zone water temperature sensor > [20] °C
  - \*However, Zone water temperature sensor is Open or Short, Condition C and D is ignored.


# 12.18 Solar Operation (Optional)

## 12.18.1 Solar Operation:

Solar function:

 This function allow user to control the solar pump to operate depend on the solar sensor reading compare to the tank installed. Solar pump will circulate the hot water energy store at solar panel to heat up the DHW Tank or Buffer Tank.

Solar Connection Diagram:



- a) Solar function can only enable when the Optional PCB is connected.
- b) Few part as below need to install to control the solar operation:
- Solar Panel
- Solar Pump
- Solar Panel Sensor
- Tank Sensor (Buffer tank sensor OR DHW Tank sensor depend on the connection direction)
  - \* During Solar Connection to the system, installer need to alert on the high water temperature may flow to the zone circuit or DHW piping circuit. Therefore pipe which withstand higher water temperature need to be installed.

#### Solar remote control setting

- 1) Solar Setting can only be set when the optional PCB connection is select "YES"
- 2) By remote controller, Setting as below list can be set for solar function operation (Installer Menu)
  - Solar Function ("YES" or "NO)
  - Tank Connection Direction ("DHW TANK" or "BUFFER TANK")
  - Delta T turns ON: Difference temperature setting between solar panel sensor and Tank to turn on solar pump. (Range :5 ~ 15°C)
  - Delta T turns OFF: Difference temperature setting between solar panel thermistor and Tank to turn off solar pump. (Range :2 ~ 10°C)
  - Outdoor temp for Anti-Freeze : Outdoor temp to start Anti-Freeze control for solar circuit. (Range : -20 ~ 10°C)
  - Tank Temperature HI Limit Set (Range: 70 ~ 90°C)

## 12.18.2 Solar Operation Control

- Solar function can only be activate if the solar function selection "YES" from remote control. To achieve hot water from solar panel, indoor need to control the solar pump and circulate hot water from solar panel.

## Under normal case:

- Solar pump start condition:
  - a) Solar panel temperature > Delta T turn on setting temp (R/C) + Tank temperature (depend on selection, DHW or Buffer) **AND**
  - b) Tank temperature (DHW or Buffer) < Solar HI Limit Temp (R/C) AND
  - c) Operation ON with heat mode (apply to solar connect to "Buffer Tank" case)
  - \* Condition c) ignore if the solar system is connect to DHW tank (control active under operation OFF time for Tank connection case)
- Solar pump stop condition:
  - a) Solar panel temperature < Delta T turn OFF setting temp (R/C) + Tank temperature (depend on selection, DHW or Buffer) OR
  - b) Tank hot water temp >= Solar HI Limit Temp (R/C) + [2]°C

## Under solar Anti-freeze protection control:

- Solar pump start condition:
  - a) Outdoor temp < Outdoor temp setting for Anti-Freeze (R/C)
- Solar pump stop condition:
  - a) Outdoor temp > Outdoor temp setting for Anti-Freeze + [2]°C

- Solar operation during error:
  - During Tank sensor (DHW or Buffer depend on selection) abnormal, Solar operation will not able to function.
  - During Solar Panel sensor detect OPEN (not include SHORT), Solar operation will not able to function too.

<sup>\*\*</sup>However, During Cool mode this function cannot activate if Tank selection is "Buffer Tank".

<sup>\*\*</sup>Solar pump can operate even if Heat pump is under error stop.

## 12.19 Boiler Bivalent Control

- Boiler is an additional or alternative heat source to heat up the room when necessary.
- Purpose of this control is to turn ON and turn OFF the Boiler output signal when boiler heating capacity needed in the system.
- Boiler is possible to connect to DHW Tank and Buffer Tank depends on the installer.
- Boiler operation parameter need to be set on Boiler itself, indoor do not control the boiler operation direction and operation.
- There are Alternative mode, Parallel mode, & Advance Parallel mode available to select by installer to fit to the total system.

## Bivalent control selection by remote controller

#### Remote control setting value:

1) Outdoor Ambient Set = (Range: -15°C ~ 15°C)

#### a) Alternative Mode

Only one heat source operates at one time, either heat pump or boiler depends on condition.

### Control detail:

During Operation ON at Heat mode or Tank mode or Heat + Tank Mode

- Boiler signal turn ON and heat pump and water pump turn OFF when:
  - a. Outdoor ambient < Outdoor Ambient Set AND
  - b. Boiler prohibit flag = 0

- Boiler signal turn OFF and heat pump and water pump turn ON when:
  - a. Outdoor ambient > Outdoor Ambient Set + [2°C] OR
  - b. Boiler prohibit flag = 1

## b) Parallel Mode

 Parallel mode allows heat pump and boiler ON at the same time. Boiler operates as an additional heating capacity when low heat pump capacity at low ambient condition.

## Control detail:

During operation ON at Heat mode or Tank mode or Heat + Tank mode

- Boiler signal turns ON when:
  - a. Outdoor ambient < Outdoor Ambient Set AND
  - b. Boiler prohibit flag = 0
- Boiler signal turns OFF when:
  - a. Outdoor ambient > Outdoor Ambient Set + [2°C] OR
  - b. Boiler prohibit flag = 1

### c) Advance Parallel Mode

 Advance parallel mode allow heat pump to operate and turn ON boiler only when ambient and temperature condition is fulfilled.

## Remote control setting value:

- 1) Outdoor Ambient Set = (Range : -15°C ~ 15°C)
- 2) Selection of boiler connection direction. (Heat only, DHW only, Heat & DHW)
- 3) Setting data under Heat Direction
  - a. Start Temperature
    b. Start Delay Timer
    c. Stop Temperature
    d. Stop Delay Timer
    | START\_TIMER |
    | STOP\_TEMP |
    | STOP\_TIMER |
- 4) Setting data under DHW Direction
  - a. Delay Timer | DELAY\_TIMER |

<sup>\*\*</sup> However indoor water pump can operate when Anti-freeze control condition fulfilled.

## Control detail:

## During operation ON at Heat Mode

- Boiler signal turns ON when
  - a. Outdoor ambient < Outdoor Ambient Set AND
  - b. Buffer tank temperature < Target Buffer Tank Temperature + [START\_TEMP] for [START\_TIMER]

    AND
  - c. Heat pump operate at room side AND
  - d. Connection of Boiler to Heating Select "YES" From installer menu AND
  - e. Buffer Tank connection select "YES" AND
  - f. Boiler prohibit flag = 0
- Boiler signal turns OFF when
  - a. Outdoor ambient > Outdoor Ambient Set + [-2°C] OR
  - b. Buffer Tank temperature > Target Buffer Tank temperature + [STOP TEMP] for [STOP TIMER] OR
  - c. Heat pump not at room side. OR
  - d. Boiler prohibit flag = 1

## **During operation ON at Tank Mode**

- Boiler signal turns ON when
  - a. Outdoor ambient < Outdoor Ambient Set AND
  - b. Heat pump operate at tank side for continuous | DELAY TIMER | AND
  - c. Connection of Boiler to DWH Tank select "YES" from installer menu. AND
  - d. Boiler prohibit flag = 0
- Boiler signal turns OFF when
  - a. Outdoor ambient > Outdoor Ambient Set + [2°C] OR
  - b. Heat pump not operates at tank side. OR
  - c. Boiler prohibit flag = 1

## **Boiler prohibit flag control**

#### Purpose:

For product safety. Boiler signal is OFF when water temperature is too high.

## Start condition:

- a. Water outlet ≥ 85°C continues for 5 minutes.
- b. Water inlet ≥ 85°C continues for 5 minutes.
- c. Zone1 water temp ≥ 75°C continues for 5 minutes.
- d. Zone2 water temp ≥ 75°C continues for 5 minutes.

## Contents:

After start condition fulfilled, set boiler prohibit flag = 1

#### Cancel condition:

- After 30 minutes from start condition fulfilled.

## Contents:

Set boiler prohibit flag = 0

# 12.20 External Room Thermostat Control (Optional)

## Purpose:


Better room temperature control to fulfill different temperature request by external room thermostat. Recommended external room thermostat:

Maker	Characteristic
Siemen (REV200)	Touch panel
Siemen (RAA20)	Analog

#### Connection of external room thermostat:

Wire Connection and thermo characteristic of Siemen REV200:


Setting	L/L1 (H)	Heat Thermo	L/L2 (C)	Cool Thermo
Set Temp < Actual Temp	Open Circuit	OFF	Short Circuit	ON
Set Temp > Actual Temp	Short Circuit	ON	Open Circuit	OFF



heating and cooling line for heat + cool model.

Wire Connection and thermo characteristic of Siemen RAA20:

Setting	L/Y1 (H)	Heat Thermo	L/Y2 (C)	Cool Thermo
Set Temp < Actual Temp	Open Circuit	OFF	Short Circuit	ON
Set Temp > Actual Temp	Short Circuit	ON	Open Circuit	OFF



## Control Content:

- External room thermostat control activate only when remote thermostat connection select YES by Indoor control panel.
- When indoor running heat mode, refer thermo On/Off from heating line feedback. And when indoor running cool mode, refer thermo On/Off from cooling line feedback.
- Heat pump Off immediately when receive thermo off feedback.


## 12.21 Three Ways Valve Control

### Purpose:

- 3 ways valve is used to change flow direction of hot water from heat pump between heating side and tank side.

#### **Control contents:**

- 1 3 ways valve switch Off:
  - o During 3 ways valve switch Off time, the hot water will provide heat capacity to heating side.
- 2 3 ways valve switch On:
  - During 3 ways valve switch On time, the hot water will provide heat capacity to tank side.
- 3 Stop condition:
  - During stop mode, 3 ways valve will be in switch off position.



- \* During pump down and force mode, fix 3 ways valve in close condition.
- \* Recommended Parts: SFA 21/18 (Siemens)


# 12.22 Two Ways Valve Control

Functionality of 2 ways valve:

Use to allow hot water to floor heating panel or block cold water to floor heating panel.

#### Control contents:


- 1 When indoor running in heat mode, OPEN the 2 ways valve.
- 2 When indoor running in cool mode, CLOSE the 2 ways valve.
- 3 Stop condition:
  - a. During stop mode, fix 2 ways valve in close condition.



- \* During pump down mode, fix 2 ways valve in close condition.
- \* During force mode, open 2 ways valve.
- \* Recommended Parts : SFA 21/18 (Siemens)

## 12.23 External OFF/ON Control


• Communication circuit between indoor unit and external controller is as per below.



- Maximum length of communication cable is 50 meter.
- Control content:

External Control Switch	Control Panel OFF/ON	Control Panel Power LED	System Status
ON	ON	ON	ON
ON	OFF	OFF	OFF
OFF	ON	ON	OFF
OFF	OFF	OFF	OFF

### Remocon Screen Display and Control Detail:



When External SW connection select "YES" from remocon installer menu:

- Heating or Cooling system will operate normally if the External Switch signal is ON.
- Once the External Switch turn OFF, System Turn OFF (Heat pump, water pump, heater etc...)
- Remocon LED remain ON or OFF according to the current operation request.
- Pop up menu at remocon main screen as above screen to inform customer system stop by External Switch.
- It is possible to press cancel and return to main screen to do change of operation setting while waiting the External Switch turn ON back.
- Remocon LED will always follow the latest changes from remocon.
- If no action on remocon for continuous 5 minutes, the pop up screen will show again on the screen.
- But once the External Switch Turn ON back, pop up screen will dsappear and system can operate normally according to the latest operation setting and request.

## 12.24 External Compressor Switch (Optional PCB)

External compressor switch port can have two purpose of control as below:

- a) Heat source ON/OFF function (Dip switch Pin 3 on PCB "OFF")
- b) Heater ON/OFF function (Dip switch Pin 3 on PCB "ON")

### a) Heat source ON/OFF function

### Purpose:

Heat pump ON/OFF function is use to turn OFF the high power consumption device (Heat pump, & Heater)
when there is energy or electric current limitation. Other optional function still can be operate under heat
pump and heater OFF condition.

#### Control Detail:

- This External Compressor Switch is possible to connect to Optional PCB only.
- Once the remocon select External Compressor Switch connection "YES", & Dip Switch on PCB "OFF"
   This heat pump ON/OFF function will activate
- The ON/OFF signal of this External Compressor Switch is same as External Switch.
- When the External Compressor Switch is ON:
  - a) Heat pump system operate normally
  - When the External Compressor Switch is OFF:
    - a) Heat pump, Indoor water pump & Heater (Booster heater & Backup Heater) need to turn OFF
    - b) Solar, Boiler and zone control can be operate follow normal control condition.

      \* pump delay OFF also included in this control

(There is NO pop up screen like External Switch when this External Compressor Switch is OFF.)

## b) Heater ON/OFF function

#### Purpose:

 Heater ON/OFF function is use to turn OFF the heater (backup heater & booster heater) when there is energy or electric current limitation. Heat pump and other optional function still can operate.

#### Control detail:

- This External Compressor Switch is possible to connect to Optional PCB only.
- Once the remocon select External Compressor Switch connection "YES", & Dip Switch on PCB "ON"
   This heater ON/OFF function will activate
- When the External Compressor Switch is ON:
  - a) Heat pump and heater operate normally
- When the External Compressor Switch is OFF:
  - a) Backup heater and booster heater cannot operate even heater request is ON.
  - b) Heat pump and option function (Solar, Boiler and zone control) can be operate follow normal control condition.

(There is NO pop up screen like External Switch when this External Compressor Switch is OFF.)

## 12.25 Heat/Cool Switch (Optional PCB)

#### Purpose:

 User can switch the running mode from heat to cool or cool to heat through external installed Heat/Cool switch. This kind of heat / cool switch may built in inside the field supply room remocon as well.

#### Control contents:


- Heat/Cool Switch can only be set when Cool Function is "enable" at custom menu setting, & Extension PCB select "YES" & Zone 1 not set "Pool" condition.
- This heat/cool switch control will be activate only when installer set the Heat/Cool Switch "USE" through remocon.
- Once the Heat/Cool Switch Set "USE", remocon will check indoor send Signal to judge the option of mode select.
  - a) When Heat/Cool Switch Contact Open : Remocon only can select Heat Mode, or Heat + Tank Mode, or Tank Mode
  - b) When Heat/Cool Switch Contact Close: Remocon only can select Cool Mode, or Cool + Tank Mode, or Tank Mode
- Operation ON/OFF will depend on remocon request.
- When Heat Mode is running with Contact Open, user change this setting to contact close, indoor will this signal to remocon judge and change mode to cool and send back to indoor. And it is same as from cool mode change to heat mode.
  - \* This switch have higher priority, remocon follow indoor send signal when control activated.
  - \* There is no effect to the operation when the mode running is only Tank Mode.

(Weekly Timer are ignored and cannot be set during Heat / Cool Switch is "Enable" Condition.)

## 12.26 SG Ready Control (Optional PCB)

Purpose:

To set ON/OFF of heat pump and target temperature by digital input of third party device if necessary in field.



#### Remote control setting

For this function, following items need to be set on R/C (installer menu) –

- SG control = YES or NO
- Capacity up setting 1
  - Heating capacity [50 ~ 150 %]
  - DHW capacity [50 ~ 150 %]
- Capacity up setting 2
  - Heating capacity [50 ~ 150 %]
  - DHW capacity [50 ~ 150 %]

#### Control contents:

If SG control on remote control = "Yes", then following control only activate by digital input.

- While Digital input is " 00 " (Normal operation)
  - Normal operation. Once detect '00' system will operate back to normal condition.
     (All the target set temperature for heating side and DHW side will return back to previous set temperature when digital signal change from "10' or"11" back to "00".)
- While digital input is detected " 01 " (HP stop)
  - Heat pump & room heater & tank heater cannot operate.
    - (Solar control and Boiler back up and 2 Zone control can activate.)
- While digital input is detected " 10 " (Capacity 1)
  - Target temperature for heating and DHW Tank is changed according to the percentage set by Remote control setting. However, which setting temperature is change depend on system setting.
- While digital input is detected "11 " (Capacity 2)
  - Target temperature for heating and DHW Tank is changed according to the percentage set by Remote control setting. However, which setting temperature is change depend on system setting.

## While digital input is detected " 10 " (Capacity 1)

Setting temperature for heating and Tank is changed.
 However, which setting temperature is change depend on system setting.

#### If Buffer selection is "YES"

## Room side

New Target Buffer tank temperature = Current Target Buffer Tank Temperature \* Remote Control setting (" capacity 1) %

- \* Max Min regulation is follow Target Buffer tank temperature control specification
- \*\* No change of Target zone water temperature, only set higher buffer tank temperature.

#### DHW Tank side

New Tank Set Temperature = Tank Set Temperature \* Remote Control setting for DHW ("Capacity 1) % \* (Max regulation depend on the tank max setting limit)

### If Buffer selection is "NO"

### Room side

New Target Zone Water Temperature = Current Target Zone Water Temperature \* Remote Control Setting (\*Capacity 1) %

(Zone 1 and Zone 2 will change according to its own target zone water temperature.)

(Max regulation depend on the temperature control type select)

#### DHW Tank side

New Tank Set Temperature = Tank Set Temperature \* Remote Control setting for DHW ("Capacity 1) % \* (Max regulation depends on the tank max setting limit)

## While digital input is detected " 11 " (Capacity 2)

Setting temperature for heating and Tank is changed.
 However, which setting temperature is change depend on system setting.

#### If Buffer selection is "YES"

#### Room side

New Target Buffer tank temperature = Current Target Buffer Tank Temperature \* Remote Control setting (" capacity 2) %

- \* Max Min regulation is follow Target Buffer tank temperature control specification
- \*\* No change of Target zone water temperature, only set higher buffer tank temperature.

#### DHW Tank side

New Tank Set Temperature = Tank Set Temperature \* Remote Control setting for DHW ("Capacity 2) % \* (Max regulation depends on the tank max setting limit)

#### If Buffer selection is "NO"

### Room side

New Target Zone Water Temperature = Current Target Zone Water Temperature \* Remote Control Setting (\*Capacity 2) %

(Zone 1 and Zone 2 will change according to it's own target zone water temperature.)

(Max regulation depend on the temperature control type select)

### DHW Tank side

New Tank Set Temperature = Tank Set Temperature \* Remote Control setting for DHW ("Capacity 2) %

- \* (Max regulation depends on the tank max setting limit)
- \*\* This function is not applicable for Cooling mode.

# 12.27 Demand Control (Optional PCB)

## Remote control setting:

When Optional PCB connection select 'YES", Demand Control function can select "YES" or "NO".

## Purpose:

- After the demand control select YES, below control will activated.
  - o 0-10V Demand control

### 0-10V Demand control

- Demand control is use to reduce the current usage of heat pump unit by third party device.

## Control start condition:

- o Select "YES" at Demand control at installer menu.
- o 0-10V input for this electrical current control is detected.

## Control content:

- o If start condition is fulfilled, indoor will receive the voltage signal from optional PCB. Indoor will send the rate value to outdoor unit.
- Outdoor will change the current limit according to the percentage receive from indoor unit.

## 12.28 Holiday Mode

• Purpose:

Promotes energy saving by allowing the user to stop the system during holiday and enables the system to resume at the preset temperature after holiday.

#### Control details:

- Indoor operate the unit according running mode request. Target temperature will follow holiday setting temperature.
  - If heat mode request is receive, Target Water Out Temperature will change according to holiday shift temperature set.
    - [If heat is set OFF at holiday, unit, water pump and zone control will OFF]
  - If tank mode request is receive, Target Tank Set Temperature will change according to the holiday tank shift temperature set.
    - [If tank is set OFF at holiday, heat pump and tank heater will OFF]
- After days of holiday have been set, heat pump will stop and only resume operation at the end of holiday countdown.

## Start condition:

- Holiday timer set and the holiday timer start
  - \* The day holiday mode was set is counted as day 1.
- Stop condition:
  - o OFF/ON button is pressed.
  - Holiday timer is reached.

## 12.29 Dry Concrete

Purpose:

Provide heat to floor heating panel and dry the wet concrete during installation.

- Setting condition:
  - o Dry concrete parameter can be set through remote control under system setup.
  - o Parameters are possible to set up to 99 days with different target set temperature
- Control details:
  - Dry concrete mode will be activates when select ON from service setup.
  - Once start dry concrete function, remote control will send step 1 setting temperature to indoor unit.
    - \* This temperature is set at zone temperature. If system is 2 zones, both zone target temperature is set as same temperature.
  - Heat pump will start heat mode operation to room side with received target water outlet temperature.
    - \* Heat pump will operate according to Heat pump Target Water Temperature.
  - After complete day 1 setup operation, day 2 data will be send to indoor at 12.00am on the second day.
  - Each preset data will be send every day until dry concrete mode is complete, unit will turns OFF and exit dry concrete function.
  - 3 ways valve and booster heater will turn OFF and 2 ways valve will turns ON.
- Cancel condition:
  - o Dry concrete mode is complete and OFF signal is received.
  - OFF signal is received by pressing OFF/ON button.

## 12.30 Flow Sensor

- The water flow sensor serves as an overload protector that shuts down the unit when the water level is detected
  to be low.
- Abnormal flow detection:

Sequence	Abnormal flow	Normal flow
Normal case	Flow rate < 11 l/min or ≥ 69 l/min	≥ 11 l/min
During status 2~6 on Anti-freeze deice	Flow rate ≥ 11 l/min	< 11 l/min

## 13. Protection Control

# 13.1 Protection Control for All Operations

## 13.1.1 Time Delay Safety Control

1 The compressor will not start for three minutes after stop of operation.

## 13.1.2 30 Seconds Forced Operation

- 1 Once the compressor starts operation, it will not stop its operation for 30 seconds.
- 2 However, it can be stopped using control panel at indoor unit.

## 13.1.3 Total Running Current Control

- 1 When the outdoor running current exceeds X value, the compressor frequency will decrease.
- 2 If the outdoor running current does not exceed X value, the compressor frequency will return to normal operating frequency.
- If the outdoor running current continue to increase till exceed Y value, compressor will stop, and if this occurs 3 times within 20 minutes, system will stop operation and OFF/ON control panel LED will blink (F16 error occurs).


	WH-UE	009HE8	WH-UE	)12HE8	WH-UE	016HE8
Operation Mode	X (A)	Y (A)	X (A)	Y (A)	X (A)	Y (A)
Heating	7.3	10.6	7.3	10.6	8.4	10.6
Cooling	6.2	10.6	6.5	10.6	8.4	10.6

#### A. DC Peak Current Control

- 1 When the current to IPM exceeds set value of 34 A, compressor will stop. Compressor will restart after three minutes.
- If the set value exceeds again for more than 30 seconds after the compressor restarts, operation will restart after two minutes.
- If the set value exceeds again for within 30 seconds after the compressor restarts, operation will restart after one minute. If this condition repeats continuously for seven times, system will stop operation and OFF/ON control panel LED will blink (F23 error occurs).

## 13.1.4 Compressor Overheating Prevention Control


• The compressor operating frequency is regulated in accordance to compressor tank temperature as shown in below figures. When the compressor tank temperature exceeds 107°C, compressor will stop, and if this occurs 4 times within 30 minutes, system will stop operation and OFF/ON control panel LED will blink (F20 error occurs).



## 13.1.5 High Pressure Sensor Control

- Purpose:
  - To protect the system operation.
- Detection period:
  - After compressor on for 1 minute.
- Detection conditions:
  - When abnormal high voltage detection, 5 V or when open circuit detection 0V for 5 seconds continuously.
- After detection:
  - When abnormality is detected 4 times within 120 minutes, unit stop operation.
  - OFF/ON control panel LED will blink (H64 error occurs).

## 13.1.6 Outside Temperature Current Control



## 13.1.7 Crank Case Heater Control

- Purpose:
  - For compressor protection during low outdoor ambient operation (during heating low temperature operation).
- Control content:
  - a. Trigger heater START condition
    - When the outdoor air temperature is below than 5°C, and discharge temperature is 11°C or below.
  - b. Resetting heater STOP condition
    - 1. When the outdoor air temperature exceeds entry condition (2°C)
    - 2. When the discharge temperature exceeds entry condition (5°C)

# 13.2 Protection Control for Heating Operation

## 13.2.1 Outdoor Air Temperature Control


The maximum current value is regulated when the outdoor air temperature rises above 14°C in order to avoid compressor overloading.

## 13.2.2 Deice Operation

When outdoor pipe temperature and outdoor air temperature is low, deice operation start where outdoor fan motor stop.

• Deice judging condition


Outdoor Unit Deice Control



#### Deice start depends:

- 1. Outdoor air sensor temp.
- 2. Outdoor pipe sensor temp.
- 3. Heating accumulation time


- Deice operation time diagram
  - a. Deice mode 1 control:



# 13.3 Protection Control for Cooling Operation

## 13.3.1 Outdoor Air Temperature Control

- The Compressor operating frequency is regulated in accordance to the outdoor air temperature as shown in the diagram below.
- This control will begin 1 minute after the compressor starts.
- Compressor frequency will adjust base on outdoor air temperature.



## 13.3.2 Freeze Prevention Control 1


- 1 When indoor heat exchanger temperature is lower than 0°C continuously for 10 seconds, compressor will stop operating.
- 2 Compressor will resume its operation three minutes after the indoor heat exchanger is higher than 1°C.
- 3 Indoor heat exchanger freeze prevention (H99) will memory in error history.

# 14. Servicing Mode

## 14.1 How to Take Out Front Plate

Please follow the steps below for take out front plate. Before removing the front plate of indoor unit, always switch off all power supply (i.e. indoor unit power supply, heater power supply and Tank Unit power supply).

- 1 Remove the 2 mounting screws which located at bottom of the front plate.
- 2 Gently pull the lower section of the front plate towards you to remove the front plate from left and right hooks.
- 3 Hold the left edge and right edge of front plate to lift up front plate from hooks.



## 14.2 Test Run

- 1 Fill up the Tank Unit with water. For details refer to Tank Unit installation instruction and operation instruction.
- 2 Set ON to the Indoor Unit and RCCB/ELCB. Then, for control panel operation please refers to air-to-water heatpump operation instruction.
- 3 For normal operation, pressure gauge reading should be in between 0.05 MPa and 0.3 MPa.
- 4 After test run, please clean the Water Filter Set. Reinstall it after finish cleaning.

# 14.3 Expansion Vessel Pre Pressure Checking

[Lower limit water volume of the system]

Please ensure the capacity of the circulating water of the total system including the capacity of the indoor unit is more than 50 L.

If the water capacity is insufficient, during deice operation, the water temperature is lowered and the water will freeze in the system's component leading to product failure.

[Upper limit water volume of the system]

The indoor unit has a build-in Expansion Vessel with 10 L air capacity and initial pressure of 1 bar.

Total amount of water in the system should be below 260 L. If the total amount of water is more than 260 L, please add expansion vessel (field supply). The expansion vessel capacity required for the system can be calculated from the formula below.

$$V = \frac{\epsilon \times V_0}{1 - \frac{98 + P_1}{98 + P_2}}$$

V : Required gas volume

<expansion vessel volume L>

Vo : System total water volume <L>

 $\mathcal{E}$ : Water expansion rate 5  $\rightarrow$  60°C = 0.0171

P<sub>1</sub>: Expansion tank filling pressure = (100) kPa

P<sub>2</sub>: System maximum pressure = 300 kPa

( ) Please confirm at actual place

 The gas volume of the sealed type expansion vessel is presented by <V>.

 It's advised to add 10% margin for required gas volume of calculation. Water expansion rate table


Trater expansion rate table			
Water temperature (°C)	Water expansion rate ε		
10	0.0003		
20	0.0019		
30	0.0044		
40	0.0078		
50	0.0121		
60	0.0171		
70	0.0228		
80	0.0291		
90	0.0360		

[Adjustment of the initial pressure of the expansion vessel when there is a difference in installation height] If the height difference between the indoor unit and the highest point of the system water circuit (H) is more than 7m, please adjust the initial pressure of the expansion vessel (Pg) according to the following formula.


Pg= (H\*10+30) kPa

# 14.4 Pump Down Procedures

Refer below steps for proper pump down procedure.




### 14.5 How To Adjust Pump Speed



Press ▲ or ▼ SW to select & confirm operation

### 14.6 How To Adjust Pump Speed




Press ▲ or ▼ SW to select & confirm operation

### NOTE:

- 1. Whenever at [Screen 5], if press ( SW to OFF, pump operation should be turned OFF.
- 2. Whenever at [Screen 6], if press ( SW to OFF, pump operation should be turned OFF.

### 14.7 How To Unlock Cool Mode

Operation must be OFF




### 14.8 EEPROM Factory Default Data Setup Procedure




- EEPROM default data setup is only possible during initialization process.
- Press (  $\triangle$  ,  $\nabla$  ,  $\triangleleft$  ,  $\triangleright$  )simultaneously for 5secs continuously, initialization process will stop & EEPROM default data setup process will start.


During EEPROM default data setup process, display should be as shown below.




- Once EEPROM default data setup process is complete, initialization process will re-start from beginning.



### 14.9 Dry Concrete Setup





### 15. Maintenance Guide


In order to ensure safety and optimal performance of the unit, seasonal inspections on the unit, functional check of RCCB/ELCB, field wiring and piping have to be carried out at regular intervals. This maintenance should be carried out by authorized dealer. Contact dealer for scheduled inspection.

### 1 Water pressure

Water pressure should not lower than 0.05 MPa (with inspects the Water Pressure Gauge). If necessary add tap water into Tank Unit. Refer to Tank unit installation instruction for details on how to add water.


#### 2 Pressure relief valve

- Check for correct operation of Pressure Relief Valve by turning on the lever to become horizontal.
- o If you do not hear a clacking sound (due to water drainage), contact your local authorized dealer.
- Push down the lever after finish checking.
- In case the water keeps drained out from the unit, switch off the system, and then contact your local authorized dealer.



#### 3 Air purge valve

Air purge valve must be installed at all high points in a closed water circuit system. An automatic air purge valve is provided inside the indoor unit. To automatically purge the air from the system, turn the plug on the air outlet anticlockwise by one complete turn from fully closed position. Excessive air is automatically purged if the plug is kept in this position.



#### 4 Indoor unit control board area

Thorough visual inspection of the control board and look for defects, i.e. loose connection, melting of wire insulator and etc.

### 5 RCCB/ELCB

Ensure the RCCB/ELCB set to "ON" condition before check RCCB/ELCB.

Turn on the power supply to the Indoor Unit.

This testing could only be done when power is supplied to the Indoor Unit.




- Push the "TEST" button on the RCCB/ELCB. The lever would turn down and indicate "0", if it functions normal
- Contact authorized dealer if the RCCB/ELCB malfunction.
- o Turn off the power supply to the Indoor Unit.
- o If RCCB/ELCB functions normal, set the lever to "ON" again after testing finish.

### 6 Reset overload protector

Overload Protector a serves the safety purpose to prevent the water over heating. When the Overload Protector a trip at high water temperature, take below steps to reset it.

- a. Take out the cover.
- b. Use a test pen to push the centre button gently in order to reset the Overload Protector.
- c. Fix the cover to the original fixing condition.



Use test pen to push this button for reset Overload protector.

### 15.1 Maintenance for Water Filter Set

### 15.1.1 Service and maintenance

### When connect CN-CNT connector with computer

Please use optional USB cable to connect with CN-CNT connector.

After connected, it requests for driver. If PC is under Windows Vista or later version, it automatically installs the driver under internet environment.

If PC uses Windows XP or earlier version and there is no internet access, please get FTDI Ltd's USB - RS232C conversion IC driver (VCP driver) and install.

http://www.ftdichip.com/Drivers/VCP.htm


#### If forget Password and cannot operate remote controller

Press  $\longrightarrow$  +  $\longrightarrow$  for 5 sec.


Password unlock screen appears, press Confirm and it shall reset.

Password will become 0000. Please reset it again. (CAUTION) Only display when it is locked by password.

#### 15.1.2 Maintenance menu



### 15.1.3 Custom menu



### 15.1.4 Specifications

# 15.1.4.1 Specifications of fresh water was heat transfer medium in brazed heat exchanger

Parameter	Quality Limits for Tap Water on the Secondary Side
Temperature	Below 60°C
рН	7 to 9
Alkalinity	60mg/I <hco<sub>3 &lt;300mg/I</hco<sub>
Conductivity	< 500µS/cm
Hardness	$[Ca^{+}, Mg^{+}] / [HCO_{3}^{-}] > 0.5$
Chloride	< 200mg/l at 60°C
Sulphate	$[SO_4^{2-}] > 100$ mg/I and $[HCO_3^{-}] / [SO_4^{2-}] > 1$
Nitrate	NO <sub>3</sub> < 100mg/I
Chlorine	< 0.5mg/l

### 15.1.4.2 External filter

Solids in the water must be filtered.

Minimum filter mesh size required for the field supply external filter in the water inlet is 20 mesh.

# 16. Troubleshooting Guide

#### 16.1 Refrigeration Cycle System

In order to diagnose malfunctions, make sure that there are no electrical problems before inspecting the refrigeration cycle.


Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a

The normal pressure of the refrigeration cycle depends on various conditions, the standard values for them are shown in the table on the right.

#### Normal Pressure (Standard)

	Gas pressure MPa (kg/cm²G)	
Heating Mode	2.3 ~ 2.9 (23 ~ 29)	
Cooling Mode	0.9 ~ 1.2 (9 ~ 12)	

- ★ Condition: Outdoor temperature 7°C at heating mode and 35°C at cooling mode.
  - Compressor operates at rated frequency.



# 16.2 Relationship between the Condition of the Air-to-Water Heatpump Indoor and Outdoor Units and Pressure and Electric Current

	Heating Mode			Cooling Mode		
Condition of the Air-to-Water Heatpump indoor and outdoor units	Low Pressure	High Pressure	Electric current during operation	Low Pressure	High Pressure	Electric current during operation
Water leakage or insufficient water flow rate in the system	*	*	-	1	1	1
Excessive amount of refrigerant	-	-	-	1	1	1
Inefficient compression	-	*	*	-	1	1
Insufficient refrigerant (gas leakage)	1	1	1	1	1	1
Outdoor heat exchange deficiency	1	1	1	*	1	1
Clogged expansion valve or Strainer	*	-	-	*	1	1

Carry out the measurements of pressure, electric current, and temperature fifteen minutes after an operation is started.

### 16.3 Breakdown Self Diagnosis Function


### 16.3.1 Self Diagnosis Function (Three Digits Alphanumeric Code)

- When abnormality occur during operation, the system will stop operation, and OFF/ON control panel LED will blink and error code will display on the control panel.
- Even error code is reset by turning OFF power supply or by selecting ERROR RESET, if the system abnormality
  is still unrepaired, system will again stop operation, and OFF/ON control panel LED will again blinks and error
  code will be display.
- The error code will store in IC memory.

#### • To check the error code

- When an abnormality occurs, system will stop operation and OFF/ON control panel LED will blink.
- Error code of the abnormality will be display on the control panel.
- To determine the abnormality description, the error code table needs to be referred.

eg:



Press 


to select Close / Reset then press


### To display past/last error code


- Turn ON power supply.
- Refer below procedure to retrieve the error code history.

### • To permanently delete error code from IC memory

- Turn ON power supply.
- Refer below procedure to clear error history.







# 16.4 Error Codes Table

Diagnosis display	Abnormality/Protection control	Abnormality judgement	Primary location to verify	
H00	No abnormality detected	_	<del>-</del>	
H12	Indoor/Outdoor capacity unmatched	90s after power supply	<ul> <li>Indoor/outdoor connection wire</li> <li>Indoor/outdoor PCB</li> <li>Specification and combination table in catalogue</li> </ul>	
H15	Outdoor compressor temperature sensor abnormality	Continue for 5 sec.	Compressor temperature sensor (defective or disconnected)	
H20	Water pump abnormality	Continue for 10 sec.	<ul><li>Indoor PCB</li><li>Water pump (malfunction)</li></ul>	
H23	Indoor refrigerant liquid temperature sensor abnormality	Continue for 5 sec.	<ul> <li>Refrigerant liquid temperature sensor (defective or disconnected)</li> </ul>	
H27	Service valve error	Continue for 5 minutes	<ul> <li>High pressure sensor (defective or disconnected)</li> </ul>	
H28	Abnormal solar sensor	Continue for 5 sec.	<ul> <li>Solar temperature sensor (defective or disconnected)</li> </ul>	
H31	Abnormal swimming pool sensor	Continue for 5 sec.	<ul> <li>Pool temperature sensor (defective or disconnected)</li> </ul>	
H36	Abnormal buffer tank sensor	Continue for 5 sec.	<ul> <li>Buffer tank sensor (defective or disconnected)</li> </ul>	
H38	Brand code not match	When indoor and outdoor brand code not same	<del>-</del>	
H42	Compressor low pressure abnormality	_	<ul> <li>Outdoor pipe temperature sensor</li> <li>Clogged expansion valve or strainer</li> <li>Insufficient refrigerant</li> <li>Outdoor PCB</li> <li>Compressor</li> </ul>	
H43	Abnormal Zone 1 sensor	Continue for 5 sec.	Water temperature Zone 1 sensor	
H44	Abnormal Zone 2 sensor	Continue for 5 sec.	Water temperature Zone 2 sensor	
H62	Water flow switch abnormality	Continue for 1 min.	<ul><li>Water flow switch</li><li>Outdoor low pressure sensor</li></ul>	
*H63	Refrigerant low pressure abnormality	Continue for 5 sec.	(defective or disconnected)  • Outdoor high pressure sensor	
H64	Refrigerant high pressure abnormality	Continue for 5 sec.	(defective or disconnected)	
*H65	Deice circulation error	Continue for 10 sec.	<ul> <li>Water flow switch sensor (defective or disconnected)</li> <li>Water pump malfunction</li> <li>Buffer tank (is used)</li> </ul>	
H67	Abnormal External Thermistor 1	Continue for 5 sec.	Room temperature Zone 1 sensor	
H68	Abnormal External Thermistor 2	Continue for 5 sec.	Room temperature Zone 2 sensor	
H70	Back-up heater OLP abnormality	Continue for 60 sec.	Back-up heater OLP     (Disconnection or activated)	
H72	Tank sensor abnormal	Continue for 5 sec.  Communication or transfer	Tank sensor	
H74	PCB communication error	error  Room heater disable and deice	Indoor main PCB and Sub PCB	
H75	Low water temperature control	request to operate under low water temperature	<ul> <li>Heater operation must enable to increase water temperature</li> </ul>	
H76	Indoor - control panel communication abnormality	_	<ul> <li>Indoor - control panel (defective or disconnected)</li> </ul>	
H90	Indoor/outdoor abnormal communication	> 1 min after starting operation	<ul><li>Internal/external cable connections</li><li>Indoor/Outdoor PCB</li></ul>	
H91	Tank heater OLP abnormality	Continue for 60 sec.	<ul> <li>Tank heater OLP (Disconnection or activated)</li> </ul>	
H95	Indoor/Outdoor wrong connection	_	Indoor/Outdoor supply voltage	
H98	Outdoor high pressure overload protection	_	Outdoor high pressure sensor Water pump or water leakage Clogged expansion valve or strainer Excess refrigerant Outdoor PCB	
H99	Indoor heat exchanger freeze prevention		<ul><li>Indoor heat exchanger</li><li>Refrigerant shortage</li></ul>	
	Pressure switch activate	4 times occurrence within 20 minutes	Pressure switch	
F12				
F12 F14	Outdoor compressor abnormal revolution	4 times occurrence within 20 minutes	Outdoor compressor	
	Outdoor compressor abnormal revolution  Outdoor fan motor lock abnormality		Outdoor compressor     Outdoor PCB     Outdoor fan motor     Excess refrigerant	

Diagnosis display	Abnormality/Protection control	Abnormality judgement	Primary location to verify
F20	Outdoor compressor overheating protection	4 times occurrence within 30 minutes	Compressor tank temperature sensor     Clogged expansion valve or strainer     Insufficient refrigerant     Outdoor PCB     Compressor
F22	IPM (power transistor) overheating protection	3 times occurrence within 30 minutes	<ul><li>Improper heat exchange</li><li>IPM (Power transistor)</li></ul>
F23	Outdoor Direct Current (DC) peak detection	7 times occurrence continuously	Outdoor PCB     Compressor
F24	Refrigeration cycle abnormality	2 times occurrence within 20 minutes	Insufficient refrigerant     Outdoor PCB     Compressor low compression
F25	Cooling/Heating cycle changeover abnormality	4 times occurrence within 30 minutes	4-way valve     V-coil
F27	Pressure switch abnormality	Continue for 1 min.	Pressure switch
F29	Low Discharge Superheat	1 times occurrence within 2550 minutes	Discharge Temperature Sensor     Discharge Pressure Sensor     Pressure Switch     Outdoor PCB
F30	Water outlet sensor 2 abnormality	Continue for 5 sec.	Water outlet sensor 2 (defective or disconnected)
F32	Abnormal Internal Thermostat	Continue for 5 sec.	Control panel PCB thermostat
F36	Outdoor air temperature sensor abnormality	Continue for 5 sec.	Outdoor air temperature sensor (defective or disconnected)
F37	Indoor water inlet temperature sensor abnormality	Continue for 5 sec.	Water inlet temperature sensor (defective or disconnected)
F40	Outdoor discharge pipe temperature sensor abnormality	Continue for 5 sec.	Outdoor discharge pipe temperature sensor (defective or disconnected)
F41	PFC control	4 times occurrence within 10 minutes	Voltage at PFC
F42	Outdoor heat exchanger temperature sensor abnormality	Continue for 5 sec.	Outdoor heat exchanger temperature sensor (defective or disconnected)
F43	Outdoor defrost sensor abnormality	Continue for 5 sec.	Outdoor defrost sensor (defective or disconnected)
F45	Indoor water outlet temperature sensor abnormality	Continue for 5 sec.	Water outlet temperature sensor (defective or disconnected)
F46	Outdoor Current Transformer open circuit	_	Insufficient refrigerant     Outdoor PCB     Compressor low
F48	Outdoor EVA outlet temperature sensor abnormality	Continue for 5 sec.	Outdoor EVA outlet temperature sensor (defective or disconnected)
F49	Outdoor bypass outlet temperature sensor abnormality	Continue for 5 sec.	Outdoor bypass outlet temperature sensor (defective or disconnected)
F95	Cooling high pressure overload protection	_	Outdoor high pressure sensor     Water pump or water leakage     Clogged expansion valve or strainer     Excess refrigerant     Outdoor PCB

**Note:** \* This error code is not applicable for this system.

### 16.5 Self-diagnosis Method

### 16.5.1 Connection Capability Rank Abnormality (H12)

### **Malfunction Decision Conditions:**

During startup operation of cooling and heating, the capability rank of indoor checked by the outdoor is used to determine connection capability rank abnormality.

#### **Malfunction Caused:**


- 1 Wrong model interconnected.
- 2 Wrong indoor unit or outdoor unit PCB (main) used.
- 3 Faulty indoor unit or outdoor unit PCB (main).

### **Abnormality Judgment:**

Continue for 90 seconds.

### **Troubleshooting:**





### 16.5.2 Compressor Tank Temperature Sensor Abnormality (H15)

#### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the compressor tank temperature sensor are used to determine sensor error.

### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

#### **Abnormality Judgment:**

Continue for 5 seconds.

### **Troubleshooting:**





### 16.5.3 Water Pump Abnormality (H20)

#### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the rotation speed detected by the IPM of water pump motor during water pump operation is used to determine abnormal water pump (feedback of rotation > 6,000rpm or < 1,000rpm).

For safety reason and to prevent component breakdown,

water pump.

#### **Malfunction Caused:**

- Operation stop due to short circuit inside the water pump motor winding.
- Operation stop due to breaking of wire inside the water pump motor.
- 3 Operation stop due to breaking of water pump lead wires.
- Operation stop due to water pump motor IPM malfunction.
- Operation error due to faulty indoor unit PCB.

### **Abnormality Judgment:**

Continue for 5 seconds.

#### Troubleshooting: always switch off the power before remove and connect the component. Turn OFF the power. - Connector Check if the water No poor contact pump connector Correct the Turn ON the power and connection normal? connection operate the water pump. Yes Disconnect the water pump No Does it operate? connector CN-PUMP1. Turn ON the power and Yes check the input voltage of the water pump from Stop the water pump. indoor unit PCB. Is the water pump drive Check the feedback power supply voltage No signal from water pump Replace the range between to indoor unit PCB. indoor unit PCB. 280~373Vdc (pin1 & 4) generated? Operate the water pump, Yes No Replace the is feedback signal (pulse) Is the water pump control water pump. generated between No Replace the power supply 15Vdc pin7 & 4 of CN-PUMP1? indoor unit PCB. (pin5 & 4) generated? Yes Yes Replace the indoor unit PCB. Operate the water pump, No is the duty command Replace the range between 0~6Vdc indoor unit PCB. (pin6 & 4) generated? Yes Replace the

### 16.5.4 Indoor Refrigerant Liquid Temperature Sensor Abnormality (H23)

### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the indoor refrigerant liquid temperature sensor are used to determine sensor error.

### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

#### **Abnormality Judgment:**

Continue for 5 seconds.

### **Troubleshooting:**





### 16.5.5 Service Valve Error (H27)

#### **Malfunction Decision Conditions:**

During cooling operation, when:-

- [a] Indoor refrigerant pipe temperature at compressor startup present indoor refrigerant pipe temperature < 2°C
- [b] Present high pressure high pressure at compressor startup < 5kg/cm<sup>2</sup>
- \*\*Judgment only for first time cooling operation and not during pump down operation.

### **Malfunction Caused:**


- 1 3 way valves closed.
- 2 Faulty high pressure sensor.
- 3 Faulty indoor refrigerant pipe temperature sensor
- 4 Faulty outdoor unit PCB (main).

### **Abnormality Judgment:**

Continue for 5 minutes.

### **Troubleshooting:**





### 16.5.6 Abnormal Solar Sensor (H28)

### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty solar sensor.
- 3 Faulty indoor sub PCB.

### **Abnormality Judgment:**

Continue for 5 seconds.

### **Troubleshooting:**





### 16.5.7 Abnormal Swimming Pool Sensor (H31)

### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty swimming pool sensor.
- 3 Faulty indoor sub PCB.

### **Abnormality Judgment:**

Continue for 5 seconds.

# Troubleshooting:





### 16.5.8 Abnormal Buffer Tank Sensor (H36)

### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

### **Abnormality Judgment:**

Continue for 5 seconds.

### **Troubleshooting:**






### 16.5.9 Brand Code Not Matching (H38)

### **Malfunction Caused:**

1 Indoor and outdoor brand code not match.

# **Troubleshooting:**





### 16.5.10 Compressor Low Pressure Protection (H42)

#### **Malfunction Decision Conditions:**


During operation of heating and after 5 minutes compressor ON, when outdoor pipe temperature below -29°C or above 26°C is detected by the outdoor pipe temperature sensor.

#### **Malfunction Caused:**

- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 2 way valve partially closed.
- 4 Faulty outdoor unit fan motor.
- 5 Refrigerant shortage (refrigerant leakage).
- 6 Clogged expansion valve or strainer.
- 7 Faulty outdoor pipe temperature sensor.
- 8 Faulty outdoor unit main PCB (main).

### **Troubleshooting:**





### 16.5.11 Abnormal Zone 1 Sensor (H43)


- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

### **Abnormality Judgment:**

Continue for 5 seconds.

# **Troubleshooting:**





### 16.5.12 Abnormal Zone 2 Sensor (H44)

### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

### **Abnormality Judgment:**

Continue for 5 seconds.

# **Troubleshooting:**





### 16.5.13 Water Flow Switch Abnormality (H62)

### **Malfunction Decision Conditions:**

During operation of cooling and heating, the water flow detected by the indoor water flow switch is used to determine water flow error.

### **Malfunction Caused:**


- 1 Faulty water pump.
- 2 Water leak in system.
- 3 Faulty connector connection.
- 4 Faulty water flow switch.
- 5 Faulty indoor unit PCB (main).

### **Abnormality Judgment:**

Continue for 10 seconds (but no judgment for 9 minutes after compressor startup/restart).

### **Troubleshooting:**





### 16.5.14 Outdoor High Pressure Abnormality (H64)

### **Malfunction Decision Conditions:**

During operation of cooling and heating, when the outdoor high pressure sensor output signal is 0 Vdc or 5 Vdc.

### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

### **Abnormality Judgment:**

Continue 4 times in 20 minutes.

### **Troubleshooting:**





### 16.5.15 Deice Circulation Error (H65)

#### **Malfunction Decision Conditions:**

During startup and operation of deice (mode 2), the water flow (> 10l/min) detected by the water flow switch is used to determine deice circulation error.

#### **Malfunction Caused:**


- 1 Water flow in air-to-water heatpump indoor unit circuitry.
- 2 Faulty indoor unit water flow switch.
- 3 Faulty indoor unit water pump.
- 4 Faulty indoor unit PCB.

### **Abnormality Judgment:**

Continue for 10 seconds.

### **Troubleshooting:**





### 16.5.16 Abnoraml External Thermistor 1 (H67)

### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty room temperature zone 1 sensor.
- 3 Faulty indoor sub PCB.

### **Abnormality Judgment:**

Continue for 5 seconds.

# **Troubleshooting:**





### 16.5.17 Abnoraml External Thermistor 2 (H68)

### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty room temperature zone 2 sensor.
- 3 Faulty indoor sub PCB.

### **Abnormality Judgment:**

Continue for 5 seconds.

# Troubleshooting:





### 16.5.18 Indoor Backup Heater OLP Abnormality (H70)

#### **Malfunction Decision Conditions:**

During operation of indoor backup heater, when no power supplies to indoor backup heater or OLP open circuit.

### **Malfunction Caused:**


- 1 Faulty power supply connector connection.
- 2 Faulty connector connection.
- 3 Faulty indoor backup heater overload protector (OLP).
- 4 Faulty indoor unit PCB (main).

### **Abnormality Judgment:**

Continue for 60 seconds.

### **Troubleshooting:**





### 16.5.19 Tank Temperature Sensor Abnormality (H72)

### **Malfunction Decision Conditions:**

When tank connection is set to ON, the temperatures detected by the tank temperature sensor are used to determine sensor error.

### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

### **Abnormality Judgment:**

Continue for 5 seconds.

### **Troubleshooting:**





### 16.5.20 PCB Communication Error (H74)

### **Malfunction Decision Conditions:**

When External PCB connection is select "YES" and no communication with External PCB micon for 10 seconds and above.

### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty indoor PCB.
- 3 Faulty indoor sub PCB.

### **Abnormality Judgment:**

After 1 minute operation started.

### **Troubleshooting:**





## 16.5.21 Indoor-Control Panel Communication Abnormality (H76)

#### **Malfunction Decision Conditions:**


During standby and operation of cooling and heating, indoor-control panel error occur.

#### **Malfunction Caused:**

- 1 Faulty connector connection.
- 2 Faulty control panel.
- 3 Faulty indoor unit PCB (main).

## **Troubleshooting:**





## 16.5.22 Indoor/Outdoor Abnormal Communication (H90)

#### **Malfunction Decision Conditions:**

During operation of cooling and heating, the data received from outdoor unit in indoor unit signal transmission is checked whether it is normal.

#### **Malfunction Caused:**


- 1 Faulty outdoor unit PCB (main).
- 2 Faulty indoor unit PCB (main).
- 3 Indoor-outdoor signal transmission error due to wrong wiring.
- 4 Indoor-outdoor signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units.
- 5 Indoor-outdoor signal transmission error due to disturbed power supply waveform.

#### **Abnormality Judgment:**

Continue for 1 minute after operation.

## **Troubleshooting:**





## 16.5.23 Tank Booster Heater OLP Abnormality (H91)

#### **Malfunction Decision Conditions:**


During operation of tank booster heater, and tank booster heater OLP open circuit.

#### **Malfunction Caused:**

- 1 Faulty connector connection.
- 2 Faulty tank booster heater overload protector (OLP).
- 3 Faulty indoor unit PCB (main).

#### **Abnormality Judgment:**

Continue for 60 seconds.



### 16.5.24 Unspecified Voltage between Indoor and Outdoor (H95)

#### **Malfunction Decision Conditions:**


The supply power is detected for its requirement by the indoor/outdoor transmission.

#### **Malfunction Caused:**

- 1 Insufficient power supply.
- 2 Faulty outdoor unit PCB (noise filter/main).

## **Troubleshooting:**





## 16.5.25 Outdoor High Pressure Protection (H98)

#### **Malfunction Decision Conditions:**


During operation of heating, when pressure 4.0 MPa and above is detected by outdoor high pressure sensor.

#### **Malfunction Caused:**

- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 2/3 way closed.
- 5 Clogged expansion valve or strainer.
- 6 Excessive refrigerant.
- 7 Faulty outdoor high pressure sensor.
- 8 Faulty outdoor unit PCB (main).

## **Troubleshooting:**





## 16.5.26 Indoor Freeze-up Protection (H99)

#### **Malfunction Decision Conditions:**


During anti-freezing control in cooling operation, when the indoor refrigerant liquid temperature < 0°C.

#### **Malfunction Caused:**

- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 2 way valve partially closed.
- 5 Clogged expansion valve or strainer.
- 6 Refrigerant shortage (refrigerant leakage).
- 7 Faulty indoor refrigerant liquid temperature sensor.
- 8 Faulty indoor unit PCB (main).

## **Troubleshooting:**





## 16.5.27 Outdoor High Pressure Switch Activate (F12)

#### **Malfunction Decision Conditions:**

During operation of cooling and heating, when pressure 4.5 MPa and above is detected by outdoor high pressure switch.

#### **Malfunction Caused:**


- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 Faulty water pump.
- 4 Insufficient water flow rate in system.
- 5 Water leak in system.
- 6 2/3 way valve closed.
- 7 Clogged expansion valve or strainer.
- 8 Excessive refrigerant.
- 9 Faulty outdoor high pressure sensor and switch.
- 10 Faulty outdoor unit PCB.

#### **Abnormality Judgment:**

Continue 4 times in 20 minutes.

## **Troubleshooting:**





### 16.5.28 Compressor Rotation Failure (F14)

#### **Malfunction Decision Conditions:**

A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

#### **Malfunction Caused:**


- 1 Compressor terminal disconnect.
- 2 Faulty outdoor unit PCB (main).
- 3 Faulty compressor.

#### **Abnormality Judgment:**

Continue 4 times in 20 minutes.

## **Troubleshooting:**





#### 16.5.29 Outdoor Fan Motor (DC Motor) Mechanism Locked (F15)

#### **Malfunction Decision Conditions:**

The rotation speed detected by the Hall IC of the fan motor during fan motor operation is used to determine abnormal fan motor (feedback of rotation > 2550 rpm or < 50 rpm).

#### **Malfunction Caused:**


- 1 Operation stop due to short circuit inside the fan motor winding.
- 2 Operation stop due to breaking of wire inside the fan motor.
- 3 Operation stop due to breaking of fan motor lead wires.
- 4 Operation stop due to fan motor Hall IC malfunction.
- 5 Operation error due to faulty outdoor unit PCB.

#### **Abnormality Judgment:**

Continue 2 times in 30 minutes.

# **Troubleshooting:**





### 16.5.30 Input Over Current Detection (F16)

#### **Malfunction Decision Conditions:**

During operation of cooling and heating, when outdoor current above 11.8 A (UD09HE8, UD12HE8) and 16.5 A UD16HE8) is detected by the current transformer (CT) in the outdoor unit PCB.

#### **Malfunction Caused:**


- Excessive refrigerant.
- 2 Faulty outdoor unit PCB (main).

#### **Abnormality Judgment:**

Continue 3 times in 20 minutes.

## **Troubleshooting:**





## 16.5.31 Compressor Overheating (F20)

### **Malfunction Decision Conditions:**

During operation of cooling and heating, when temperature above 107°C is detected by the compressor tank temperature sensor.

#### **Malfunction Caused:**


- 1 Faulty compressor tank temperature sensor.
- 2 2/3 way valve closed.
- 3 Refrigerant shortage (refrigerant leakage).
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).
- 6 Faulty compressor.

#### **Abnormality Judgment:**

Continue 4 times in 30 minutes.

## **Troubleshooting:**





## 16.5.32 IPM Overheating (F22)

#### **Malfunction Decision Conditions:**

During operation of cooling and heating, when temperature 95°C is detected by the outdoor IPM temperature sensor.

#### **Malfunction Caused:**


- 1 Faulty outdoor unit fan motor.
- 2 Faulty outdoor unit PCB (main).

#### **Abnormality Judgment:**

Continue 3 times in 30 minutes.

## **Troubleshooting:**





## 16.5.33 Output Over Current Detection (F23)

#### **Malfunction Decision Conditions:**

During operation of cooling and heating, when outdoor DC current is above 34 A (UX09,12HE8) or 54 A ± 4.0 A (UD16HE8) is detected by the IPM DC Peak sensing circuitry in the outdoor unit PCB (main).


For safety reason and to prevent component breakdown,

#### **Malfunction Caused:**

- Faulty outdoor unit PCB (main).
- Faulty compressor.

#### **Abnormality Judgment:**

Continue for 7 times.



## 16.5.34 Refrigeration Cycle Abnormality (F24)

#### **Malfunction Decision Conditions:**

- 1 During operation of cooling and heating, compressor frequency > Frated.
- 2 During operation of cooling and heating, running current: 0.65 A < I < 1.65 A.
- 3 During operation of cooling, water inlet temperature indoor refrigerant liquid temperature < 5°C.
- 4 During operation of heating, indoor refrigerant liquid temperature water inlet temperature < 5°C.

#### **Malfunction Caused:**


- 1 Faulty water inlet or indoor refrigerant liquid temperature sensors.
- 2 2/3 way valve closed.
- 3 Refrigerant shortage (refrigerant leakage).
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).
- 6 Poor compression of compressor.

#### **Abnormality Judgment:**

Continue 2 times in 20 minutes.

## **Troubleshooting:**





## 16.5.35 Four Way Valve Abnormality (F25)

#### **Malfunction Decision Conditions:**

- 1 During heating operation, when the indoor pipe temperature of thermostat ON indoor unit < 0°C.
- 2 During cooling operation, when the indoor pipe temperature of thermostat ON indoor unit > 45°C.

#### **Malfunction Caused:**


- 1 Faulty sensor.
- 2 Faulty connector connection.
- 3 Faulty outdoor unit PCB (noise filter/main).
- 4 Faulty four way valve.

#### **Abnormality Judgment:**

Continue 4 times in 30 minutes.

## **Troubleshooting:**





## 16.5.36 Outdoor High Pressure Switch Abnormal (F27)

#### **Malfunction Decision Conditions:**

During compressor stop, and outdoor high pressure switch is remain opened.

#### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty switch.
- 3 Faulty outdoor unit PCB (main).

#### **Abnormality Judgment:**

Continue for 1 minute.

## **Troubleshooting:**





## 16.5.37 Low Discharge Superheat (F29)

#### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor error.

#### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).
- 4 Faulty High Pressure Switch
- 5 Refrigerant shortage (refrigerant leakage).

#### **Abnormality Judgment:**

1 times occurrence within 2550 minutes.

## **Troubleshooting:**





## 16.5.38 Indoor Water Outlet Temperature Sensor 2 Abnormality (F30)

#### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the indoor water outlet temperature sensor 2 are used to determine sensor error.

#### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB.

#### **Abnormality Judgment:**

Continue for 5 seconds.

## **Troubleshooting:**





## 16.5.39 Outdoor Air Temperature Sensor Abnormality (F36)

#### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the outdoor air temperature sensor are used to determine sensor error.

#### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

#### **Abnormality Judgment:**

Continue for 5 seconds.

## **Troubleshooting:**





## 16.5.40 Indoor Water Inlet Temperature Sensor Abnormality (F37)

#### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the indoor water inlet temperature sensor are used to determine sensor error.

#### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

#### **Abnormality Judgment:**

Continue for 5 seconds.

## **Troubleshooting:**





## 16.5.41 Outdoor Discharge Pipe Temperature Sensor Abnormality (F40)

### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the outdoor discharge pipe temperature sensor are used to determine sensor error.

#### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

#### **Abnormality Judgment:**

Continue for 5 seconds.

## **Troubleshooting:**





## 16.5.42 Power Factor Correction (PFC) Abnormality (F41)

#### **Malfunction Decision Conditions:**

During operation of cooling and heating, when the PFC protection circuitry in the outdoor unit PCB (main) senses abnormal high DC voltage level.

#### **Malfunction Caused:**


- 1 Power supply surge.
- 2 Compressor windings not uniform.
- 3 Faulty outdoor unit PCB (main).

#### **Abnormality Judgment:**

Continue 4 times in 10 minutes.

## **Troubleshooting:**





### 16.5.43 Outdoor Pipe Temperature Sensor Abnormality (F42)

#### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor error.

#### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

#### **Abnormality Judgment:**

Continue for 5 seconds.

## **Troubleshooting:**





### 16.5.44 Outdoor Defrost Temperature Sensor Abnormality (F43)

#### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the outdoor defrost temperature sensor are used to determine sensor error.

#### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

#### **Abnormality Judgment:**

Continue for 5 seconds.

## **Troubleshooting:**





## 16.5.45 Indoor Water Outlet Temperature Sensor Abnormality (F45)

#### **Malfunction Decision Conditions:**

During startup and operation of cooling and heating, the temperatures detected by the indoor water outlet temperature sensor are used to determine sensor errors.

#### **Malfunction Caused:**


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

#### **Abnormality Judgment:**

Continue for 5 seconds.

## **Troubleshooting:**





## 16.5.46 Outdoor Current Transformer Open Circuit (F46)

#### **Malfunction Decision Conditions:**

A current transformer (CT) open circuit is detected by checking the compressor running frequency (≥ rated frequency) and CT detected input current (< 0.65 A) for continuously 20 seconds.

#### **Malfunction Caused:**


- 1 CT defective.
- 2 Faulty outdoor unit PCB (main).
- 3 Compressor defective (low compression).

#### **Abnormality Judgment:**

Continue 3 times in 20 minutes.

## **Troubleshooting:**





## 16.5.47 Cooling High Pressure Overload Protection (F95)

### **Malfunction Decision Conditions:**


During operation of cooling, when pressure 4.0 MPa and above is detected by outdoor high pressure sensor.

#### **Malfunction Caused:**

- 1 Dust accumulation in the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 2 way valve closed.
- 4 Faulty outdoor unit fan motor.
- 5 Clogged expansion valve or strainer.
- 6 Excessive refrigerant.
- 7 Faulty outdoor high pressure sensor.
- 8 Faulty outdoor unit PCB (main).

## **Troubleshooting:**






# 17. Disassembly and Assembly Instructions

### **№** WARNING


High Voltage are generated in the electrical parts area by the capacitor. Ensure that the capacitor has discharged sufficiently before proceeding with repair work. Failure to heed this caution may result in electric shocks.

### 17.1 To Remove Front Plate




2. Gently pull the lower section of the front plate towards you to remove the front plate from left and right hooks.

# 17.2 To Remove Pressure Gauge




# 17.3 To Open Control Board Cover




1. Remove 6 screws from the Control Board Cover.

## 17.4 To Remove Control Panel




3. Remove 2 screws then take out the bottom case.


## 17.5 To Remove RCCB




## 17.6 To Remove Transformer and Electronic Controller Board




# 17.7 To Open Control Board




## 17.8 To Remove Pressure Relief Valve, Air Purge Valve and Flow Sensor





## During reinstall Air Purge Valve






# 17.9 To Remove Water Pump and Bottle Complete





# 17.10 To Remove Filter



# 18. Technical Data

# 18.1 Operation Characteristics

## 18.1.1 WH-SDC09H3E8 WH-UD09HE8


### **Heating Characteristics at Different Outdoor Air Temperature**

Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT)

Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C

Piping length: 7 m




## **Cooling Characteristics at Different Outdoor Air Temperature**

Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C

Piping length: 7 m




## **Cooling Characteristics at Different Outdoor Air Temperature**

Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 19°C Indoor water outlet temperature : 14°C


Piping length: 7 m



Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 23°C Indoor water outlet temperature : 18°C




## **Heating Characteristics at Different Piping Length**

Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT)


Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C



# **Cooling Characteristics at Different Piping Length**Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature: 12°C Indoor water outlet temperature: 7°C




#### 18.1.2 WH-SDC12H9E8 WH-UD12HE8

# **Heating Characteristics at Different Outdoor Air Temperature**

Condition

Outdoor air temperature: 7°C (DBT), 6°C (WBT)


Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C



Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)


Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C



Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)


Indoor water inlet temperature : 19°C Indoor water outlet temperature : 14°C



Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 23°C Indoor water outlet temperature : 18°C




# **Heating Characteristics at Different Piping Length**

Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT)


Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C



# **Cooling Characteristics at Different Piping Length**Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature: 12°C Indoor water outlet temperature: 7°C




#### 18.1.3 WH-SDC16H9E8 WH-UD16HE8

# **Heating Characteristics at Different Outdoor Air Temperature**

Condition

Outdoor air temperature: 7°C (DBT), 6°C (WBT)


Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C



Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)


Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C



Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)


Indoor water inlet temperature : 19°C Indoor water outlet temperature : 14°C



Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 23°C Indoor water outlet temperature : 18°C




## **Heating Characteristics at Different Piping Length**

Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT)


Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C



# **Cooling Characteristics at Different Piping Length**Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature: 12°C Indoor water outlet temperature: 7°C



# 18.2 Heating Capacity Table

## 18.2.1 WH-SDC09H3E8 WH-UD09HE8

Water Out (°C)	3	0	3:	5	4	0	4	5	5	0	5	5
Outdoor Air (°C)	Capacity (W)	Input Power (W)										
-15	8650	3060	8300	3210	7950	3410	7600	3610	7150	3710	6700	3810
-7	9350	2910	9000	3160	8850	3540	8700	3920	8300	3890	7900	3860
2	9310	2350	9000	2510	9000	2780	9000	3050	8900	3490	8800	3940
7	9000	1540	9000	1860	9000	2160	9000	2460	9000	2760	9000	3060
25	9000	1050	9000	1240	8730	1440	8460	1640	8280	1820	8100	2000

## 18.2.2 WH-SDC12H9E8 WH-UD12HE8

Water Out (°C)	3	0	3	5	4	0	4	5	5	0	5	5
Outdoor Air (°C)	Capacity (W)	Input Power (W)										
-15	9300	3460	8900	3620	8500	3790	8100	3950	7500	4050	7000	4160
-7	10400	3370	10000	3660	9600	3950	9200	4240	8700	4260	8200	4270
2	11800	3100	11400	3310	11000	3530	10600	3740	9800	3940	9100	4140
7	12000	2100	12000	2530	12000	2960	12000	3390	12000	3780	12000	4160
25	12000	1380	12000	1660	11800	1940	11700	2230	11500	2490	11400	2740

## 18.2.3 WH-SDC16H9E8 WH-UD16HE8

Water Out (°C)	3	0	3	5	4	0	4	5	5	0	5	5
Outdoor Air (°C)	Capacity (W)	Input Power (W)										
-15	10600	4090	10300	4380	10000	4670	9700	4960	8800	4940	7900	4910
-7	11900	4030	11400	4430	10800	4830	10300	5220	9600	5090	9000	4950
2	13500	3740	13000	3960	12400	4180	11900	4400	10800	4460	9800	4510
7	16000	3210	16000	3740	16000	4270	16000	4800	15200	5110	14500	5410
25	16000	2310	16000	2690	16000	3070	16000	3450	16000	3670	15900	3890

# 18.3 Cooling Capacity Table

## 18.3.1 WH-SDC09H3E8 WH-UD09HE8

Water In (°C)	12		1	9	23		
Water Out (°C)	7		1	4	18		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Capacity (W)	Input Power (W)	Capacity (W)	Input Power (W)	
16	7500	1150	9100	1200	7000	1130	
25	8350	1770	10900	1780	7000	1240	
35	7000	2230	8300	2320	7000	1520	
43	5520	2540	7690	2770	5600	1800	

## 18.3.2 WH-SDC12H9E8 WH-UD12HE8


Water In (°C)	12		1	9	23		
Water Out (°C)	7		1	4	18		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Capacity (W)	Input Power (W)	Capacity (W)	Input Power (W)	
16	7860	1180	13150	1400	10000	1730	
25	12080	2900	15700	2050	10000	1970	
35	10000	2560	12000	2670	10000	2400	
43	7800	3800	11100	3190	8000	2850	

## 18.3.3 WH-SDC16H9E8 WH-UD16HE8

Water In (°C)	12		1	9	23		
Water Out (°C)	7		1	4	18		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Capacity (W)	Input Power (W)	Capacity (W)	Input Power (W)	
16	9200	1620	16400	2580	12200	2450	
25	14400	3920	19200	3830	12200	2790	
35	12200	4760	15000	4980	12200	2960	
43	7750	3400	13800	5950	9700	4000	

# 19. Exploded View and Replacement Parts List

# 19.1 Indoor Unit



- The above exploded view is for the purpose of parts disassembly and replacement.
- The non-numbered parts are not kept as standard service parts.

#### <Model: WH-SDC09H3E8 >

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-SDC09H3E8	REMARK
	1	BASE PAN	1	CWD521450	
	2	HOT WATER COIL - COMPLETE	1	ACXB90C00220	
	3	RECEIVER	1	CWB141039	
	4	CATCHER	2	CWH601011	
	5	FLARE NUT (5/8)	1	CWT251064	
	6	FLARE NUT	1	CWT251061	
	7	FLARE NUT (1/4)	1	CWT251063	
	8	WATER PUMP	1	CWB532116	0
	9	FERRITE CORE	1	CWA431122	
	10	LEAD WIRE - FOR PUMP	1	ACXA60C06140	0
	11	PRESSURE RELIEF VALVE	1	CWB621136	0
	12	FILTER COMPLETE	1	CWB51C1021	
	13	FLOW SENSOR	1	CWB621137	0
	14	PRESSURE GAUGE	1	CWB070003	
	15	HEATER ASS'Y	1	ACXA34K00080	0
	16	SOUND PROOF MATERIAL	1	ACXG30-00680	
	17	AIR PURGE VALVE	1	ACXB62-00130	0
	18	THERMOSTAT	4	CWA151074	0
	19	CONTROL BOARD	1	CWH102629	
Ŵ	20	ELECTRONIC CONTROLLER - MAIN	1	ACXA73C11510	0
$\overline{\wedge}$	21	TERMINAL BOARD ASS'Y (1 TO 5)	1	CWA28K1240	0
<u> </u>	22	TERMINAL BOARD ASS'Y (A, B)	1	CWA28K1260	0
$\overline{\wedge}$	23	REACTOR	1	G0C103Z00003	0
	24	HINGE	2	CWH611006	
	25	HINGE	2	CWH611007	
Ņ	26	RESIDUAL CURRENT CIRCUIT BREAKER	1	CWA181008	0
$\overline{\wedge}$	27	RESIDUAL CURRENT CIRCUIT BREAKER	1	K5KYYAY00003	0
	28	SENSOR - CO. (WATER IN, OUT REF TEMP)	1	CWA50C3377	0
	29	SENSOR - CO. (HEX WATER OUTLET)	1	CWA50C3378	0
$\wedge$	30	REMOTE CONTROL COMPLETE	1	CWA75C4681	0
	31	CABINET SIDE PLATE	2	CWE041850A	
	32	CABINET FRONT PLATE	1	CWE061396A	
	33	LOCK	2	CWH891004	
	34	DECORATION BASE ASS'Y	1	CWE35K1285	
	35	ACCESSORY - COMPLETE	1	CWH82C2174	
	36	INSTALLING HOLDER	1	CWH361103A	
	37	OPERATING INSTRUCTION	1	ACXF55-02060	
	38	OPERATING INSTRUCTION	1	ACXF55-02070	
	39	OPERATING INSTRUCTION	1	ACXF55-02090	
	40	OPERATING INSTRUCTION	1	ACXF55-02100	
	41	OPERATING INSTRUCTION	1	ACXF55-02110	
	42	INSTALLATION INSTRUCTION	1	ACXF60-03130	
	43	INSTALLATION INSTRUCTION	1	ACXF60-03260	
	44	BAG - COMPLETE (FLEXIBLE PIPE)	1	CWG87C900	
		,	1	CWH361119A	
	45	INSTALLING HOLDER		CWIISOTTIBA	


- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.

#### <Model: WH-SDC12H9E8 WH-SDC16H9E8>


SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-SDC12H9E8	WH-SDC16H9E8	REMARK
	1	BASE PAN	1	CWD521450	←	
	2	HOT WATER COIL - COMPLETE	1	ACXB90C00220	ACXB90C00250	
	3	RECEIVER	1	CWB141039	←	
	4	CATCHER	2	CWH601011	←	
	5	FLARE NUT (5/8)	1	CWT251064	←	
	6	FLARE NUT	1	CWT251061	←	
	7	FLARE NUT (1/4)	1	CWT251063	←	
	8	WATER PUMP	1	CWB532116	←	0
	9	FERRITE CORE	1	CWA431122	←	
	10	LEAD WIRE - FOR PUMP	1	ACXA60C06140	←	0
	11	PRESSURE RELIEF VALVE	1	CWB621136	←	0
	12	FILTER COMPLETE	1	CWB51C1021	←	
	13	FLOW SENSOR	1	CWB621137	←	0
	14	PRESSURE GAUGE	1	CWB070003	←	
	15	HEATER ASS'Y	1	ACXA34K00090	←	0
	16	SOUND PROOF MATERIAL	1	ACXG30-00680	←	
	17	AIR PURGE VALVE	1	ACXB62-00130	<b>←</b>	0
	18	THERMOSTAT	4	CWA151074	<b>←</b>	0
	19	CONTROL BOARD	1	CWH102629	<b>←</b>	
$\triangle$	20	ELECTRONIC CONTROLLER - MAIN	1	ACXA73C11520	ACXA73C11530	0
À	21	TERMINAL BOARD ASS'Y (1 TO 5)	1	CWA28K1240	←	0
$\overline{\wedge}$	22	TERMINAL BOARD ASS'Y (A, B)	1	CWA28K1238	←	0
$\overline{\wedge}$	23	REACTOR	1	G0C103Z00003	<b>←</b>	0
	24	HINGE	2	CWH611006	<b>←</b>	
	25	HINGE	2	CWH611007	<b>←</b>	
$\triangle$	26	RESIDUAL CURRENT CIRCUIT BREAKER	2	CWA181008	<b>←</b>	0
	28	SENSOR - CO. (WATER IN, OUT REF TEMP)	1	CWA50C3377	←	0
	29	SENSOR - CO. (HEX WATER OUTLET)	1	CWA50C3378	←	0
<u> </u>	30	REMOTE CONTROL COMPLETE	1	CWA75C4681	←	0
	31	CABINET SIDE PLATE	2	CWE041850A	←	
	32	CABINET FRONT PLATE	1	CWE061396A	<b>←</b>	
	33	LOCK	2	CWH891004	←	
	34	DECORATION BASE ASS'Y	1	CWE35K1285	←	
	35	ACCESSORY - COMPLETE	1	CWH82C2174	←	
	36	INSTALLING HOLDER	1	CWH361103A	←	
	37	OPERATING INSTRUCTION	1	ACXF55-02060	←	
	38	OPERATING INSTRUCTION	1	ACXF55-02070	<b>←</b>	
	39	OPERATING INSTRUCTION	1	ACXF55-02090	<b>←</b>	
	40	OPERATING INSTRUCTION	1	ACXF55-02100	<b>←</b>	
	41	OPERATING INSTRUCTION	1	ACXF55-02110	←	
	42	INSTALLATION INSTRUCTION	1	ACXF60-03130	←	
	43	INSTALLATION INSTRUCTION	1	ACXF60-03260	←	
	44	BAG - COMPLETE (FLEXIBLE PIPE)	1	CWG87C900	←	
	45	INSTALLING HOLDER	1	CWH361119A	<b>←</b>	
	46	ACCESSORY - COMPLETE	1	CWH82C1754	←	

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488). "O" marked parts are recommended to be kept in stock.


# 19.2 Outdoor Unit



- The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.



- The above exploded view is for the purpose of parts disassembly and replacement.
- The non-numbered parts are not kept as standard service parts.



- The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.

# <Model: WH-UD09HE8 WH-UD12HE8 WH-UD16HE8>

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-UD09HE8	WH-UD12HE8	WH-UD16HE8	REMARK
	1	BASE PAN ASS'Y	1	ACXD52K00260	←	←	
Ŵ	2	COMPRESSOR	1	5JD420XBA22	←	←	0
	3	CRANKCASE HEATER	1	CWA341053	←	←	
	4	BUSHING - COMPRESSOR MOUNT	3	CWH50055	<b>←</b>	<b>←</b>	
	5	NUT - COMPRESSOR MOUNT	3	CWH561049	<b>←</b>	<b>←</b>	
	6	GASKET FOR TERMINAL COVER	3	CWB811017	<b>←</b>	<b>←</b>	
	7	CONDENSER COMPLETE	1	CWB32C3986	<b>←</b>	←	
	8	TUBE ASSY (CAP.TUBE)	1	CWT07K1606	←	←	
	9	3-WAYS VALVE (GAS)	1	CWB011251	<b>←</b>	←	0
	10	4-WAYS VALVE	1	CWB001046	<b>←</b>	←	0
	11	HIGH PRESSURE SENSOR	1	CWA501463	←	←	0
	12	DISCHARGE MUFFLER	1	CWB121014	←	←	
	13	ACCUMULATOR	1	CWB131026A	←	←	
	14	3-WAYS VALVE	1	ACXB01-00040	←	←	0
	15	2-WAYS VALVE	1	CWB021637	←	←	0
	16	EXPANSION VALVE	1	CWB051049	<b>←</b>	←	
	17	SOUND PROOF MATERIAL	1	ACXG30-00850	<b>←</b>	←	
	18	SOUND PROOF MATERIAL	1	CWG302266	<b>←</b>	<b>←</b>	
	19	SOUND PROOF BOARD	1	CWH15K1031	<b>←</b>	<b>←</b>	
⚠	20	V-COIL COMP. (4-WAY VALVE)	1	CWA43C2169J	<b>←</b>	<b>←</b>	0
$\triangle$	21	V-COIL COMP. (EXPANSION VALVE)	1	CWA43C2602	←	←	0
$\triangle$	22	V-COIL COMP. (2 WAY VALVE)	1	CWA43C2607	←	←	0
	23	SENSOR - COMP. (OUTDOOR AIR PIPE TEMP CN-TH1)	1	CWA50C2730	<b>←</b>	<b>←</b>	0
	24	SENSOR - COMP. (DEFROST TEMO CN-TH2)	1	CWA50C2577	←	←	0
	25	SENSOR-COMP. (DISHARGE TEMP CN-DIS)	1	CWA50C2576	←	←	0
	26	SENSOR - COMP. (EVA EXIT TEMP CN-TH3)	1	CWA50C3204	<b>←</b>	<b>←</b>	0
	27	CABINET REAR PLATE- COMPLETE	1	CWE02C1059	←	←	
	28	CONTROL BOARD CASING	1	CWH10K1049	←	←	
$\triangle$	29	TERMINAL BOARD ASS'Y	1	CWA28K1214	←	←	0
$\triangle$	30	ELECTRONIC CONTROLLER - NF	1	CWA747838	←	←	0
$\triangle$	31	ELECTRONIC CONTROLLER (MAIN)	1	ACXA73C08820R	ACXA73C08830R	ACXA73C08840R	0
$\triangle$	32	REACTOR	3	G0C293J00001	←	←	0
	33	SENSOR - (COMP TANK TEMP CN-TANK)	1	CWA50C2629	←	←	0
	34	TERMINAL COVER	1	CWH171039A	<b>←</b>	←	
	35	NUT-TERMINAL COVER	1	CWH7080300J	<b>←</b>	<b>←</b>	
	36	FAN MOTOR BRACKET	1	CWD54K1084	<b>←</b>	<b>←</b>	
	37	SCREW-FAN MOTOR BRACKET	8	CWH551040J	<b>←</b>	<b>←</b>	
Ŵ	38	FAN MOTOR (UPPER)	1	EHDS83CAC	<b>←</b>	<b>←</b>	0
$\overline{\mathbb{A}}$	39	FAN MOTOR (LOWER)	1	EHDS83DAC	<b>←</b>	<b>←</b>	0
	40	SCREW - FAN MOTOR MOUNT	8	CWH551323	←	<b>←</b>	
	41	PROPELLER FAN ASSY	2	CWH00K1006	<b>←</b>	<b>←</b>	
	42	NUT	2	CWH561092	<b>←</b>	<b>←</b>	
	43	CABINET FRONT PLATE	1	CWE061098A	<b>←</b>	<b>←</b>	
	44	DISCHARGE GRILLE	2	CWE201073	<b>←</b>	←	
	45	CABINET SIDE PLATE ASSY	1	CWE04K1023A	<b>←</b>	<b>←</b>	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-UD09HE8	WH-UD12HE8	WH-UD16HE8	REMARK
	45	CABINET SIDE PLATE ASSY	1	CWE04K1023A	←	←	
	46	CABINET TOP PLATE CO.	1	CWE03C1096	<b>←</b>	<b>←</b>	
	47	CABINET FRONT PLATE CO.	1	CWE06C1091	←	←	
	48	HANDLE	2	CWE161008	<b>←</b>	←	
	49	PIPE COVER (FRONT)	1	CWD601074A	←	←	
	50	PIPE COVER (BACK)	1	CWD601075A	<b>←</b>	<b>←</b>	
	51	STRAINER	2	CWB111032	<b>←</b>	<b>←</b>	
	52	PRESSURE SWITCH	1	CWA101013	<b>←</b>	<b>←</b>	0
$\triangle$	53	ELECTRO MAGNETIC SWITCH	1	K6C2AGA00002	←	<b>←</b>	0
$\triangle$	54	ELECTRO MAGNETIC SWITCH	1	K6C4E8A00001	←	<b>←</b>	0
	55	ACCESSORY - COMPLETE	1	CWH82C2031	<b>←</b>	<b>←</b>	
	56	ACCESSORY CO. (DRAIN ELBOW)	1	CWG87C900	←	←	
$\triangle$	57	REACTOR	3	G0C153J00009	←	←	0
	58	PTC THERMISTORS	1	D4DDG1010001	<b>←</b>	<b>←</b>	0

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.