
Service Manual

(Mono bloc) Air-to-Water Heatpump System



Mono bloc Unit WH-MXC09G3E5 WH-MXC12G6E5

> Destination **Europe Turkey**

WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.



PRECAUTION OF LOW TEMPERATURE

In order to avoid frostbite, be assured of no refrigerant leakage during the installation or repairing of refrigerant circuit.



© Panasonic Corporation 2015.

TABLE OF CONTENTS

| 1. | Safe | ety Precautions | 3 |
|-----|--------------|---|-----|
| 2. | Spe | cifications | 5 |
| _ | 2.1 2.2 | WH-MXC09G3E5WH-MXC12G6E5 | |
| 3. | Feat | tures | 9 |
| 4. | Loc | ation of Controls and Components | .10 |
| 4 | 4.1 | Mono Bloc Unit | .10 |
| 5. | Dim | ensions | .20 |
| į | 5.1 | Mono Bloc Unit | .20 |
| 6. | Refr | igeration And Water Cycle Diagram | .21 |
| 7. | | ck Diagram | |
| - | 7.1 | WH-MXC09G3E5 | |
| 7 | 7.2 | WH-MXC12G6E5 | |
| 8. | Wiri | ng Connection Diagram | .25 |
| - | 3.1 | WH-MXC09G3E5 | |
| | 3.2 | WH-MXC12G6E5 | |
| | | tronic Circuit Diagram | |
| • | 9.1 9.2 | WH-MXC09G3E5 WH-MXC12G6E5 | |
| 10. | . Prin | ted Circuit Board | |
| | 10.1 | Water System | |
| | 10.2 | Refrigerant System | |
| | | allation Instruction | |
| | 11.1 11.2 | Select The Best Location Mono Bloc Unit Installation | |
| | 11.3 | Piping Installation | .38 |
| • | 11.4 | Connect The Cord And Cable To Mono Blounit | |
| | 11.5 | Checking and Test Run Procedures | |
| 12 | . Ope | ration and Control | .46 |
| | 12.1 | Basic Function | .46 |
| | 12.2 | Water Pump | |
| | 12.3 12.4 | Pump Down Operation [Service Mode: 01] Flow Switch | |
| • | 12.5 | Indoor Unit Safety | .70 |
| | 12.6 12.7 | Auto Restart Control | |
| | 12.7 12.8 | Indication PanelIndoor Back-Up Heater Control | 71 |
| | 12.9 | Tank Booster Heater Control | |
| | | Base Pan Heater Control (Optional) | |
| | | Sterilization Mode | |
| | | Anti Freeze Control | |
| • | 12.14 | Solar Operation (Optional) | .75 |
| • | 12.15 | External Room Thermostat Control (Option | |
| | | Three Ways Valve Control | .80 |
| • | 12.17 | Two Ways Valve Control | .80 |
| | | External OFF/ON Control | |
| | | Dry Concrete Function | |

| 13. Pro | tection Control | 83 |
|--|--|--|
| 13.1 13.2 13.3 | Protection Control for All Operations Protection Control for Heating Operation Protection Control for Cooling Operation | 85 |
| 14. Serv | vicing Mode | 88 |
| 14.1 14.2 14.3 14.4 14.5 14.6 14.7 14.8 | Remove The Cabinet Front Plate Test Run Proper Pump Down Procedure How To Adjust Water Flow Rate Expansion Vessel Pre Pressure Checking How to Unlock Cool Mode Dry Concrete [SERVICE MODE: 03] EEPROM Factory Default Data Setup Procedure | 88 89 89 90 |
| 15. Maii | ntenance Guide | 91 |
| 16. Tro | ubleshooting Guide | . 93 |
| 16.1 16.2 16.3 | Refrigeration Cycle SystemRelationship Between The Condition Of The Mono Bloc Unit And Pressure And Electric Current | 「he ic 9₄ |
| 16.4 16.5 | Error Codes Table Self-diagnosis Method | 96 |
| 17. Disa | assembly and Assembly Instructions | 134 |
| 17.1 17.2 17.3 17.4 17.5 17.6 17.7 | To Remove The Cabinet Front Plate To Remove The Cabinet Top Plate To Remove The Cabinet Rear Plate To Remove Pressure Gauge To Remove RCCB To Remove Transformer and Electronic Controller Board To Remove Pressure Relief Valve, Flow Switch and Air Purge Valve To Remove Water Pump To Remove Bottle Complete | 134 135 135 136 137 138 |
| 18. Tec | hnical Data | 140 |
| 18.1 18.2 18.3 | Operation Characteristics Heating Capacity Table Cooling Capacity Table | 148 148 |
| | loded View and Replacement Parts List | |
| 19.1 19.2 | (Refrigerant System)(Water System) | 149 154 |

1. Safety Precautions

- Read the following "SAFETY PRECAUTIONS" carefully before installation of (Mono bloc) Air-to-Water Heat pump system (hereafter referred to as "Mono bloc unit").
- Electrical works and water installation works must be done by licensed electrician and licensed water system installer respectively. Be sure to use the correct rating and main circuit for the model to be installed.
- The caution items stated here must be followed because these important contents are related to safety. The
 meaning of each indication used is as below. Incorrect installation due to ignorance or negligence of the
 instructions will cause harm or damage, and the seriousness is classified by the following indications.

| ⚠ WARNING | This indication shows the possibility of causing death or serious injury. |
|------------------|---|
| ⚠ CAUTION | This indication shows the possibility of causing injury or damage to properties only. |

• The items to be followed are classified by the symbols:

| \Diamond | Symbol with white background denotes item that is PROHIBITED from doing. |
|------------|--|
| 0 0 | Symbol with dark background denotes item that must be carried out. |

- Carry out test run to confirm that no abnormality occurs after the installation. Then, explain to user the operation, care and maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.
- If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.

| | ⚠ WARNING | |
|-----|---|------------|
| 1. | Do not install Mono bloc unit near handrail of veranda. When installing Mono bloc unit at veranda of high rise building, child may climb up to Mono bloc unit and cross over the handrail and causing accident. | 0 |
| 2. | Do not use unspecified cord, modified cord, join cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire. | 0 |
| 3. | Do not tie up the power supply cord into a bundle by band. Abnormal temperature rise on power supply cord may happen. | 0 |
| 4. | Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury. | 0 |
| 5. | Do not sit or step on the unit, you may fall down accidentally. | \Diamond |
| 6. | Keep plastic bag (packaging material) away from small children, it may cause suffocation. | 0 |
| 7. | Do not use pipe wrench to install refrigerant pipe. It might deform the piping and cause the unit to malfunction. | 0 |
| 8. | Do not purchase unauthorized electrical parts for installation, service, maintenance and etc They might cause electrical shock or fire. | 0 |
| 9. | This unit is a multi supply appliances. All circuits must be disconnected before accessing to the unit terminals. | 0 |
| 10. | Do not modify the wiring of Mono bloc unit for installation of other components (i.e. heater, etc.). Overloaded wiring or wire connection points may cause electrical shock or fire. | 0 |
| 11. | Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury etc. | 0 |
| 12. | For electrical work, follow the local national wiring standard, regulation and this installation instruction. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in electrical work, it will cause electrical shock or fire. | 0 |
| 13. | For water circuit installation work, follow to relevant European and national regulations (including EN61770) and local plumbing and building regulation codes. | 0 |
| 14. | Must engage an authorized dealer or specialist for installation. If installation is defective, it will cause water leakage, electrical shock or fire. | 0 |
| 15. | Install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electrical shock or fire. | 0 |
| 16. | Only use the supplied or specified installation parts. Else, it may causes Mono bloc unit vibrate, fall, water leakage, electrical shock or fire. | 0 |
| 17. | Install at a flat, strong and firm location which is able to withstand the Mono bloc unit's weight. If the location is slanting, or strength is not enough the set will fall and cause injury. | 0 |

| | ⚠ WARNING | |
|-----|--|---|
| 18. | This equipment is strongly recommended to be installed with Residual Current Device (RCD) on-site according to the respective national wiring rules or country-specific safety measures in terms of residual current. | 0 |
| 19. | The unit is only for use in a closed water system. Utilization in an open water system may lead to excessive corrosion of the water piping and risk of incubating bacteria colonies, particularly Legionella, in water. | 0 |
| 20. | If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information. | 0 |
| 21. | Select a location where in case of water leakage, the leakage will not cause damage to other properties. | 0 |
| 22. | When installing electrical equipment at wooden building of metal lath or wire lath, in accordance with electrical facility standard, no electrical contact between equipment and building is allowed. Insulator must be installed in between. | 0 |
| 23. | This installation may be subjected to building regulation approval applicable to respective country that may require to notify the local authority before installation. | 0 |
| 24. | Any work carried out on the Mono bloc unit after removing the front panel which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor. | 0 |
| 25. | This unit must be properly earthed, the electrical earth must not be connected to a gas pipe, water pipe, the earth of a lightening rod or a telephone. Otherwise there is a danger of electrical shock in the event of an insulation breakdown or electrical earth fault in the Mono bloc unit. | • |

| | ⚠ CAUTION | |
|-----|--|------------|
| 1. | Do not install the Mono bloc unit in areas where there is a risk of flammable gas leakage. There is a risk of fire if flammable gas accumulates near or around the Mono bloc unit. | \Diamond |
| 2. | Do not release refrigerant during piping work for installation, re-installation and during repairing a refrigeration parts. Take care of the liquid refrigerant, it may cause frostbite. | \Diamond |
| 3. | Make sure the power supply cord does not contact with hot part (i.e. water piping). High temperature may cause insulator of power supply cord damage hence electrical shock or fire. | \Diamond |
| 4. | Do not touch the sharp aluminium fin, sharp parts may cause injury. | \Diamond |
| 5. | Do not apply excessive force to water pipes that may damage the pipes. If water leakage occurs, it will cause flooding and damage to other properties. | 0 |
| 6. | Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water leakage may happen and may cause damage to properties of the user. | 0 |
| 7. | The piping installation work must be flushed before the Mono bloc unit is connected to remove contaminants. Contaminants may damage the Mono bloc unit components. | 0 |
| 8. | Select an installation location where it is accessible for maintenance. | 0 |
| 9. | Power supply connection to Mono bloc unit. Power supply point should be in easily accessible place for power disconnection in case of emergency. Must follow local national wiring standard, regulation and this installation instruction. Strongly recommended to make permanent connection to a circuit breaker. It must be a double pole switch with a minimum 3.0 mm gap. Power supply 1: Use approved 30A circuit breaker. Power supply 2: Use approved 30A circuit breaker. | 9 |
| 10. | Ensure the correct polarity is maintained throughout all wiring. Otherwise, it will cause electrical shock or fire. | 0 |
| 11. | After installation, the installer is obliged to verify correct operation of the Mono bloc unit. Check the connection point for water leakage during test run. If leakage occurs, it will cause damage to other properties. | 0 |
| 12. | Installation work. Four or more people are required to carry out the installation work. The weight of Mono bloc unit might cause injury if carried by less than four people. | 0 |

2. Specifications

2.1 WH-MXC09G3E5

| ltem | | Unit | Refrigerant System | |
|------------------------------|-------------------|------------------|--|-------|
| Performance Test Condition | on | | EN14511 | |
| Cooling Condition (Ambien | nt/Water) | | A35W7 | - |
| Cooling Capacity | | kW | 7.00 | - |
| | | BTU/h | 23900 | - |
| | | kcal/h | 6020 | - |
| EER | | W/W | 3.17 | - |
| | | kcal/hW | 2.72 | - |
| Heating Condition (Ambier | nt/Water) | | A7W35 | A2W35 |
| Heating Capacity | | kW | 9.00 | 9.00 |
| | | BTU/h | 30700 | 30700 |
| | | kcal/h | 7740 | 7740 |
| COP | | W/W | 4.84 | 3.59 |
| | | kcal/hW | 4.16 | 3.08 |
| Air Flow | | m³/min (ft³/min) | Cooling: 89.5 (3160) Heating: 76.8 (2710) | |
| Refrigeration Control Device | ce | | Expansion Valve | |
| Refrigeration Oil | | cm ³ | FV50S (1200) | |
| Refrigerant (R410A) | | kg (oz) | 2.30 (81.2) | |
| Compressor | Туре | | Hermetic Motor (Rotary) | |
| | Motor Type | | Brushless (4-poles) | |
| | Rated Output | kW | 3.00 | |
| Fan | Туре | | Propeller Fan | |
| | Material | | P | P |
| | Motor Type | | DC (8-poles) | |
| | Input Power | W | - | |
| Output Power | | W | 60 | |
| | Fan Speed | rpm | Cooling: 540 (Top Fan) 580 (Bottom Fa Heating: 490 (Top Fan) 530 (Bottom Fan) | |
| Heat Exchanger | Fin material | | Aluminium (Pre Coat) | |
| | Fin Type | | Corrugated Fin | |
| | Row × Stage × FPI | | 2 × 51 × 18 | |
| | Size (W × H × L) | mm | 903.7 × 1295.4 × 38.1 | |

| ltem | | Unit | Mono b | oc Unit |
|--------------------------------------|-------------|----------------|----------------------------|--------------------------|
| Dimension Height | | mm (inch) | 1410 (55-1/2) | |
| | Width | mm (inch) | 1283 (5 | 50-1/2) |
| | Depth | mm (inch) | 320 (12 | -19/32) |
| Net Weight | | kg (lbs) | 148 (326) | |
| Noise Level | Noise Level | | Cooling: 49 Heating: 49 | Cooling: - Heating: - |
| | | Power Level dB | Cooling: 67 Heating: 66 | Cooling: - Heating: - |
| Power Source (Phase, Voltage, Cycle) | | Ø | Single | |
| | | V | 230 | |
| | | Hz | 50 | |

| lte | em | Unit | Mono bloc Unit | |
|------------------------------------|------------------------------------|--------|--------------------------------|-----------------------------|
| Input Power | | kW | Cooling: 2.21 Heating: 1.86 | Cooling: - Heating: 2.51 |
| Maximum Input Power For Mono bl | oc Unit | kW | 5. | 41 |
| Power Supply 1: Phase (ø) / Max. (| Current (A) / Max. Input Power (W) | | Single / 2 | 5.0 / 5.41k |
| Power Supply 2: Phase (ø) / Max. (| Current (A) / Max. Input Power (W) | | Single / 13 | 3.0 / 3.00k |
| Power Supply 3: Phase (ø) / Max. (| Current (A) / Max. Input Power (W) | | - / - | - / - |
| Starting Current | | Α | 10 |).2 |
| Running Current | Running Current | | Cooling: 10.2 Heating: 8.6 | Cooling: - Heating: 11.6 |
| Maximum Current For Mono bloc U | Jnit | Α | 25.0 | |
| Power Factor | | % | Cooling: 94 Heating: 94 | Cooling: - Heating: 94 |
| Power factor means total figure of | compressor and outdoor fan motor. | | | |
| Power Cord | Number of core | | - | |
| Length | | m (ft) | - | |
| Thermostat | | | Electronic Control | |
| Protection Device | | | Electronic Control | |

| Item | | Unit | Water System |
|--|------------------|--------------|--|
| Performance Test Condition | | | EN14511 |
| Operation Range | Outdoor Ambient | °C | Cooling: 16 ~ 43 Heating: -20 ~ 35 |
| | Water Outlet | °C | Cooling: 5 ~ 20 Heating: 25 ~ 55 |
| Internal Pressure Differentia | l | kPa | Cooling: 14.3 Heating: 22.8 |
| Water Pipe Diameter | Inlet | mm (inch) | 30 (1-3/16) |
| | Outlet | mm (inch) | 30 (1-3/16) |
| Water Drain Hose Inner Diar | meter | mm (inch) | 15.00 (19/32) |
| Pump | Motor Type | | DC Motor |
| | No. of Speed | | 7 (software selection) |
| | Input Power | W | 50 |
| Hot Water Coil | Туре | | Brazed Plate |
| | No. of Plates | | 36 |
| | Size (H × W × L) | mm | 65 × 120 × 376 |
| | Water Flow Rate | l/min (m³/h) | Cooling: 20.1 (1.2) Heating: 25.8 (1.5) |
| Pressure Relief Valve Water | Circuit | kPa | Open: 300, Close: 265 and below |
| Flow Switch | | | Magnetic Lead Switch |
| Protection Device | | A | Residual Current Circuit Breaker (30) |
| Expansion Vessel | Volume | I | 10 |
| | MWP | bar | 3 |
| Capacity of Integrated Electric Heater | | kW | 3.00 |

Note:

- Cooling capacities are based on outdoor air temperature of 35°C Dry Bulb with controlled water inlet temperature of 12°C and water outlet temperature of 7°C.
- Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled water inlet temperature of 30°C and water outlet temperature of 35°C.

 Specifications are subjected to change without prior notice for further improvement.
- 3.

2.2 WH-MXC12G6E5

| Item | | Unit | Refrigerant System | |
|-----------------------------------|-------------------|------------------|--|--------------|
| Performance Test Condition | | | EN14511 | |
| Cooling Condition (Ambient/Water) | | | A35W7 | - |
| Cooling Capacity | | kW | 10.00 | - |
| | | BTU/h | 34100 | - |
| | | kcal/h | 8600 | - |
| EER | | W/W | 2.81 | - |
| | | kcal/hW | 2.42 | - |
| Heating Condition (Ambie | nt/Water) | | A7W35 | A2W35 |
| Heating Capacity | | kW | 12.00 | 12.00 |
| | | BTU/h | 41000 | 41000 |
| | | kcal/h | 10320 | 10320 |
| COP | | W/W | 4.74 | 3.44 |
| | | kcal/hW | 4.08 | 2.96 |
| Air Flow | | m³/min (ft³/min) | Cooling: 93.3 (3290) Heating: 80.0 (2830) | |
| Refrigeration Control Devi | ce | | Expansion Valve | |
| Refrigeration Oil | | cm ³ | FV50S (1200) | |
| Refrigerant (R410A) | | kg (oz) | 2.30 (81.2) | |
| Compressor | Туре | | Hermetic Motor (Rotary) | |
| | Motor Type | | Brushless (4-poles) | |
| | Rated Output | kW | 3.00 | |
| Fan | Туре | | Prope | ller Fan |
| | Material | | PP | |
| | Motor Type | | DC (8-poles) | |
| | Input Power | W | | - |
| | Output Power | W | 60 | |
| | Fan Speed | rpm | Cooling: 600 (Top Fan) 640 (Bottom F Heating: 510 (Top Fan) 550 (Bottom I | |
| Heat Exchanger | Fin material | | Aluminium | n (Pre Coat) |
| | Fin Type | | Corrugated Fin | |
| | Row × Stage × FPI | | 2 × 51 × 18 | |
| | Size (W × H × L) | mm | 903.7 × 1295.4 × 38.1 | |

| Item | | Unit | Mono bloc Unit | | |
|---|-------------------|----------------|--------------------------------|-----------------------------|--|
| Dimension | Height | mm (inch) | 1410 (55-1/2) | | |
| | Width | mm (inch) | 1283 (| 50-1/2) | |
| | Depth | mm (inch) | mm (inch) 320 (12-19/32 | | |
| Net Weight | • | kg (lbs) | 148 (326) | | |
| Noise Level | | Ι ΛΒ-Δ Ι | | Cooling: - Heating: - | |
| | | Power Level dB | Cooling: 68 Heating: 67 | Cooling: - Heating: - | |
| Power Source (Phase, Voltage, Cycle) | | Ø | Single | | |
| | | V | 230 | | |
| | | Hz | 50 | | |
| Input Power | | kW | Cooling: 3.56 Heating: 2.53 | Cooling: - Heating: 3.49 | |
| Maximum Input Power Fo | or Mono bloc Unit | kW | 6.27 | | |
| Power Supply 1: Phase (ø) / Max. Current (A) / Max. Input Power (W) | | wer (W) | Single / 29.0 / 6.27k | | |
| Power Supply 2: Phase (ø) / Max. Current (A) / Max. Input Power (W) | | wer (W) | Single / 26.0 / 6.00k | | |
| Power Supply 3: Phase (ø) / Max. Current (A) / Max. Input Power (W) | | wer (W) | -/-/- | | |

| | Item | Unit | Mono bloc Unit | | |
|--------------------------|--|--------|--|--|--|
| Starting Current | | А | 16.5 | | |
| Running Current | | A | Cooling: 16.5 Cooling: - Heating: 11.7 Heating: 16. | | |
| Maximum Current For Mo | ono bloc Unit | Α | 29.0 | | |
| Power Factor | | % | Cooling: 94 Cooling: - Heating: 94 Heating: 94 | | |
| Power factor means total | figure of compressor and outdoor fan mot | or. | | | |
| Power Cord | Number of core | | - | | |
| | Length | m (ft) | - | | |
| Thermostat | | | Electronic Control | | |
| Protection Device | | | Electronic Control | | |

| | Item | Unit | Water System |
|--|------------------|--------------|--|
| Performance Test Condition | | | EN14511 |
| Operation Range | Outdoor Ambient | °C | Cooling: 16 ~ 43 Heating: -20 ~ 35 |
| | Water Outlet | °C | Cooling: 5 ~ 20 Heating: 25 ~ 55 |
| Internal Pressure Differential | | kPa | Cooling: 28.5 Heating: 40.3 |
| Water Pipe Diameter | Inlet | mm (inch) | 30 (1-3/16) |
| | Outlet | mm (inch) | 30 (1-3/16) |
| Water Drain Hose Inner Dian | neter | mm (inch) | 15.00 (19/32) |
| Pump | Motor Type | | DC Motor |
| | No. of Speed | | 7 (software selection) |
| | Input Power | W | 67 |
| Hot Water Coil | Туре | | Brazed Plate |
| | No. of Plates | | 36 |
| | Size (H × W × L) | mm | 65 × 120 × 376 |
| | Water Flow Rate | l/min (m³/h) | Cooling: 28.7 (1.7) Heating: 34.4 (2.1) |
| Pressure Relief Valve Water | Circuit | kPa | Open: 300, Close: 265 and below |
| Flow Switch | | | Magnetic Lead Switch |
| Protection Device | | A | Residual Current Circuit Breaker (30) |
| Expansion Vessel | Volume | I | 10 |
| | MWP | bar | 3 |
| Capacity of Integrated Electric Heater | | kW | 6.00 |

- Note:

 1. Cooling capacities are based on outdoor air temperature of 35°C Dry Bulb with controlled water inlet temperature of 12°C and water outlet
- temperature of 7°C.

 Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled water inlet temperature of 30°C and water outlet temperature of 35°C.

 Specifications are subjected to change without prior notice for further improvement.

3. Features

- Inverter Technology
 - o Energy saving
- High Efficiency
- Compact Design
- Environment Protection
 - o Non-ozone depletion substances refrigerant (R410A)
- Easy to use remote control
- Weekly Timer setting
- Quality Improvement
 - Random auto restart after power failure for safety restart operation
 - o Gas leakage protection
 - o Prevent compressor reverse cycle
 - o Inner protector to protect compressor

• Serviceability Improvement

- Breakdown Self Diagnosis function
- System Status Check Buttons for servicing purpose
- System Service Mode Button for servicing purpose
- o Front maintenance design for Mono bloc unit


• Operation Condition

| | | Water outlet temperature (°C) | Ambient temperature (°C) | |
|---------|---------|-------------------------------|--------------------------|--|
| COOLING | Maximum | 20 | 43 | |
| COOLING | Minimum | 5 | 16 | |
| HEATING | Maximum | 55 | 35 | |
| HEATING | Minimum | 25 | -20 | |

NOTICE: When the outdoor temperature is out of the above temperature range, the heating capacity will drop significantly and Mono bloc unit might stop for protection control.


4. Location of Controls and Components


4.1 Mono Bloc Unit



10

4.1.1 Main Components





Type designation 60245 IEC 57 or heavier cord / cable

Component name

- 1 PCB
- (2) Pressure relief valve
- (3) Flow switch
- 4 Pressure gauge
- (5) Water pump
- 6 RCCB
- 7 Bushing
- 8 Cabinet front plate

- Cabinet top plate
- 10 Overload protector
- 11) Heater assembly
- (2) Expansion vessel
- (13) Cover
- 14 Air purge valve

Connector name


- a Water inlet
- **b** Water outlet

It is advisable to avoid more than 2 blockage directions. For better ventilation & multiple-outdoor installation, please consult authorized dealer/specialist.

4.1.2 Location of Control

4.1.2.1 Remote Control

The user interface allows the installer and user to setup, use and maintain the unit.



(1) OFF/ON Button

This button starts or stops the mode operation function of the unit.

(7) (2) Operation LED

This LED indicates the unit is in operation.

® ③ External Thermo Controller Connected Display

This LCD show the external thermo controller connected display.

4 Force Heater Request OFF/ON Indicator

This icon indicates force heater request OFF/ON mode operation.

(5) Backup Heater Enabled/Disabled Indicator

This icon indicates backup heater enabled/disabled mode operation.

(6) Quiet Mode Indicator

This icon indicates quiet mode operation.

(7) Tank Mode Indicator

This icon indicates tank mode operation.

(8) Cool Mode OFF/ON Indicator

This icon indicates cooling mode OFF/ON operation.

(9) Heat Mode OFF/ON Indicator

This icon indicates heating mode OFF/ON operation.

(10) Auto Mode OFF/ON Indicator

This icon indicates auto mode OFF/ON operation.

(1) Solar Display

This LCD show the solar display.

(2) Caution (Tank Temperature above 60°C) Indicator

This LCD show the Caution display.

(13) Timer/Clock Setting Display

This LCD show the weekly schedule timer setting and clock display.

(14) Outdoor Ambient Temperature Display

This LCD show the outdoor ambient temperature.

(15) Water Outlet Temperature Display

This LCD show the water outlet temperature.

(6) Backup Heater Actual (OFF/ON) Indicator

This icon indicates backup heater actual (OFF/ON) operation.

(17) Booster Heater Actual (OFF/ON) Indicator

This icon indicates booster heater actual (OFF/ON) operation.

(18) System Setting Mode OFF/ON Indicator

This icon indicates the system setting mode request OFF/ON display.

(19) System Status Check Mode OFF/ON Indicator

This icon indicates the status check mode request OFF/ON display.

20 System Service Mode OFF/ON Indicator


This icon indicates the system service mode request OFF/ON display.

4.1.3 To adjust initial settings

Dealer

Select menus and determine settings according to the system available in the household. It is recommended that all alterations of settings are done by an authorised dealer or specialist.

- After initial installation, you may manually adjust the settings. The initial setting remains active until the user changes it.
- The remote control can be used for multiple installations.
- Ensure the operation LED is OFF before setting.
- The system may not work properly if set wrongly. Please consult an authorised dealer.
- 1 Press and simultaneously and hold for 5 seconds until the display shows SETTING STATUS.
- 2) Press or to select the menu.
- (3) Press to enter the menu.
- 4 Press or to select YES/NO, or other options. YES: to enable the menu
 NO: to disable the menu
- (5) Press to confirm.



| Menu (1 ~ 20) | | Default Setting | Setting | 9 | Display | |
|---------------|---|--------------------|-------------------------|---------------------|-----------|-----|
| 1 | Room Thermostat Connection To select whether or not to connect to the optional room thermostat. | NO | YES | NO | ra añ | con |
| 2 | Backup Heater Selection To reduce the heater power if unnecessary. *Options of kW vary depending on the model. | 9 kW | | / 6 kW / kW | HEATER | (RP |
| 3 | Water System Freeze Prevention To activate or deactivate the water freeze prevention when the system is OFF. | YES | YES | NO | An tı | FrE |
| 4 | Tank Connection To select whether or not to connect to the optional water tank unit. Note: If NO is selected, menus 5 to 15 are skipped. | NO | YES | NO | TANK | con |
| 5 | Solar Priority To select the use of solar panel for heating up the water tank. | NO | YES | NO | SOLAR | Pry |
| 6 | *1,*2 Cooling Priority To choose the room cooling as priority during COOL + TANK mode. Note: If YES is selected, menus 8 and 9 are skipped for COOL + TANK mode. | YES | YES | NO | COOL | Pry |
| 7 | Heating Priority To select the room heating as priority during HEAT + TANK mode. Note: If YES is selected, menus 8 and 9 are skipped for HEAT + TANK mode. | NO | YES | NO | HEAT | Pry |
| 8 | *1,*2 Cooling/Heating Operation Interval To set the interval for COOL or HEAT mode during COOL + TANK or HEAT + TANK mode. Note: If YES is selected in menus 6 and 7, this menu is skipped. | 3 hours | 0.5 hours ~ 10 hours | | COOL/HEAT | int |
| 9 | *1 Tank Heat-up Interval To set the interval for the water tank during COOL + TANK or HEAT + TANK mode. Note: If YES is selected in menus 6 and 7, this menu is skipped. | 30 minutes | | utes ~ 5 minutes | TANK | int |

Dealer Operation/settings to be done only by the authorised dealer/specialist.

User Operation/settings to be done by the authorised dealer/specialist or user.

| 10 Booster Heater To activate or deactivate the water tank's booster heater. Note: If NO is selected, menu 11 is skipped. | YES | YES | NO | BOOSTER | Fun | | |
|--|-----------------|-----------------------------------|---------|---------|------|--|--|
| 11 Booster Heater Delay Timer To delay time for the booster heater to activate while the system is heating up the water tank. | 1 hour | 20 minutes ~ 1 hour 35 minutes | | BOOSTER | dL4 | | |
| Do not use the system during sterilisation in order to prevent scalding with hot water, or overheating of shower. Ask an authorised dealer to determine the level of sterilisation function field settings according to the local laws and regulations. | | | | | | | |
| 12 Sterilisation To sterilise the water tank, if required. Note: If NO is selected, menus 13 to 15 are skipped. | YES | YES | NO | St rl | Fun | | |
| 13 Sterilisation Day & Time To set timer for sterilisation. (Only once a week. Operates even under a standby condition) | Monday 12:00 | Monday ~ Sunday 0:00 ~ 23:50 | | | Str | | |
| 14 Sterilisation Temperature To set the temperature of sterilisation. | 70 °C | 40 °C ~ 75 °C | | St rl | ьо і | | |
| 15 Continuation of Sterilisation To maintain heating temperature in order to complete the sterilisation. | 10 minutes | 5 minutes ~ 1 hour | | Str | opr | | |
| 16 Base Pan Heater To select whether or not to connect to the optional base pan heater. Note: If NO is selected, menu 17 is skipped. | NO | YES | NO | 6P An | hEr | | |
| 17 Base Pan Heater type Type A - The base pan heater activates only during deice operation. Type B - The base pan heater activates when outdoor ambient temperature is 5 °C or lower. | A | A | В | 60 An | hbr | | |
| 18 *1,*2 Cool Outdoor Temperature setting To set the outdoor ambient temperature for the AUTO mode to change from HEAT to COOL. | 15 °C | 5 °C ~ 25 °C | | H -[| 588 | | |
| 19 *1, *2 Heat Outdoor Temperature setting To set the outdoor ambient temperature for the AUTO mode to change from COOL to HEAT. | 10 °C | 5 °C ~ | · 25 °C | [-H | 588 | | |
| 20 Dry Concrete During construction to dry the concrete under a preset temperature. Do not use this menu for any other purposes and in period other than during construction (refer to information page). | - | 1 day ~ | 99 days | dr Y | [an | | |

User

Remote control preparation 1 Press .

- 2) Press or to set the current day.
- (3) Press to confirm.
- 4 Repeat steps 2 and 3 to set the current time.

- The current day and time need to be set in cases below:
- When the power is turned on for the first time.
- A long time has elapsed since the power was turned on the last time.
- The current time that has been set will be the standard time for all the timer operations.



Caution Indicator (Tank Temperature above 60 °C)

^{*1} The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.

^{*2} Only displayed when COOL mode is unlocked (Means when COOL mode is available).

4.1.4 How to use

User

Turn on or off the system

OFF/ON ①

When the system is ON, the operation LED is lit and the actual water outlet temperature and outdoor ambient temperature are shown on the display.

User

Select operation mode

Press to select operation mode.

AUTO Depending on the preset outdoor temperature, the system selects HEAT or *1COOL operation mode. AUTO · Depending on the preset outdoor temperature, the system selects HEAT + TANK or *1 COOL + TANK operation mode. + TANK • The panel/floor HEAT operation is either HEAT turned ON or OFF. The mono bloc unit provides heat to the system. **HEAT** • The mono bloc unit provides heat to the + TANK sanitary water tank and the system. • This mode can be selected only when the sanitary water tank is installed. **TANK** • The sanitary water tank is either turned ON or OFF.

 The mono bloc unit provides heat to the sanitary water tank.

+ TANK

*1, *2 COOL • The mono bloc unit provides cooling to the system.

• The system controls the booster heater in the sanitary water tank.


- *1, *2 COOL The panel is either turned ON or OFF.
 - · The mono bloc unit provides cooling to the system.

Initiate the backup heater

Press HEATER

- The backup heater provides extra heat at low outdoor temperature. The backup heater is possible only in the heat mode.
- Once the backup heater is set, it is automatically operated when conditions are fulfilled.
- To disable the backup heater, press again.

The system is turned off by an external switch.



User

Enjoy quiet operation

Press .

• This operation reduces the noise of mono bloc unit. The operation may cause heating \$^1\$ cooling ability to decrease.

System status check mode

1) Press CHECK

(The display shows STATUS.)

- Press or to check the selected mode.
 - Dry concrete (does not show during normal operation)
 - The Water Inlet Temperature
 - Tank Temperature
 - Compressor Running Frequency
 - Error History
 - Heat mode total power consumption (Up to 999 days)
 - *1 Cool mode total power consumption (Up to 999 days)
 - Tank mode total power consumption (Up to 999 days)
 - Press to exit the STATUS mode.

■ Note:

- Once the STATUS mode is entered, the display shows STATUS.
- · The STATUS mode cannot be activated when the display shows SETTING.
- · The total power consumption is an estimated value based on AC 230 V and may differ from value measured by precise equipment.

Dealer

System temperature setting

The system controls the temperature for each menu based on the outdoor ambient temperature.

- To set or change the temperatures, make sure to contact your nearest authorised dealer.
- 1) Press and hold of for 5 seconds to enter the temperature range setting mode.
 (The display shows SETTING.)
- 2 Press or to select a menu.
- 3 Press to enter the menu.
- 4 Press or to set the desired temperature.
- Repeat steps (2) to (5) to set other menus.



Checking the temperature range

- 1) Press and hold for 5 seconds to enter the temperature range setting mode.
- (2) Press or to select a menu.
- Press oto exit.

| Menu | Default setting | Temperature setting | Display | | |
|---|--------------------|--|-------------|---------|-----|
| Setting of low outdoor ambient temperature. | -5 °C | -15 °C ~ 15 °C | | ON aut | Lo |
| Setting of high outdoor ambient temperature. | 15 °C | -15 °C ~ 15 °C | | ON aut | Н, |
| Setting of water outlet temperature at low outdoor ambient temperature. | 55 °C | 25 °C ~ 55 °C | HEAT | ON H ZO | Lo |
| Setting of water outlet temperature at high outdoor ambient temperature. | 35 °C | 25 °C ~ 55 °C | | ON H SQ | Н, |
| During HEAT mode, the water outlet temperature is adjusted as is shown the diagram on the right. It is performed within the preset temperature range. | | | | | |
| | | <outdoor ambient="" td="" to<=""><td>emperature</td><td>></td><td></td></outdoor> | emperature | > | |
| Setting of outdoor ambient temperature to turn OFF heating operation during HEAT mode. | 24 °C | 5 °C ~ 35 °C | HEAT | OFF | SEŁ |
| Setting of outdoor ambient temperature to turn ON the backup heater. | 0 °C | -15 °C ~ 20 °C | HEATER | ONout | 5EE |
| Setting of water outlet temperature during*1COOL mode. | 10 °C | 5 °C ~ 20 °C | *1, *2 COOL | | 588 |
| Setting of sanitary water tank temperature. | 52 °C | 40 °C ~ 75 °C | TANK | | SEE |

^{*1} The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.

*2 Only displayed when COOL mode is unlocked (Means when COOL mode is available).

User

Shifting the water temperature

This easily shifts the water outlet temperature if the setting is undesirable.

1 Press to enter the water temperature shifting mode.

2 Press to change setting.

③ Press ♠ or ♦ to set the desired temperature. (temperature range: -5 °C ~ 5 °C)

Water outlet temperature>
H 20 H
Shift value

4 Press to confirm the setting.

Desired temperature setting TIMER OUTDOOR ACTUAL HEAT SETTING OFF/ON O SETTING SETITUR SETITING SETTING SETTING SETTING SETTING SETTING SETITUR SETITING SETITIN

■ Note:

- Press or wait for 30 seconds to exit the SETTING mode.
- The set temperature will be saved in the system once confirmed.
- The SETTING mode cannot be activated when the SERVICE and STATUS indicators are ON.
- The system will shift the temperature within water outlet temperature range.

<Outdoor ambient temperature>

User

Holiday mode

- By setting the day (s) in holiday mode, it promotes energy saving while you are on holiday, and enables the system to resume at the preset temperature after your holiday.
- · Ensure that the system is OFF before setting.
- The system will resume operation automatically at 00:00 am after the holiday.
- The day the HOLIDAY mode was set is counted as day 1.


Example:

Setting the holiday mode on June 21, 08:00 am. By setting 3 days, the system resumes operation on June 24, 00:00 am.

- 2 Press or to set the desired days. (Setting range: 1 day ~ 999 days)
- \bigcirc Press \bigcirc to confirm the setting.

■ Note:

• Press or wait 30 seconds to exit the HOLIDAY mode.



User Operation/settings to be done by the authorised dealer/specialist or user.

User

Weekly timer setting

Promotes energy saving by allowing you to set up to 6 programmes in any given day.

Lights up if Timer operation is selected
Indicates the next timer operation programme

Programme number in a day

TIMER 1 2 3 4 5 6 Indicates the next timer

ON Timer ON

OFF Timer OFF

OFF Timer OFF

OPERATION


OPERATION

Day to be selected

- 1 Press to enter the timer setting mode.
- 2) Press or to select your desired day.
- 3 Press to confirm your selection.
- (4) "1" will be blinking, press to set programme 1.
- (5) Press to select ON or OFF timer.
- 6 Press or to select your desired time.
 You can set , and the Water
 Temperature Thermo Shift setting.
- 7 Press to confirm programme 1. The selected day will be highlighted with ▼.
 - After 2 seconds, the display will move to the next programme. Repeat steps 4 to 7 to set programmes 2 to 6.
 - During timer setup, if no button is pressed within 30 seconds, or if the is pressed, the setting at that moment is confirmed and timer setup is ended.

To check current timer programme

- 1 Press to enter timer mode and press to enter day setting.
- 2 Press or until your desired day is shown, press to confirm your selection.
- ③ Press ♠ or ♥ to check the set programmes.



To modify current timer programme or add new timer programme

1 Perform steps 1 to 7 of "Weekly timer setting" to modify existing timer programme, or add any timer programme.

To cancel current timer programme

- 1 Press to enter day.
- 2 Press or until your desired day is shown, press to enter programme setting.
- 3 Press a or until your desired programme is shown.
 - Press to cancel the programme and ▼ will disappear.

To disable/enable Weekly Timer

- To disable weekly timer setting, press , then press .
- To enable previous weekly timer setting, press $\stackrel{\text{TIMER}}{\longrightarrow}$, then press $\stackrel{\text{SET}}{\bigcirc}$.

■ Note:


- You may set the timer for each day of the week (Monday to Sunday) with 6 programmes per day.
- When the system is switched on by the timer, it will use the previously set temperature to control the water outlet temperature.
- The same timer programme cannot be set on the same day.
- You may also select 2 or more days with the same timer setting.

Dry Concrete Function

- During construction to dry the concrete under a preset temperature.
- 1 Press and simultaneously and hold for 5 seconds until the display shows "ra ฉนั cฉก".
- 2 Press . (The display shows "dr 4 Lon".)
- ③ Press ot to select day.
 - Press or to set the desired temperature.
- (4) Press \bigcirc to confirm the selection.
- 5 Repeat step 3 and 4 to set other days and temperature.
- Press CANCEL to exit.


To Reset the Remote Control to Default Setting

- 1 Press , , , continuously for 5 seconds. The operation is off during this period.
- 2 The display shows " dF LE, dHE, dhE" for 2 seconds for confirmation. After 2 seconds, it goes to normal display.




5. Dimensions


5.1 Mono Bloc Unit



6. Refrigeration And Water Cycle Diagram









7. Block Diagram

7.1 WH-MXC09G3E5




7.2 WH-MXC12G6E5





8. Wiring Connection Diagram

8.1 WH-MXC09G3E5




8.2 WH-MXC12G6E5







9. Electronic Circuit Diagram

9.1 WH-MXC09G3E5



9.2 WH-MXC12G6E5







10. Printed Circuit Board

10.1 Water System

10.1.1 Main Printed Circuit Board




10.1.2 Solar Printed Circuit Board (Optional)




10.2 Refrigerant System


10.2.1 Main Printed Circuit Board



10.2.2 Noise Filter Printed Circuit Board




10.2.3 Capacitor Printed Circuit Board





11. Installation Instruction Mono Bloc Unit

Dimension Diagram



Main Components





Component name

- 1) PCB
- (2) Pressure relief valve
- (3) Flow switch
- 4 Pressure gauge
- (5) Water pump
- (6) RCCB
- 7 Bushing
- 8 Cabinet front plate

- 10 Overload protector
- 11) Heater assembly
- (12) Expansion vessel
- (13) Cover
- (4) Air purge valve

Connector name

- (a) Water inlet
- (b) Water outlet

It is advisable to avoid more than 2 blockage directions. For better ventilation & multiple-outdoor installation, please consult authorized dealer/specialist.

11.1 Select The Best Location

- Install the Mono bloc unit in outdoor locations only.
- Avoid installations in areas where the ambient temperature may drop below -20°C.
- The Mono bloc unit must be installed on a flat, solid surface.
- A place removed from any heat source or steam which may affect the operation of the Mono bloc unit.
- A place where air circulation is good.
- A place where drainage can be easily done.
- A place where Mono bloc unit's operation noise will not cause discomfort to the user.
- A place which is accessible for maintenance.
- Ensure to keep minimum distance of spaces as illustrated below from wall, ceiling, or other obstacles.
- A place where flammable gas leaking might not occur.
- A place where the Mono bloc unit's piping and wiring lengths come within reasonable ranges.
- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- Do not place any obstacles which may cause a short circuit of the discharged air.
- Avoid installing the Mono bloc unit at a location where suction side may be exposed directly to wind.
- If Mono bloc unit installed near sea, region with high content of sulphur or oily location (e.g. machinery oil, etc.), it lifespan maybe shorten.
- When installing the product in a place where it will be affected by typhoon or strong wind such as wind blowing between buildings, including the rooftop of a building and a place where there is no building in surroundings, fix the product with an overturn prevention wire, etc. (Overturn prevention fitting model number: K-KYZP15C)



 When connecting solar pump station cable between Mono bloc unit and solar pump station, the distance between both apparatuses shall be 2 ~ 8 meters and the maximum length of 10 metres only.

Failure to do so may lead to abnormal operation to the system.

11.2 Mono Bloc Unit Installation

Mono bloc unit will become heavy when filled with water. Please install the unit on a strong concrete floor and consider the weight of the unit and water.

- Fix Mono bloc unit on the concrete floor with M12 anchor bolt at 4 locations.
- Pull-out strength of these anchor bolts must be above 15000N.




Illustration of grip type and embedded type anchor bolt

11.3 Piping Installation

⚠ WARNING

This section is for authorized and licensed electrician / water system installer only. Work behind the front plate secured by screws must only be carried out under supervision of qualified contractor, installation engineer or service person.

Please engage a licensed water circuit installer to install this water circuit.

- The minimum requirement of water in the system is 50 litres. If this value could not be achieved, please install additional buffer tank (field supply).
- This water circuit must comply with relevant European and national regulations (including EN61770), and local building regulation codes.
- Ensure the components installed in the water circuit could withstand water pressure during operation.
- Do not apply excessive force to piping that may damage the pipes.
- Use Rp 1 ¼" nut for both water inlet and water outlet connection and clean all piping with tap water before connecting to the Mono bloc unit.
- Cover the pipe end to prevent dirt and dust when inserting it through a wall. If an existing tank is to be connected
 to this Mono bloc unit, ensure the pipes are clean before water pipe installation is carried out.
- An external filter (30 mesh or more field supplied) must be installed before the water inlet of the Mono bloc unit.
- Refer to Diagram 3.1 for pipe connection of Radiator, Floor Heater, Tank Unit, Solar Pump Station, 3-way Valve Kit and etc. Fail to connect the pipes appropriately might cause the unit malfunction.





Diagram 3.1: Typical Water Piping Installation

- Choose proper sealer which can withstand the pressures and temperatures of the system.
- Make sure to use two spanners to tighten the connection. Tighten the nuts with torque wrench: 117.6 N•m.
- If non-brass metallic piping is used for installation, make sure to insulate the piping to prevent galvanic corrosion.
- Do not use pipes that are crushed or deformed. If these inferior pipes are used, it may cause unit malfunction.
- Make sure to insulate the water circuit piping (insulator thickness: 20 mm or more) to prevent condensation during cooling operation (cooling model only) and reduction of heating capacity, as well as avoid freezing of the outdoor water circuit piping during winter season.
- After installation, check the water leakage condition in connection area during test run.
- In case of a power supply failure or pump operating failure, drain the system (as suggested in the figure below).



When water is idle inside the system, freezing up is very likely to happen which could damage the system.

Drainage piping installation

- Use a drain hose with inner diameter of 15 mm.
- The hose must be installed in a continuously downward direction and left open to the frost-free atmosphere.
- If drain hose is long, use a metal support fixture along the way to eliminate the wayy pattern of drain tube.
- Water will drip from this hose, therefore the outlet of this hose must be installed in an area where the outlet cannot become blocked.
- Do not insert this hose into sewage or drain pipe that may generate ammonia gas, sulfuric gas, etc.
- If necessary, use a hose clamp to tighten the hose at drain hose connector to prevent it from leaking.






Illustration of how to fix drain hose to Mono bloc unit

11.4 Connect The Cord And Cable To Mono Bloc Unit

(REFER TO WIRING DIAGRAM AT UNIT FOR DETAIL)

- 1. An isolating device must be connected to the power supply cable.
- Isolating device (Disconnecting means) should have minimum 3.0 mm contact gap.
- Connect the approved polychloroprene sheathed power supply 1 cord (3 × 4.0 or 6.0 mm²) and power supply 2 cord (3 × 4.0 mm²), type designation 60245 IEC 57 or heavier cord to the RCCB, and to the other end of the cord to isolating device (Disconnecting means).
- 2. To avoid the cable and cord being damaged by sharp edges, the cable and cord must be passed through a bushing (located at the right hand side of the mono bloc unit) before being connected to the terminal block. The bushing must be used and must not be removed.
- 3. Secure the cable onto the control board with the holder (clamper).






How to guide cable/cord to bushing


Connecting with external device (optional)

- 1. All connections shall follow to the local national wiring standard.
- 2. It is strongly recommended to use manufacturer-recommended parts and accessories for installation.
- 3. Maximum output power of booster heater shall be ≤ 3 kW. Booster Heater cord must be (3 × min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
- 4. Two-way Valve shall be spring and electronic type, refer to "Field Supply Accessories" table for details. Valve cable shall be (3 × min 0.5 mm²), of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
 - * note: Shall be CE marking compliance component.
 - Maximum load for the valve is 9.8VA.
- 5. Three-way Valve shall be spring and electronic type, refer to "Field Supply Accessories" table for details. Valve cable shall be (3 × min 0.5 mm²), of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
 - * note: Shall be CE marking compliance component.
 - It shall be directed to heating mode when it is OFF.
 - Maximum load for the valve is 9.8VA.
- 6. Room Thermostat cable must be (4 or 3 × min 0.5 mm²), double insulation layer of PVC-sheathed or polychloroprene sheathed cable.
- 7. Tank OLP cable must be (2 × min 0.5 mm²), double insulation layer of PVC-sheathed or polychloroprene sheathed cable.
 - * note: if such connection deemed NO necessary for tank OLP, please connect jumper between terminal no. 13 and 14.

- 8. Tank Sensor shall be resistance type, please refer to Graph 4.1 for the characteristic and details of sensor. Its cable shall be (2 × min 0.3 mm²), double insulation layer (with insulation strength of min 30V) of PVC-sheathed or polychloroprene sheathed cable.
- 9. External Controller shall be connected to 1-pole switch with min 3.0mm contact gap. (connection refer to Diagram 4.2). Its cable must be (2 × min 0.5 mm²), double insulation layer of PVC-sheathed or polychloroprene sheathed cable.
 - * note: When making such connection, kindly remove the jumper between terminal no. 17 and 18.
 - Switch used shall be CE compliance component.
 - Maximum operating current shall be less than 3A_{rms}.
- 10. Must install Solar Connection PCB ⓓ (optional) to Mono bloc unit when Solar Pump Station is utilized. Refer Solar Connection PCB's installation instruction for detail of installation.
- 11. Solar Three-way Valve cable shall be (3 × min 0.5 mm²), double insulation layer PVC-sheathed or polychloroprene sheathed cable.
- 12. Solar Pump Station cable shall be (2 × min 0.5 mm²), of double insulation PVC-sheathed or polychloroprene sheathed cable. Strongly recommended install with maximum length of 10 meter only.



| Terminal screw | Tightening torque N•cm { kgf•cm} |
|----------------|-------------------------------------|
| M4 | 157 ~ 196 {16 ~ 20} |
| M5 | 196 ~ 245 {20 ~ 25} |



Graph 4.1: Tank sensor characteristic

11.4.1 Wire Stripping And Connecting Requirement




Diagram 4.2: External Controller connecting diagram

11.4.2 Connecting Requirement

For model WH-MXC09G3E5:

- This equipment's power supply 1 complies with IEC 61000-3-12 provided that the short circuit power S_{SC} is
 greater than or equal to 1700kW at the interface point between the user's supply and the public system. It is the
 responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network
 operator if necessary, that the equipment is connected only to a supply with a short circuit power S_{SC} greater
 than or equal to 1700kW.
- The equipment's power supply 1 complies with IEC/EN 61000-3-11 and shall be connected to a suitable supply network, having services current capacity > 100A per phase.
 Please liaise with supply authority that the service current capacity at the interface point is sufficient for the installation of the equipment.
- The equipment's power supply 2 complies with IEC/EN 61000-3-12.
- The equipment's power supply 2 complies with IEC/EN 61000-3-11 and shall be connected to suitable supply network, with the following maximum permissible system impedance Z_{max} = 0.453 Ω at the interface.
 Please liaise with supply authority to ensure that the power supply 2 is connected only to a supply of that impedance or less.

For model WH-MXC12G6E5:

- This equipment's power supply 1 complies with IEC 61000-3-12 provided that the short circuit power S_{SC} is
 greater than or equal to 1700kW at the interface point between the user's supply and the public system. It is the
 responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network
 operator if necessary, that the equipment is connected only to a supply with a short circuit power S_{SC} greater
 than or equal to 1700kW.
- The equipment's power supply 1 complies with IEC/EN 61000-3-11 and shall be connected to a suitable supply network, having services current capacity > 100A per phase.
 Please liaise with supply authority that the service current capacity at the interface point is sufficient for the installation of the equipment.
- The equipment's power supply 2 complies with IEC/EN 61000-3-12.
- The equipment's power supply 2 complies with IEC/EN 61000-3-11 and shall be connected to suitable supply network, with the following maximum permissible system impedance $Z_{max} = 0.453 \Omega$ at the interface.
- Please liaise with supply authority to ensure that the power supply 2 is connected only to a supply of that impedance or less.


11.4.3 Wired Remote Control Installation


| | ⚠ WARNING | | | | | |
|------------|---|--|--|--|--|--|
| \Diamond | Do not modify the length of the remote control cable. Otherwise, it will cause fire or electrical shock. | | | | | |
| 0 | Be sure to turn off the main power before installing and connecting the remote control. Otherwise, it will cause the electrical shock. | | | | | |
| 0 | Use the attached accessories parts and specified parts for installation. Otherwise, it will cause the set to fall, fire or electrical shock. | | | | | |
| 0 | Wire routing must be properly arranged so that control board cover is fixed properly. If control board cover is not fixed properly, it will cause fire or electrical shock. | | | | | |
| 0 | If passing the remote control cable through a wall, be sure to install a water trap above the cable. Otherwise, it will cause the electrical shock. | | | | | |
| | ⚠ CAUTION | | | | | |
| 0 | Install in a flat surface to avoid warping of remote control, else damage to the LCD case or operation problems may result. | | | | | |
| 0 | Avoid installing the remote control cable near refrigerant pipes or water pipes, else will cause electrical shock or fire. | | | | | |
| 0 | Install the remote control cable at least 5 cm away from electric wires of other appliances to avoid miss operation (electromagnetic noise). | | | | | |
| 0 | Be sure to use only the accessory screws to avoid damage of remote control PCB. | | | | | |

Attached Accessories

| No. | Name | Qty. | Diagram | Remark |
|-----|------------------------------------|------|---------------------------|---|
| (1) | Remote control | 1 | | |
| (2) | Remote control cable | 1 | 4 | Length (15 m) |
| (3) | Screw (M4 machine pitched - 30 mm) | 3 | шилишилин (() | Installing the remote control to an outlet box (embedded cable) |
| (4) | Screw (M4 self-tapping - 14 mm) | 3 | W | Installing the remote control to the wall (exposed cable) |

11.4.4 Selecting The Installation Location






- Allow sufficient space around the remote control (1) as shown in the illustration above.
- Install in a place which is away from direct sunlight and high humidity.


- Install in a flat surface to avoid warping of the remote control. If installed to a wall with an uneven surface, damage to the LCD case or operation problems may result.
- Install in a place where the LCD can be easily seen for operation. (Standard height from the floor is 1.2 to 1.5 meters.)
- Avoid installing the remote control cable near refrigerant pipes or drain pipes, else it will cause electrical shock or fire.

11.4.5 Installing The Remote Control Unit To The Wall




- 1 Remove the remote control (1) lower case. (Insert a flat-tipped screw driver or similar tool 2 to 3 mm into one of the gaps at the bottom of the case, and twist to open. Refer to the illustration above.)
 - Be careful not to damage the lower case.
- 2 Do not remove the protective tape which is affixed to the upper case circuit board when removing the remote control lower case.
- 3 Secure the lower case to an outlet box or wall. Refer to (A) or (B) instructions below depending on your choice of cable installation.
- 4 Be sure to use only the screws provided.
- 5 Do not over tighten the screws, as it may result in damage to the lower case.

- A. If Remote Control Cable Is Embedded
 - 1 Embed an outlet box (JIS C 8336) into the wall. Outlet box may be purchased separately. Medium-sized square outlet box (obtain locally) Part No. DS3744 (Panasonic Co., Ltd.) or equivalent.
 - 2 Secure the remote control lower case to the outlet box with the two accessory screws (3). Make sure that the lower case is flat against the wall at this time, with no bending.
 - 3 Pass the remote control cable (2) into the box.
 - 4 Route the remote control cable (2) inside the lower case through rear feeding-out direction.
 - 5 Insert firmly the connector of remote control cable (2) to connector (CON1) in the upper case circuit board. [Refer to the illustration at below.]
 - 6 Secure the remote control upper case to the lower case with the tabs provided.





A CAUTION

When the wall is hollow, please be sure to use the sleeve for remote control cable to prevent dangers caused by mice biting the cable.




- B. If Remote Control Cable Is Exposed
 - 1 Install the remote control lower case to the wall with the two accessory screws (4).
 - 2 Fasten the screws properly until screw head is lower than the rib and reach the base of remote control lower case to ensure they do not damage the PCB inside the remote control (1).





- 3 The feeding-out direction for the remote control cable can be either via top, left or right side.
- 4 Use nipper to cut a notch at the upper case. (Select the intended feeding-out position)
- 5 Route the remote control cable (2) inside the lower case in accordance with the intended feeding-out direction. (Refer to the illustration at below)
- 6 Insert firmly the connector of remote control cable (2) to connector (CON1) in the upper case circuit board. (Refer to the illustration at below)
- 7 Secure the remote control upper case to the lower case with the tabs provided.





11.4.6 Connecting The Remote Control Cable To Mono Bloc Unit

MARNING

Be sure to turn off the main power before installing and connecting the remote control. Otherwise, it will cause the electrical shock.

- 1 Remove the cabinet front plate.
- 2 Connect the remote control cable with the provided connector as shown in below illustration. (Refer wiring diagram for detail.)
- Guide the remote control cable through the clamper and Bushing ①.
 (Refer illustration "How to connect Remote Control to Provided Connector" for detail.)
- 4 Reinstall the cabinet front plate after connection complete.







How to connect Remote Control to Provided Connector

11.5 Checking and Test Run Procedures

MARNING


Be sure to switch off all the power supply before performing each of the below action.





11.5.1 Disposal of Mono Bloc Unit Drain Water

- When a Drain elbow 11 is used, please ensure to follow below:
 - o The unit should be placed on a stand which is taller than 50mm.
 - o Cover the 8 holes (ø20mm) with Rubber cap [2] (refer to illustration below)
 - o Use a tray (field supply) when necessary to dispose the Mono bloc unit drain water.



• If the unit is used in an area where temperature falls below 0°C for 2 or 3 consecutive days, it is recommended not to use the Drain elbow 11 and Rubber cap 22, for the drain water freezes and the fan will not rotate.

12. Operation and Control

12.1 Basic Function

Inverter control, which equipped with a microcomputer in determining the most suitable operating mode as time passes, automatically adjusts output power for maximum comfort always. In order to achieve the suitable operating mode, the microcomputer maintains the set temperature by measuring the temperature of the environment and performing temperature shifting. The compressor at outdoor unit is operating following the frequency instructed by the microcomputer at indoor unit that judging the condition according to internal water setting temperature and water outlet temperature.

12.1.1 Internal Water Setting Temperature

Once the operation starts, control panel setting temperature will be taken as base value for temperature shifting processes. These shifting processes are depending on the Air-to-Water Heat pump settings and the operation environment. The final shifted value will be used as internal water setting temperature and it is updated continuously whenever the electrical power is supplied to the unit.

12.1.2 Heating Operation

12.1.2.1 Thermostat Control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature > 2°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) <-3°C.

12.1.2.2 Thermostat Control (Outdoor Ambient Temperature)

Stops provide heating to room side during high outdoor ambient condition. Control content:


- Heating operation and water pump will turn OFF when outdoor ambient temperature > outdoor thermo off temperature + 3°C.
 - (Outdoor thermo off set temperature is set by control panel. Thermo off set temperature is between 5°C ~ 35°C)
- Heating operation will resume when Outdoor ambient temperature < Outdoor thermo OFF set temperature + 1°C.

12.1.2.3 Heat Mode Operation

Operation of heat pump provide heating capacity to room side by hot water through heating panel, floor heating or fan coil unit.

- 1 3 ways valve control:
 - 3 ways valve switch and fix to heating side.
- 2 Heat pump operates follow normal heating operation.
- 3 Back up heater operate follow normal operation.
- 4 Solar 3 way valve operates follow solar operation specification.
- 5 2 ways valve control:
 - o 2 ways valve opens.

Heat Mode Operation Time Chart



12.1.3 Cooling Operation


12.1.3.1 Thermostat control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature > -1.5°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) >3°C.


12.1.3.2 Cool Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch and fix to cooling side.
- 2 Heat pump operates follow normal cooling operation.
- 3 Back up heater DOES NOT operate during cool mode.
- 4 Solar 3 way valve operates follow solar operation specification.
- 5 2 ways valve control:
 - o 2 ways valve is closed.

Cool Mode Operation Time Chart



12.1.4 Auto Mode Operation



Control details:

- o To enable the unit to operate either heat or cool mode automatically, heat to cool set temperature and cool to heat set temperature can be set by control panel.
- Automatic operation is judged based on control panel setting temperature and outdoor ambient temperature.
- * Minimum setting of heat to cool set temperature is 1°C higher than cool to heat set temperature.

Judgement control:

- If outdoor ambient temperature < Heat to Cool Set Temperature, unit will operate in Heat Mode or else the unit will operate in Cool Mode.
- o If current operation is Cool mode, outdoor ambient temperature > Cool to Heat Temperature, unit will maintain Cool mode operation or else the unit will operate Heat mode.
- o If current operation is Heat mode, outdoor ambient temperature >Heat to Cool Temperature, unit will maintain Heat mode operation or else the unit will operate Cool mode.
- Every 60 minutes the outdoor ambient temperature is judged.
- When Auto + Tank mode is selected, operation mode switching is judged by both outdoor ambient temperature and indoor air temperature.

12.1.5 Tank Mode Operation


Control contents:


- 3 ways valve direction
- 3 ways valve switch to tank side during Tank Thermo ON condition. Switch 3 ways valve to room side when tank achieve Tank Thermo OFF temperature and SOLAR turn ON condition.
- Heat Pump Thermostat characteristic
- Water set temperature = Tank set temperature or [50°C] whichever lower.
- Heat pump Water Outlet set temperature is set to [53°C] at tank mode.
- Tank Thermo ON/OFF characteristic
- THERMO OFF TEMP:
 - 1.THERMO OFF TEMP = Tank water set temperature + [0°C].
 - 2.Tank temperature > THERMO OFF TEMP for continuous 10 seconds after heat pump OFF, water pump OFF or
 - 3. Tank temperature > Tank set temperature + [2°C] for continuously 20 seconds.
- THERMO ON TEMP:
 - 1.THERMO ON TEMP = Tank water set temperature + [-2°C].

When detect tank temperature < THERMO ON TEMP, water pump ON for 3 minutes then heat pump ON.

Characteristic of heat pump thermo ON/OFF under Tank Mode condition:

- Water Outlet Thermo Condition
- o Heat pump THERMO OFF TEMP:
 - 1. Heat pump THERMO OFF TEMP = 53°C + [+4°C].
 - 2. Water outlet temperature > Heat pump THERMO OFF TEMP for continuous 3 minutes, heat pump OFF.
- o Heat pump THERMO ON TEMP:
 - 1. Heat pump THERMO ON TEMP = Water inlet during thermo OFF time + [-3°C].
 - 2. Heat pump ON back when water outlet temperature < Heat pump THERMO ON TEMP.
- Water Inlet Thermo Condition
- o Heat pump THERMO OFF TEMP:
 - 1. Water inlet temperature > 55°C for continuous 60 seconds, heat pump OFF.
- Heat pump THERMO ON TEMP:
 - 1. Heat pump THERMO ON TEMP = Water inlet temperature < 55°C.
- Booster heater control
- Booster heater turns ON and OFF follow normal operation.
- o Booster heater turns ON condition:
 - 1. During start up time (initialization), Booster heater turns ON after DELAY TIMER.
 - 2. When tank temperature lower than HEATER ON TEMP.
 - 3.20 minutes from previous heater OFF.
- Booster heater turns OFF CONDITION:
 - 1. When tank temperature higher than tank set temperature for continuous 15 seconds.
- Solar 3-way valve
- o Solar pump operates follow solar operation specification.
- 2 way valve closes
- Other
- Indoor backup heater cannot be ON during tank mode only.





12.1.6 Heat + Tank Mode Operation

Setting 1: When Heating priority is set by control panel:

- 1. 3 ways valve control:
 - o 3 ways valve switch to room side during External Room Thermo ON **OR** Solar 3 ways valve ON **OR** Tank Thermo OFF time, and switch to tank side at External Room Thermo OFF **AND** Solar 3 ways valve OFF.
- 2. Heat pump operation control:
 - o During External Room Thermo ON time: (When room thermo ON, heat pump must operate to room side)
 - Heat pump operates follow normal operation at room side.
 - o During External Room Thermo ON time:
 - Switch 3 ways valve to tank side, IF

Under Solar Priority Set condition:

- Tank temperature < Tank THERMO ON TEMP AND Solar Valve OFF Under Solar Priority Not Set condition:
- o Tan temperature < Tank THERMO ON TEMP
- Switch back 3 ways valve to room side, Heat pump and water pump turn OFF, IF
 - o External Room Thermo ON back **OR** Under Solar Priority Set condition:
 - Tank temperature > Tank THERMO OFF TEMP for continuous 10 seconds **OR** Solar Valve ON. Under Solar Priority Not Set condition:
 - Tank temperature > Tank THERMO OFF TEMP for continuous 10 seconds.
 - * Judge only after heat pump THERMO OFF
 - * THERMO ON and THERMO OFF point refer to case below.

Operation condition when 3 ways valve switch to tank side:

- Tank water set temperature = tank set temperature or [50°C] whichever lower.
- Heat Pump Water Outlet set temperature is set to [53°C] during tank interval.
- Initial Tank THERMO ON TEMP = heat pump tank target temperature + [-2°C].

Tank Thermo ON/OFF Characteristic

- o THERMO OFF TEMP:
 - 1. THERMO OFF TEMP = Heat pump tank target temperature + [0°C].
 - Tank temperature > THERMO OFF TEMP for continuous 10 seconds after heat pump OFF due to water thermo, switch 3 ways valve to room side OR
 - 3. Tank temperature > Tank set temperature + 2°C for continuous 10 seconds, switch 3 ways valve to room side.
- Next THERMO ON TEMP:
 - 1. THERMO ON TEMP = Heat pump tank target temperature + [2°C] or
 - 2. If tank temperature < THERMO ON TEMP AND External Room Thermo OFF, switch to tank side.

Characteristic of heat pump thermo ON/OFF under tank side condition

Water Outlet Thermo condition

- Heat pump THERMO OFF TEMP:
 - 1. Heat pump THERMO OFF TEMP = 53°C + [+4°C].
 - 2. Water outlet temperature > Heat pump THERMO OFF TEMP for continuous 90 seconds, heat pump OFF and water pump continue ON.
- Next THERMO ON TEMP:
 - THERMO ON TEMP = Water inlet when heat pump THERMO OFF + [-3°C].
 - 2. If water outlet temperature < THERMO ON TEMP AND External Room Thermo OFF, heat pump ON.


Water Inlet Thermo condition

- Heat pump THERMO OFF TEMP
 - 1. Water inlet temperature > [55°C] for continuous 30 seconds, heat pump OFF, water pump continue ON.
- Next THERMO ON TEMP:
 - 1. THERMO ON TEMP = Water inlet temperature <55°C.
 - 2. If water inlet temperature < THERMO ON TEMP AND External Room Thermo OFF, heat pump ON.


Solar Operation Condition (Only during solar priority is set condition)

- When solar request ON, solar valve will ON, turn OFF heat pump and water pump and switch 3 ways valve to room side.
- o THERMO ON TEMP:
 - 1. THERMO ON TEMP = Heat pump tank target temperature + [-2°C].
 - 2. If tank temperature < THERMO ON TEMP **AND** External Room Thermo OFF **AND** Solar 3WV OFF, switch to tank side. Turn ON heat pump after water pump turns ON for 3 minutes.
 - 3. Backup heater control:
 - o During External Room Thermo ON time, follow normal backup heater control operation.
 - o During External Room Thermo OFF time, Backup heater OFF.
 - 4. Booster heater control:
 - o Booster heater ON/OFF follow normal operation.
 - * Under solar priority is set condition, when solar 3 way valve is ON, booster heater turn OFF.
 - 5. Solar 3 way valve:
 - o Solar 3 way valve operates follow solar operation specification.
 - * Under solar priority is et condition, when solar 3WV turns ON, booster heater will turns OFF and 3 ways valve switch to room side.
 - * Under solar priority is not set condition, solar 3WV will OFF when heat pump operate to tank side.
 - o 2 way valve open.

Heat + Tank Mode (Heating priority set) Under Solar Priority Set Condition:



Under Solar Priority Not Set Condition:



Setting 2: When heating priority is not set by control panel:

- When Solar Priority is set/not set by control panel:
 - 1. 3 ways valve control:
 - o 3 ways valve switch to room side during heating heat-up interval, and switch to tank side during tank heat-up interval. Both modes will switch alternatively. Tank mode is the Initial running mode of this heat + tank mode (heating no priority).
 - 2. Heat pump operation control:
 - During heating heat-up interval
 - Follow normal heating operation Under solar priority set condition:
 - Switch to tank heat-up interval and start counting tank heat-up timer when External Room Thermo
 OFF AND solar 3WV OFF AND Tank temperature < THERMO ON TEMP (End Room Interval
 Early) OR
 - Switch to tank heat-up interval and start counting tank heat-up timer when tank temperature <
 THERMO ON TEMP AND solar 3WV OFF.

Under solar priority not set condition:

- Switch to tank heat interval and start counting tank heat-up timer when External Room Thermo
 OFF AND Tank < THERMO ON TEMP (End Room Interval) OR
- Switch to tank heat-up interval and start counting tank heat-up timer when tank temperature < THERMO ON TEMP.
- * THERMO ON TEMP is defined Tank thermo ON/OFF condition below.
- During tank heat-up interval
 - Heat pump tank target temperature = Tank set temperature or [50°C] whichever lower.
 - Heat pump Water Outlet set temperature is set to [53°C] during tank interval.
 - Initial Tank THERMO ON TEMP = heat pump tank target temperature + [-2°C].

Tank thermo ON/OFF characteristic:

- o THERMO OFF TEMP:
 - 1. THERMO OFF TEMP = Heat pump tank target temperature + [0°C].
 - 2. Tank temperature > THERMO OFF TEMP for continuous 10 seconds after heat pump off due to water thermo, switch 3 ways valve to room side. End Tank heat-up interval and start count heating heat-up interval.
 - 3. Tank temperature > Tank set temperature + [2°C] for continuous 10 seconds, switch 3 way valve to room side. End Tank heat up interval and start count heating up interval.
- o THERMO ON TEMP:
 - 1. THERMO ON TEMP = Heat pump tank target temperature + [-2°C].
 - 2. After heating heat-up interval, always detect tank temperature. Switch to next tank heat-up interval when tank temperature < THERMO ON TEMP.

Characteristic of heat pump thermo ON/OFF under tank side condition

Water Outlet Thermo condition


- Heat pump THERMO OFF TEMP:
 - 1. Heat pump THERMO OFF TEMP = 53°C + [+4°C]
 - 2. Water outlet temperature > Heat pump THERMO OFF TEMP for continuous 90 seconds, heat pump OFF but water pump continue ON.
- THERMO ON TEMP:
 - THERMO ON TEMP = Water inlet temperature, when heat pump thermo OFF + [-3°C].


Water Inlet Thermo condition


- o Heat pump THERMO OFF TEMP:
 - 1. Water inlet temperature > [55°C] for continuous 60 seconds, heat pump OFF.
- THERMO ON TEMP:
 - 1. THERMO ON TEMP = Water inlet temperature < [55°C]

Solar Operation Condition (Only during solar priority is set condition)

- When solar pump ON, tank heat-up interval end early and 3 ways valve switch to room side.
 - o THERMO IN TEMP:
 - 1. THERMO ON TEMP = Heat pump tank target temperature + [-2°C].
 - 2. After heating heat-up interval, always detect tank temperature. Switch to next tank heat-up interval when tank temperature < THERMO ON TEMP and solar 3 way valve OFF.
 - Tank interval will end and start heating interval timer, IF
 - Tank interval timer finish AND External Room Thermo ON OR
 - Only when this condition occur at tank side before tank temperature thermo OFF switch to room side compulsory and continue until complete room heat-up interval and switch back to tank side.
 - 2. Fulfill Tank thermo OFF condition.
 - 3. Backup heater control:
 - During heating heat-up interval.
 - Follow normal back up heater control operation.
 - During tank heat-up interval.
 - Back up heater OFF during this interval.
 - 4. Booster heater control:
 - During heating heat up interval.
 - Booster heater ON/OFF according to booster heater operation control.
 - During tank heat-up interval.
 - Once switch from heating heat-up interval to tank heat-up interval, turn OFF the booster heater and start counting the BOOSTER HEATER DEPLAY TIMER.
 - Booster heater turn ON after BOOSTER HEATER DELAY TIMER fulfill and tank temperature lower than tank set temperature.
 - BOOSTER HEATER DELAY TIMER is clear when switch to heating heat-up interval.
 - 5. Solar 3 way valve
 - Solar 3WV operates follow solar operates specification.
 - * Under solar priority is set condition, when solar 3WV is ON, booster heater turn OFF.
 - * Under solar priority is not set condition, solar 3WV only can ON during heating heat-up interval.
 - 6. 2 way valve opens.







12.1.7 Cool + Tank Mode Operation

12.1.7.1 Cooling Priority SET

- 1. 3 ways valve control:
 - 3 ways valve switch to room side during External Room Thermo ON OR Tank Thermo OFF time, and switch to tank side at External Room Thermo OFF AND Solar 3 ways valve OFF.
- 2. Heat pump operation control:-

During External Room Thermo ON time: (When room thermo ON heat pump must operate to room side).

Heat pump operates follow normal operation at room side.

During External Room Thermo OFF time:

- a) Switch 3 ways valve to tank side, IF Under Solar Priority Set condition:
 - Tank temperature > Tank THERMO OFF TEMP AND Solar Valve OFF.

Under Solar Priority Not Set condition:

- Tank temperature < Tank THERMO ON TEMP.
- b) Switch back 3 ways valve to room side, Heat pump and water pump turn OFF, IF Under Solar Priority Set condition:
 - Tank temperature > Tank THERMO OFF TEMP for continuous 10 seconds OR Solar Valve ON. Under Solar Priority Not Set condition:
 - Tank temperature > Tank THERMO OFF TEMP for continuous 10 seconds.

Operation condition when 3 ways valve switch to tank side:

- Tank water set temperature = tank set temperature or [55°C] whichever lower.
- Heat Pump Water Outlet set temperature is set to 53°C.
- Initial Tank THERMO ON TEMP = heat pump tank target temperature + [-2°C].

Tank Thermo ON/OFF characteristic

- THERMO OFF TEMP:
 - 1. THERMO OFF TEMP = Tank water set temperature + [0°C].
 - 2. Tank temperature > THERMO OFF TEMP for continuous 10 seconds, switch 3 ways valve to room side.
- 3. Tank temperature > Tank set temperature + [2°C] for continuous 10 seconds, switch 3 ways valve to room side.
- o Next THERMO ON TEMP:
 - 1. THERMO ON TEMP = Tank water set temperature + [-2°C].
 - 2. If tank temperature < THERMO ON TEMP AND External Room Thermo OFF, switch to tank side.

^{*}THERMO ON and THERMO OFF point refer to case below.

Characteristic of heat pump thermo ON/OFF under tank side condition

a) Water Outlet Thermo Condition

- o Heat pump THERMO OFF TEMP:
 - 1. Heat pump THERMO OFF TEMP = [53°C] + [+4°C].
 - 2. Water outlet temperature > Heat pump THERMO OFF TEMP for continuous 3 minutes, heat pump OFF.
- Next THERMO ON TEMP:
 - 1. THERMO ON TEMP = Water inlet when heat pump thermo OFF + [-3°C].
 - 2. When water outlet temperature < Heat pump THERMO ON TEMP, heat pump ON.

b) Water Inlet Thermo Condition

- o Heat pump THERMO OFF TEMP:
 - 1. Water inlet temperature > [55°C] for continuous 60 seconds, heat pump OFF.
- o Next THERMO ON TEMP:
 - 1. THERMO ON TEMP = Water inlet temperature < 55°C.

c) Solar Operation Condition (Only under Solar Priority Set Condition)

- When solar request ON, solar valve will ON and switch 3 ways valve to room side.
- o THERMO ON TEMP:
 - 1. THERMO ON TEMP = Heat pump tank target temperature + [-2°C].
 - If tank temperature < THERMO ON TEMP AND External Room Thermo OFF AND Solar 3WV OFF, switch to tank side.

3. Backup heater control:-

Back-up heater does not operate at Cool + Tank Mode.

4. Booster heater control:-

- Booster heater ON/OFF follow normal operation.
- * Under solar priority is set condition, when solar 3 way valve is ON, booster heater turns OFF.

5. Solar 3 way valve:

o Solar 3 way valve operates follow solar operation specification.

- * Under solar priority is set condition, when solar 3WV turns ON, booster heater will turn OFF and 3 ways valve switch to room side.
- * Under solar priority is not set condition, solar 3WV will OFF when heat pump operates to tank side.

6. 2 ways valve control:

o 2 ways valve is closed.

12.1.7.2 Cooling Priority NOT SET

- 1. 3 ways valve control:
 - 3 ways valve switch to room side during room cooling interval and switch to tank side during tank heat-up interval. Both modes will switch alternately. Tank mode is the initial running mode of this cool + tank mode.
- 2. Heat pump operation control:
 - a) During room cooling interval
 - Follow normal cooling operation.

Under Solar Priority Set condition:

- Switch to tank heat-up interval and start tank heat-up timer when External Room Thermo OFF AND solar 3WV OFF AND Tank temperature < THERMO ON TEMP (End Room Interval Early) OR
- Switch to tank heat-up interval and start counting tank heat-up timer when tank temperature < THERMO ON TEMP AND solar 3VW OFF.

Under Solar Priority Not Set Condition:

- Switch to tank heat-up interval and start counting tank heat-up timer when External Room Thermo OFF
 AND Tank temperature < THERMO ON TEMP (End Room Interval Early) OR
- Switch to tank heat-up interval and start counting tank heat-up timer when tank temperature < THERMO ON TEMP.
- * THERMO ON TEMP is defined from following tank thermo ON/OFF condition.
 - b) During tank heat-up interval
 - Tank water set temperature = tank set temperature or 55°C whichever lower.
 - Heat Pump Water Outlet set temperature is set to [53°C].
 - Initial Tank THERMO ON TEMP = heat pump tank target temperature + [-2°C].

Tank Thermo ON/OFF characteristic

- THERMO OFF TEMP:
 - 1) THERMO OFF TEMP = Tank water set temperature + [0°].
 - 2) Tank temperature > THERMO OFF TEMP for continuous 10 seconds, 3 ways valve is switch to room side. End Tank heat-up interval and start count cooling interval.
 - 3) Tank temperature > Tank set temperature + [2°] for continuously 10 seconds, 3 ways valve is switch to room side. End Tank heat-up interval and start count cooling interval.
- o THERMO ON TEMP:
 - 1) THERMO ON TEMP = Tank water set temperature + [-2°C].
 - 2) During cooling interval or external room thermo OFF, always detect tank temperature. Switch to next tank heat-up interval when tank temperature < THERMO ON TEMP.

Case 2:

- o Heat pump THERMO OFF TEMP:
 - 1) Heat pump THERMO OFF TEMP = [53°C] + [+4°C].
 - 2) Water outlet temperature > Heat pump THERMO OFF TEMP for continuous 3 minutes, heat pump OFF.
- o THERMO ON TEMP:
 - 1) THERMO ON TEMP = Water inlet when heat pump thermo OFF + [-3°C].

Water Inlet Thermo Condition

- Heat pump THERMO OFF TEMP:
 - 1) Water inlet temperature > [55°C] for continuous 60 seconds, heat pump OFF.
- THERMO ON TEMP:
 - 1) THERMO ON TEMP = Water inlet temperature > [55°C].
- c) Solar Operation Condition (Only under Solar Priority Set Condition)
 - When solar pump ON, tank heat-up interval end early and 3 ways valve switch to room side.
 - THERMO ON TEMP:
 - 1) THERMO ON TEMP = Heat pump tank target temperature + [-2°C].
 - 2) After cooling interval or external room thermo OFF, always detect tank temperature. Switch to next tank heat-up interval when tank temperature < THERMO ON TEMP.
 - o Tank interval will end and start cooling interval timer, IF
 - Tank interval timer finish AND External Room Thermo ON OR
 Only when this condition occur at tank side before case 1 thermo OFF, switch to room side is compulsory and continue until complete cooling interval and switch back to tank side.
 - 2) Fulfill case 1 of thermo OFF condition.

3. Backup heater control:

a) Backup heater does not operate at Cool + Tank Mode.

4. Booster heater control:


- a) During cooling interval
 - Booster heater ON/OFF according to booster heater operation control.
- b) During tank heat-up interval
 - Once switch from cooling interval to tank heat-up interval, booster heater is turns OFF and BOOSTER HEATER DELAY TIMER starts counting.
 - Booster heater turns ON after BOOSTER HEATER DELAY TIMER fulfill and tank temperature lower than tank set temperature.
 - BOOSTER HEATER DELAY TIMER is clear when switch to cooling interval.

5. Solar 3 ways valve

- Solar 3WV operates follow solar operation specification.
- * Under solar priority is set condition, when solar 3WV is ON, booster heater turns OFF.
- * Under solar priority is not set condition, solar 3WV only can ON during cooling interval.
- 6. 2 ways valve control:
 - 2 ways valve is closed.

12.1.8 Setting Water Outlet Temperature for Heat Mode

• The set temperature defines the parameters for the outdoor ambient temperature dependent operation of the unit. Where by the internal water setting temperature is determined automatically depending on the outdoor temperature. The colder outdoor temperatures will result in warmer water and vice versa. The user has the possibility to shift up or down the target water temperature by control panel setting.




- Outdoor temperature is updated every 30 minutes when operation ON.
- Setting water outlet temperature always follow H20 (Lo) or H2O (Hi) whenever is higher if outdoor ambient sensor or indoor communication error happen.

Operation under tank mode

• When heat pump operate to tank side, the water outlet target temperature is 53°C.


12.1.9 Water Temperature Thermo Shift Setting

- Switchs are ignored during "PUMPDW" = ON.
- Switchs are ignored during "STATUS" = ON.
- "▲", "▼", "SELECT" switch are ignored if "SETTING" = OFF.
- "CANCEL" switch is ignored if "SETTING" = OFF & "STATUS" = OFF.
- If "SET" Switch pressed for less than 5secs, immediately enter water temperature shift setting mode.
- Once enter this setting mode, "SETTING" display is ON.
 This setting mode is used to easily shift the target water outlet temperature.



12.1.10 Outdoor Fan Motor Operation


Outdoor fan motor is adjusted according to operation condition. It starts when compressor starts operation and it stops 30 seconds after compressor stops operation.




12.2 Water Pump

12.2.1 Water Pump Control

- Once the indoor unit is ON, the water pump will be ON immediately and no error judgement for 9 minutes. However, during this 9 minutes operation, if there is any abnormality cause at outdoor or malfunction, the compressor should be OFF immediately and restart delay after 3 minutes.
- The system will start checking on the water flow level after operation start for 9 minutes. If water flow level is detected low continuously 10 seconds, the water pump and the compressor will be OFF permanently and OFF/ON control panel LED will blink (H62 error occurs).
- When error happens, the power has to be reset to clear the error.
- If there is no error indication, the water pump shall be continuously running.
- The water pump will remain ON when compressor OFF due to thermostat OFF setting is reached.
- Water pump must always operate during heating mode, deice operation and also during heater ON condition.
- Water pump will stops 15 seconds after the unit stops operation.



12.2.2 A-class Pump Specification




Control signal is analog voltage (DC0V-6V) generated by microcomputer PWM port. Microcomputer can change analog voltage by changing PWM duty.

12.2.3 Water Flow Rate Setting

Set water pump speed to adjust the water flow rate.

Depend on the hyraulic system pressure loss and type, the water flow rate can be adjusted by control panel.

- 1 Press SERVICE button for 5 seconds.
- 2 Press ▲ button to enter menu S02 and press SET button.
- 3 Press SELECT button then press ▲/▼ button to change SPEED and press SET to confirm.
- 4 Press OFF/ON button to quit setting.




Note:

- * Before adjust the water flow rate, make sure that the total water volume in the installation is minimum 50 litres for heating side.
- * Please ensure the minimum flow rate is not less than 13l/min and not more than 50l/min.

12.2.4 Water Pump Speed Feedback Error

- Basically pump speed feedback is control by micon.
- When pump speed is below low limit or over high limit for a few seconds, micon detect pump error and system is stopped.
- Error detection conditions:
 - Current pump speed < 1000 rpm or
 - Current pump speed > 6000rpm for 10 seconds.
- Control contents:
 - When error occurs, water pump, heating and heater is stopped for 30 seconds then restart again (Retry control).
 - When micon detect error again, system is stopped and error code [H20] is displayed at control panel.



12.2.5 Water Pump Only Operation

Purpose

Circulate and fill the piping with water during installation time

- Water pump only circulation can be set from the control panel SERVICE S/W when the operation is in Standby Mode.
- Press the SERVICE S/W for continuous 5 sec to enter Service Mode.
- In Service Mode, select SR: 02 and press SET S/W to start water pump only operation.
- 3 way valve turn OFF and 2 way valve turn ON.
- Water pump will stop operation when H62 is triggered.
- Press the OFF/ON button to stop the water pump only operation.

12.3 Pump Down Operation [Service Mode: 01]

Purpose

Ensure the pump down operation when relocating or disposing of the unit. The pump down operation will extract all refrigerant from the piping into the outdoor unit.

Controls:

- 1 Press the SERVICE S/W for continuous 5 seconds to enter Service Mode.
- 2 In service mode, select Sr: 01 and press SET S/W to start Pump Down operation.
- 3 There will be no low pressure error and freeze prevention judgement during Pump Down operation.
- 4 3 ways valve will shift to room side and 2 ways valve will turn ON.
- 5 Press OFF/ON button to stop the unit.

12.4 Flow Switch


12.4.1 Flow Switch Control

- 1 The water flow switch serves as an overload protector that shuts down the unit when the water level is detected to be low.
- 2 Detection is Lo (0 V) when there is no water flow, and detection is Hi (5 V) when there is water flow.

12.5 Indoor Unit Safety

12.5.1 Indoor Unit Safety Control

- 1 When water pump is ON, the system will start checking flow switch status (ON/OFF).
- 2 If the flow switch ON for 10 seconds, the system will check on the water inlet temperature for 10 seconds. If the water inlet temperature not exceeds 80°C, the water pump shall be continuously running with normal mode.
 - If the water inlet temperature exceeds 80°C for continuously 10 seconds, the water pump will be OFF immediately.
- 3 After water pump OFF for more than 10 minutes, it will be ON back and the indoor unit safety control checking is restarted.



12.6 Auto Restart Control

1 When the power supply is cut off during the operation of Air-to-Water Heatpump, the compressor will reoperate after power supply resumes.

12.7 Indication Panel

| LED | Operation |
|-----------|---------------|
| Color | Green |
| Light ON | Operation ON |
| Light OFF | Operation OFF |

Note:

• If Operation LED is blinking, there is an abnormality operation occurs.

12.8 Indoor Back-Up Heater Control

12.8.1 Indoor Electric Heater Control

- 1 Normal Heating Mode
 - Heater On condition:
 - a. Heater switch is ON
 - b. After Heatpump thermo ON for [30] mins
 - c. After water pump operate [9] mins
 - d. Outdoor air temperature < Outdoor set temperature for heater
 - e. When water outlet temperature < Water set temperature + [-8°C]
 - f. [20] minutes since previous Backup heater Off
 - When heatpump cannot operate due to error happens during normal operation, heater will go into force mode automatic
 - * Heater need to operate during deice operation
 - o Heater Stop Condition:
 - a. When outdoor set temperature > outdoor set temperature + [+2°C] for continuous 15 secs OR
 - b. When water out temp> water set temperature + [-2°C] for continuous 15 secs OR
 - c. Heater switch is Off OR
 - d. Heatpump thermo-off or OFF condition


2 Force Heater Mode

- o Heater On condition:
 - a. After water pump operate [9] mins
 - b. When water outlet temperature < water set temperature + [-8°C]
 - c. [20] minutes since previous Backup heater Off
- Heater Stop condition
- a. Force mode off OR
- b. When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs
- * Do not operate heater at the following situation
- 1 Water outlet temperature sensor, and water inlet sensor abnormal
- 2 Flow switch abnormal
- 3 Circulation pump stop condition
- 4 During Heatpump switch to tank side

12.9 Tank Booster Heater Control

12.9.1 Tank Booster Heater Control

Heating operation condition:



- 1 Booster heater Turn On condition:
 - After BOOSTER HEATER DELAY TIMER fulfill during heatpump startup time in tank mode, or during switching from heating heat-up interval to tank heat-up interval in heat + tank mode (heating priority not set).
 - Tank temperature < Tank set temperature + [-5°C],
 - 20 minutes since previous heater off.
 - * BOOSTER HEATER DELAY TIMER is clear when tank heat-up interval end.
- 2 Booster heater Turn Off condition:
 - Tank temperature > Tank set temperature + [+2°C] for continuous 15 sec
 - When BOOSTER HEATER DELAY TIMER start count after switch from heating heat-up interval to tank heat-up interval
 - * DELAY TIMER can be set by control panel.

12.10 Base Pan Heater Control (Optional)

- To enable the base pan heater function, control panel initial setting has to be manually adjusted by activating Base Pan Heater menu.
- There are 2 optional start condition can be selected, Type A or Type B.
- Control details:
 - 1 Type A: (Default Auto Mode)

Start conditions:

When outdoor air temperature ≤ 3°C during heating and deice operation is ON.

Control contents:

 Base pan heater is ON during deice operation and continues ON for 10 minutes after deice operation ends.

Cancel condition:

- When outdoor temperature > 6°C after deice end or
- When operation is not at heating mode or
- o Base pan heater ON timer count is completed.
- 2 Type B: (ON Mode)

Start conditions:

○ When outdoor air temperature is ≤ 5 °C and operates in heating mode, base pan heater is ON.

Cancel conditions:

- When outdoor air temperature is > 7°C or
- When operation is not at heating mode.

Note:

* Base pan heater cannot be ON during test mode and stand by mode.

12.11 Sterilization Mode

- Purpose:
 - o To sterilize water tank by setting the required boiling temperature.
- Control start condition:
 - o Tank connection menu is set to YES by control panel.
 - Sterilization menu is set to YES by control panel.
 - Sterilization signal received from control panel by timer.
- Control stop condition:
 - After sterilization timer completed or
 - o After 4 hours of operation since sterilization function starts.
- Control content:
 - Once the sterilization function is enable, set the target sterilization set temperature.
 - Booster heater will allow to ON during solar SET condition.
 - Booster heater OFF Temp = Sterilization set temperature +0°C
 - Booster heater ON Temp = Sterilization set temperature -7°C
 - Sterilization timer which set by control panel will start count after tank achieve sterilization set temperature.
 - o Target tank temperature will set back to normal tank set temperature.

12.12 Quiet Operation

- Purpose:
 - o To provide quiet operation compare to normal operation by reduces outdoor unit noise.
 - · Starting condition:
 - When quiet button is presses.
 - When guiet is request to ON by weekly timer. (Refer to control panel)
 - When any of above mentioned condition is achieved, this control is activated.
 New target FM speed = Present target FM speed 80 rpm
 Minimum target FM speed = 200 rpm
 - Cancellation condition:
 - Cancel by pressing quiet button.
 - Stop by OFF/ON button
 - o When quiet is request to OFF by weekly timer.

^{*} Tank heater control is not affected by solar pump when solar priority set.

12.13 Anti Freeze Control


- Anti freeze protection control menu can be set YES or NO by control panel.
- In heatpump system, there are 3 types of anti freeze control:
 - 1. Expansion tank anti-freeze control
 - Expansion tank anti freeze heater ON condition:
 - o Outdoor ambient temp. < 3°C
 - Expansion tank anti freeze heater OFF condition:
 - Outdoor ambient temp. > 4°C
 - 2. Water pump circulation anti freeze control
 - Water pump turns ON when <u>ALL</u> below conditions are fulfilled:
 - Heatpump OFF (stand by) OR error occurs.
 - Water flowing flag is ON.
 - Water flow switch is not abnormal.
 - Outdoor ambient temp. < 3°C OR outdoor ambient temp. sensor is abnormal.
 - Water inlet/outlet temp. < 6°C.
 - After 5 minutes from previous water pump OFF.
 - Water pump turn OFF when <u>ANY</u> of below conditions is fulfilled:
 - o Outdoor ambient temperature ≥ 4° C.
 - During -5°C < outdoor ambient temp. < 4°C
 - After water pump ON for 4 minutes, and water inlet temp. ≥ 8°C.
 - Else, shift to back up heater anti freeze control.
 - o During outdoor ambient temp. < -5°C
 - After water pump ON for 4 minutes, and water inlet/outlet ≥ 20°C.
 - Else, shift to back up heater anti freeze control.
 - However, if flow switch is abnormal (H62), then water pump circulation anti freeze control will not activate.
 - 3. Back up heater anti freeze control:
 - Back up heater turn ON when ALL below conditions is fulfilled:
 - Water inlet/outlet temp. < 6°C.
 - Water pump circulation anti freeze control activated and water pump ON for 4 minutes.
 - Back up heater turns OFF when ANY of below conditions is fulfilled:
 - Water inlet/outlet temp. > 28°C.
 - o Water pump circulation anti freeze control deactivated/water pump OFF.
 - However, if back up heater is abnormal (H70) then back up heater anti freeze control will not activate.

12.14 Solar Operation (Optional)

12.14.1 Solar Operation:

- 1 External solar heat source signal can be connect to unit for proper control of heat source switching during tank boiling time.
- 2 Control according to preset whether solar priority is set or not.
- 3 When tank connection is NOT set at SETTING mode, solar operation is disabled.
- When Pump A (from solar pump station) is detected On through connection Y3 and Y4, then the Solar pump 3 Way Valve is requested ON (Refer to figure below).

Connecting diagram with the Solar Pump Station



12.14.2 Solar Operation Control

When solar priority is SET

- 1 Operation condition:
 - a 3 way valve operates if all of the following conditions are fulfilled:
 - Power On. (regardless operation ON or OFF)
 - There is operation request from solar pump station.
 - Tank hot water temp is below solar on upper limit temp 72°C.

2 Stop condition:

- a 3 way valve stops operating when:
 - No power supply to unit OR
 - There is **NO** operation request from solar pump station **OR**
 - Tank hot water temp is above solar off upper limit temp 80°C.
 - * heat pump OFF OR operate to room side when solar pump operate during solar priority set.
 - * booster heater OFF when solar pump operate during solar priority set.

When solar priority is NOT SET


- 1 Operation condition:
 - a 3 way valve operates if all of the following conditions are fulfilled:
 - Power On. (regardless operation ON or OFF)
 - There is operation request from solar pump station.
 - Tank hot water temp is below solar on upper limit temp 72°C.
 - Heat pump thermo OFF in tank mode OR Heat pump operate to room side (during operation ON and tank mode selected).

2 Stop condition:


- a 3 way valve stops operating when:
 - No power supply to unit **OR**
 - There is **NO** operation request from solar pump station **OR**
 - Tank hot water temp is above solar off upper limit temp 80°C.
 - Heat pump thermo ON and operate to tank side. (during operation ON and tank mode selected)

Solar Operation Chart in different mode and condition


Tank Mode (Solar Priority SET condition)




Tank Mode (Solar Priority NOT SET condition)



Heat + Tank Mode (Heating Priority NOT SET) (Solar Priority SET condition)



Heat + Tank Mode (Heating Priority NOT SET) (Solar Priority NOT SET condition)




T1 - Heating

T2 - Tank interval

T3 - Booster heater delay timer

Heat + Tank Mode (Heating Priority SET) & Cool + Tank Mode



12.15 External Room Thermostat Control (Optional)

Purpose:


1 Better room temperature control to fulfill different temperature request by external room thermostat. Recommended external room thermostat:

| Maker | Characteristic |
|-----------------|----------------|
| Siemen (REV200) | Touch panel |
| Siemen (RAA20) | Analog |

Connection of external room thermostat:

Wire Connection and thermo characteristic of Siemen REV200:


| Setting | L/L1 (H) | Heat Thermo | L/L2 (C) | Cool Thermo |
|------------------------|---------------|-------------|---------------|-------------|
| Set Temp < Actual Temp | Open Circuit | OFF | Short Circuit | ON |
| Set Temp > Actual Temp | Short Circuit | ON | Open Circuit | OFF |



Connect only heating line for heating only model. And connect both heating and cooling line for heat + cool model.

Wire Connection and thermo characteristic of Siemen RAA20:

| Setting | L/Y1 (H) | Heat Thermo | L/Y2 (C) | Cool Thermo |
|------------------------|---------------|-------------|---------------|-------------|
| Set Temp < Actual Temp | Open Circuit | OFF | Short Circuit | ON |
| Set Temp > Actual Temp | Short Circuit | ON | Open Circuit | OFF |



Control Content:

- External room thermostat control activate only when remote thermostat connection select YES by Indoor control
 panel.
- When indoor running heat mode, refer thermo On/Off from heating line feedback. And when indoor running cool
 mode, refer thermo On/Off from cooling line feedback.
- Heat pump Off immediately when receive thermo off feedback.


12.16 Three Ways Valve Control

Purpose:

- 3 ways valve is used to change flow direction of hot water from heat pump between heating side and tank side.

Control contents:

- 1 3 ways valve switch Off:
 - o During 3 ways valve switch Off time, the hot water will provide heat capacity to heating side.
- 2 3 ways valve switch On:
 - o During 3 ways valve switch On time, the hot water will provide heat capacity to tank side.
- 3 Stop condition:
 - o During stop mode, 3 ways valve will be in switch off position.



- * During pump down and force mode, fix 3 ways valve in close condition.
- * Recommended Parts: SFA 21/18 (Siemens)


12.17 Two Ways Valve Control

Functionality of 2 ways valve:

Use to allow hot water to floor heating panel or block cold water to floor heating panel.

Control contents:


- 1 When indoor running in heat mode, OPEN the 2 ways valve.
- 2 When indoor running in cool mode, CLOSE the 2 ways valve.
- 3 Stop condition:
 - a. During stop mode, fix 2 ways valve in close condition.



- * During pump down mode, fix 2 ways valve in close condition.
- * During force mode, open 2 ways valve.
- * Recommended Parts : SFA 21/18 (Siemens)


12.18 External OFF/ON Control

• Communication circuit between indoor unit and external controller is as per below.



- Maximum length of communication cable is 20 meter.
- Control content:

| External Control Switch | Control Panel OFF/ON | Control Panel Power LED | System Status |
|-------------------------|----------------------|-------------------------|---------------|
| ON | ON | ON | ON |
| ON | OFF | OFF | OFF |
| OFF | ON | ON | OFF |
| OFF | OFF | OFF | OFF |



^{*} During External Switch OFF condition, it is allow to change the setting and also timer operation.

12.19 Holiday Mode

• Purpose:

Promotes energy saving by allowing the user to stop the system during holiday and enables the system to resume at the preset temperature after holiday.

Control details:

- o Range of days can be set in holiday mode is from 1 to 999 days.
- o After days of holiday have been set, heat pump will stop and only resume operation at 12.00am at the end of holiday countdown.

Start condition:

- Unit is OFF and holiday mode is set.
 - * The day the holiday mode was set is counted as day 1.

• Stop condition:

- o OFF/ON button is pressed.
- o Holiday counter is reached.

12.20 Dry Concrete Function

Purpose

Provide heat to floor heating panel and dry the wet concrete during installation.

Setting condition:

- o Dry concrete parameter can be set through control panel by selecting dry concrete menu.
- Parameters are possible to set up to 99 days with different target set temperature.

Control details:

- o Dry concrete operation can be activate under Service Mode 3.
- o Once dry concrete function start, day 1 setting temperature will be send to indoor unit by control panel.
- O Unit will operate heat mode with dry concrete preset water outlet temperature. (No shift value added to the preset water outlet temperature)
- o After complete day 1 setup operation, day 2 data will be send to indoor at 12.00am on the second day.
- Each preset data will be send everyday until dry concrete mode is complete, unit will turns OFF and exit dry concrete function.
- o 3 ways valve and booster heater will turn OFF and 2 ways valve will turns ON.

Cancel condition:

- o Unit will turns OFF and exit dry concrete function.
- o OFF signal is received by pressing OFF/ON button or error H76 is occurred.

13. Protection Control

13.1 Protection Control for All Operations

13.1.1 Time Delay Safety Control

1 The compressor will not start for three minutes after stop of operation.

13.1.2 30 Seconds Forced Operation

- 1 Once the compressor starts operation, it will not stop its operation for 30 seconds.
- 2 However, it can be stopped using control panel at indoor unit.

13.1.3 Total Running Current Control

- 1 When the outdoor running current exceeds X value, the compressor frequency will decrease.
- 2 If the outdoor running current does not exceed X value, the compressor frequency will return to normal operating frequency.
- 3 If the outdoor running current continue to increase till exceed Y value, compressor will stop, and if this occurs 3 times within 20 minutes, system will stop operation and OFF/ON control panel LED will blink (F16 error occurs).


| | MXC09D3E8 | | MXC12D9E8 | |
|----------------|-----------|-------|-----------|-------|
| Operation Mode | X (A) | Y (A) | X (A) | Y (A) |
| Heating | 24.1 | 30.0 | 28.1 | 30.0 |
| Cooling | 16.4 | 30.0 | 18.1 | 30.0 |

A. DC Peak Current Control

- 1 When the current to IPM exceeds set value of 34 A, compressor will stop. Compressor will restart after three minutes.
- 2 If the set value exceeds again for more than 30 seconds after the compressor restarts, operation will restart after two minutes.
- 3 If the set value exceeds again for within 30 seconds after the compressor restarts, operation will restart after one minute. If this condition repeats continuously for seven times, system will stop operation and OFF/ON control panel LED will blink (F23 error occurs).

13.1.4 Compressor Overheating Prevention Control

 The compressor operating frequency is regulated in accordance to compressor tank temperature as shown in below figures. When the compressor tank temperature exceeds 107°C, compressor will stop, and if this occurs 4 times within 30 minutes, system will stop operation and OFF/ON control panel LED will blink (F20 error occurs).



13.1.5 Low Frequency Protection Control 1

 When the compressor continuously operates at frequency lower than 21 Hz for 240 minutes, the operation frequency will change to 20 Hz for 2 minutes.

13.1.6 Low Frequency Protection Control 2


• When all the below conditions comply, the minimum compressor frequency will change to lower frequency.

| Temperature, T, for: | Heating | Cooling |
|----------------------------|------------------|------------------|
| Outlet water (°C) | T < 14 or T ≥ 48 | T < 14 or T ≥ 30 |
| Outdoor air (°C) | T < 4 or T ≥ 24 | T < 13 or T ≥ 38 |
| Indoor heat exchanger (°C) | T ≥ 0 | T < 30 |

13.1.7 High Pressure Sensor Control

- Purpose:
 - To protect the system operation.
- Detection period:
 - After compressor on for 1 minute.
- Detection conditions:
 - When abnormal high voltage detection, 5 V or when open circuit detection 0V for 5 seconds continuously.
- After detection:
 - When abnormality is detected 4 times within 120 minutes, unit stop operation.
 - OFF/ON control panel LED will blink (H64 error occurs).

13.1.8 Outside Temperature Current Control



13.1.9 Crank Case Heater Control

- Purpose:
 - For compressor protection during low outdoor ambient operation (during heating low temperature operation).
- Control content:
 - a. Trigger heater START condition
 - o When the outdoor air temperature is below than 5°C, and discharge temperature is 11°C or below.
 - b. Resetting heater STOP condition
 - 1. When the outdoor air temperature exceeds entry condition (2°C)
 - 2. When the discharge temperature exceeds entry condition (5°C)

13.2 Protection Control for Heating Operation

13.2.1 Outdoor Air Temperature Control


The maximum current value is regulated when the outdoor air temperature rises above 14°C in order to avoid compressor overloading.

13.2.2 Deice Operation

When outdoor pipe temperature and outdoor air temperature is low, deice operation start where outdoor fan motor stop.

· Deice judging condition

Outdoor Unit Deice Control




Deice start depends:

- 1. Outdoor air sensor temp.
- 2. Outdoor pipe sensor temp.
- 3. Heating accumulation time

Deice mode selection condition

 There are 2 deice modes, according to water inlet temperature and outdoor ambient temperature the deice mode is decided.


Water inlet temperature




Judgement details:

- 1) When water inlet temperature is more than 50°C, unit will operate deice mode 1.
- 2) When water inlet temperature is less than 27°C, unit will operate deice mode 2.
- 3) When water inlet temperature is less than 50°C and outdoor ambient temperature is less than -10°C, unit will operate deice mode 2.
- 4) When water outlet temperature sensor 2 detect temperature is less than 22°C, unit will operate deice mode 2.

- Deice operation time diagram
 - a. Deice mode 1 control:




b. Deice mode 2 control:



13.3 Protection Control for Cooling Operation

13.3.1 Outdoor Air Temperature Control

- The Compressor operating frequency is regulated in accordance to the outdoor air temperature as shown in the diagram below.
- This control will begin 1 minute after the compressor starts.
- Compressor frequency will adjust base on outdoor air temperature.




13.3.2 Freeze Prevention Control 1

- 1 When indoor heat exchanger temperature is lower than 0°C continuously for 10 seconds, compressor will stop operating.
- 2 Compressor will resume its operation three minutes after the indoor heat exchanger is higher than 1°C.
- 3 Indoor heat exchanger freeze prevention (H99) will memory in error history.

14. Servicing Mode

14.1 Remove The Cabinet Front Plate

- 1. Remove the 5 mounting screws as shown in the illustration.
- 2. Slide the cabinet front plate downward to release the pawls. Then, pull it toward front to remove it.



14.2 Test Run

- 1. Fill up the Tank Unit with water. For details refer to Tank Unit installation instruction and operation instruction.
- 2. Antifreeze agent must be added into water circuit to prevent freezing of water when outdoor ambient temperatures is low. Recommended antifreeze: Propylene glycol: 40% (equivalent to -20°C)
- 3. Set ON to the Mono bloc unit and RCCB. Then, for remote control operation please refers to (Mono bloc) Airto-Water Heatpump's operation instruction.
- 4. For normal operation, pressure gauge reading should be in between 0.05 MPa and 0.3 MPa. If necessary, adjust the water pump speed accordingly to obtain normal water pressure operating range. If adjust water pump speed cannot solve the problem, contact your local authorized dealer.
- 5. After test run, please clean the external filter. Reinstall it after finish cleaning.

14.3 Proper Pump Down Procedure

- Strictly follow the steps below for proper pump down procedure. Explosion may occur if the steps are not followed as per sequence.
 - 1. Press the "SERVICE" switch on remote control to enter SERVICE mode. Operate the system in Sr : 01 mode for pump down operation.
 - 2. After 10~15 minutes, (after 1 or 2 minutes in case very low ambient temperatures (< 10°C)), fully close 2 way valve.
 - 3. After 3 minutes, fully close 3 way valve.
 - 4. Press the "OFF/ON" switch on remote control to stop pump down operation.
 - 5. Remove the refrigerant piping.


14.4 How To Adjust Water Flow Rate

Before adjust the water flow rate, make sure that the total water volume in the installation is 50 litres minimum for heating side. The default setting is SPEED 3 (Only for WH-MXC09G3E5) and SPEED

4 for WH-MXC12G6E5. Please ensure the minimum flow rate is not less than 13 l/min and not more than 50 l/min. The available external static pressure (kPa) in function of the water flow rate (l/min) is shown in the P-Q graph. Depend on the hydraulic system pressure loss and type, the water flow rate can be adjusted by remote control.

- 1 When the Air-to-Water Heatpump is in stop operation, press SERVICE button for 5 seconds.
- 2 Press ▲/▼ button to select menu S02 (PUMP SPEED ADJUST MODE) and press SET button to confirm the menu.
- 3 Press SELECT button then press ▲/▼ button to change pump speed and press SET button to confirm the pump speed.
- 4 Press OFF/ON button to exit PUMP SPEED ADJUST MODE.


During PUMP SPEED ADJUST MODE, we can select AIR PURGE function by pressing FORCE button. In AIR PURGE function, the pump will operate ON and OFF for 10 minutes to purge the air in the hydraulic system. Press again the FORCE button to exit AIR PURGE function. PUMP SPEED ADJUST MODE will stop operation.



14.5 Expansion Vessel Pre Pressure Checking

- Expansion Vessel with 10 L air capacity and initial pressure of 1 bar is installed in this Mono bloc unit.
- Total amount of water in system should be below 200 L.
 (Note: This amount of water is not include the tank unit volume)
- If total amount of water is more than 200L, please install additional expansion vessel (field supply).
- Please keep the installation height difference of system water circuit within 10 m. (Inner volume of same Mono bloc unit is about 5 L)

14.6 How to Unlock Cool Mode




- 1. Press buttons SET and SERVICE for 5 seconds.
- 2. Press SELECT button.
- 3. Unlock COOL mode with ▲/▼.
- 4. Press SET button.

14.7 Dry Concrete [SERVICE MODE: 03]

- If Dry Concrete has been set, Dry Concrete status can be activated and monitored by following procedure.
 - 1 Press SERVICE button for 5 seconds.
 - 2 Press ▲ to enter menu Sr: 03 and press SET button to activate Dry Concrete function.
 - 3 Press OFF/ON button to quit setting.


14.8 EEPROM Factory Default Data Setup Procedure

- 1 This process should be done at Gemstar (and/or) PAPAMY as the last process after any inspection.
- 2 This condition should be activated by pressing combination of few SW's for certain time as shown.



These 3 SW's should press continuously for 5secs. (Operation should be OFF during this period)

- 3 When this condition is activated, default data should be written in EEPROM.
- 4 Once the default data is written in the EEPROM, the following full LCD display should be ON for 2secs for confirmation. After 2secs, it goes back to normal display.



15. **Maintenance Guide**


In order to ensure optimal performance of the unit, seasonal inspections on the unit, external filter and field wiring have to be carried out at regular intervals. This maintenance should be carried out by authorized dealer.

1. Water pressure

Water pressure should not lower than 0.05 MPa (with inspects the pressure gauge). If necessary add tap water into tank unit. Refer to boiler tank installation instruction for details on how to add water.

2. Pressure relief valve

- Take out the cover ⁽³⁾ with remove the mounting screw for access to the pressure relief valve.
- Check for correction operation of pressure relief valve by turn up the lever to become horizontal. (Refer to figure of "Pressure relief valve")
- If you do not hear a clacking sound (due to water drainage), contact your local authorized dealer.
- Turn down the lever after checking finish.
- In case the water keeps drained out from the unit, switch off the system, and then contact your local authorized dealer.
- Reinstall the cover ⁽³⁾ with tighten the mounting screws properly, if the pressure relief valve is functioning normal.



3. Air purge valve

Air purge valve must be installed at all high points in a closed water circuit system. An automatic air purge valve is provided inside the indoor unit. To automatically purge the air from the system, turn the plug on the air outlet anticlockwise by one complete turn from fully closed position. Excessive air is automatically purged if the plug is kept in this position.



Air purge valve

4. Indoor unit control board area

Thorough visual inspection of the control board and look for defects, i.e. loose connection, melting of wire insulator and etc.

RCCB/ELCB

Ensure the RCCB/ELCB set to "ON" condition before check RCCB/ELCB.

Turn on the power supply to the indoor unit.

This testing could only be done when power is supplied to the indoor unit.




Be careful not to touch parts other than RCCB/ELCB test button when the power is supplied to Indoor Unit. Else, electrical shock may happen.

- o Push the "TEST" button on the RCCB/ELCB. The lever would turn down and indicate "0" and indicate green colour if it functions normal.
- o Contact authorized dealer if the RCCB/ELCB malfunction.
- o Turn off the power supply to the indoor unit.
- o If RCCB/ELCB functions normal, set the lever to "ON" again after testing finish.

6. Reset overload protector

Overload protector serves the safety purpose to prevent the water over heating. When the overload protector trip at high water temperature, take below steps to reset it.

- a. Take out OLP cover.
- b. Use a test pen to push the centre button gently in order to reset the Overload protector.
- c. After finish, install back the Overload protector following the reverse order of step a & b.




How to reset Overload protector

7. External water filter (field supply)

Clean the external water filter in regularly basic.

- External water filter is located inside the tube connector which is before water inlet connector of Mono bloc unit (indicated with "WATER IN"). (Refer to figure below)
- Use spanner to detach the tube connector nut.
- Take out the filter carefully so that not deforms it shape.
- Use tap water only to wash the residue on the filter. If necessary, gently use soft brush only to clean the hard dirt.
- After clean, put it back to the original location and tighten the nut connection with torque wrench.



16. Troubleshooting Guide


16.1 Refrigeration Cycle System

In order to diagnose malfunctions, make sure that there are no electrical problems before inspecting the refrigeration cycle. Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a fan. The normal pressure of the refrigeration cycle depends on various conditions, the standard values for them are shown in the table on the right.

Normal Pressure (Standard)

| | Gas pressure MPa (kg/cm²G) |
|--------------|-------------------------------|
| Heating Mode | 2.3 ~ 2.9 (23 ~ 29) |
| Cooling Mode | 0.9 ~ 1.2 (9 ~ 12) |

- ★ Condition: Outdoor temperature 7°C at heating mode and 35°C at cooling mode.
 - Compressor operates at rated frequency.



16.2 Relationship Between The Condition Of The Mono Bloc Unit And Pressure And Electric Current

| | Heating Mode | | Cooling Mode | | | |
|--|--------------|---------------|-----------------------------------|--------------|---------------|-----------------------------------|
| Condition of the Mono bloc Unit | Low Pressure | High Pressure | Electric current during operation | Low Pressure | High Pressure | Electric current during operation |
| Water leakage or insufficient water flow rate in the system | 7 | 7 | 7 | 7 | 7 | K |
| Excessive amount of refrigerant | 7 | 7 | 7 | 7 | 7 | 7 |
| Inefficient compression | 7 | 7 | 7 | 7 | 7 | 7 |
| Insufficient refrigerant (gas leakage) | 7 | 7 | 7 | 7 | 7 | 7 |
| Mono bloc unit (refrigerant system) heat exchange deficiency | 4 | 7 | 7 | 7 | 7 | 7 |
| Clogged expansion valve or Strainer | 7 | 7 | 7 | 7 | 7 | 7 |

Carry out the measurements of pressure, electric current, and temperature fifteen minutes after an operation is started.

16.3 Breakdown Self Diagnosis Function

16.3.1 Self Diagnosis Function (Three Digits Alphanumeric Code)

- When abnormality occur during operation, the system will stop operation, and OFF/ON remote control LED will blink and error code will display on the remote control Timer display LCD.
- Even error code is reset by turning OFF power supply or by pressing ERROR RESET button, if the system abnormality is still un-repaired, system will again stop operation, and OFF/ON remote control LED will again blink.
- The error code will store in IC memory.

· To check the error code


- 1. When an abnormality occurs, system will stop operation and OFF/ON remote control LED will blink.
- 2. Error code of the abnormality will display on the remote control Timer display LCD.
- 3. To determine the abnormality description, the Error Code Table needs to be referred.

To display past/last error code

- 1. Turn ON power supply.
- 2. Press and hold the CHECK button for more than 5 seconds to enter status mode.
- 3. Press the SEARCH DOWN/UP button to retrieve past/last error code.
- 4. Press the CANCEL button or wait 30 seconds to exit status mode.

To permanently delete error code from IC memory

- 1. Turn ON power supply.
- 2. Press and hold the ERROR RESET button for more than 8 seconds till a beep sound is heard.



16.4 Error Codes Table

| Diagnosis display | Abnormality/Protection control | Abnormality Judgement | Primary location to verify |
|-------------------|--|--------------------------------------|---|
| H00 | No abnormality detected | _ | |
| H12 | Indoor/Outdoor capacity unmatched | 90s after power supply | Indoor/outdoor connection wire Indoor/outdoor PCB Specification and combination table in catalogue |
| H15 | Outdoor compressor temperature sensor abnormality | Continue for 5 sec. | Compressor temperature sensor (defective or disconnected) |
| H20 | Water pump abnormality | Continue for 10 sec. | Indoor PCBWater pump (malfunction) |
| H23 | Indoor refrigerant liquid temperature sensor abnormality | Continue for 5 sec. | Refrigerant liquid temperature sensor (defective or disconnected) |
| H27 | Service valve error | Continue for 5 minutes | High pressure sensor (defective or disconnected) |
| H42 | Compressor low pressure abnormality | _ | Outdoor pipe temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB Compressor |
| H62 | Water flow switch abnormality | Continue for 1 min. | Water flow switch |
| H64 | Refrigerant high pressure abnormality | Continue for 5 sec. | Outdoor high pressure sensor (defective or disconnected) |
| *H65 | Deice circulation error | Continue for 10 sec. | Water flow switch sensor (defective or disconnected) Water pump malfunction Buffer tank (is used) |
| H70 | Back-up heater OLP abnormality | Continue for 60 sec. | Back-up heater OLP (Disconnection or activated) |
| H72 | Tank sensor abnormal | Continue for 5 sec. | Tank sensor |
| H76 | Indoor - remote control communication abnormality | _ | Indoor - control panel (defective or disconnected) |
| H90 | Indoor/outdoor abnormal communication | > 1 min after starting operation | Internal/external cable connections Indoor/Outdoor PCB |
| H91 | Tank heater OLP abnormality | Continue for 60 sec. | Tank heater OLP (Disconnection or activated) |
| H95 | Indoor/Outdoor wrong connection | _ | Indoor/Outdoor supply voltage |
| H98 | Outdoor high pressure overload protection | _ | Outdoor high pressure sensor Water pump or water leakage Clogged expansion valve or strainer Excess refrigerant Outdoor PCB |
| H99 | Indoor heat exchanger freeze prevention | _ | Indoor heat exchanger Refrigerant shortage |
| F12 | Pressure switch activate | 4 times occurrence within 20 minutes | Pressure switch |
| F14 | Outdoor compressor abnormal revolution | 4 times occurrence within 20 minutes | Outdoor compressor |
| F15 | Outdoor fan motor lock abnormality | 2 times occurrence within 30 minutes | Outdoor PCB Outdoor fan motor |
| F16 | Total running current protection | 3 times occurrence within 20 minutes | Excess refrigerant Outdoor PCB |
| F20 | Outdoor compressor overheating protection | 4 times occurrence within 30 minutes | Compressor tank temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB Compressor |
| F22 | IPM (power transistor) overheating protection | 3 times occurrence within 30 minutes | Improper heat exchange IPM (Power transistor) |
| F23 | Outdoor Direct Current (DC) peak detection | 7 times occurrence continuously | Outdoor PCB Compressor |
| F24 | Refrigeration cycle abnormality | 2 times occurrence within 20 minutes | Insufficient refrigerant Outdoor PCB Compressor low compression |
| F25 | Cooling/Heating cycle changeover abnormality | 4 times occurrence within 30 minutes | 4-way valve V-coil |
| F27 | Pressure switch abnormality | Continue for 1 min. | Pressure switch |
| F30 | Water outlet sensor 2 abnormality | Continue for 5 sec. | Water outlet sensor 2 (defective or disconnected) |
| F36 | Outdoor air temperature sensor abnormality | Continue for 5 sec. | Outdoor air temperature sensor (defective or disconnected) |

| Diagnosis display | Abnormality/Protection control | Abnormality Judgement | Primary location to verify |
|-------------------|---|--------------------------------------|---|
| F37 | Indoor water inlet temperature sensor abnormality | Continue for 5 sec. | Water inlet temperature sensor (defective or disconnected) |
| F40 | Outdoor discharge pipe temperature sensor abnormality | Continue for 5 sec. | Outdoor discharge pipe temperature sensor (defective or disconnected) |
| F41 | PFC control | 4 times occurrence within 10 minutes | Voltage at PFC |
| F42 | Outdoor heat exchanger temperature sensor abnormality | Continue for 5 sec. | Outdoor heat exchanger temperature sensor (defective or disconnected) |
| F43 | Outdoor defrost sensor abnormality | Continue for 5 sec. | Outdoor defrost sensor (defective or disconnected) |
| F45 | Indoor water outlet temperature sensor abnormality | Continue for 5 sec. | Water outlet temperature sensor (defective or disconnected) |
| F46 | Outdoor Current Transformer open circuit | _ | Insufficient refrigerant Outdoor PCB Compressor low |
| F48 | Outdoor EVA outlet temperature sensor abnormality | Continue for 5 sec. | Outdoor EVA outlet temperature sensor (defective or disconnected) |
| F49 | Outdoor bypass outlet temperature sensor abnormality | Continue for 5 sec. | Outdoor bypass outlet temperature sensor (defective or disconnected) |
| F95 | Cooling high pressure overload protection | _ | Outdoor high pressure sensor Water pump or water leakage Clogged expansion valve or strainer Excess refrigerant Outdoor PCB |

16.5 Self-diagnosis Method

16.5.1 Connection Capability Rank Abnormality (H12)

Malfunction Decision Conditions:

During startup operation of heating, the capability rank of indoor checked by the outdoor is used to determine connection capability rank abnormality.


Malfunction Caused:

- 1. Wrong model interconnected.
- 2. Wrong indoor unit or outdoor unit PCB (main) used.
- 3. Faulty indoor unit or outdoor unit PCB (main).

Abnormality Judgment:

Continue for 90 seconds.

Troubleshooting:



16.5.2 Compressor Tank Temperature Sensor Abnormality (H15)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the compressor tank temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1. Faulty connector connection.
- 2. Faulty sensor.
- 3. Faulty outdoor unit PCB (main).

Abnormality Judgment:



16.5.3 Water Pump Abnormality (H20)


Malfunction Decision Conditions:

During startup and operation of cooling and heating, the rotation speed detected by the IPM of water pump motor during water pump operation is used to determine abnormal water pump (feedback of rotation > 6,000rpm or < 1,000rpm).

Malfunction Caused:

- 1. Operation stop due to short circuit inside the water pump motor winding.
- 2. Operation stop due to breaking of wire inside the water pump motor.
- 3. Operation stop due to breaking of water pump lead wires.
- 4. Operation stop due to water pump motor IPM malfunction.
- 5. Operation error due to faulty indoor unit PCB.

Abnormality Judgment:



16.5.4 Indoor Refrigerant Liquid Temperature Sensor Abnormality (H23)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the indoor refrigerant liquid temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1. Faulty connector connection.
- 2. Faulty sensor.
- 3. Faulty indoor unit PCB (main).

Abnormality Judgment:



16.5.5 Service Valve Error (H27)

Malfunction Decision Conditions:

During cooling operation, when:-


- [a] Indoor refrigerant pipe temperature at compressor startup present indoor refrigerant pipe temperature < 2°C
- [b] Present high pressure high pressure at compressor startup < 5kg/cm²
- **Judgment only for first time cooling operation and not during pump down operation.

Malfunction Caused:

- 1. 3 way valves closed.
- 2. Faulty high pressure sensor.
- 3. Faulty indoor refrigerant pipe temperature sensor
- 4. Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 minutes.




16.5.6 Compressor Low Pressure Protection (H42)

Malfunction Decision Conditions:

During operation of heating and after 5 minutes compressor ON, when outdoor pipe temperature below -29°C or above 26°C is detected by the outdoor pipe temperature sensor.

Malfunction Caused:

- 1. Dust accumulation on the outdoor unit heat exchanger.
- 2. Air short circuit at outdoor unit.
- 3. 2 way valve partially closed.
- 4. Faulty outdoor unit fan motor.
- 5. Refrigerant shortage (refrigerant leakage).
- 6. Clogged expansion valve or strainer.
- 7. Faulty outdoor pipe temperature sensor.
- 8. Faulty outdoor unit main PCB (main).



16.5.7 Water Flow Switch Abnormality (H62)

Malfunction Decision Conditions:


During operation of heating, the water flow detected by the indoor water flow switch is used to determine water flow error.

Malfunction Caused:

- 1. Faulty water pump.
- 2. Water leak in system.
- 3. Faulty connector connection.
- 4. Faulty water flow switch.
- 5. Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 10 seconds (but no judgment for 9 minutes after compressor startup/restart).



16.5.8 Outdoor High Pressure Abnormality (H64)

Malfunction Decision Conditions:


During operation of heating, when the outdoor high pressure sensor output signal is 0Vdc or 5Vdc.

Malfunction Caused:

- 1. Faulty connector connection.
- 2. Faulty sensor.
- 3. Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 20 minutes.



16.5.9 Indoor Backup Heater OLP Abnormality (H70)


Malfunction Decision Conditions:

During operation of indoor backup heater, when no power supplies to indoor backup heater or OLP open circuit.

Malfunction Caused:

- 4. Faulty power supply connector connection.
- 5. Faulty connector connection.
- 6. Faulty indoor backup heater overload protector (OLP).
- 7. Faulty indoor unit PCB (main).

Abnormality Judgment:



16.5.10 Tank Temperature Sensor Abnormality (H72)


Malfunction Decision Conditions:

When tank connection is set to ON, the temperatures detected by the tank temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1. Faulty connector connection.
- 2. Faulty sensor.
- 3. Faulty indoor unit PCB (main).

Abnormality Judgment:



16.5.11 Indoor-Control Panel Communication Abnormality (H76)

Malfunction Decision Conditions:

During standby and operation of heating, indoor-remote control error occur.


Malfunction Caused:

- 1. Faulty connector connection.
- 2. Faulty remote control.
- 3. Faulty indoor unit PCB (main).

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



16.5.12 Indoor/Outdoor Abnormal Communication (H90)

Malfunction Decision Conditions:

During operation of heating, the data received from outdoor unit in indoor unit signal transmission is checked whether it is normal.

Malfunction Caused:

- 1. Faulty outdoor unit PCB (main).
- 2. Faulty indoor unit PCB (main).
- 3. Indoor-outdoor signal transmission error due to wrong wiring.
- Indoor-outdoor signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units.
- 5. Indoor-outdoor signal transmission error due to disturbed power supply waveform.

Abnormality Judgment:

Continue for 1 minute after operation.

For safety reason and to prevent component breakdown, **Troubleshooting:** always switch off the power before remove and connect the component. Check the indoor-outdoor units connection wires. Yes Correct the indoor-outdoor Is there any wiring error? units connection wires. No Turn OFF the power and disconnect terminal 3 wire. Turn ON the power and measure Vdc between terminal 2 & 3 from the outdoor unit. No Is the Vdc fluctuate Replace the outdoor unit between 45-60Vdc? PCB (main). Yes Turn OFF the power and reconnect terminal 3 wire. Turn ON the power and again measure Vdc between terminal 2 & 3 from the outdoor unit. No Is the Vdc fluctuate Replace the indoor unit between 15-60Vdc? PCB (main).

16.5.13 Tank Booster Heater OLP Abnormality (H91)


Malfunction Decision Conditions:

During operation of tank booster heater, and tank booster heater OLP open circuit.

Malfunction Caused:

- 1. Faulty connector connection.
- 2. Faulty tank booster heater overload protector (OLP).
- 3. Faulty indoor unit PCB (main).

Abnormality Judgment:




16.5.14 Unspecified Voltage between Indoor and Outdoor (H95)

Malfunction Decision Conditions:

The supply power is detected for its requirement by the indoor/outdoor transmission.

Malfunction Caused:

- 1. Insufficient power supply.
- 2. Faulty outdoor unit PCB (noise filter/main).



16.5.15 Outdoor High Pressure Protection (H98)

Malfunction Decision Conditions:

During operation of heating, when pressure 4.0 MPa and above is detected by outdoor high pressure sensor.

Malfunction Caused:

- 1. Faulty water pump.
- 2. Insufficient water flow rate in system.
- 3. Water leak in system.
- 4. 2/3 way closed.
- 5. Clogged expansion valve or strainer.
- 6. Excessive refrigerant.
- 7. Faulty outdoor high pressure sensor.
- 8. Faulty outdoor unit PCB (main).

For safety reason and to prevent component breakdown, **Troubleshooting:** always switch off the power before remove and connect the component. Check the 2/3 way valve. Check the system water pump Yes Replace the faulty water Is the 2/3 way valve closed? Open the 2/3 way valve Is the water pump working? pump. **↓** No Yes Check for clogged Check the system water expansion valve or strainer. flow rate. - Replace the expansion Yes Is the expansion valve or valve and/or strainer Is the water pump speed strainer clogged (ice formed)? - Reclaim and recharge Readjust the water pump adjusted according to system refrigerant speed. No hydraulic external static pressure? Check refrigerant amount. **↓** Yes Check the system water passage. Reclaim and recharge with Is the additional refrigerant correct amount of amount filled correctly? refrigerant. Fix the system water Is there any water leakage? - Replace the outdoor unit leakage. Yes PCB (main) No - Replace the outdoor high

pressure sensor

16.5.16 Indoor Freeze-up Protection (H99)

Malfunction Decision Conditions:


During anti-freezing control in cooling operation, when the indoor refrigerant liquid temperature < 0°C.

Malfunction Caused:

- 1. Faulty water pump.
- 2. Insufficient water flow rate in system.
- 3. Water leak in system.
- 4. 2 way valve partially closed.
- 5. Clogged expansion valve or strainer.
- 6. Refrigerant shortage (refrigerant leakage).
- 7. Faulty indoor refrigerant liquid temperature sensor.
- 8. Faulty indoor unit PCB (main).

Troubleshooting:





16.5.17 Outdoor High Pressure Switch Activate (F12)

Malfunction Decision Conditions:

During operation of heating, when pressure 4.5MPa and above is detected by outdoor high pressure switch.

Malfunction Caused:


- 1. Dust accumulation on the outdoor unit heat exchanger.
- 2. Air short circuit at outdoor unit.
- 3. Faulty water pump.
- 4. Insufficient water flow rate in system.
- 5. Water leak in system.
- 6. 2/3 way valve closed.
- 7. Clogged expansion valve or strainer.
- 8. Excessive refrigerant.
- 9. Faulty outdoor high pressure sensor and switch.
- 10. Faulty outdoor unit PCB.

Abnormality Judgment:

Continue 4 times in 20 minutes.

Troubleshooting:





16.5.18 Compressor Rotation Failure (F14)

Malfunction Decision Conditions:

A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction Caused:


- 1. Compressor terminal disconnect.
- 2. Faulty outdoor unit PCB (main).
- 3. Faulty compressor.

Abnormality Judgment:

Continue 4 times in 20 minutes.

Troubleshooting:





16.5.19 Outdoor Fan Motor (DC Motor) Mechanism Locked (F15)

Malfunction Decision Conditions:


The rotation speed detected by the Hall IC of the fan motor during fan motor operation is used to determine abnormal fan motor (feedback of rotation > 2550rpm or < 50rpm).

Malfunction Caused:

- 1. Operation stop due to short circuit inside the fan motor winding.
- 2. Operation stop due to breaking of wire inside the fan motor.
- 3. Operation stop due to breaking of fan motor lead wires.
- 4. Operation stop due to fan motor Hall IC malfunction.
- 5. Operation error due to faulty outdoor unit PCB.

Abnormality Judgment:

Continue 2 times in 30 minutes.



16.5.20 Input Over Current Detection (F16)

Malfunction Decision Conditions:

During operation of heating, when outdoor current above 27.9A is detected by the current transformer (CT) in the outdoor unit PCB.

Malfunction Caused:

- 1. Excessive refrigerant.
- 2. Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 3 times in 20 minutes.

For safety reason and to prevent component breakdown, **Troubleshooting:** always switch off the power before remove and connect the component. Get restarted and measure the AC current from the outdoor LIVE terminal. Νo Is the measured AC current Replace the outdoor unit over 27.9A? PCB (main). Yes Check refrigerant amount. Yes Reclaim and recharge with Excess refrigerant? correct amount of refrigerant. No

Replace the outdoor unit PCB (main).

16.5.21 Compressor Overheating (F20)

Malfunction Decision Conditions:

During operation of heating, when temperature above 112°C is detected by the compressor tank temperature sensor.

Malfunction Caused:


- 1. Faulty compressor tank temperature sensor.
- 2. 2/3 way valve closed.
- 3. Refrigerant shortage (refrigerant leakage).
- 4. Clogged expansion valve or strainer.
- 5. Faulty outdoor unit PCB (main).
- 6. Faulty compressor.

Abnormality Judgment:

Continue 4 times in 30 minutes.

Troubleshooting:





16.5.22 IPM Overheating (F22)

Malfunction Decision Conditions:

During operation of heating, when temperature 95°C is detected by the outdoor IPM temperature sensor.

Malfunction Caused:


- 1. Faulty outdoor unit fan motor.
- 2. Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 3 times in 30 minutes.

Troubleshooting:





16.5.23 Output Over Current Detection (F23)

Malfunction Decision Conditions:


During operation of heating, when outdoor DC current is above 34A is detected by the IPM DC Peak sensing circuitry in the outdoor unit PCB (main).

Malfunction Caused:

- 1. Faulty outdoor unit PCB (main).
- 2. Faulty compressor.

Abnormality Judgment:

Continue for 7 times.



16.5.24 Refrigeration Cycle Abnormality (F24)

Malfunction Decision Conditions:

- 1. During operation of heating, compressor frequency > Frated.
- 2. During operation of heating, running current: 0.65A < I < 1.65A.
- 3. During operation of heating, indoor refrigerant liquid temperature water inlet temperature < 5°C.

Malfunction Caused:


- 1. Faulty water inlet or indoor refrigerant liquid temperature sensors.
- 2. 2/3 way valve closed.
- 3. Refrigerant shortage (refrigerant leakage).
- 4. Clogged expansion valve or strainer.
- 5. Faulty outdoor unit PCB (main).
- 6. Poor compression of compressor.

Abnormality Judgment:

Continue 2 times in 20 minutes.

Troubleshooting:





16.5.25 Four Way Valve Abnormality (F25)

Malfunction Decision Conditions:


During heating operation, when the indoor pipe temperature of thermostat ON indoor unit < 0°C.

Malfunction Caused:

- 1. Faulty sensor.
- 2. Faulty connector connection.
- 3. Faulty outdoor unit PCB (noise filter/main).
- 4. Faulty four way valve.

Abnormality Judgment:

Continue 4 times in 30 minutes.



16.5.26 Outdoor High Pressure Switch Abnormal (F27)

Malfunction Decision Conditions:


During compressor stop, and outdoor high pressure switch is remain opened.

Malfunction Caused:

- 1. Faulty connector connection.
- 2. Faulty switch.
- 3. Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 1 minute.



16.5.27 Indoor Water Outlet Temperature Sensor 2 Abnormality (F30)


Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water outlet temperature sensor 2 are used to determine sensor error.

Malfunction Caused:

- 1. Faulty connector connection.
- 2. Faulty sensor.
- 3. Faulty indoor unit PCB.

Abnormality Judgment:



16.5.28 Outdoor Air Temperature Sensor Abnormality (F36)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the outdoor air temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1. Faulty connector connection.
- 2. Faulty sensor.
- 3. Faulty outdoor unit PCB (main).

Abnormality Judgment:



16.5.29 Indoor Water Inlet Temperature Sensor Abnormality (F37)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the indoor water inlet temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1. Faulty connector connection.
- 2. Faulty sensor.
- 3. Faulty indoor unit PCB (main).

Abnormality Judgment:



16.5.30 Outdoor Discharge Pipe Temperature Sensor Abnormality (F40)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the outdoor discharge pipe temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1. Faulty connector connection.
- 2. Faulty sensor.
- 3. Faulty outdoor unit PCB (main).

Abnormality Judgment:



16.5.31 Power Factor Correction (PFC) Abnormality (F41)

Malfunction Decision Conditions:


During operation of heating, when the PFC protection circuitry in the outdoor unit PCB (main) senses abnormal high DC voltage level.

Malfunction Caused:

- 1. Power supply surge.
- 2. Compressor windings not uniform.
- 3. Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 10 minutes.



Resistance of Compressor Windings

| Trodictarios di Compressor Windings | |
|-------------------------------------|-------------|
| Connection | 5JD420XCA22 |
| U-V | 0.435Ω |
| U-W | 0.452Ω |
| V-W | 0.441Ω |

Resistance at 20°C

16.5.32 Outdoor Pipe Temperature Sensor Abnormality (F42)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1. Faulty connector connection.
- 2. Faulty sensor.
- 3. Faulty outdoor unit PCB (main).

Abnormality Judgment:



16.5.33 Outdoor Defrost Temperature Sensor Abnormality (F43)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the outdoor defrost temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1. Faulty connector connection.
- 2. Faulty sensor.
- 3. Faulty outdoor unit PCB (main).

Abnormality Judgment:



16.5.34 Indoor Water Outlet Temperature Sensor Abnormality (F45)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the indoor water outlet temperature sensor are used to determine sensor errors.

Malfunction Caused:

- 1. Faulty connector connection.
- 2. Faulty sensor.
- 3. Faulty indoor unit PCB (main).

Abnormality Judgment:



16.5.35 Outdoor Current Transformer Open Circuit (F46)

Malfunction Decision Conditions:


A current transformer (CT) open circuit is detected by checking the compressor running frequency (≥ rated frequency) and CT detected input current (< 0.65A) for continuously 20 seconds.

Malfunction Caused:

- 1. CT defective.
- 2. Faulty outdoor unit PCB.
- 3. Compressor defective (low compression).

Abnormality Judgment:

Continue 3 times in 20 seconds.



16.5.36 Cooling High Pressure Overload Protection (F95)

Malfunction Decision Conditions:


During operation of cooling, when pressure 4.0MPa and above is detected by outdoor high pressure sensor.

Malfunction Caused:

- 1. Dust accumulation in the outdoor unit heat exchanger.
- 2. Air short circuit at outdoor unit.
- 3. 2 way valve closed.
- 4. Faulty outdoor unit fan motor.
- 5. Clogged expansion valve or strainer.
- 6. Excessive refrigerant.
- 7. Faulty outdoor high pressure sensor.
- 8. Faulty outdoor unit PCB (main).

Troubleshooting:





17. Disassembly and Assembly Instructions


⚠ WARNING

High Voltage are generated in the electrical parts area by the capacitor. Ensure that the capacitor has discharged sufficiently before proceeding with repair work. Failure to heed this caution may result in electric shocks.


⚠ WARNING

Be sure to switch off all the power supply before performing each of the below action.


17.1 To Remove The Cabinet Front Plate



17.2 To Remove The Cabinet Top Plate




17.3 To Remove The Cabinet Rear Plate



17.4 To Remove Pressure Gauge




17.5 To Remove RCCB



17.6 To Remove Transformer and Electronic Controller Board


 Disconnect the 2 lead wire T1, T2 (Black) and connector CN-T1 (White) from the Electronic Controller Board.

Transformer




② Remove 4 screws to remove Transformer.

Electronic Controller Board




- Using screw driver remove screw to remove Electronic Controller Board.
- Disconnect all connectors of CN-HT(WHT), CN-V2(WHT), CN-V3(GRN), CN-RCV2(WHT), CN-DP2(WHT), CN-TH2(WHT), CN-TH2(WHT), CN-TH3(WHT), CN-TH1(WHT), CN-FLOW(YLW), CN-REMOTE2(WHT), CN-OLP1(WHT), CN-PUMP2(WHT), CN-SOLAR(WHT), CN-T1(WHT), lead wire T2(BLK) and T1(BLK) from the Electronic Controller Board.

17.7 To Remove Pressure Relief Valve, Flow Switch and Air Purge Valve




⚠ When reinstall Flow Switch, ensure the arrow on the flow switch is parallel with the pipe shaft and is facing in the direction of flow.

⚠ During reinstall Air Purge Valve.




17.8 To Remove Water Pump



⚠ When reinstall the water pipe, use grease or water at the joining.

17.9 To Remove Bottle Complete



⚠ When reinstall the water pipe, use grease or water at the joining.


18. Technical Data


18.1 Operation Characteristics

18.1.1 WH-MXC09G3E5

Heating Characteristics at Different Outdoor Air Temperature


- Condition
 - o Indoor water inlet temperature: 30°C
 - o Indoor water outlet temperature: 35°C







Cooling Characteristics at Different Outdoor Air Temperature

- Condition
 - Indoor water inlet temperature: 12°CIndoor water outlet temperature: 7°C









Outdoor Temperature (°C)

Cooling Characteristics at Different Outdoor Air Temperature

- Condition
 - Indoor water inlet temperature: 19°C
 - Indoor water outlet temperature: 14°C




Outdoor Temperature (°C)




Outdoor Temperature (°C)

Cooling Characteristics at Different Outdoor Air Temperature

- Condition
 - Indoor water inlet temperature: 23°C
 - Indoor water outlet temperature: 18°C








Outdoor Temperature (°C)


18.1.2 WH-MXC12G6E5

Heating Characteristics at Different Outdoor Air Temperature

- Condition
 - o Indoor water inlet temperature: 30°C
 - o Indoor water outlet temperature: 35°C









Outdoor Temperature (°C)

Cooling Characteristics at Different Outdoor Air Temperature

- Condition
 - o Indoor water inlet temperature: 12°C
 - o Indoor water outlet temperature: 7°C









Outdoor Temperature (°C)


Cooling Characteristics at Different Outdoor Air Temperature

• Condition

Indoor water inlet temperature: 19°C
 Indoor water outlet temperature: 14°C









Outdoor Temperature (°C)

Cooling Characteristics at Different Outdoor Air Temperature

- Condition
 - o Indoor water inlet temperature: 23°C
 - o Indoor water outlet temperature: 18°C



Outdoor Temperature (°C)



Outdoor Temperature (°C)

18.2 Heating Capacity Table

18.2.1 WH-MXC09G3E5

| Water Out (°C) | 30 | | 35 40 | | 45 | | 50 | | 55 | | | |
|---------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|
| Outdoor Air (°C) | Capacity (W) | Input Power (W) |
| -15 | 9000 | 3240 | 9000 | 3510 | 9000 | 3910 | 9000 | 4300 | 9000 | 4730 | 9000 | 5160 |
| -7 | 9000 | 2710 | 9000 | 3160 | 9000 | 3620 | 9000 | 4070 | 9000 | 4270 | 9000 | 4460 |
| 2 | 9000 | 2360 | 9000 | 2510 | 9000 | 2780 | 9000 | 3050 | 9000 | 3560 | 9000 | 4070 |
| 7 | 9000 | 1640 | 9000 | 1860 | 9000 | 2160 | 9000 | 2460 | 9000 | 2760 | 9000 | 3060 |
| 25 | 13600 | 1500 | 13600 | 1710 | 13200 | 1930 | 12800 | 2140 | 12000 | 2410 | 11200 | 2670 |

18.2.2 WH-MXC12G6E5

| Water Out (°C) | 30 | | 35 40 | | 45 | | 50 | | 55 | | | |
|---------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|-----------------|-----------------------|
| Outdoor Air (°C) | Capacity (W) | Input Power (W) |
| -15 | 12000 | 4750 | 12000 | 4960 | 12000 | 5410 | 11000 | 5380 | 10800 | 5820 | 10500 | 6260 |
| -7 | 12000 | 3850 | 12000 | 4410 | 12000 | 4980 | 12000 | 5540 | 12000 | 5900 | 12000 | 6260 |
| 2 | 12000 | 3190 | 12000 | 3490 | 12000 | 3870 | 12000 | 4250 | 12000 | 4860 | 12000 | 5470 |
| 7 | 12000 | 2180 | 12000 | 2530 | 12000 | 2960 | 12000 | 3390 | 12000 | 3780 | 12000 | 4160 |
| 25 | 13600 | 1550 | 13600 | 1760 | 13400 | 2100 | 13200 | 2430 | 12600 | 2660 | 12000 | 2890 |

18.3 Cooling Capacity Table

18.3.1 WH-MXC09G3E5


| Water In (°C) | | 12 | | 1 | 19 | 23 | |
|----------------|----|-----------------|--------------------|-----------------|--------------------|-----------------|--------------------|
| Water Out (°C) | | 7 | | 14 | | 18 | |
| t t | °C | Capacity (W) | Input Power (W) | Capacity (W) | Input Power (W) | Capacity (W) | Input Power (W) |
| Ambient | 18 | 7.00 | 1.36 | 8.55 | 1.41 | 7.00 | 1.00 |
| | 25 | 7.65 | 1.91 | 11.10 | 1.98 | 7.00 | 1.10 |
| OD | 35 | 7.00 | 2.21 | 9.23 | 2.37 | 7.00 | 1.35 |
| | 43 | 6.25 | 2.66 | 8.55 | 2.71 | 5.60 | 1.60 |


18.3.2 WH-MXC12G6E5


| Water In (°C) | | 12 | | 1 | 9 | 23 | |
|----------------|----|-----------------|--------------------|-----------------|--------------------|-----------------|--------------------|
| Water Out (°C) | | 7 | | 14 | | 18 | |
| t t | °C | Capacity (W) | Input Power (W) | Capacity (W) | Input Power (W) | Capacity (W) | Input Power (W) |
| Ambient | 18 | 10.00 | 1.75 | 13.20 | 1.96 | 10.00 | 1.40 |
| | 25 | 11.20 | 2.67 | 16.50 | 3.01 | 10.00 | 1.60 |
| OO | 35 | 10.00 | 3.56 | 12.55 | 3.63 | 10.00 | 1.95 |
| | 43 | 8.00 | 3.35 | 10.00 | 3.46 | 8.00 | 2.30 |

19. Exploded View and Replacement Parts List

19.1 (Refrigerant System)







The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.

<Model: Refrigerant System>


| SAFETY | REF. NO. | DESCRIPTION & NAME | QTY. | WH-MXC09G3E5 | WH-MXC12G6E5 | REMARK |
|----------|----------|--|------|--------------|--------------|--------|
| | 1 | BASE PAN ASS'Y | 1 | CWD52K1276 | ← | |
| ⚠ | 2 | COMPRESSOR | 1 | 5JD420XCA22 | ← | 0 |
| | 3 | BUSHING - COMPRESSOR MOUNT | 3 | CWH50055 | ← | |
| | 4 | NUT-COMPRESSOR MOUNT | 3 | CWH561049 | ← | |
| | 5 | CRANKCASE HEATER | 1 | CWA341053 | ← | |
| | 6 | CONDENSER COMPLETE | 1 | CWB32C3891 | ← | |
| | 7 | HIGH PRESSURE SENSOR | 1 | CWA501463 | ← | 0 |
| | 8 | DISCHARGE MUFFLER | 1 | CWB121014 | ← | |
| | 9 | HIGH PRESSURE SWITCH | 1 | CWA101013 | ← | 0 |
| | 10 | 3-WAYS VALVE (GAS) | 1 | CWB011699 | ← | 0 |
| | 11 | 4-WAYS VALVE | 1 | CWB001046 | ← | 0 |
| | 12 | 3-WAYS VALVE (LIQUID) | 1 | CWB011700 | ← | 0 |
| | 13 | STRAINER | 4 | CWB111032 | ← | |
| | 14 | GASKET FOR TERMINAL COVER | 3 | CWB811017 | ← | |
| | 15 | RECEIVER | 1 | CWB141069 | ← | |
| | 20 | SOUND PROOF MATERIAL (COMP BODY) | 1 | CWG302795 | ← | |
| | 21 | SOUND PROOF MATERIAL (TOP) | 1 | CWG302266 | ← | |
| | 22 | SOUND PROOF BOARD | | CWH151085 | ← | |
| | 23 | V-COIL COMPLETE (4 WAY VALVE) | 1 | CWA43C2169J | ← | 0 |
| | 24 | V-COIL COMPLETE (MAIN EXPANSION VALVE) | 1 | CWA43C2602 | ← | 0 |
| | 25 | SENSOR - COMP. (OUTDOOR AIR, PIPE TEMP) | 1 | CWA50C2730 | ← | 0 |
| | 26 | SENSOR - COMP. (DISCHARGE TEMP) | 1 | CWA50C2576 | ← | 0 |
| | 28 | CABINET REAR PLATE - COMPLETE | 1 | CWE02K1019A | ← | |
| | 29 | CONTROL BOARD CASING | 1 | CWH10K1049 | ← | |
| | 30 | SENSOR - COMP. (DEFROST TEMP) | 1 | CWA50C2577 | <u>←</u> | 0 |
| Æ | 31 | TERMINAL BOARD ASS'Y (1,2,3) | 1 | CWA28K1213 | <u>←</u> | 0 |
| <u> </u> | 32 | TERMINAL BOARD ASS'Y (U,V,W,A) | 1 | CWA28K1334 | <u></u> | 0 |
| <u> </u> | 38 | ELECTRONIC CO. (NOISE FILTER) | 1 | CWA747856 | <u>`</u> | 0 |
| <u> </u> | 39 | ELECTRONIC CO. (CAPACITOR) | 1 | CWA747853 | <u></u> | 0 |
| <u> </u> | 44 | ELECTRONIC CONTROLLER (MAIN) | 1 | CWA73C8883R | CWA73C8886R | 0 |
| <u> </u> | 46 | REACTOR | 1 | G0C592J00006 | <i>←</i> | 0 |
| <u> </u> | 50 | FAN MOTOR BRACKET | 1 | CWD54K1084 | ← | |
| | 51 | SCREW - FAN MOTOR BRACKET | 2 | CWH551040J | ← | |
| A | 52 | FAN MOTOR (UPPER) | 1 | EHDS83LAC | <u>←</u> | 0 |
| <u> </u> | 53 | FAN MOTOR (LOWER) | 1 | EHDS83MAC | | 0 |
| <u> </u> | 54 | SCREW - FAN MOTOR MOUNT | 8 | CWH551323 | ← | |
| | | | _ | | ← | |
| | 55 56 | PROPELLER FAN ASSY | 2 | CWH00K1006 | ← | |
| | 56 57 | NUT CABINET FRONT PLATE | 2 | CWH561092 | ← | |
| | 57 | | 1 | CWE061098A | ← | |
| | 58 | DISCHARGE GRILLE | 2 | CWE201073 | ← | |
| | 59 | CABINET SIDE PLATE ASSY | 1 | CWE04K1023A | ← | |
| | 60 | WIRE NET | 1 | CWD041103A | ← | |
| | 61 | CABINET TOP PLATE | 1 | CWE03C1105 | ← | |
| | 62 | ACCESSORY CO. (RUBBER CAP) | 1 | CWH82C1839 | ← | |
| | 66 | CABINET FRONT PLATE | 1 | CWE061274A | ← | |
| | 67 | HANDLE | 2 | CWE161014 | ← | |
| | 68 | TUBE ASSY (CAP.TUBE) | 1 | CWT07K1606 | ← | |
| | 70 | EXPANSION VALVE (1) | 1 | CWB051029 | ← | |
| | 71 | EXPANSION VALVE (2) | 1 | CWB051049 | ← | 0 |
| | 72 | 2-WAYS VALVE(LIQUID) | 1 | CWB021637 | ← | 0 |
| | 73 | V-COIL COMPLETE (2-WAY VALVE) | 1 | CWA43C2607 | ← | 0 |
| | 74 | V-COIL COMPLETE (BYPASS EXPANSION VALVE) | 1 | CWA43C2335 | ← | 0 |
| | | , ··· | | 1 | l . | |


| SAFETY | REF. NO. | DESCRIPTION & NAME | QTY. | WH-MXC09G3E5 | WH-MXC12G6E5 | REMARK |
|-------------|----------|-----------------------------------|------|--------------|--------------|--------|
| | 76 | HEATER | 1 | CWA341071 | ← | |
| | 78 | SENSOR - COMP. (BYPASS EXIT TEMP) | 1 | CWA50C3165 | ← | 0 |
| | 80 | SOUND PROOF MATERIAL | 1 | CWG302598 | | |
| | 81 | SOUND PROOF MATERIAL | 1 | CWG302975 | ← | |
| \triangle | 82 | ELECTRO MAGNETIC SWITCH | 1 | K6C1AYY00003 | ← | 0 |
| | 83 | LEADWIRE COMPRESSOR | 1 | CWA68C2031 | ← | 0 |

(Note)

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488). "O" marked parts are recommended to be kept in stock.

19.2 (Water System)





Note The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.

<Model: Water System>

| SAFETY | REF. NO. | DESCRIPTION & NAME | QTY. | WH-MXC09G3E5 | WH-MXC12G6E5 | REMARK |
|-------------------------|----------|---|------|--------------|--------------|--------|
| | 1 | BASE PAN ASS'Y | 1 | CWD52K1381 | ← | |
| | 2 | HOT WATER COIL - COMPLETE | 1 | CWB90C1132 | ← | |
| | 3 | RECEIVER | 1 | CWB141073 | ← | |
| | 4 | FLOW SWITCH | 1 | CWB621128 | ← | 0 |
| Æ | 5 | PUMP | 1 | CWB532116 | ← | 0 |
| | 16 | BOTTLE COMP. | 1 | CWH90C0053 | ← | |
| | 17 | HEATER ASS'Y | 1 | CWA34K1046 | CWA34K1048 | |
| | 18 | SOUND PROOF MATERIAL | 1 | CWG302599 | ← | |
| | 19 | THERMOSTAT | 2 | CWA151074 | ← | 0 |
| ^ | 20 | ELECTRONIC CONTROLLER (MAIN) | 1 | CWA73C8881R | CWA73C8882R | 0 |
| Æ. | 21 | TERMINAL BOARD ASS'Y (A,B) | 1 | CWA28K1200 | ← | 0 |
| | 22 | SOUND PROOF MATERIAL | 1 | CWG302594 | ← | |
| Æ | 25 | TERMINAL BOARD ASS'Y (1,2,3,4,5,6) | 1 | CWA28K1211 | ← | 0 |
| \wedge | 26 | TERMINAL BOARD ASS'Y (7,8,9,10,11,12) | 1 | CWA28K1221 | ← | 0 |
| $\overline{\mathbb{A}}$ | 27 | REACTOR | 1 | G0C103Z00003 | ← | 0 |
| $\overline{\mathbb{A}}$ | 28 | TERMINAL BOARD ASS'Y (13,14,15,16,17,18) | 1 | CWA28K1222 | ← | 0 |
| $\overline{\mathbb{A}}$ | 29 | CIRCUIT BREAKER | 2 | CWA181005 | ← | 0 |
| | 30 | TRANSFORMER - COMPLETE | 1 | CWA40C1096 | ← | 0 |
| | 31 | SENSOR - COMPLETE (WATER IN,OUT, REF TEMP) | 1 | CWA50C2749 | ← | 0 |
| | 32 | REMOTE CONTROL COMPLETE | 1 | CWA75C4466 | ← | 0 |
| | 33 | PRESSURE GAUGE | 1 | CWB07C0001 | ← | 0 |
| | 34 | PRESSURE RELIEF VALVE | 1 | CWB621092 | ← | 0 |
| | 35 | AIR PURGE VALVE | 1 | CWB621094 | ← | 0 |
| <u> </u> | 36 | TERMINAL BOARD ASS'Y | 1 | CWA28K1238 | ← | 0 |
| | 39 | OPERATING INSTRUCTION | 1 | CWF569738 | ← | |
| | 40 | INSTALLATION INSTRUCTION | 1 | CWF616517 | ← | |
| | 41 | OPERATING INSTRUCTION | 1 | CWF569739 | ← | |
| | 44 | CONTROL BOARD COVER | 1 | CWH131420A | ← | |
| | 45 | HANDLE | 2 | CWE161014 | ← | |
| | 46 | CABINET SIDE PLATE ASS'Y | 1 | CWE04K1194A | ← | |
| | 47 | CABINET FRONT PLATE | 1 | CWE061275A | ← | |
| | 48 | HOLDER COUPLING | 1 | CWH351181A | ← | |
| | 49 | SENSOR – COMPLETE (HEX WATER OUTLET) | 1 | CWA50C3258 | ← | 0 |

(Note)

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.