Air conditioner

User manual

AR**AXKA***

- Thank you for purchasing this Samsung air conditioner.
- Before operating this unit, please read this user manual carefully and retain it for future reference.

SAMSUNG

Contents

Safety Information	4
Safety Information	4
At a Glance	15
Indoor Unit Overview	15
Display	16
Remote Control Overview	17
Replacing the remote control batteries	17
Remote Control Operation	18
Selecting an operation mode	18
To set the temperature • To adjust the fan speed • To adjust the airflow direction	19
Smart Features	20
Power Smart Features	20
WindFree Cooling function	20
AI Auto mode	21
Auto mode • Cool mode	22
Dry mode • Fan mode	23
Heat mode • Automatic defrost	24
Variety Smart Features	25
Fast function	25
Eco function	26
Quiet function • Purify function Electricity consumption check	27 29
Usage time check • Beep function	30
Auto clean function	31
Freeze Wash function	33
Display lighting function • Wi-Fi function (SmartThings app)	34
Time scheduling	35
Timed on/ Timed off function	35
good'sleep function	36

Cleaning and Maintenance	37
Schedule	37
Cleaning	38
Appendix	43
Troubleshooting	43
Information about Refrigerant	46
SmartThings app	47
Reference	50



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.



Correct disposal of batteries in this product

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66.

For information on Samsung's environmental commitments and product-specific regulatory obligations, e.g. REACH, WEEE, Batteries, visit: www.samsung.com/uk/aboutsamsung/sustainability/environment/ our-commitment/data/

🕂 WARNING: Read This Manual

Read and follow all safety information and instructions before installation, use, or maintenance of this appliance. Incorrect installation, use, or maintenance of this appliance can result in death, serious injury, or property damage. Keep these instructions with this appliance. This manual is subject to change. For the latest version, visit www.samsung.com.

Because the instructions in this manual cover various models, the characteristics of your air conditioner may differ slightly from those described. If you have any questions, please contact your service provider or visit www.samsung.com.

Notices and notes

To make you aware of safety messages and highlighted information, we use the following notices and notes throughout this manual:

Hazards or unsafe practices that may result in severe personal injury or death.

Hazards or unsafe practices that may result in minor personal injury or property damage.

IMPORTANT

Information of special interest

NOTE

Supplementary information that may be useful



WARNING: Low burning velocity material (This appliance is filled with R-32.)

The user and installer guides should be read carefully.

The user and installer guides should be read carefully.

The service guide should be read carefully.

FOR GENERAL

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

For use in Europe : This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

IMPORTANT

To perform its antimicrobial function this product has been treated with the biocide substance Silver zinc zeolite.

FOR INSTALLATION

/ WARNING

Use a power cord with this product's power specifications or higher and use the power cord for this appliance only. In addition, do not use an extension cord.

- Extending the power cord may result in electric shock or fire.
- Do not use an electric transformer. This may result in electric shock or fire.
- If the voltage/frequency/rated current condition is different, it may cause fire.

The installation of this appliance must be performed by a qualified technician or service company. Do not attempt to install the air conditioner yourself.

• Failing to do so may result in electric shock, fire, explosion, problems with the product, or injury and may also void warranty on the installed product.

Install an Isolation Switch next to the Air Conditioner (but not on the panels of the Air Conditioner) and circuit breaker dedicated to the air conditioner.

• Failing to do so may result in electric shock or fire.

Fix the outdoor unit firmly so that the electric part of the outdoor unit is not exposed.

• Failing to do so may result in electric shock, fire, explosion, or problems with the product.

Do not install this appliance near a heater, or inflammable material. Do not install this appliance in a humid, oily or dusty location, in a location exposed to direct sunlight and water (or rain). Do not install this appliance in a location where gas may leak.

• This may result in electric shock or fire.

Never install the outdoor unit in a location such as on a high external wall where it could fall.

• If the outdoor unit falls, it may result in injury, death or property damage.

This appliance must be properly grounded. Do not ground the appliance to a gas pipe, plastic, water pipe, or telephone line.

- Failing to do so may result in electric shock, fire, and explosion.
- Make sure to use a socket-outlet with ground.

The product shall be stored in a room with no ignition sources (e.g. open flames, gas appliance, electric heater, etc.).

- Note that the refrigerant has no odour.
- A CAUTION

Please cover the air conditioner with PE BAG after installation, and remove it when you start to run air conditioner.

Install your appliance on a level and hard floor that can support its weight.

• Failing to do so may result in abnormal vibrations, noise, or problems with the product.

Install the drain hose properly so that water drains correctly.

• Failing to do so may result in water overflowing and property damage. Avoid adding drain to waste pipes as odours may arise in the future.

When installing the outdoor unit, make sure to connect the drain hose so that draining is performed correctly.

 The water generated during heating by the outdoor unit may overflow and result in property damage.
 In particular, in winter, if a block of ice falls, it may result in injury, death or property damage.

Do not install the product in a place where thermo-hygrostat is needed (such as server room, machinery room, computer room, etc.)

 Those places do not provide guaranteed operation condition of the product therefore performance can be poor in these places.

FOR POWER SUPPLY

🗥 WARNING

When the circuit breaker is damaged, contact your nearest service centre.

Do not pull or excessively bend the power line. Do not twist or tie the power line. Do not hook the power line over a metal object, place a heavy object on the power line, insert the power line between objects, or push the power line into the space behind the appliance.

This may result in electric shock or fire.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly gualified persons in order to avoid a hazard



When not using the air conditioner for a long period of time or during a thunder/lightning storm, cut the power at the circuit breaker

Failing to do so may result in electric shock or fire.

FOR USING

A WARNING

If the appliance is flooded, please contact your nearest service centre.

• Failing to do so may result in electric shock or fire.

If the appliance generates a strange noise, a burning smell or smoke, cut off the power supply immediately and contact the nearest service centre.

• Failing to do so may result in electric shock or fire.

If the air conditioner malfunctions or requires repair, immediately stop its operation and disconnect the entire power system. Then consult the authorized service personnel.

In the event of a gas leak (such as propane gas, LP gas, etc.), ventilate immediately without touching the power line. Do not touch the appliance or power line.

- Do not use a ventilating fan.
- A spark may result in an explosion or fire.

To reinstall the air conditioner, please contact your nearest service centre.

- Failing to do so may result in problems with the product, water leakage, electric shock, or fire.
- Delivery service for the product is not provided. If you reinstall the product in another location, additional construction expenses and an installation fee will be charged.
- Especially, when you wish to install the product in an unusual location such as in an industrial area or near the seaside where it is exposed to salt in the air, please contact your nearest service centre.

Do not touch the circuit breaker with wet hands.

• This may result in electric shock.

Do not turn the air conditioner off with the circuit breaker while it is operating.

• Turning the air conditioner off and then on again with the circuit breaker may cause a spark and result in electric shock or fire.

After unpacking the air conditioner, keep all packaging materials well out of the reach of children, as packaging materials can be dangerous to children.

• If a child places a bag over its head, it may result in suffocation.

Do not touch the airflow blade with your hands or fingers during heating.

• This may result in electric shock or burns.

Do not insert your fingers or foreign substances into the air inlet/ outlet of the air conditioner.

• Take special care that children do not injure themselves by inserting their fingers into the product.

Do not strike or pull the air conditioner with excessive force.

• This may result in fire, injury, or problems with the product. Do not place an object near the outdoor unit that allows children to climb onto the machine.

- This may result in children seriously injuring themselves. Do not use this air conditioner for long periods of time in badly ventilated locations or near infirm people.
- Since this may be dangerous due to a lack of oxygen, open a window at least once an hour.

Do not use means to accelerate the defrost operation or to clean, other than those recommended by Samsung.

Do not pierce or burn.

Be aware that refrigerants may not contain an odour.

If any foreign substance such as water has entered the appliance, cut off the power supply and contact the nearest service centre.

• Failing to do so may result in electric shock or fire.

Do not attempt to repair, disassemble, or modify the appliance yourself.

- Do not use any fuse (such as copper, steel wire, etc.) other than the standard fuse.
- Failing to do so may result in electric shock, fire, problems with the product, or injury.

Do not place objects or devices under the indoor unit.

• Water dripping from the indoor unit may result in fire or property damage.

Check that the installation frame of the outdoor unit is not broken at least once a year.

• Failing to do so may result in injury, death or property damage.

To prevent personal injury, make sure that you change the directions of the horizontal airflow blades after stopping the movements of the vertical airflow blade. (In case of adjusting the horizontal airflow manually)

When the air conditioner does not operate properly for cooling or heating, there is a possibility of refrigerant leakage. If any leakage, stop operation, ventilate the room, and consult your dealer immediately for recharging refrigerant.

The refrigerant is not harmful. However, if it comes in contact with fire, it may generate harmful gases and there is risk of fire.

During transportation of the indoor unit, the pipe lines shall be covered with brackets for protection. Do not move the product with holding the pipe lines.

• It may cause gas leakage.

Do not install the product in a ship or a vehicle (such as a campervan).

• Salt, vibration or other environmental factor may cause the product malfunction, electric shock or fire.

Do not stand on top of the appliance or place objects (such as laundry, lighted candles, lighted cigarettes, dishes, chemicals, metal objects, etc.) on the appliance.

• This may result in electric shock, fire, problems with the product, or injury.

Do not operate the appliance with wet hands.

• This may result in electric shock.

Do not spray volatile material such as insecticide onto the surface of the appliance.

• As well as being harmful to humans, it may also result in electric shock, fire or problems with the product.

Do not drink the water from the air conditioner.

• The water may be harmful to humans.

Do not hit, shake, drop, or attempt to disassemble the remote control.

When replacing the remote control batteries, keep them out of the reach of infants.

• If an infant eats batteries, contact a doctor immediately.

When replacing the remote control batteries, be careful not to get the battery fluid on your skin.

• Battery fluid is harmful to humans.

Do not touch the pipes connected with the product.

• This may result in burns or injury.

Do not cut or burn the refrigerant container or pipings.

Do not point the air direction to the fireplace or heater.

Do not use this air conditioner to preserve precision equipment, food, animals, plants or cosmetics, or for any other unusual purposes.

• This may result in property damage.

Avoid directly exposing humans, animals or plants to the airflow from the air conditioner for long periods of time.

• This may result in harm to humans, animals or plants.

FOR CLEANING

A WARNING

Do not clean the appliance by spraying water directly onto it. Do not use benzene, thinner or alcohol to clean the appliance.

• This may result in discolouration, deformation, damage, electric shock or fire.

Before cleaning, servicing, or performing maintenance, make sure to disconnect the product from its power source and wait until the fan stops.

• Failing to do so may result in electric shock or fire.

A CAUTION

Take care when cleaning the surface of the heat exchanger of the outdoor unit since it has sharp edges.


• This should be done by a qualified technician. Please contact your installer or service centre.

Do not clean the inside of the air conditioner by yourself.

- For cleaning inside the appliance, contact your nearest service centre.
- When cleaning the filter, refer to the descriptions in the 'Cleaning' section.
- Failing to do so may result in damage, electric shock or fire.
- Make sure to prevent any injury from sharp edges of the surface when handling the heat exchanger.


Indoor Unit Overview

The appearance of the actual product may differ slightly from the image below.



Indoor Unit Overview

Display



NOTE

• If the Wi-Fi indicator blinks for 10 seconds when operation starts, it means that the air conditioner is not connected to Wi-Fi. See "SmartThings app" on page 47 and connect the air conditioner to Wi-Fi.


NOTE

When the Wi-Fi is turned on, the indicator blinks


three times and then turns on.

• When connected to Wi-Fi, the air conditioner can gather and learn your user patterns so that it can run in AI Auto mode.

Most operating instructions in this manual require using the remote control.



Replacing the remote control batteries



Two 1.5V AAA batteries

- **01** Set temperature indicator
- 02 Timer option indicator
- 03 Operation mode indicator
- 04 Options indicator
- 05 Low battery indicator
- 06 Transmit indicator
- 07 Fan speed indicator
- 08 WindFree indicator
- 09 Vertical air swing indicator
- 10 Horizontal air swing indicator
- 11 Power button
- 12 Temperature button
- 13 Timer button
- 14 Fan speed button
- 15 Direction button/Selection button
- 16 Vertical air swing button
- 17 Mode button
- 18 Fast/WindFree button
- 19 Horizontal air swing button
- 20 Options/Clean button
- 21 SET button/Temperature type button(°C↔°F)

NOTE

 Although Direct and Indirect is displayed on the remote control display, it is not available on this model.

Remote Control Operation

You can use the air conditioner easily by selecting a mode and then by controlling the temperature, fan speed, and air direction.



Selecting an operation mode

To change the current mode between Auto, Cool, Dry, Fan, and Heat, press the 😡 (Mode) button.

You can use AI Auto mode after Wi-Fi is connected.

NOTE

You can use the Cool, Dry, and Heat modes in the following operation range.

Mode	Cool	Dry	Heat
Indoor temperature	16 °C to 32 °C	18 °C to 32 °C	27 °C or less
Outdoor temperature	-10 °C to 46 °C	-10 °C to 46 °C	-15 °C to 24 °C ¹⁾
Indoor humidity	Relative humidity of 80 % or less ²⁾	_	-

 $^{1)}$ If the outdoor temperature drops to –15 °C, the heating capacity may decrease by as much as 60-70 %.

²⁾ If the air conditioner operates in Cool mode in a high-humidity environment for an extended period of time, condensation may occur.

• For more information about outdoor temperature in the multi system, refer to the manual for the multi system.

You can switch between Celsius and Fahrenheit indications on the remote control.



Press and hold for 3 or more seconds.

- The temperature indications on the indoor unit are not switched.
- This function is canceled when the remote control batteries are replaced. In this case, run this function again.



To set the temperature

To control the temperature in each mode, press the $\begin{bmatrix} + \\ - \\ - \end{bmatrix}$ (Temperature) button:

Mode	Temperature control
AI Auto/Auto/ Cool/Heat	Adjust by 1 °C from 16 °C to 30 °C.
Dry	Adjust by 1 °C from 18 °C to 30 °C.
Fan	No temperature control.

To adjust the fan speed

Select from the following fan speeds in each mode:

Mode	Available fan speeds	
Al Auto/Auto/ Dry	ජී ^{නාත} (Auto)	
Cool/Fan/Heat	^{ఈగాం} (Auto), ఈ (Low), ఈ (Med), ఈ (High), ఈ (Turbo)	


To adjust the airflow direction

Keep the airflow in a constant direction by stopping the movements of the vertical and horizontal airflow blades.



- If you adjust the vertical airflow blade manually, it may not close completely when you turn off the air conditioner.
- Always use the remote control to adjust the airflow blades. Do not move the blades by hand. They may not operate normally.
- You cannot control the vertical airflow direction in Cool mode when the good'sleep function is on.

Power Smart Features




WindFree Cooling function

Use the WindFree Cooling function to enjoy a mild breeze coming through fine holes in the WindFree panel instead of air coming directly through the airflow blades.

In Cool/Dry/Fan mode 🕨



- To cancel this function, press the (WindFree) button again.
- When the WindFree Cooling function is on, the air conditioner automatically controls the temperature and fan speed to keep your room mild and comfortable.
- When the WindFree Cooling function is canceled, the air conditioner returns to the original fan speed and air comes out of the airflow blades.
- In Cool mode, the recommended set temperature during the WindFree Cooling operation is 24 °C to 26 °C.
- You can use the WindFree Cooling function in Cool, Dry, or Fan mode.
- You cannot select the Quiet function during the WindFree Cooling operation.
- Selecting the WindFree Cooling function cancels the Fast, Eco, and airflow direction ((), ()) functions.




Al Auto mode

Use AI Auto mode to automatically operate any of Cool, Dry, Heat, and WindFree Cooling modes depending on the learned user patterns gathered from an external server via Wi-Fi module. The favourite temperature and operation mode are also set based on the current temperatures (indoor/outdoor) and the gathered user patterns.



- You can use this mode after Wi-Fi is connected. Otherwise, Auto mode is activated.
- In AI Auto mode, the C_{AI} (AI Auto) and [→] (Wi-Fi) indicators appears on the display of the indoor unit.
- If the gathered user patterns are not sufficient, the set temperature is set to 24 °C.
- The set temperature is controlled within the range of 16 °C to 30 °C in AI Auto mode. You can also change it manually.
- When you press 🚱 (Mode) in AI Auto mode, the mode is cancelled.
- If you change the set temperature in AI Auto mode, it automatically changes back to the AI comfort temperature after 1 hour.



Auto mode

Use Auto mode to perform the powerful cooling or heating function to automatically reach the desired temperature. When the difference between the room temperature and the set temperature decreases, the air conditioner controls the fan speed and airflow direction.



NOTE


- If Wi-Fi cannot be connected or the Wi-Fi function is not supported, this Auto mode is automatically activated instead of AI Auto mode.
- When the room temperature is higher than the set temperature, the air conditioner automatically produces cool air.
- When the room temperature is lower than the set temperature, the air conditioner automatically produces warm air.

Cool mode

Use Cool mode to stay cool in hot weather.



- For comfort, keep the temperature difference between the indoor and outdoor air within 5 °C.
- After selecting Cool mode, select the desired function, temperature, and fan speed.
 - To cool more quickly, select a lower temperature and a faster fan speed.
 - To save energy, select a higher temperature and a slower fan speed.
 - As the room temperature nears the set temperature, the compressor motor will slow down to save energy.






Dry mode

Use Dry mode in rainy or humid weather.



NOTE

- The proper set temperature range for dehumidifying operation is 24 to 26 °C. If you feel that the current humidity seems high, use a lower set temperature.
- You cannot use Dry mode for heating. Dry mode is designed to produce a cooling side-effect.



Fan mode

Use Fan mode to run the air conditioner like a floor fan, providing a breeze without heating or cooling.



- If the air conditioner will not be used for an extended period of time, run it in Fan mode for 3 to 4 hours to dry the internal components.
- The outdoor unit does not operate in Fan mode. This is normal and not a fault with the air conditioner.



Heat mode

Use Heat mode to stay warm.




NOTE

- While the air conditioner warms up, the fan may not operate for about 3 to 5 minutes at the beginning to prevent cold blasts.
- If the air conditioner heats insufficiently, use an additional heating appliance in combination with the air conditioner.

Automatic defrost

When the outdoor temperature is low and the humidity is high, frost may develop on the outdoor heat exchanger, which may decrease heating efficiency. When these conditions are met while Heat mode is on, the air conditioner runs the Defrost function for 5 to 12 minutes to remove frost from the outdoor heat exchanger.

- When the Defrost function is on, the d → (Defrost) indicator appears on the indoor unit display, steam is produced on the outdoor unit, the air conditioner moves the airflow blades to the lowest position to prevent cold air from coming out from the indoor unit.
- You cannot select other functions with the remote control until the Defrost function is finished.



Fast function


Use the Fast function to quickly cool or heat your room. This function is the most powerful cooling and heating function provided by the air conditioner. You can select this function in Cool or Heat mode.

In Cool or Heat mode



- You can change the airflow direction, but you cannot change the set temperature and the fan speed.
- When you select the Fast function in Heat mode, you may not be able to increase the fan speed for 3 to 5 minutes while the unit heats up.
- Selecting the Fast function cancels the WindFree Cooling, Eco, good'sleep, and Quiet functions.
- You can also start the Fast function from the Options menu:





Eco function

For the multi system, this function is not supported.

Use the Eco function to reduce electricity consumption while staying cool or warm. You can select this function in Cool or Heat mode.

SET




NOTE

Select Eco.

- When the Eco function starts, the pattern == ___ appears on the remote control for a few seconds and vertical air swing begins.
- You can change the set temperature, airflow direction, and fan speed.
- The allowed set temperatures while the Eco function is on are:

Mode	Minumum set temperature	Maximum set temperature
Cool	24 °C	30 °C
Heat	16 °C	30 °C

- If you change the set temperature to be outside the allowed range for the current mode, the set temperature is automatically reset to be within the range.
- When you turn off the Eco function, the air swing continues. Use the ((Vertical air swing) or ((Horizontal air swing) button to turn it off.
- Selecting the Eco function cancels the WindFree Cooling, good'sleep, Fast, and Quiet functions.



Quiet function

Use the Quiet function to reduce the unit's operating noise. You can select this function in Cool or Heat mode.




NOTE

- You can change the set temperature and the airflow direction, but you cannot change the fan speed.
- Selecting the Quiet function cancels the WindFree Cooling, Eco, good'sleep, and Fast functions.



Purify function

Use the Purify function to filter out dust and fine dust from the indoor air to create clean, comfortable, and safe air to breathe.



\triangle caution

• Do not touch the PM1.0 filter on the top of the indoor unit while the Purify function is on.

Failing to do so may result in electric shock.

- Of the PM10, PM2.5 and PM1.0 cleanliness, the wort value is displayed on the indoor unit display.
- When the Purify function is additionally selected, there is little difference in electricity consumption and operating noise.
- To start or cancel the Purify function, follow the procedure above again.

NOTE


- When the Purify function is selected, the PM10, PM2.5, or PM1.0 concentration is displayed on the indoor unit display.
 - The ranges of PM10, PM2.5, and PM1.0 concentration values displayed on the display are from 05 to 999, and the concentration values are displayed in units of 1.

	PM10		PN	42.5/PM1.0
Cleanliness	Colour	Concentration (µg/m ³)	Colour	Concentration (µg/m ³)
Very poor	Red	151 or more	Red	76 or more
poor	Yellow	81 to 150	Yellow	36 to 75
Moderate	Green	31 to 80	Green	16 to 35
Good	Blue	30 or less	Blue	15 or less

- Indoor air is clean. $[05 \leftrightarrow 999]$ Indoor air is contaminated.

- PM1.0 cleanliness levels comply with Samsung's own guidelines.


- The dust concentration may vary depending on the environmental conditions (for example, when the product is near a construction site, road, or fabric sofa, or when a vacuum cleaner is used or bedding and clothes are arranged near the product, etc.).
- The dust concentration may be high when the product is used in an environment with shag carpet, an animal hospital, a clothing store, a place with high humidity, smoke, or a lot of insects, etc.
- The dust concentration may increase when the product is used in an environment with a humidifier, an electric pressure cooker or a sprayer, etc. in operation.
- The dust concentration may be high continuously when the product is used in a place where yellow dust is present, or outside air is introduced (for example, near a building air conditioner, an apartment ventilation system, or a window with a draft).
- Because the dust concentration values may differ in the same environment depending on measurement method, use the displayed values as a reference.
- The PM10, PM2.5 and PM1.0 concentration values displayed may differ from those measured by other company's instrument or product.
- The PM10, PM2.5 and PM1.0 concentration values displayed may be temporarily elevated in an environment affected by electromagnetic waves or electrical noises.



Electricity consumption check

For the multi system, this function is not supported.

Use the Usage function to check the amount of electricity consumed by using the air conditioner. The amount consumed is displayed on the indoor unit display for a few seconds, and the set temperature appears.



The value range displayed is between 0.1 kWh and 99 kWh. Electricity consumption is calculated from the moment the air conditioner turns on. The value is reset when the air conditioner turns off.


- The usage shown on the indoor unit display may slightly differ from the amount of electricity actually consumed.
- You can view electricity consumption only when the air conditioner is operating.



Usage time check

For the single system, this function is not supported.

Use the Usage time function to check the operation duration from the moment when the air conditioner is turned on to the moment when the Usage time function is selected. The usage time is displayed on the indoor unit display for a few seconds, and the set indoor temperature appears.



The usage time is displayed in units of hour. For example, 0.1 is equivalent to 6 minutes; 2.5, 2 hours and 30 minutes; 3.7, 3 hours and 42 minutes. The value range displayed is between 0.0 and 99. The value is reset when the air conditioner turns off.


NOTE

- The usage time shown on the indoor unit display may a little differ from the actual operation time of the air conditioner.
- You can view the usage time only when the air conditioner is operating.

Beep function

Use the Beep function to turn on or off the beep that sounds when you press a button on the remote control.





Auto clean function

Use the Auto clean function if the indoor unit produces odors.

Activating Auto clean

To activate Auto clean, press the ()) (Options) button for at least 3 seconds.

The indoor unit display shows:



If the air conditioner is off, Auto clean starts immediately. If the air conditioner is running, Auto clean starts as soon as the air conditioner turns off.

NOTE

• You can also activate Auto clean from the Options menu:



- Once Auto clean is selected, it is always activated whenever the air conditioner turns off.
- Auto clean runs for 10 to up to 30 minutes depending on internal dry conditions. The indoor unit display shows the cleaning progress from 1% to 99%.
- If you start another function while Auto clean is progressing, Auto clean pauses and will resume when the other function stops.
- When Auto clean completes, the air conditioner turns off.
- Auto clean does not run after Heat or Fan mode.

Canceling Auto clean

To cancel Auto clean while it is running, follow the procedure below:



NOTE

• Canceling Auto clean does not deactivate it.

Deactivating Auto clean

To deactivate Auto clean, follow the procedure below while the air conditioner is in operation or turned off:



Wash


Freeze Wash function


Use the Freeze Wash function to wash away microorganisms or dust on the surface of the indoor heat exchanger by freezing and thawing operation.

In operation stop condition,



- The Freeze Wash function runs from 30 to 80 minutes (running the outdoor unit) depending on either temperature or humidity in the room, through the following cycle:freezing → defrosting → drying of the indoor unit heat exchanger.
- The indoor unit display shows the cleaning progress (1-99 %).
- To use another function while in Wash operation, press the (Power) button on the remote control to stop operation.
- When the room temperature is low or its humidity is high, the Freeze Wash function may not work.
- Before finishing the Freeze Wash function, the airflow blade is closed and then the drying operation starts.
- During the Freeze Wash cycle, when you hear a creaking noise from the indoor unit: DON'T worry because it is normal and it can happen! it will disappear at the end of the cycle.
- The area around the indoor unit may appear blurred or condensation may form while the Freeze Wash function is in operation.
- You may see frost or water on the surface of the outdoor unit's valve while the Freeze Wash function is in operation.
- It is recommended to use the Wash function once every 2 weeks. Otherwise, dust or dirt that is difficult to be removed may accumulate in the heat exchanger.





Display lighting function

Use the Display lighting function to turn on or off the lighting of the indoor unit display.



NOTE

- If you change the current mode or function when the Display lighting function is on, the display lighting turns on for 5 seconds and then turns off again.
- To turn off the Display lighting function, run the method above again or turn the product off and on.

Wi-Fi function (SmartThings app)

Turn on the Wi-Fi function to pair your smartphone with the air conditioner.

Timer 🕨 Press an


Press and hold for 5 or more seconds.

NOTE

• When you turn on the Wi-Fi function, your smartphone pairs with


the air conditioner, the $\widehat{\text{m}}$ (Transmit) indicator blinks, and \mathbb{RP} appears on the remote control display for a few seconds.

- Once your smarphone is connected with the air conditioner, you can control it via the wireless Internet using the SmartThings app installed on your smartphone.
- For more information about how to prepare your smartphone for connection and how to control the air conditioner using the SmartThings app, see "SmartThings app" on page 47.
- To turn on or off the Wi-Fi, press and hold (C) (Options) and SET (SET) for 5 seconds.
 - In order to launch the SmartThings app, press and hold the (Time) (Timer) button for 5 seconds, which enables to connect the air conditioner.




Timed on/ Timed off function

Use the Timed on/off function to turn the air conditioner on or off after a duration. Scheduling durations before the air conditioner turns on or off helps use the air conditioner economically.



- To cancel the Timed on/off function, set the duration to 0.0.
- When you start the Timed on/off function, the () (Timer) indicator appears on the indoor unit display.
- You can set the duration to from 0.5 hours to 24 hours.
- You cannot set the same duration for both Timed on and Timed off functions.

Combining Timed on and Timed off			
When the air conditioner is off	Example: Timed on 3 hours, Timed off 5 hours The air conditioner turns on 3 hours after the last time you press the $\frac{SET}{VPLM}$ (SET) button to start the Timed on/off function, remains on for 2 hours, then turns off again.		
When the air conditioner is on	Example: Timed on 3 hours, Timed off 1 hour The air conditioner turns off 1 hour after the last time you press the SET Timed on/off function, remains off for 2 hours, then turns on again.		



good'sleep function

Use the good'sleep function to save energy while you are sleeping. You can select this function in Cool or Heat mode.




- To cancel the good'sleep function, set the duration to 0.0.
- When you start the good'sleep function, the 🕒 (Timer) indicator appears on the indoor unit display.
- You can set the duration to from 0.5 hours to 12 hours.
- The recommended set temperatures while the good'sleep function is on are:

Mode	Recommended set temperature	Optimal set temperature
Cool	25 °C to 27 °C	26 °C
Heat	21 °C to 23 °C	22 °C

- The good'sleep function can operate while the WindFree Cooling function is on.
- Selecting the good'sleep function cancels Eco, Fast, and Quiet functions.

Task	How often	By whom	Instruction
Run the Auto clean function.	As needed	Owner	"Auto clean function" on page 31.
Run the Freeze Wash function.	Once every two weeks	Owner	"Freeze Wash function" on page 33.
Clean the filter.	Once every two weeks	Owner	"Cleaning the filter" on page 40.
Cleaning the PM 1.0 filter	Once every 3 months	Owner	"Cleaning the PM 1.0 filter" on page 41.
Clean the WindFree panel	At least once a month	Owner	"Cleaning the WindFree panel" on page 42.
Clean the exterior of the indoor unit.	As needed	Owner	"Cleaning the outside of the indoor unit" on page 38.
Clean the exterior of the outdoor unit.	At least once a year	Owner	"Cleaning the heat exchanger on the outdoor unit" on page 38.
Replace the remote control batteries	As needed	Owner	"Replacing the remote control batteries" on page 17.
Apply corrosion inhibitor on outdoor unit. (Only if installed near salt water such as an ocean)	At least once a year	Qualified technician	Contact your service provider.
Clean inside the indoor or outdoor unit.	Once a year	Qualified technician	Contact your service provider.
Inspect the units, electrical connections, refrigerant tubes, and protections.	Once a year	Qualified technician	Contact your service provider.



Cleaning the outside of the indoor unit

- 1 Turn off the air conditioner and wait until the fan stops.
- 2 Disconnect the power supply.
- **3** Use a soft brush or tepid damp cloth to clean the exterior.

🕂 WARNING

• Do not clean the appliance by spraying water directly onto it. Water entering the unit may result in electric shock or fire that could cause death, serious injury, or property damage:

A CAUTION


- Do not use an alkaline detergent to clean the indoor unit display.
- Do not use sulphuric acid, hydrochloric acid, or organic solvents such as paint thinner, kerosene, acetone, benzene, or alcohol to clean the unit surfaces.


Cleaning the heat exchanger on the outdoor unit


- 1 Turn off the air conditioner and wait until the fan stops.
- 2 Disconnect the power supply.
- **3** Spray water on the heat exchanger to remove dust and other debris.

AUTION

- Do not use sulphuric acid, hydrochloric acid, or organic solvents such as paint thinner, kerosene, acetone, benzene, or alcohol to clean the unit surfaces.
- If you need to inspect or clean the inside of the heat exchanger on the outdoor unit, contact a local service centre for help.







Cleaning the sensors


If dust or foreign substances develop on a sensor, it may detect high dust concentration. Use a vacuum cleaner to clean the sensor and its surrounding area.

- Do not put any dust into the sensor openings.
- Open the indoor unit cover, fix the support, and wipe the sensors with a cotton swab.

Cleaning

Cleaning the filter

Clean the air filter every two weeks or when the **[** F (filter-cleaning reminder) appears on the indoor unit display. The time between cleanings may vary, depending on the usage and environmental conditions.




- 1 Slide the filter off of the unit.
- 2 Use a soft brush or vacuum cleaner to remove any dust or debris on the filter.
- 3 Soak the filter in a solution of water and mild detergent for 30 minutes.
- 4 Rinse the filter and let it air dry in a well-ventilated area that is out of direct sunlight.
- 5 Reinstall the filter.
- 6 Reset the filter-cleaning reminder:



- Take care not to damage the filter during cleaning.
- Do not scrub the air filter with a hard-bristle brush or another cleaning utensil.
- Do not expose the air filter to direct sunlight when drying it.

Cleaning the PM 1.0 filter

Clean the PM 1.0 filter every 3 months. The time between cleanings may vary, depending on the usage and environmental conditions.



A CAUTION

- Unplug the power plug for safety when cleaning PM 1.0 filter.
- The inside surface of the PM 1.0 filter is sharp. Be careful not to cut your hand.
- When cleaning the PM 1.0 filter, do not disassemble it.

NOTE


- If the filter is very dirty, immerse the filter in the water in which a neutral detergent is dissolved for 30 minutes, then rinse the filter until it is not dirty.
- Dry the PM 1.0 filter completely by leaning vertically against the wall avoiding the direct sunlight in the shade for 12 hours.



To close the cover, pull stopper frontward.

Cleaning the WindFree panel

Clean the WindFree panel at least once a month.



- 1 Pull the airflow blade open.
- 2 Hold and pull both sides of the WindFree panel until it comes free from the air conditioner.
- 3 Use a soft brush or vacuum cleaner to remove any dust.
- 4 Hang the WindFree panel in the grooves at the bottom left and right.
- 5 Align the projections of the WindFree panel with the grooves at the top, middle, and bottom of the front panel.
- 6 After inserting the WindFree panel, press the top 4 places and the bottom 3 places by hand so that there is no gap to the panel.

• If you attach the WindFree panel without the airflow blade being open, it may become obstructed by the WindFree panel and may not open properly.

Troubleshooting

If the air conditioner is not operating normally, refer to the troubleshooting guide below.

Problem	Solution
The air conditioner stops working.	 Make sure the unit is receiving power. Check the circuit breaker. If it is flipped off, flip it on again and restart the unit. If the problem persists, contact your service provider. The Timed off function may have turned off the unit. Turn on the unit again.
Cannot change the temperature.	 Check if the unit is in Fan or Fast mode. If so, you cannot change the set temperature; the unit automatically controls the set temperature.
Improper airflow temperature.	 Check the set temperature. In Cool mode, cooling occurs only when the set temperature is lower than the current temperature. In Heat mode, heating occurs only when the set temperature is higher than the current temperature. Use the (Temperature) button on the remote control to change the set temperature. Check if the air filter is blocked with dirt or debris. If the air filter is blocked, the cooling and heating performance may decrease. Clean the air filter regularly (page 40). Check if the outdoor unit is covered or is installed near obstacles. Remove the coverings and obstacles. Check if the Defrost function is on (page 24). During defrost, the fan stops and warm air does not come out. Check if doors or windows are open. This may cause poor circulation or performance. Close all doors and windows. Check if the pipe length between the units exceeds the maximum pipe length (see "Typical installation" in the Installation manual). If so, the cooling and heating performance may decrease.
Cannot change the airflow direction.	 Check if the good'sleep function is on in Cool mode. If so, you cannot control the airflow direction.
Cannot change the fan speed.	• Check if the unit is in Auto, Dry, or Fast mode or the good'sleep function is on in Cool mode. In these conditions, you cannot control the fan speed; the unit automatically controls the fan speed.

Problem	Solution
The remote control does not work.	 Replace the batteries in the remote control. Make sure the remote control can send an unobstructed signal to the unit. Keep bright lights away from the unit. Light from fluorescent bulbs or neon signs may interrupt the signal from the remote control.
The Timed on/off function does not work.	 Make sure to press the SET (SET) button on the remote control when setting the timer.
The indicator on the remote control blinks continuously.	 Press the (b) (Power) button to turn off the unit, or disconnect the power plug. If the indicator light on the remote control continues blinking, contact your service provider.
Odors are coming from the unit during regular operation.	 If the unit is operating in a smoky area, ventilate the room or operate the unit in Fan mode for 3 to 4 hours. There are no components in the unit that produce a strong odor. Check if the drain lines are clean. Clean them regularly.
The remote control display shows an error message.	 If the indoor unit indicator blinks, write down the error code. Contact your service provider and provide them with the error code.
The unit is generating noise.	• It is normal for the unit to generate some noise while operating. If the pipe length between the units is less than 3 m and no coil was used (see "Typical installation" in the Installation manual), additional noise may be transmitted from the outdoor unit to the indoor unit via the piping.
Smoke is coming from the outdoor unit.	 In winter, most likely this is steam coming from the outdoor heat exchanger while the Defrost function is on.
Water drips from the pipe connections on the outdoor unit.	 Condensation may develop when the ambient temperature or humidity changes significantly. This is normal.
Condensation forms on the surface of the indoor unit.	 If the humidity is higher in the room in Cool mode, or the difference between the desired temperature and indoor temperature is great, condensation may form on the surface of the indoor unit.

Problem	Solution
The cleanliness colour indicator continuously lights up in red. (The cleanliness indications are strange.)	 Check the sensors for any foreign substances and clean them if necessary. If you have followed all the solutions presented in this section and the cleanliness colour indicator lights up in red for a long time, it might be a problem with the sensor. Contact a Samsung Service Centre. When the product is used in a place where a humidifier, an electric pressure cooker, a sprayer, etc. is operating, the cleanliness may be indicated as Poor.
The fan speed does not change according to cleanliness.	• Set the fan speed to Auto. The fan speed does not change automatically when it is set to Turbo, Low, Med, or High.
The PM10, PM2.5, PM1.0 concentration values do not change from the Good (05) level.	• The dust concentration may continue to be at the Good level in an enclosed space.

Information about Refrigerant

Important information: regulation regarding the refrigerant used.

This product contains fluorinated greenhouse gases. Do not vent gases into the atmosphere.

If the system contains 5 tCO₂e or more of fluorinated greenhouse gases, it must be checked for leakage at least once every 12 months, according to regulation No. 517/2014. This activity must be covered by qualified personnel only. In the case of the situation above, the installer (or authorized person with responsibility for final check) must provide a maintenance book, with all the information recorded, according to REGULATION (EU) No. 517/2014 OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 16 April 2014 on fluorinated greenhouse gases.

Refrigerant type	GWP value
R-32	675

- GWP: Global Warming Potential
- Calculating tCO₂e: kg x GWP/1000

SmartThings app

The SmartThings app may change without prior notice to improve product usability and performance.

Use the SmartThings app on your smartphone to control the air conditioner via the wireless Internet.

To remotely control the air conditioner, you need to connect your smartphone to the air conditioner. If already connected, skip to "Step 6. Controlling the air conditioner with your smartphone" on page 48.

Step 1. Checking the requirements for connection

Before connecting your smartphone with the air conditioner, make sure that the following requirements are met:

- Wi-Fi access point: 2.4 GHz Wi-Fi access point only
- The air conditioner and you smartphone must be within the coverage of the same Wi-Fi access point and connected to it. After the connection, you can control the air conditioner from any place via various wireless networks such as Wi-Fi, 3G, LTE and 5G.
- The SmartThings app supports Android OS 7.0 or later (with at least 2 GB RAM) and iOS 12.0 or later. The app is optimized for iPhone 6s or later and Samsung smartphones (Galaxy S and Note series). The updates of the SmartThings app or the functions supported by it may be discontinued for the previously supported OS versions due to the reasons such as usability and security.

Step 2. Connecting your smartphone to the Wi-Fi network

- 1 Turn on the Wi-Fi access point.
- 2 Tap Settings \rightarrow Wi-Fi on your smartphone.
- **3** Tap the **Wi-Fi** switch to activate it, and then select the 2.4 GHz Wi-Fi access point to connect to.
- 4 If needed, enter the password for the access point.
- 5 Tap Advanced.
- 6 Top the Switch to mobile data switch to deactivate it.

Step3. Installing the SmartThings app

If the SmartThings app is not installed on your smartphone, follow the procedure below. If installed, skip to "Step 4. Configuring the SmartThings app" on page 47.

- 1 Launch Play Store or App Store.
- 2 Tap the search field, and then search for "SmartThings".
- **3** Tap **INSTALL** for the found SmartThings app item.
- 4 Select Agree.

Step 4. Configuring the SmartThings app

After the SmartThings app is installed, follow the procedure below to configure it. If already configured, skip to "Step 5. Connecting your smartphone to the air conditioner" on page 48.

- 1 Launch the SmartThings app.
- 2 When you see pop-up windows asking for location, Wi-Fi, Bluetooth permissions, tap Start.
- 3 Tap Sign In.
- 4 Sign in to your Samsung account.
- If you have no Samsung account, create your Samsung account.
- 5 Consent to TERMS AND CONDITIONS.
- 6 When you see a pop-up window asking for access permission to location information, tap ALLOW.

Step 5. Connecting your smartphone to the air conditioner

- 1 Plug in the power cord of the air conditioner, and then turn on the power.
- 2 Launch the SmartThings app.
- **3** Tap **Add device** on the home screen of the SmartThings app.
- 4 Tap Samsung Air conditioner > Room air conditioner.
- Press the Timer (Timer) button on the remote control for at least 4 seconds.

To notify that registration of the selected air conditioner to your Samsung account is in progress, the ((Transmit)) indicator blinks for several seconds and (P) appears on the remote control display. When the connection is finished, the ((Transmit)) indicator turns off and (P) disappears. A new device card for the selected air conditioner is added to the home screen of the SmartThings app.

Step 6. Controlling the air conditioner with your smartphone

- 1 Launch the SmartThings app.
- 2 On the home screen of the SmartThings app, tap the device card for the air conditioner, which was added when you proceeded with "Step 5. Connecting your smartphone to the air conditioner" on page 48.
- **3** Refer to the table on the next page and remotely control the air conditioner with your smartphone.

/ WARNING

- RF exposure warning statement for keeping 20cm distance when installing this module.
- Warning that this module should not be installed and operating simultaneously with other radio without additional evaluation or FCC filing.

- Instruction for host system labeling, the host system should have proper label showing that it "Contains FCC ID : A3LSWL-B70F"
- Your device uses non-harmonised frequency and is intended for use in all European countries. The WLAN can be operated in the EU without restriction indoors, but cannot be operated outdoors in France.

Specifications

Wi	-Fi
Frequency Range	Transmitter Power(Max)
2412 - 2472 MHz	20 dBm

Open Source Announcement

The software included in this product contains open source software. You may obtain the complete corresponding source code for a period of three years after the last shipment of this product by contacting our support team via http://opensource.samsung. com (Please use the "Inquiry" menu.)

It is also possible to obtain the complete corresponding source code in a physical medium such as a CD-ROM; a minimal charge will be required.

The following URL http://opensource.samsung.com/ opensource/SMART_AT_051/seq/0 leads to the open source license information as related to this product. This offer is valid to anyone in receipt of this information.



Category	Function	Description
Manitaring	Set temperature	Displays the set temperature.
Monitoring	Current temperature	Displays the current temperature.
	Power	Turns the air conditioner on or off.
	Mode	Selects the desired operation.
	Temperature	Adjusts the indoor set temperature.
	Fan Speed	Sets the fan speed of operation mode.
	Wind direction	Sets the fan directions of operation mode.
	WindFree Cooling	Turns the WindFree Cooling function on or off.
		Sets the Timed on/off function.
	Schedule	 The maximum number of schedules you can set using the Timed on/off function is 10.
		 The set times for the Timed on and Timed off functions must be different.
Control		• Once the Timed on/off function is set, the setting remains even if you unplug the air conditioner and plug in it again.
		Selects an option function of operation mode.
		• The available options might be different depending on the air conditioner model.
		 The fan speed and airflow direction are set automatically according to the selected options.
		• For detailed information on the options of the product, see page 20 ~ 34.
		Sets additional functions.
	Calling	 Press the Settings button on the control screen to check or set detailed information of air conditioner.
	Settings	• The functions of Clean, Filter, and Beep can be set.
		 When the Beep function is off, the beep sound from the device will be mute.

Reference

English	Hereby, Samsung declares that this radio equipment is in compliance with Directive 2014/53/ EU and with the relevant statutory requirements in the UK. The full text of the EU declaration of conformity and the UK declaration of conformity is available at the following internet address: The official Declaration of conformity may be found at http://www.samsung.com, go to Support > Search Product Support and enter the model name.
Czech	Společnost Samsung tímto prohlašuje, že toto radiové zařízení splňuje požadavky směrnice 2014/53/EU a příslušné požadavky právních norem platných ve Spojeném království. Úplné znění EU Prohlášení o shodě a UK Prohlášení o shodě je k dispozici na následující internetové adrese: Oficiální prohlášení o shodě naleznete na webu http://www.samsung.com, kde klepněte na odkaz Podpora a do pole Hledat Podporu zadejte název modelu.
Danish	Samsung erklærer hermed, at dette radioudstyr er i overensstemmelse med direktiv 2014/53/EU og med relevante lovmæssige krav i Storbritannien. Hele teksten i EU- overensstemmelseserklæringen og UK-overensstemmelseserklæringen findes på denne webadresse: Den officielle overensstemmelseserklæring kan findes på http://www.samsung. com. Gå til support > Søg efter produktsupport, og angiv modelnavnet.
German	"Samsung erklärt hiermit, dass diese Funkanlage mit der Richtlinie 2014/53/EU und den entsprechenden gesetzlichen Anforderungen im Vereinigten Königreich übereinstimmt. Der gesamte Text der EU-Konformitätserklärung und der Konformitätserklärung für das Vereinigte Königreich ist unter der folgenden Internetadresse verfügbar: Die offizielle Konformitätserklärung ist unter http://www.samsung. com zu finden. Gehen Sie zu Support > Produktsupport durchsuchen und geben Sie den Modellnamen ein."
Estonian	Samsung kinnitab käesolevaga, et antud raadioseade vastab direktiivile 2014/53/EL ja asjakohastele seadusjärgsetele nõuetele Suurbritannias. EL-i vastavusdeklaratsiooni ja Suurbritannia vastavusdeklaratsiooni terviktekst on saadaval internetis järgmisel aadressil: Ametliku vastavusdeklaratsiooni leiate aadressilt http://www.samsung.com, avage menüü Tugi > Otsi toote tuge ja sisestage seejärel mudeli nimi.
Spanish	Por la presente, Samsung declara que este equipo radioeléctrico cumple con la Directiva 2014/53/UE y con los requisitos legales relevantes en el Reino Unido. El texto completo de la declaración de conformidad con la UE y de la declaración de conformidad con Reino Unido está disponible en la siguiente dirección de Internet: La Declaración de conformidad oficial se puede encontrar en http://www.samsung.com, vaya a soporte > Búsqueda de soporte de productos e introduzca el nombre del modelo.
Greek	Συνεπώς, η Samsung δηλώνει ότι αυτός ο ραδιοεξοπλισμός συμμορφώνεται με την Οδηγία 2014/53/ΕΕ και με τις σχετικές νόμιμες απαιτήσεις του Ηνωμένου Βασιλείου. Το πλήρες κείμενο της δήλωσης συμμόρφωσης με την ευρωπαϊκή οδηγία και της δήλωσης συμμόρφωσης με τη βρετανική νομοθεσία είναι διαθέσιμο στη διεύθυνση: Μπορείτε να βρείτε την επίσημη δήλωση συμμόρφωσης στην τοποθεσία http://www.samsung.com. Επιλέξτε Υποστήριξη > Αναζήτηση υποστήριξης προϊόντος και εισαγάγετε το όνομα μοντέλου.

French	Par la présente, Samsung déclare que cet équipement radio est conforme à la directive 2014/53/UE et aux exigences réglementaires applicables au Royaume-Uni. Le texte intégral de la déclaration de conformité de l'UE et de la déclaration de conformité du Royaume-Uni est disponible à l'adresse Internet suivante : La Déclaration officielle de conformité se trouve sur http://www.samsung.com, rendez-vous sur la page d'assistance > Rechercher dans l'Assistance et saisissez un nom de modèle.
Italian	Con la presente, Samsung dichiara che questa apparecchiatura radio è conforme alla Direttiva 2014/53/UE e ai relativi requisiti di legge nel Regno Unito. Il testo integrale della dichiarazione di conformità EU e del Regno Unito è disponibile al seguente indirizzo: La dichiarazione ufficiale di conformità è disponibile su http://www.samsung.com, selezionare supporto> Cerca Supporto Prodotto e inserire il nome del modello.
Latvian	Ar šo uzņēmums Samsung paziņo, ka šī radioiekārta atbilst Direktīvai 2014/53/ES un attiecīgajām likumiskajām prasībām Apvienotajā Karalistē. Pilns ES atbilstības deklarācijas teksts un Apvienotās Karalistes atbilstības deklarācijas teksts ir pieejams šajā interneta adresē: Oficiālo atbilstības deklarāciju var atrast vietnē http://www.samsung.com, atverot Atbalsts > Meklēt produkta atbalstu un ievadot modeļa nosaukumu.
Lithuanian	Šiuo dokumentu "Samsung" patvirtina, kad radijo įranga atitinka 2014/53/ES direktyvos reikalavimus ir JK susijusius įstatyminius reikalavimus. Visą ES atitikties deklaracijos ir JK atitikties deklaracijos tekstą rasite apsilankę internetinėje svetainėje adresu: Oficiali atitikties deklaracija pateikiama svetainėje http://www.samsung.com, eikite į skirtuką Palaikymas > leškoti gaminio palaikymo ir įveskite modelio numerį.
Dutch	Samsung verklaart hierbij dat deze radioapparatuur voldoet aan Richtlijn 2014/53/ EU en aan de relevante statutaire vereisten in het VK. De volledige tekst van de EU- Conformiteitsverklaring en de conformiteitsverklaring van het VK vindt u op deze website: De officiële Conformiteitsverklaring vindt u op http://www.samsung.com, ga naar Ondersteuning > Productondersteuning zoeken en voer de modelnaam in.
Hungarian	A Samsung ezennel kijelenti, hogy ez a rádióberendezés megfelel a 2014/53/EU irányelvnek és az Egyesült Királyságban a vonatkozó jogszabályi követelményeknek. Az EU megfelelőségi nyilatkozat és az Egyesült Királyság megfelelőségi nyilatkozat teljes szövege a következő internet cím alatt található: A hivatalos Megfelelőségi nyilatkozat a http://www.samsung.com honlapon olvasható, lépjen a Támogatás > Terméktámogatás keresése menüpontra, és adja meg a modell nevét.
Polish	Niniejszym firma Samsung deklaruje, że ten sprzęt radiowy jest zgodny z wymogami dyrektywy 2014/53/UE oraz odnośnych ustaw obowiązujących w Wielkiej Brytanii. Pełny tekst deklaracji zgodności z przepisami europejskimi i brytyjskimi jest dostępny na stronie internetowej: Treść oficjalnej deklaracji zgodności jest dostępna pod adresem http://www. samsung.com w menu Wsparcie > Szukaj, gdzie należy podać nazwę modelu.
Portuguese	A Samsung declara, pelo presente, que este equipamento de rádio está em conformidade com a Diretiva 2014/53/UE e com os requisitos legais relevantes no Reino Unido. O texto integral da declaração de conformidade europeia e da declaração de conformidade do Reino Unido está disponível no seguinte endereço da Internet: A Declaração de conformidade oficial pode ser encontrada em http://www.samsung.com, vá a Suporte > Pesquisar Suporte do produto e insira o nome do modelo.

Reference

Slovenian	Družba Samsung izjavlja, da je ta radijska oprema v skladu z Direktivo 2014/53/EU in ustreznimi zakonskimi zahtevami v Združenem kraljestvu. Celotno besedilo izjave ES o skladnosti in izjave Združenega kraljestva o skladnosti je na voljo na spodnjem internetnem naslovu: Uradno izjavo o skladnosti lahko najdete na naslovu http://www.samsung.com. Pojdite na podporo > Iskanje podpore za izdelek, nato vnesite ime izdelka.
Slovak	Spoločnosť Samsung týmto vyhlasuje, že toto zariadenie rádiového typu je v súlade so smernicou 2014/53/EÚ a náležitými zákonnými požiadavkami v Spojenom kráľovstve. Celé znenie Vyhlásenia o zhode v EÚ a Vyhlásenia o zhode v Spojenom kráľovstve je k dispozícii na nasledujúcej internetovej adrese: Oficiálne Vyhlásenie o zhode sa nachádza na lokalite http://www.samsung.com, prejdite na položky Podpora > Vyhľadávanie podpory produktov a zadajte názov modelu.
Finnish	Samsung vakuuttaa, että tämä radiolaite on direktiivin 2014/53/EU ja Yhdistyneen kuningaskunnan oleellisten lakisääteisten vaatimusten mukainen. EU-vaatimustenmukaisuusvakuutuksen ja Yhdistyneen kuningaskunnan vaatimustenmukaisuusvakuutuksen koko teksti on saatavilla seuraavassa Internet-osoitteessa: Virallinen vaatimustenmukaisuusvakuutus on osoitteessa http://www.samsung. com. Valitse Tuki > Etsi tuotetukea ja kirjoita mallinimi.
Swedish	Härmed deklarerar Samsung att denna radioutrustning uppfyller direktivet 2014/53/EU och de relevanta lagstadgade kraven i Storbritannien. Den fullständiga texten i EU-deklarationen om överensstämmelse och Storbritanniens deklaration om överensstämmelse finns tillgänglig på följande internetadress: Den officiella deklarationen om överensstämmelse finns på http:// www.samsung.com. Gå till stöd > Sök produktsupport och ange modellnamnet.
Bulgarian	С настоящото Samsung gekлapupa, че това радиооборудване е в съответствие с Директива 2014/53/ЕС и със съответните законови изисквания в Обединеното кралство. Пълният текст на ЕС Декларацията за съответствие и Декларацията за съответствие за Обединеното кралство е наличен на следния интернет адрес: Официалната Декларация за съответствие можете да намерите на http://www.samsung. com, omugeme на omugeme на поддръжка > Търсене на поддръжка за продукт и въведете името на модела.
Romanian	Prin prezenta, Samsung declară faptul că acest echipament radio respectă Directiva 2014/53/UE și toate cerințele legale relevante din Regatul Unit. Textul complet al declarației de conformitate UE și al declarației de conformitate din Regatul Unit este disponibil la următoarea adresă de internet: Declarația de conformitate oficială poate fi găsită la http://www.samsung.com, accesați asistența > Căutați asistența produsului și introduceți numele modelului.
Norwegian	Samsung erklærer herved at dette radioutstyret er i samsvar med direktiv 2014/53/EU og med de relevante lovpålagte kravene i Storbritannia. Den fullstendige teksten til EU- samsvarserklæringen og den britiske samsvarserklæringen er tilgjengelig på følgende nettadresse: Den offisielle samsvarserklæringen finnes på http://www.samsung.com. Gå til Support > Søk gjennom produktsupport og angi modellnavn.
Turkish	Samsung, bu radyo ekipmanının 2014/53/AB Direktifi ve Birleşik Krallık'taki ilgili yasal gerekliliklere uygun olduğunu beyan eder. AB uygunluk beyanının ve Birleşik Krallık uygunluk beyanının tam metni aşağıdaki internet adresinde mevcuttur: Resmî Uygunluk beyanını http:// www.samsung.com adresinde bulabilirsiniz. Destek > Ürün Desteği Ara'ya gidin ve model adını girin.

Russian	Настоящим компания Samsung заявляет, что данное радиооборудование соответствует Директиве 2014/53/ЕС и соответствующим требованиям законодательства Великобритании. Полный текст декларации о соответствии ЕС и декларации о соответствии Великобритании доступен по следующему веб-адресу: Официальная Декларация о соответствии доступна по адресу http://www.samsung.com, пройдите в раздел Поддержка > Поиск продукта и введите имя модели.
Ukrainian	Цим компанія Samsung заявляє, що це радіообладнання відповідає вимогам Директиви 2014/53/ ЄС і відповідним законодавчим нормам Великобританії. Повний текст декларації про відповідність нормам країн ЄС і Великобританії доступний за такою адресою в інтернеті: Офіційний текст Декларації про відповідність можна знайти на сайті http://www.samsung.com; перейдіть до розділу підтримки, потім — до поля пошуку підтримки для певного виробу та введіть назву моделі.
Serbian	Kompanija Samsung ovim izjavljuje da je ova radio oprema u skladu sa direktivom 2014/53/EU i sa odgovarajućim zakonskim zahtevima u UK. Kompletan sadržaj deklaracija o usaglašenosti za EU i UK dostupan je na sledećoj internet adresi: Zvaničnu deklaraciju o usaglašenosti možete naći na adresi http://www.samsung.com, idite na Podrška > Pretraga podrške za proizvode i unesite naziv modela.
Croatian	Ovime Samsung izjavljuje da je ova radijska oprema usklađena s Direktivom 2014/53/EU i relevantnim uvjetima propisanim zakonom u Ujedinjenoj Kraljevini. Potpuni tekst EU deklaracije o sukladnosti te UK deklaracije o sukladnosti dostupan je na sljedećoj internetskoj adresi: Službenu Izjavu o sukladnosti možete pronaći na adresi http://www.samsung.com, ako odaberete Podrška > Traži podršku za proizvod i unesete naziv modela

SAMSUNG

QUESTIONS OR COMMENTS?

UK 0330 SAMSUNG (7267864) www.samsung.com/uk/sup IRELAND (EIRE) 0818 717100 www.samsung.com/ie/sup GERMANY 06196 77 555 77 www.samsung.com/de/sup FRANCE 01 48 63 00 0 www.samsung.com/fr/sup ITALIA 800-SAMSUNG (800.7267864) www.samsung.com/fr/sup SPAIN 91175 00 15 www.samsung.com/es/sup PORTUGAL 808 207 267 www.samsung.com/be_fr/sup LUXEMBURG 261 03 710 www.samsung.com/be_fr/sup NETHERLANDS 088 90 90 100 www.samsung.com/be_fr/suppor BELGIUM 02-201-24-18 www.samsung.com/be_fr/suppor NORWAY 21629099 www.samsung.com/cb/suppor DENMARK 707 019 70 www.samsung.com/dk/sup FINLAND 030-6227 515 www.samsung.com/fi/supj SWEDEN 0771 726 786 www.samsung.com/fi/supj POLAND 801-172-678* tub +48 22 607-93-33* http://www.samsung.com/lu/sup HUNGARY 06805AMSUNG (0680-726-7864) www.samsung.com/lu/sup AUSTRIA 0800 72 67 86 (0800 - SAMSUNG) www.samsung.com/ch_f/support </th <th>port port port port port port port port</th>	port port port port port port port port
GERMANY 06196 77 555 77 www.samsung.com/de/sup FRANCE 01 48 63 00 00 www.samsung.com/fr/sup ITALIA 800-SAMSUNG (800.7267864) www.samsung.com/fr/sup SPAIN 91 175 00 15 www.samsung.com/e/s/sup PORTUGAL 808 207 267 www.samsung.com/le/s/sup LUXEMBURG 261 03 710 www.samsung.com/le/s/sup LUXEMBURG 02-201-24-18 www.samsung.com/le/support BELGIUM 02-201-24-18 www.samsung.com/le/support DENMARK 707 019 70 www.samsung.com/le/support SWEDEN 0771 726 786 www.samsung.com/le/support SWEDEN 0771 726 786 www.samsung.com/le/support HUNGARY 06805AMSUNG (0680-726-7864) www.samsung.com/le/support WUTZERLAND 0800 72 67 86 (0800-5AMSUNG) www.samsung.com/le/support SWITZERLAND 0800 72 67 86 (0800-5AMSUNG) www.samsung.com/le/support SWITZERLAND 0800 72 67 86 (0800-5AMSUNG) www.samsung.com/le/support SWITZERLAND 0800 726 786 (0800-726 786) www.samsung.com/le/support SUITZERLAND 0800 726 786 (0800-7	port port port port port port c (Dutch) t (French)
FRANCE 01 48 63 00 00 www.samsung.com/fr/sup ITALIA 800-SAMSUNG (800.7267864) www.samsung.com/it/sup SPAIN 91 175 00 15 www.samsung.com/es/sup PORTUGAL 808 207 267 www.samsung.com/bc/sup LUXEMBURG 261 03 710 www.samsung.com/bc/sup LUXEMBURG 0261 03 710 www.samsung.com/bc/support WETHERLANDS 088 90 90 100 www.samsung.com/bc/support BELGIUM 02-201-24-18 www.samsung.com/bc/support NORWAY 21629099 www.samsung.com/lo/sup DENMARK 707 019 70 www.samsung.com/lo/sup SWEDEN 0771 726 786 www.samsung.com/lo/sup POLAND 030-6227 515 www.samsung.com/lo/sup BUST172-678* lub +48 22 607-93-33* specjalistyczna infolinia do obsługi zapytań http://www.samsung.com/lo/sup AUSTRIA 0800 726 786 (0800-SAMSUNG) www.samsung.com/lo/sup www.samsung.com/lo/sup BUINGARY 06805AMSUNG (0608-726-7864) www.samsung.com/lo/support www.samsung.com/lo/support SWITZERLAND 0800 726 786 (0800-SAMSUNG) www.samsung.com/ch_fr/support	port port port port port c (Dutch) t (French)
ITALIA 800-SAMSUNG (800.7267864) www.samsung.com/it/sup SPAIN 91175 00 15 www.samsung.com/es/sup PORTUGAL 808 207 267 www.samsung.com/be/sup LUXEMBURG 261 03 710 www.samsung.com/be_fr/sup NETHERLANDS 088 90 90 100 www.samsung.com/be_fr/support WWW.Samsung.com/be/support www.samsung.com/be/support www.samsung.com/be/support NORWAY 21629099 www.samsung.com/ck/sup DENMARK 707 019 70 www.samsung.com/ck/sup FINLAND 030-6227 515 www.samsung.com/se/sup SWEDEN 0771726 786 www.samsung.com/se/sup POLAND 801-172-678* tub +48 22 607-93-33* http://www.samsung.com/pl/s * (opłata według taryfy operatora) http://www.samsung.com/hu/sup HUNGARY 06805AMSUNG (0680-726-7864) www.samsung.com/hu/sup SWITZERLAND 0800 726 786 (0800-SAMSUNG) www.samsung.com/ch/support SWITZERLAND 0800 726 786 (0800-726 786) www.samsung.com/ck/sup CZECH 800 - SAMSUNG (0800-726 786) www.samsung.com/ck/sup SULVAKIA 0800 - SAMSUNG (0800	port port port pport port (Dutch) rt (French)
SPAIN91175 00 15www.samsung.com/es/supPORTUGAL808 207 267www.samsung.com/pt/supLUXEMBURG261 03 710www.samsung.com/be_fr/supNETHERLANDS088 90 90 100www.samsung.com/los_pt/supBELGIUM02-201-24-18www.samsung.com/be/supportNORWAY21629099www.samsung.com/be/fr/supportDENMARK707 019 70www.samsung.com/dk/supFINLAND030-6227 515www.samsung.com/ks/supSWEDEN0771 726 786www.samsung.com/se/supPOLAND801-172-678* lub +48 22 607-93-33*http://www.samsung.com/ks/supMUNGARY0680SAMSUNG (0680-726-7864)www.samsung.com/hu/supAUSTRIA0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/supportSWITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/supportSUITZERLAND0800 - SAMSUNG (0800-726 786)www.samsung.com/ch/supportSUOVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ch/supportMONTENEGRO020 405 888www.samsung.com/supp	port port pport port (Dutch) rt (French)
PORTUGAL808 207 267Numerating com/bc/supLUXEMBURG261 03 710www.samsung.com/bc_fr/supNETHERLANDS088 90 90 100www.samsung.com/bc_fr/supportBELGIUM02-201-24-18www.samsung.com/bc/supportNORWAY21629099www.samsung.com/bc/supportDENMARK707 019 70www.samsung.com/dk/supFINLAND030-6227 515www.samsung.com/dk/supSWEDEN0771 726 786www.samsung.com/se/supPOLAND801-172-678* lub +48 22 607-93-33*specjalistyczna infolinia do obsługi zapytań dotyczących telefonów komórkowych: 801-672-678*HUNGARY0680SAMSUNG (0680-726-7864)www.samsung.com/hu/supAUSTRIA0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support gSLOVAKIA0800 - SAMSUNG (0800-726786)SUITZERLAND0800 - SAMSUNG (0800-726786)www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/supBUITZERLAND0800 - SAMSUNG (0800-726786)www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support <br< td=""><td>port pport port (Dutch) rt (French)</td></br<>	port pport port (Dutch) rt (French)
LUXEMBURG261 03 710www.samsung.com/be_fr/suNETHERLANDS088 90 90 100www.samsung.com/log_fr/suBELGIUM02-201-24-18www.samsung.com/be_fr/supportNORWAY21629099www.samsung.com/be_fr/supportDENMARK707 019 70www.samsung.com/dk/supFINLAND030-6227 515www.samsung.com/dk/supSWEDEN0771 726 786www.samsung.com/fi/supjSWEDEN801-172-678* lub +48 22 607-93-33*www.samsung.com/pe/supPOLAND8001-72-678* lub +48 22 607-93-33*http://www.samsung.com/pl/sSpecjalistyczna infolinia do obsługi zapytań dotyczących telefonów komórkowych: 801-672-678* * (opłata według taryfy operatora)www.samsung.com/hu/supHUNGARY0680SAMSUNG (0680-726-7864)www.samsung.com/hu/supSWITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/support www.samsung.com/ch/support SUVAKIA0800 - SAMSUNG (800-726786)SLOVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ck/support www.samsung.com/ck/support Www.samsung.com/ck/support Www.samsung.com/ck/support Www.samsung.com/ch_fr/support Www.samsung.com/ch_fr/support Www.samsung.com/ck/support Www.samsung.com/ck/support Www.samsung.com/ck/support Www.samsung.com/ck/support Www.samsung.com/ck/support Www.samsung.com/ck/support Www.samsung.com/ck/support Www.samsung.com/ck/support Www.samsung.com/ck/support Www.samsung.com/ck/support Www.samsung.com/ck/support Www.samsung.com/ck/support 	pport port : (Dutch) rt (French)
NETHERLANDS088 90 90 100www.samsung.com/hl/supBELGIUM02-201-24-18www.samsung.com/be/supportNORWAY21629099www.samsung.com/be/supportDENMARK707 019 70www.samsung.com/dk/supFINLAND030-6227 515www.samsung.com/fi/supSWEDEN0771 726 786www.samsung.com/fi/supSWEDEN0771 726 786www.samsung.com/fi/supPOLAND801-172-678* lub +48 22 607-93-33*http://www.samsung.com/pl/sBULGRARY06805AMSUNG (0680-726-7864)www.samsung.com/pl/sHUNGARY06805AMSUNG (0680-726-7864)www.samsung.com/hu/supSWITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/supportSWITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/supportSUITZERLAND0800 726 786 (0800-726786)www.samsung.com/ch/supportSUITZERLAND0800 726 786 (0800-726 786)www.samsung.com/ch/supportSUITZERLAND0800 726 786www.samsung.com/ch/supportSUITZERLAND0800 726 786www.samsung.com/ch/supportSUITZERLAND0800 726 786	port (Dutch) rt (French)
BELGIUM02-201-24-18www.samsung.com/be/support www.samsung.com/be_fr/support www.samsung.com/be_fr/supportNORWAY21629099www.samsung.com/be_fr/supportDENMARK707 019 70www.samsung.com/dk/supFINLAND030-6227 515www.samsung.com/fi/supportSWEDEN0771 726 786www.samsung.com/fi/supportSWEDEN0771 726 786www.samsung.com/fi/supportPOLAND801-172-678* lub +48 22 607-93-33*http://www.samsung.com/se/supBULAND0801-172-678* lub +48 22 607-93-33*http://www.samsung.com/pl/sVery OLAND801-172-678* lub +48 22 607-93-33*http://www.samsung.com/pl/sMUNGARY0680SAMSUNG (0680-726-7864)www.samsung.com/pl/sMUNGARY0680SAMSUNG (0680-726-7864)www.samsung.com/hu/supAUSTRIA0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/supportSWITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch_fr/supportCZECH800 - SAMSUNG (800-726 786)www.samsung.com/ch_fr/supportSLOVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ck/supportBOSNIA072 726 786www.samsung.com/hr/supNorth Macedonia023 207 777www.samsung.com/mk/supMONTENEGRO020 405 888www.samsung.com/support	: (Dutch) rt (French)
BELGIUM02-201-24-18www.samsung.com/be_fr/supportNORWAY21629099www.samsung.com/no/supDENMARK707 019 70www.samsung.com/dk/supFINLAND030-6227 515www.samsung.com/fi/supSWEDEN0771 726 786www.samsung.com/fi/supSWEDEN00771 726 786www.samsung.com/se/supPOLAND801-172-678* lub +48 22 607-93-33*http://www.samsung.com/se/supPOLAND801-172-678* lub +48 22 607-93-33*http://www.samsung.com/pl/sPOLAND8001-172-678* lub +48 22 607-93-33*www.samsung.com/pl/sSpecjalistyczna infolinia do obsługi zapytań dotyczących telefonów komórkowych: 801-672-678* * (opłata według taryfy operatora)http://www.samsung.com/pl/sHUNGARY06805AMSUNG (0680-726-7864)www.samsung.com/hu/supAUSTRIA0800 72 67 864 (0800-SAMSUNG)www.samsung.com/ch/support www.samsung.com/ch_support www.samsung.com/ch_support gendeSWITZERLAND0800 726 786 (0800-726786)www.samsung.com/ch_support www.samsung.com/ch_support www.samsung.com/ch_support gendeCZECH800 - SAMSUNG (0800-726786)www.samsung.com/cs/sup www.samsung.com/cs/sup www.samsung.com/cs/sup gendeSLOVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/sk/sup www.samsung.com/hr/sup 	rt (French)
BELGIUM02-201-24-18www.samsung.com/be_fr/supportNORWAY21629099www.samsung.com/no/supDENMARK707 019 70www.samsung.com/dk/supFINLAND030-6227 515www.samsung.com/fi/supSWEDEN0771 726 786www.samsung.com/fi/supSWEDEN0771 726 786www.samsung.com/se/supPOLAND801-172-678* lub +48 22 607-93-33*http://www.samsung.com/se/supPOLAND801-172-678* lub +48 22 607-93-33*http://www.samsung.com/pl/sYou and the form of the form o	rt (French)
DENMARK707 019 70www.samsung.com/dk/supFINLAND030-6227 515www.samsung.com/fi/supjSWEDEN0771 726 786www.samsung.com/se/sup801-172-678* lub +48 22 607-93-33*Specjalistyczna infolinia do obsługi zapytań dotyczących telefonów komórkowych: 801-672-678*http://www.samsung.com/pl/sHUNGARY0680SAMSUNG (0680-726-7864)www.samsung.com/hu/supAUSTRIA0800 72 67 864 (0800-SAMSUNG)www.samsung.com/hu/supSWITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/supportCZECH800 - SAMSUNG (0800-726786)www.samsung.com/ch_sr/supportSLOVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ch/supportSUVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ch/supportSUVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ch/supportSUVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ch/slupportSUVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ch/slupportSUVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ch/slupportSUVAKIA023 207 777www.samsung.com/ba/supNorth Macedonia023 207 777www.samsung.com/ba/supMONTENEGRO020 405 888www.samsung.com/supp	
FINLAND030-6227 515www.samsung.com/fi/suppSWEDEN0771 726 786www.samsung.com/se/supB01-172-678* lub +48 22 607-93-33* Specjalistyczna infolinia do obsługi zapytań dotyczących telefonów komórkowych: 801-672-678* * (opłata według taryfy operatora)http://www.samsung.com/pl/sHUNGARY0680SAMSUNG (0680-726-7864)www.samsung.com/hu/supAUSTRIA0800 72 67 864 (0800-SAMSUNG)www.samsung.com/at/supSWITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/supportCZECH800 - SAMSUNG (080-726786)www.samsung.com/ch/srupporSLOVAKIA0800 - SAMSUNG (0800-726 786www.samsung.com/ch/supportSUVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ch/supportSUVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ch/supportSUVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ch/supportSUNAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ch/supportSUVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ch/supportSUVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ch/supportSUNA025 233 999www.samsung.com/ha/supNorth Macedonia023 207 777www.samsung.com/suppinMONTENEGRO020 405 888www.samsung.com/suppin	port
FINLAND030-6227 515www.samsung.com/fi/suppSWEDEN0771 726 786www.samsung.com/se/supB01-172-678* lub +48 22 607-93-33* Specjalistyczna infolinia do obsługi zapytań dotyczących telefonów komórkowych: 801-672-678* * (opłata według taryfy operatora)http://www.samsung.com/pl/sHUNGARY0680SAMSUNG (0680-726-7864)www.samsung.com/hu/supAUSTRIA0800 72 67 864 (0800-SAMSUNG)www.samsung.com/at/supSWITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/supportCZECH800 - SAMSUNG (080-726786)www.samsung.com/ch/srupporSLOVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ck/supportSUVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ck/supportSUVAKIA020 20 777www.samsung.com/ba/supNorth Macedonia023 207 777www.samsung.com/mk/supMONTENEGRO020 405 888www.samsung.com/support	port
801-172-678* lub +48 22 607-93-33* Specjalistyczna infolinia do obsługi zapytań dotyczących telefonów komórkowych: 801-672-678* * (opłata według taryfy operatora)http://www.samsung.com/pl/sHUNGARY0680SAMSUNG (0680-726-7864)www.samsung.com/hu/supAUSTRIA0800 72 67 864 (0800-SAMSUNG)www.samsung.com/at/supSWITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/supportSWITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/supportSUITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/supportSUOVAKIA0800 - SAMSUNG (800-726786)www.samsung.com/ck/supportSLOVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ck/supportSUOVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ck/supportSUOVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ck/supportSUOVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ck/supportSUOVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ck/supportMONTENEGRO020 405 888www.samsung.com/mk/support	
POLANDSpecjalistyczna infolinia do obsługi zapytań dotyczących telefonów komórkowych: 801-672-678* * (opłata według taryfy operatora)http://www.samsung.com/pl/sHUNGARY0680SAMSUNG (0680-726-7864)www.samsung.com/hu/sup www.samsung.com/at/supAUSTRIA0800 72 67 864 (0800-SAMSUNG)www.samsung.com/at/supSWITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/support www.samsung.com/ch/support got ansung.com/ch/supportSWITZERLAND0800 - SAMSUNG (800-726786)www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch/support got ansung.com/ch/support www.samsung.com/ch/support ww	port
POLANDSpecjalistyczna infolinia do obsługi zapytań dotyczących telefonów komórkowych: 801-672-678* * (opłata według taryfy operatora)http://www.samsung.com/pl/sHUNGARY0680SAMSUNG (0680-726-7864)www.samsung.com/hu/sup www.samsung.com/ch/support www.samsung.com/ch/supportAUSTRIA0800 72 67 864 (0800-SAMSUNG)www.samsung.com/hu/supSWITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/support www.samsung.com/ch/support www.samsung.com/ch_fr/support www.samsung.com/ch_fr/support www.samsung.com/ch_fr/support www.samsung.com/ch_fr/support www.samsung.com/ch_fr/support www.samsung.com/ch_fr/support www.samsung.com/ch_fr/support www.samsung.com/ch_fr/support www.samsung.com/ch_fr/support www.samsung.com/ch_fr/support www.samsung.com/ch/supSLOVAKIA0800 - SAMSUNG (800-726786)www.samsung.com/ck/sup of 2726 786CROATIA072 726 786www.samsung.com/hr/sup MONTENEGROwww.samsung.com/hr/sup www.samsung.com/hs/supNorth Macedonia023 207 777www.samsung.com/suppMONTENEGRO020 405 888www.samsung.com/supp	
dotyczących telefonow komorkowych: 801-6/2-6/8** (opłata według taryfy operatora)HUNGARY0680SAMSUNG (0680-726-7864)Www.samsung.com/hu/supAUSTRIA0800 72 67 864 (0800-SAMSUNG)SWITZERLAND0800 726 786 (0800-SAMSUNG)CZECH800 - SAMSUNG (800-726786)SLOVAKIA0800 - SAMSUNG (0800-726 786)Www.samsung.com/ch_fr/supportSLOVAKIA0800 - SAMSUNG (0800-726 786)Www.samsung.com/ch_fr/supportSLOVAKIA072 726 786BOSNIA075 233 999North Macedonia023 207 777Wow.samsung.com/mk/supMONTENEGRO020 405 888	. /
* (opłata według taryfy operatora) HUNGARY 0680SAMSUNG (0680-726-7864) www.samsung.com/hu/sup AUSTRIA 0800 72 67 864 (0800-SAMSUNG) www.samsung.com/at/sup SWITZERLAND 0800 726 786 (0800-SAMSUNG) www.samsung.com/ch/support CZECH 800 - SAMSUNG (800-726786) www.samsung.com/ch/support SLOVAKIA 0800 - SAMSUNG (0800-726786) www.samsung.com/ct/sup CROATIA 072 726 786 www.samsung.com/hr/sup BOSNIA 055 233 999 www.samsung.com/b/sup North Macedonia 023 207 777 www.samsung.com/ks/sup MONTENEGRO 020 405 888 www.samsung.com/supp	upport/
AUSTRIA0800 72 67 864 (0800-SAMSUNG)www.samsung.com/at/supSWITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/support www.samsung.com/ch_fr/supportCZECH800 - SAMSUNG (800-726 786)www.samsung.com/cc/supSLOVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ck/supCROATIA072 726 786www.samsung.com/hr/supBOSNIA055 233 999www.samsung.com/b/supNorth Macedonia023 207 777www.samsung.com/ks/supMONTENEGRO020 405 888www.samsung.com/supp	
AUSTRIA0800 72 67 864 (0800-SAMSUNG)www.samsung.com/at/supSWITZERLAND0800 726 786 (0800-SAMSUNG)www.samsung.com/ch/support www.samsung.com/ch_fr/supportCZECH800 - SAMSUNG (800-726 786)www.samsung.com/cc/supSLOVAKIA0800 - SAMSUNG (0800-726 786)www.samsung.com/ck/supCROATIA072 726 786www.samsung.com/hr/supBOSNIA055 233 999www.samsung.com/b/supNorth Macedonia023 207 777www.samsung.com/ks/supMONTENEGRO020 405 888www.samsung.com/supp	port
SWITZERLAND 0800 726 786 (0800-SAMSUNG) www.samsung.com/ch/support CZECH 800 - SAMSUNG (800-726786) www.samsung.com/cz/sup SLOVAKIA 0800 - SAMSUNG (0800-726786) www.samsung.com/cz/sup CROATIA 072 726 786 www.samsung.com/sk/sup BOSNIA 072 726 786 www.samsung.com/hr/sup North Macedonia 023 207 777 www.samsung.com/ks/sup MONTENEGRO 020 405 888 www.samsung.com/supp.	
CZECH800 - SAMSUNG (800-726786)www.samsung.com/ch_fr/supporSLOVAKIA0800 - SAMSUNG (0800-726786)www.samsung.com/cz/supCROATIA072 726 786www.samsung.com/sk/supBOSNIA055 233 999www.samsung.com/ba/supNorth Macedonia023 207 777www.samsung.com/ks/supMONTENEGRO020 405 888www.samsung.com/supp	(German)
SLOVAKIA 0800 - SAMSUNG (0800-726 786) www.samsung.com/sk/sup CROATIA 072 726 786 www.samsung.com/hr/sup BOSNIA 055 233 999 www.samsung.com/ba/sup North Macedonia 023 207 777 www.samsung.com/mk/sup MONTENEGRO 020 405 888 www.samsung.com/supp	t (French)
CROATIA 072 726 786 www.samsung.com/hr/sup BOSNIA 055 233 999 www.samsung.com/ba/sup North Macedonia 023 207 777 www.samsung.com/mk/sup MONTENEGRO 020 405 888 www.samsung.com/supp.	port
BOSNIA 055 233 999 www.samsung.com/ba/sup North Macedonia 023 207 777 www.samsung.com/mk/sup MONTENEGRO 020 405 888 www.samsung.com/supp	port
North Macedonia 023 207 777 www.samsung.com/mk/supplement MONTENEGRO 020 405 888 www.samsung.com/supplement	port
MONTENEGRO 020 405 888 www.samsung.com/supp	port
	port
SLOVENIA 080 697 267 (brezplačna številka) www.samsung.com/si/sup	oort
SERBIA 011 321 6899 www.samsung.com/rs/sup	port
ALBANIA 045 620 202 www.samsung.com/al/sup	oort
*3000 Цена на един градски разговор www.samsung.com/bg/sup	port
О800 ПТ 3Т Безплатен за всички оператори	
*8000 (apel in retea)	
08008-726-78-64 (08008-SAMSUNG) Apel GRATUIT	
ROMANIA Atenție: Dacă efectuați apelul din rețeaua Digi (RCS/ www.samsung.com/ro/sup	
RDS), vă rugăm să ne contactați formând numărul	port
Telverde fără ultimele două cifre, astfel: 0800872678.	port
CYPRUS 8009 4000 only from landline, toll free 80111-SAMSUNG (80111 726 7864) only from land line www.samsung.com/gr/sup	port
GREECE 80111-SAMSUNG (80111 726 7864) only from land line www.samsung.com/gr/sup (+30) 210 6897691 from mobile and land line	
LITHUANIA 8-800-77777 www.samsung.com/lt/sup	
LATVIA 8000-7267 www.samsung.com/lv/sup	port
ESTONIA 800-7267 www.samsung.com/ee/sup	port