

KOBE KMF-H60A5/APC

number	Error Code	
1	E1	Room temperature sensor fault
2	E2	Outdoor coil temperature sensor fault
3	E3	Indoor coil temperature sensor fault
4	E4	indoor fan motor or DC motor feedback fault
5	E5	indoor & outdoor communication fault
6	E6	sliding door fault
7	E8	display panel and the main control board communication failures
8	E9	Humidity sensor failure
9	EA	indoor fan zero-crossing detection fault
10	Eb	indoor E ² PROM fault
11	F0	Outdoor DC Fan motor fault
12	F1	IPM modular fault
13	F2	PFC modular fault
14	F3	Compreaaor operation fault
15	F4	Exhaust Temperature sensor fault
16	F5	Compreassor top cover protection
17	F6	Outdoor ambient temp sensor fault
18	F7	Over/under voltage protection
19	F8	Outdoor modular communication fault
20	F9	Outdoor E ² PROM fault
21	FA	Suction temperature sensor fault
22	Fb	Indoor dc motor fault(Floor Standing)
23	FC	Four-way valve switching fault
24	Fd	outdoor fan zero-crossing detection fault
25	P2	High voltage protection
26	P3	Lack of fluid protection
27	P4	Outdoor coil prevent overload protection
28	P5	Exhaust protection
29	P6	protection from high temperature(indoor unit)
30	P7	antifreezing protection(outdoor unit)
31	P8	Outdoor over-current protection
32	P9	display panel and the main control board communication failures
33	L0	Module under-voltage fault
34	L1	Phase current over-current protection
35	L2	The compressor out of step fault
36	L3	The compressor lacks of failure
37	L4	Driver module IPM of failure
38	L5	FPC module IPM of failure
39	L6	PFC Over current
40	L7	Current detecting AD abnormal protection
41	L8	Shunt resistance unbalance fault
42	L9	IPM temperature sensor failure
43	H0	frost
44	CL	clean